# TWN4

# **Simple Protocol**

DocRev25, April 29, 2022



**ELATEC GmbH** 



# **Contents**

1.	Simp	ole Prot	ocol				 	 	 	 				3
	1.1.	Comm	and				 	 	 	 				3
	1.2.	Respo	nse				 	 	 	 			 	3
	1.3.	Data T	ransmiss	ion			 	 	 	 			 	4
		1.3.1.	ASCII.				 	 	 	 			 	4
		1.3.2.	Binary				 	 	 	 			 	4
		1.3.3.	CRC .				 	 	 	 			 	4
		1.3.4.	Referen	ce messages			 	 	 	 			 	4
	1.4.	Data T	ypes				 	 	 	 				5
	1.5.	Comm	ands .				 	 	 	 				5
		1.5.1.	API SYS				 	 	 	 				5
			1.5.1.1.	Reset			 	 	 	 			 	5
			1.5.1.2.	StartBootload	er .		 	 	 	 			 	6
			1.5.1.3.											6
			1.5.1.4.	GetVersionSt										6
				GetUSBType	•									6
			1.5.1.6.											7
			1.5.1.7.											7
			_	GetDeviceUI										7
				SetParameter										, 7
				GetLastError										8
				. GetProdSerN										8
		150												8
		1.5.2.												8
				WriteByte .										8
			1.5.2.2.	<b>,</b>										
			1.5.2.3.	TestEmpty .										9
			1.5.2.4.	TestFull										9
			1.5.2.5.	GetBufferSize										9
			1.5.2.6.	GetByteCoun										9
			1.5.2.7.	SetCOMPara										10
			1.5.2.8.	GetUSBDevic										10
				GetHostChan										10
				. USBRemoteV		•								10
			1.5.2.11	. WriteBytes .			 	 	 	 				11
				. ReadBytes .										11
		1.5.3.	API PEF	RIPH			 	 	 	 				11
			1.5.3.1.	GPIOConfigu	eOut	puts	 	 	 	 				11
			1.5.3.2.	GPIOConfigu	eInpu	uts .	 	 	 	 			 	11
			1.5.3.3.	GPIOSetBits			 	 	 	 				12
			1.5.3.4.	GPIOClearBit	S		 	 	 	 				12
			1.5.3.5.											12
				GPIOBlinkBits										12
				GPIOTestBit										13
				Веер										13
				•										



	1.5.3.9. DiagLEDOn	
	1.5.3.10. DiagLEDOff	
	1.5.3.11. DiagLEDToggle	14
	1.5.3.12. DiagLEDIsOn	14
	1.5.3.13. SendWiegand	14
	1.5.3.14. SendOmron	14
	1.5.3.15. LEDInit	15
	1.5.3.16. LEDOn	15
	1.5.3.17. LEDOff	15
	1.5.3.18. LEDToggle	15
	1.5.3.19. LEDBlink	16
	1.5.3.20. BeepOn	16
	1.5.3.21. BeepOff	16
1.5.4.	API RF	16
	1.5.4.1. SearchTag	16
	1.5.4.2. SetRFOff	17
	1.5.4.3. SetTagTypes	17
	1.5.4.4. GetTagTypes	
	1.5.4.5. GetSupportedTagTypes	17
155	API TILF	18
1.5.5.	1.5.5.1. TILF_SearchTag	18
		18
	1.5.5.2. TILF_ChargeOnlyRead	18
	1.5.5.3. TILF_ChargeOnlyReadLo	
	1.5.5.4. TILF_SPProgramPage	18
	1.5.5.5. TILF_SPProgramPageLo	19
	1.5.5.6. TILF_MPGeneralReadPage	19
	1.5.5.7. TILF_MPSelectiveReadPage	19
	1.5.5.8. TILF_MPProgramPage	19
	1.5.5.9. TILF_MPSelectiveProgramPage	20
	1.5.5.10. TILF_MPLockPage	20
	1.5.5.11. TILF_MPSelectiveLockPage	20
	1.5.5.12. TILF_MPGeneralReadPageLo	20
	1.5.5.13. TILF_MPSelectiveReadPageLo	
	1.5.5.14. TILF_MPProgramPageLo	21
	1.5.5.15. TILF_MPSelectiveProgramPageLo	21
	1.5.5.16. TILF_MPLockPageLo	21
	1.5.5.17. TILF_MPSelectiveLockPageLo	22
	1.5.5.18. TILF_MUGeneralReadPage	22
	1.5.5.19. TILF_MUSelectiveReadPage	22
	1.5.5.20. TILF_MUSpecialReadPage	22
	1.5.5.21. TILF_MUProgramPage	23
	1.5.5.22. TILF_MUSelectiveProgramPage	23
	1.5.5.23. TILF_MUSpecialProgramPage	23
	1.5.5.24. TILF_MULockPage	24
	1.5.5.25. TILF_MUSelectiveLockPage	24
	1.5.5.26. TILF_MUSpecialLockPage	24
1.5.6.	API HITAG1S	25
	1.5.6.1. Hitag1S_ReadPage	25
	1.5.6.2. Hitag1S_ReadBlock	25
	1.5.6.3. Hitag1S_WritePage	25
	1.5.6.4. Hitag1S WriteBlock	



	<b>5</b> =	26
1.5.7.	API HITAG2	26
	1.5.7.1. Hitag2_ReadPage	26
	1.5.7.2. Hitag2_WritePage	27
	1.5.7.3. Hitag2_Halt	27
		27
1.5.8.		27
		27
	_	28
159	_	28
		28
		28
		28
		29
	·	29
		29
	,	
	9	29
	5	30
		30
1.5.10		30
	= 0	30
	_	30
	<u> </u>	31
	<del>-</del>	32
	1.5.10.8. MifareClassic_CopyValueBlock	32
1.5.11	API MIFAREULTRALIGHT	32
	1.5.11.1. MifareUltralight_ReadPage	32
	1.5.11.2. MifareUltralight_WritePage	33
		33
	<u> </u>	33
		33
		34
	<u> </u>	34
	<del>-</del>	34
	<del>_</del>	35
		35
	<u> </u>	35
	<u> </u>	35
1 5 12		36
1.5.12		36
	_	
	_ ,	36
	_ ,	36
	= 0 71	36
	= 071	37
	= 0	37
	= •	37
	= •	37
	1.5.12.9. ISO15693_WriteSingleBlockExt	38



1.5.13. API CRYPTO	38
1.5.13.1. Crypto_Init	38
1.5.13.2. Encrypt	38
1.5.13.3. Decrypt	39
1.5.13.4. CBC_ResetInitVector	39
1.5.14. API DESFIRE	39
1.5.14.1. DESFire_GetApplicationIDs	39
1.5.14.2. DESFire_CreateApplication	10
	10
1.5.14.4. DESFire_SelectApplication	10
· ·	11
1.5.14.6. DESFire_GetKeySettings	11
— · · · · ·	11
1.5.14.8. DESFire_GetFileSettings	12
— • • • • • • • • • • • • • • • • • • •	12
	12
	13
<del>-</del>	13
	13
<del>-</del>	13
	14
	14
	14
	 15
<del>-</del>	15
	15
	16
<del>-</del>	16
<del>-</del>	16
_	16
— ·	. o 17
	 17
= 5 ,	 17
	 18
<del>-</del>	18
	18
_ ,	. o 18
<del>-</del>	19
	19
<del>-</del>	19
<del>-</del>	50
_	50
	50
_	50
_	51
_	51
	51
<del>-</del>	52
=	52
	52



1.5.16. API ICLASS	53
1.5.16.1. ICLASS_GetPACBits	53
1.5.16.2. ICLASS_SelectPage	53
1.5.16.3. ICLASS_Authenticate	53
1.5.16.4. ICLASS_ReadBlock	54
1.5.16.5. ICLASS_WriteBlock	54
1.5.17. API ISO14443	54
1.5.17.1. ISO14443A_GetATS	54
1.5.17.2. ISO14443B_GetATQB	55
1.5.17.3. ISO14443_4_CheckPresence	55
1.5.17.4. ISO14443_4_TDX	55
1.5.17.5. ISO14443A_GetATQA	55
1.5.17.6. ISO14443A_GetSAK	56
1.5.17.7. ISO14443B_GetAnswerToATTRIB	56
1.5.17.8. ISO14443_3_TDX	56
1.5.17.9. ISO14443A_SearchMultiTag	56
1.5.17.10ISO14443A_SelectTag	57
1.5.18. API AT55	57
1.5.18.1. AT55_Begin	57
1.5.18.2. AT55_ReadBlock	57
1.5.18.3. AT55_ReadBlockProtected	57
1.5.18.4. AT55_WriteBlock	58
1.5.18.5. AT55_WriteBlockProtected	58
1.5.18.6. AT55_WriteBlockAndLock	58
1.5.18.7. AT55_WriteBlockProtectedAndLock	58
1.5.19. API NFCSNEP	59
1.5.19.1. SNEP_Init	59
1.5.19.2. SNEP_GetConnectionState	59
1.5.19.3. SNEP_GetFragmentByteCount	59
1.5.19.4. SNEP_BeginMessage	59
1.5.19.5. SNEP_SendMessageFragment	60
1.5.19.6. SNEP_TestMessage	60
1.5.19.7. SNEP_ReceiveMessageFragment	60
1.5.19.8. SNEP_RequestMessage	60
1.5.20. API EM4150	61
1.5.20.1. EM4150_Login	61
1.5.20.2. EM4150_ReadWord	61
1.5.20.3. EM4150_WriteWord	61
1.5.20.4. EM4150_WritePassword	62
1.5.20.5. EM4150_GetTagInfo	62
1.5.21. API FILESYS	62
1.5.21.1. FSMount	62
1.5.21.2. FSFormat	63
1.5.21.3. FSOpen	63
1.5.21.4. FSClose	63
1.5.21.5. FSCloseAll	63
1.5.21.6. FSSeek	64
1.5.21.7. FSTell	64
1.5.21.8. FSReadBytes	64
1.5.21.9. FSWriteBytes	64
1.5.21.10FSFindFirst	65



1.5.21.11FSFindNext	
1.5.21.12FSDelete	
1.5.21.13FSRename	65
1.5.21.14FSGetStorageInfo	66
1.5.22. API MIFAREPLUS	66
1.5.22.1. MFP_WritePerso	66
1.5.22.2. MFP_CommitPerso	66
1.5.22.3. MFP_Authenticate	67
1.5.22.4. MFP_ReadBlock	67
1.5.22.5. MFP WriteBlock	67
1.5.22.6. MFP ReadValueBlock	67
1.5.22.7. MFP_WriteValueBlock	
1.5.22.8. MFP IncrementValueBlock	
1.5.22.9. MFP_DecrementValueBlock	
1.5.22.10MFP_CopyValueBlock	
1.5.23. API ADC	
1.5.23.1. ADCInitChannel	
1.5.23.2. ADCGetConversionValue	
1.5.24. API FELICA	
1.5.24.1. FeliCa_TDX	
1.5.24.2. FeliCa_ReadWithoutEncryption	
1.5.24.3. FeliCa_WriteWithoutEncryption	
1.5.24.4. FeliCa_RequestSystemCode	
1.5.24.5. FeliCa_Poll	
1.5.24.6. FeliCa_RequestService	
1.5.25. API SLE44XX	
1.5.25.1. SLE44XX_GetATR	
1.5.25.2. SLE444X_ReadMainMemory	
1.5.25.3. SLE444X_UpdateMainMemory	
1.5.25.4. SLE444X_ReadSecurityMemory	
1.5.25.5. SLE444X_UpdateSecurityMemory	
1.5.25.6. SLE444X_ReadProtectionMemory	
1.5.25.7. SLE444X_WriteProtectionMemory	
1.5.25.8. SLE444X_CompareVerificationData	
1.5.25.9. SLE44X8_ReadMainMemory	
1.5.25.10SLE44X8_WriteErrorCounter	
1.5.25.11SLE44X8_VerifyPSCByte	
1.5.25.12SLE44X8_UpdateMainMemory	
1.5.26. API NTAG	
1.5.26.1. NTAG Read	
1.5.26.2. NTAG_Write	
1.5.26.3. NTAG_FastRead	
1.5.26.4. NTAG_ReadCounter	
1.5.26.5. NTAG_ReadSig	
1.5.26.6. NTAG_GetVersion	
——————————————————————————————————————	
1.5.26.7. NTAG_PwdAuth	
1.5.26.8. NTAG_SectorSelect	
1.5.27. API SRX	
1.5.27.1. SRX_ReadBlock	77
I D Z Z Z S R X WYTTORIOCK	/ /



1.5.28. API SAMAVX
1.5.28.1. SAMAVx AuthenticateHost
1.5.28.2. SAMAVx_GetKeyEntry
1.5.29. API EM4102
1.5.29.1. EM4102_GetTagInfo
1.5.30. API SPI
1.5.30.1. SPIInit
1.5.30.2. SPIDeInit
1.5.30.3. SPIMasterBeginTransfer
1.5.30.4. SPIMasterEndTransfer
1.5.30.5. SPITransmit
1.5.30.6. SPIReceive
1.5.30.7. SPITransceive
1.5.31. API BLE
1.5.31.1. BLEPresetConfig
1.5.31.2. BLEPresetUserData
1.5.31.3. BLEInit
1.5.31.4. BLECheckEvent
1.5.31.5. BLEGetAddress
1.5.31.6. BLEGetVersion
1.5.31.7. BLEGetEnvironment
1.5.31.8. BLEGetGattServerAttributeValue
1.5.31.9. BLESetGattServerAttributeValue
1.5.31.10BLERequestRssi
1.5.31.11BLERequestEndpointClose
1.5.31.12BLEGetGattServerCharacteristicStatus
1.5.31.13BLEFindGattServerAttribute
1.5.31.14BLEDiscover
1.5.31.15BLECheckDiscoveredString
1.5.31.16BLEConnectToDevice
1.5.31.17BLEDisconnectFromDevice
1.5.31.18BLEGattGetAttribute
1.5.31.19BLEGattGetValue
1.5.31.20BLEGattSetValue
1.5.31.21BLECommand
1.5.31.22BLESecurity
1.5.31.23BLESecuritySetOob
1.5.31.24BLESecurityUseScOob
1.5.31.25BLESetStreamingUUID
1.5.31.26BLESetStreamingMode
1.5.31.27BLEGetDiscoveredData
1.5.32. API I2CCARD
1.5.32.1. I2CCard_Read
1.5.32.2. I2CCard_Write
1.5.33. API TOPAZ
1.5.33.1. TopazRID
1.5.33.2. TopazReadByte
1.5.33.3. TopazReadAllBlocks
1.5.33.4. TopazWriteByteWithErase
1.0.00. 1. 10paz viltobyto vitti i i i i i i i i i i i i i i i i i



	1.5.34. API CTS	91
	1.5.34.1. CTS_ReadBlock	91
	1.5.34.2. CTS_WriteBlock	91
	1.5.34.3. CTS_UpdateBlock	91
	1.5.35. API EM4305	92
	1.5.35.1. EM4305_Begin	92
	1.5.35.2. EM4305_Read	92
	1.5.35.3. EM4305_Write	92
	1.5.35.4. EM4305_Login	92
	1.5.35.5. EM4305_Protect	93
	1.5.35.6. EM4305_Disable	93
٩.	How to Set Specific Tags in Simple Protocol	94
	A.1. Example with Enabling Only MIFARE	94
	A.2. Example with Felica and HID Prox Only	94
В.	Disclaimer	97



# 1. Simple Protocol

This document describes the serial protocol of TWN4.

In order to operate this protocol, a firmware type TWN4\_Cxvvv\_PRSwww.bix is required, where vvv and www are the version numbers.

A firmware as mentioned above combines virtual USB (CDC) or true serial communication with a TWN4 app, which implements the simple protocol (PRS = PRotocol Simple).

This protocol is called simple because it is based on a communication with ASCII characters which can also be tested manually by using a terminal program. There is no additional overhead for things like packet repetition, address bytes...

The simple protocol is also available in binary mode. This means, that the data is not transmitted via ASCII characters but as single bytes.

Moreover it is possible to add a CRC at the end of every transmission. This lets you detect transmission errors.

The communication is based on a command/response structure: TWN4 will only send data to the host as a response of a command. Command and response are lines of bytes terminated by a carriage return. Carriage return is not shown explicitly anymore in the following documentation. A byte is always represented and transmitted by two hexadecimal ASCII characters.

#### 1.1. Command

A command always starts with two bytes which reflect the API and function number to be executed.

#### 1.2. Response

A response always starts with a byte, which reflects execution of the command on protocol level. Following possible error values:

ERR\_NONE 0
ERR\_UNKNOWN\_FUNCTION 1
ERR\_MISSING\_PARAMETER 2
ERR\_UNUSED\_PARAMETERS 3
ERR\_INVALID\_FUNCTION 4
ERR\_PARSER 5



#### 1.3. Data Transmission

Data can be transmitted in two ways:

- by sending ASCII characters
- by sending binary values

Standard communication setting is ASCII, CRC off with 9600 baud.

Communication settings can be done in the app **App\_PRS104\_Simple\_Protocol.c** in the folder \Apps\Samples\Simple Protocol in the TWN4DevPack.

#### 1.3.1. ASCII

To transmit a value of e.g. 0x1F, it is necessary to split this into two ASCII characters '1' and 'F'. These characters has to be sent sequentially.

#### 1.3.2. Binary

To transmit a value of e.g. 0x1F, it can be sent directly in binary format. The first two bytes (LSB first) indicate the number of the following bytes.

```
<Length of command bytes (2 bytes, LSB first)> <command bytes>
```

See 1.3.4 for an example.

#### 1.3.3. CRC

On both ASCII and binary format, a CRC can be added at the end of each transmission. In case of binary format, the length bytes are not part of the CRC calculation. The CRC is calculated as follows:

The CRC calculation starts with CRC = 0xFFFF

#### 1.3.4. Reference messages

The following table shows reference messages for function GetUSBType



Mode	CRC	Command (Host -> TWN4)	Response (TWN4 -> Host)
ASCII	Off	""0005\r""	""0001\r""
AGOII	On	""000515A7\r""	""000131E1\r""
Binary	Off	0x02 0x00 0x00 0x05	0x02 0x00 0x00 0x01
Dillary	On	0x04 0x00 0x00 0x05 0x15 0xA7	0x04 0x00 0x00 0x01 0x31 0xE1

# 1.4. Data Types

The description of the commands is using data types, which have to be built-up as follows:

Data Type	Description
[Byte]:	One single byte (sent as two hex digits)
[UInt16]:	Two bytes (LSB first)
[UInt32]:	Four bytes (LSB first)
[Bool]:	One single byte which can hold two values: 0 or 1
[Byte Array(n)]:	A sequence of bytes with known and fixed number of bytes. The number of bytes is not transferred explicitely, because both host and TWN4 do know this number.
[Byte Array(Var)]:	A sequence of bytes, where the first byte holds the number of following bytes
[Byte Array(Var), x LB]:	A sequence of bytes, where the first x bytes hold the number of following bytes
[ASCII string]:	A sequence of bytes which contain ASCII characters, except the first byte which holds the number of following bytes

In Simple Protocol, all numbers are sent with LSB first. For example, the number 0x1234 has to be sent as 3412.

#### 1.5. Commands

#### 1.5.1. API SYS

#### 1.5.1.1. Reset

Command:	[0001]
Response:	[00]
Example	
Command:	0001
Response:	



#### 1.5.1.2. StartBootloader

Command:	[0002]
Response:	[00]
Example	
Command:	0002
Response:	

### 1.5.1.3. GetSysTicks

Command:	[0003]
Response:	[00][UInt32: Ticks]
Example	
Command:	0003
Response:	00D3480700
	(Ticks: 477395)

### 1.5.1.4. GetVersionString

Command:	[0004][Byte: <i>MaxLen</i> ]
Response:	[00][ASCII string: Version]
Example	
Command:	0004FF
	(MaxLen: FF)
Response:	001D54574E342F42312E30332F434346312E35372F505253312E3033-2F5049
	(Version: TWN4/B1.03/CCF1.57/PRS1.03/PI)

### 1.5.1.5. GetUSBType

Command:	[0005]
Response:	[00][Byte: <i>Type</i> ]
Example	
Command:	0005
Response:	0001
	(Type: 1)



### 1.5.1.6. GetDeviceType

Command:	[0006]
Response:	[00][Byte: <i>Type</i> ]
Example	
Command:	0006
Response:	000B
	(Type: 11)

### 1.5.1.7. Sleep

Command:	[0007][UInt32: <i>Ticks</i> ][UInt32: <i>Flags</i> ]
Response:	[00][Byte: Result]
Example	
Command:	0007E803000001000000
	(Ticks: E8030000, Flags: 01000000)
Response:	0000
	(Result: 0)

#### 1.5.1.8. GetDeviceUID

Command:	[8000]
Response:	[00][Byte Array(12): <i>UID</i> ]
Example	
Command:	0008
Response:	002D002F000B47303531353233
	(UID: 2D002F000B47303531353233)

#### 1.5.1.9. SetParameters

Command:	[0009][Byte Array(Var): TLV]
Response:	[00][Bool: Result]
Example	
Command:	00090707010103010200
	(TLV: 07010103010200)
Response:	0001
	(Result: true)



#### 1.5.1.10. GetLastError

Command:	[000A]
Response:	[00][UInt32: LastError]
Example	
Command:	000A
Response:	00CB000000
	(LastError: 203)

#### 1.5.1.11. GetProdSerNo

Command:	[000D][Byte: MaxLen]
Response:	[00][ASCII string: SerNo]
Example	
Command:	000DFF
	(MaxLen: FF)
Response:	001031323334353637383930313233343536
	(SerNo: 1234567890123456)

#### 1.5.2. API IO

# 1.5.2.1. WriteByte

Command:	[0100][Byte: Channel][Byte: Byte]
Response:	[00]
Example	
Command:	01000041
	(Channel: 00, Byte: 41)
Response:	00

#### 1.5.2.2. ReadByte

Command:	[0101][Byte: Channel]
Response:	[00][Byte: <i>Byte</i> ]
Example	
Command:	010100
	(Channel: 00)
Response:	0000
	(Byte: 0)



### 1.5.2.3. TestEmpty

Command:	[0102][Byte: Channel][Byte: Dir]
Response:	[00][Bool: Result]
Example	
Command:	01020001
	(Channel: 00, Dir: 01)
Response:	0001
	(Result: Yes)

#### 1.5.2.4. TestFull

Command:	[0103][Byte: Channel][Byte: Dir]
Response:	[00][Bool: Result]
Example	
Command:	01030001
	(Channel: 00, Dir: 01)
Response:	0000
	(Result: No)

#### 1.5.2.5. GetBufferSize

Command:	[0104][Byte: Channel][Byte: Dir]
Response:	[00][UInt16: BufferSize]
Example	
Command:	01040001
	(Channel: 00, Dir: 01)
Response:	000000
	(BufferSize: 0)

### 1.5.2.6. GetByteCount

Command:	[0105][Byte: Channel][Byte: Dir]
Response:	[00][UInt16: ByteCount]
Example	
Command:	01050001
	(Channel: 00, Dir: 01)
Response:	000000
	(ByteCount: 0)



#### 1.5.2.7. SetCOMParameters

Command:	[0109][Byte: Channel][UInt32: Baudrate][Byte: WordLength][Byte: Parity][Byte: Stop-Bits][Byte: FlowControl]
Response:	[00][Bool: Result]
Example	
Command:	0109028025000008000100
	(Channel: 02, Baudrate: 80250000, WordLength: 08, Parity: 00, StopBits: 01, FlowControl: 00)
Response:	0001
	(Result: true)

#### 1.5.2.8. GetUSBDeviceState

Command:	[010A]
Response:	[00][Byte: State]
Example	
Command:	010A
Response:	0003
	(State: USB_DEVICE_STATE_CONFIGURED)

#### 1.5.2.9. GetHostChannel

Command:	[010B]
Response:	[00][Byte: Channel]
Example	
Command:	010B
Response:	0001
	(Channel: CHANNEL_USB)

### 1.5.2.10. USBRemoteWakeup

Command:	[010C]
Response:	[00]
Example	
Command:	010C
Response:	00



### 1.5.2.11. WriteBytes

Command:	[010D][Byte: Channel][Byte Array(Var), 2 LB: Bytes]
Response:	[00][UInt16: BytesWritten]
Example	
Command:	010D020300000815
	(Channel: 02, Bytes: 000815)
Response:	000300
	(BytesWritten: 3)

### 1.5.2.12. ReadBytes

Command:	[010E][Byte: Channel][UInt16: MaxBytes]
Response:	[00][Byte Array(Var), 2 LB: Bytes]
Example	
Command:	010E020F00
	(Channel: 02, MaxBytes: 0F00)
Response:	000300000815
	(Bytes: 000815)

#### 1.5.3. API PERIPH

### 1.5.3.1. GPIOConfigureOutputs

Command:	[0400][Byte: Bits][Byte: PullUpDown][Byte: OutputType]
Response:	[00]
Example	
Command:	0400010000
	(Bits: 01, PullUpDown: 00, OutputType: 00)
Response:	00

### 1.5.3.2. GPIOConfigureInputs

Command:	[0401][Byte: Bits][Byte: PullUpDown]
Response:	[00]
Example	
Command:	04010100
	(Bits: 01, PullUpDown: 00)
Response:	00



#### 1.5.3.3. GPIOSetBits

Command:	[0402][Byte: <i>Bits</i> ]
Response:	[00]
Example	
Command:	040201
	(Bits: 01)
Response:	00

#### 1.5.3.4. GPIOClearBits

Command:	[0403][Byte: <i>Bits</i> ]
Response:	[00]
Example	
Command:	040301
	(Bits: 01)
Response:	00

### 1.5.3.5. GPIOToggleBits

Command:	[0404][Byte: <i>Bits</i> ]
Response:	[00]
Example	
Command:	040401
	(Bits: 01)
Response:	00

#### 1.5.3.6. GPIOBlinkBits

Command:	[0405][Byte: Bits][UInt16: TimeHi][UInt16: TimeLo]
Response:	[00]
Example	
Command:	04050164006400
	(Bits: 01, TimeHi: 6400, TimeLo: 6400)
Response:	00



#### 1.5.3.7. GPIOTestBit

Command:	[0406][Byte: <i>Bit</i> ]
Response:	[00][Byte: Result]
Example	
Command:	040601
	(Bit: 01)
Response:	0000
	(Result: 0)

### 1.5.3.8. Beep

Command:	[0407][Byte: Volume][UInt16: Frequency][UInt16: OnTime][UInt16: OffTime]
Response:	[00]
Example	
Command:	0407646009F401F401
	(Volume: 64, Frequency: 6009, OnTime: F401, OffTime: F401)
Response:	00

#### 1.5.3.9. DiagLEDOn

Command:	[0408]
Response:	[00]
Example	
Command:	0408
Response:	00

### 1.5.3.10. DiagLEDOff

Command:	[0409]
Response:	[00]
Example	
Command:	0409
Response:	00



# 1.5.3.11. DiagLEDToggle

Command:	[040A]
Response:	[00]
Example	
Command:	040A
Response:	00

#### 1.5.3.12. DiagLEDIsOn

Command:	[040B]
Response:	[00][Bool: Result]
Example	
Command:	040B
Response:	0000
	(Result: No)

#### 1.5.3.13. SendWiegand

Command:	[040C][Byte: GPIOData0][Byte: GPIOData1][UInt16: PulseTime][UInt16: Interval-Time][Byte Array(Var): Bits][Byte: BitCount]
Response:	[00]
Example	
Command:	040C08106400E80301AA08
	(GPIOData0: 08, GPIOData1: 10, PulseTime: 6400, IntervalTime: E803, Bits: AA, Bit-Count: 08)
Response:	00

#### 1.5.3.14. SendOmron

Command:	[040D][Byte: GPIOClock][Byte: GPIOData][UInt16: T1][UInt16: T2][UInt16: T3][Byte Array(Var): Bits][Byte: BitCount]
Response:	[00]
Example	
Command:	040D0810F401F401F40101AA08
	(GPIOClock: 08, GPIOData: 10, T1: F401, T2: F401, T3: F401, Bits: AA, BitCount: 08)
Response:	00



#### 1.5.3.15. LEDInit

Command:	[0410][Byte: <i>LEDs</i> ]
Response:	[00]
Example	
Command:	041007
	(LEDs: 07)
Response:	00

#### 1.5.3.16. LEDOn

Command:	[0411][Byte: <i>LEDs</i> ]
Response:	[00]
Example	
Command:	041107
	(LEDs: 07)
Response:	00

#### 1.5.3.17. LEDOff

Command:	[0412][Byte: <i>LEDs</i> ]
Response:	[00]
Example	
Command:	041207
	(LEDs: 07)
Response:	00

### 1.5.3.18. **LEDToggle**

Command:	[0413][Byte: <i>LEDs</i> ]
Response:	[00]
Example	
Command:	041307
	(LEDs: 07)
Response:	00



#### 1.5.3.19. LEDBlink

Command:	[0414][Byte: LEDs][UInt16: TimeOn][UInt16: TimeOff]
Response:	[00]
Example	
Command:	041407F401F401
	(LEDs: 07, TimeOn: F401, TimeOff: F401)
Response:	00

### 1.5.3.20. BeepOn

Command:	[0416][Byte: Volume][UInt16: Frequency]
Response:	[00]
Example	
Command:	0416646009
	(Volume: 64, Frequency: 6009)
Response:	00

### 1.5.3.21. BeepOff

Command:	[0417]
Response:	[00]
Example	
Command:	0417
Response:	00

### 1.5.4. API RF

#### 1.5.4.1. SearchTag

Command:	[0500][Byte: MaxIDBytes]
Response:	[00][Bool: Result][Byte: TagType][Byte: IDBitCount][Byte Array(Var): ID]
Example	
Command:	050010
	(MaxIDBytes: 10)
Response:	000180200466CF4DC2
	(Result: true, TagType: ISO14443A/MIFARE, IDBitCount: 32, ID: 66CF4DC2)



#### 1.5.4.2. SetRFOff

Command:	[0501]
Response:	[00]
Example	
Command:	0501
Response:	00

### 1.5.4.3. SetTagTypes

Command:	[0502][UInt32: TagTypesLF][UInt32: TagTypesHF]
Response:	[00]
Example	
Command:	0502FFFFFFFFFFFF
	(TagTypesLF: FFFFFFF, TagTypesHF: FFFFFFF)
Response:	00

### 1.5.4.4. GetTagTypes

Command:	[0503]
Response:	[00][UInt32: LFTagTypes][UInt32: HFTagTypes]
Example	
Command:	0503
Response:	002FFE0700F7000000
	(LFTagTypes: 523823, HFTagTypes: 247)

### 1.5.4.5. GetSupportedTagTypes

Command:	[0504]
Response:	[00][UInt32: LFTagTypes][UInt32: HFTagTypes]
Example	
Command:	0504
Response:	002FFE0700F7000000
	(LFTagTypes: 523823, HFTagTypes: 247)



#### 1.5.5. API TILF

### 1.5.5.1. TILF\_SearchTag

Command:	[0600][Byte: MaxIDBytes]
Response:	[00][Bool: Result][Byte: IDBitCount][Byte Array(Var): ID]
Example	
Command:	060010
	(MaxIDBytes: 10)
Response:	000140080000000042E8653
	(Result: true, IDBitCount: 64, ID: 0000000042E8653)

### 1.5.5.2. TILF\_ChargeOnlyRead

Command:	[0601]
Response:	[00][Bool: Result][Byte Array(8): Data]
Example	
Command:	0601
Response:	00010000000042E8653
	(Result: true, Data: 0000000042E8653)

#### 1.5.5.3. TILF\_ChargeOnlyReadLo

Command:	[0602]
Response:	[00][Bool: Result][Byte Array(16): ReadData]
Example	
Command:	0602
Response:	000100007F7E7EFFFDFFFFFFFFFFFFFF
	(Result: true, ReadData: 00007F7E7EFFFDFFFFFFFFFFFFFFD)

#### 1.5.5.4. TILF\_SPProgramPage

Command:	[0603][Byte Array(8): WriteData]
Response:	[00][Bool: Result][Byte Array(16): ReadData]
Example	
Command:	06030001020304050607
	(WriteData: 0001020304050607)
Response:	000100007ECA617420000000DADF7E0000
	(Result: true, ReadData: 00007ECA617420000000DADF7E0000)



### 1.5.5.5. TILF\_SPProgramPageLo

Command:	[0604][Byte Array(10): WriteData]
Response:	[00][Bool: Result][Byte Array(16): ReadData]
Example	
Command:	060400010203040506070809
	(WriteData: 00010203040506070809)
Response:	000100007ECA617420000000DADF7E0000
	(Result: true, ReadData: 00007ECA617420000000DADF7E0000)

### 1.5.5.6. TILF\_MPGeneralReadPage

Command:	[0605][Byte: Address]
Response:	[00][Bool: Result][Byte Array(8): ReadData]
Example	
Command:	060500
	(Address: 00)
Response:	00010000000042E8653
	(Result: true, ReadData: 0000000042E8653)

#### 1.5.5.7. TILF\_MPSelectiveReadPage

Command:	[0606][Byte: Address][Byte Array(3): SelectiveAddress]
Response:	[00][Bool: Result][Byte Array(8): ReadData]
Example	
Command:	06060000102
	(Address: 00, SelectiveAddress: 000102)
Response:	00010000000042E8653
	(Result: true, ReadData: 0000000042E8653)

### 1.5.5.8. TILF\_MPProgramPage

Command:	[0607][Byte: Address][Byte Array(8): WriteData]
Response:	[00][Bool: Result][Byte Array(8): ReadData]
Example	
Command:	0607004469726563746F72
	(Address: 00, WriteData: 4469726563746F72)
Response:	00010000000042E8653
	(Result: true, ReadData: 0000000042E8653)



### 1.5.5.9. TILF\_MPSelectiveProgramPage

Command:	[0608][Byte: Address][Byte Array(3): SelectiveAddress][Byte Array(8): WriteData]
Response:	[00][Bool: Result][Byte Array(8): ReadData]
Example	
Command:	060800001024469726563746F72
	(Address: 00, SelectiveAddress: 000102, WriteData: 4469726563746F72)
Response:	00010000000042E8653
	(Result: true, ReadData: 0000000042E8653)

### 1.5.5.10. TILF\_MPLockPage

Command:	[0609][Byte: <i>Address</i> ]
Response:	[00][Bool: Result][Byte Array(8): ReadData]
Example	
Command:	060900
	(Address: 00)
Response:	0000
	(Result: fail, ReadData: )

#### 1.5.5.11. TILF\_MPSelectiveLockPage

Command:	[060A][Byte: Address][Byte Array(3): SelectiveAddress]
Response:	[00][Bool: Result][Byte Array(8): ReadData]
Example	
Command:	060A0000102
	(Address: 00, SelectiveAddress: 000102)
Response:	0000
	(Result: fail, ReadData: )

### 1.5.5.12. TILF\_MPGeneralReadPageLo

Command:	[060B][Byte: Address]
Response:	[00][Bool: Result][Byte Array(16): ReadData]
Example	
Command:	060B00
	(Address: 00)
Response:	000100007ECA617420000000DADF7E0000
	(Result: true, ReadData: 00007ECA617420000000DADF7E0000)



### 1.5.5.13. TILF\_MPSelectiveReadPageLo

Command:	[060C][Byte: Address][Byte Array(3): SelectiveAddress]
Response:	[00][Bool: Result][Byte Array(16): ReadData]
Example	
Command:	060C0000102
	(Address: 00, SelectiveAddress: 000102)
Response:	000100007ECA617420000000DADF7E0000
	(Result: true, ReadData: 00007ECA617420000000DADF7E0000)

### 1.5.5.14. TILF\_MPProgramPageLo

Command:	[060D][Byte: Address][Byte Array(10): WriteData]
Response:	[00][Bool: Result][Byte Array(16): ReadData]
Example	
Command:	060D00536F6D6520746578742E
	(Address: 00, WriteData: 536F6D6520746578742E)
Response:	000100007ECA617420000000DADF7E0000
	(Result: true, ReadData: 00007ECA617420000000DADF7E0000)

#### 1.5.5.15. TILF\_MPSelectiveProgramPageLo

Command:	[060E][Byte: Address][Byte Array(3): SelectiveAddress][Byte Array(10): WriteData]
Response:	[00][Bool: Result][Byte Array(16): ReadData]
Example	
Command:	060E00000102536F6D6520746578742E
	(Address: 00, SelectiveAddress: 000102, WriteData: 536F6D6520746578742E)
Response:	000100007ECA617420000000DADF7E0000
	(Result: true, ReadData: 00007ECA617420000000DADF7E0000)

### 1.5.5.16. TILF\_MPLockPageLo

Command:	[060F][Byte: Address]
Response:	[00][Bool: Result][Byte Array(16): ReadData]
Example	
Command:	060F00
	(Address: 00)
Response:	0000
	(Result: fail, ReadData: )



### 1.5.5.17. TILF\_MPSelectiveLockPageLo

Command:	[0610][Byte: Address][Byte Array(3): SelectiveAddress]
Response:	[00][Bool: Result][Byte Array(16): ReadData]
Example	
Command:	06100000102
	(Address: 00, SelectiveAddress: 000102)
Response:	000100007FEFFFFFFFFFFFFFFFFFFFFFFFFFFFFF
	(Result: true, ReadData: 00007FEFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFF

### 1.5.5.18. TILF\_MUGeneralReadPage

Command:	[0611][Byte: Address]
Response:	[00][Bool: Result][Byte Array(7): Data]
Example	
Command:	061100
	(Address: 00)
Response:	0000
	(Result: fail, Data: )

#### 1.5.5.19. TILF\_MUSelectiveReadPage

Command:	[0612][Byte: Address][Byte: SelectiveAddress]
Response:	[00][Bool: Result][Byte Array(7): Data]
Example	
Command:	06120000
	(Address: 00, SelectiveAddress: 00)
Response:	0000
	(Result: fail, Data: )

### 1.5.5.20. TILF\_MUSpecialReadPage

Command:	[0613][Byte: Address][Byte Array(5): SpecialAddress1][Byte Array(3): SpecialAddress2]
Response:	[00][Bool: Result][Byte Array(7): Data]
Example	
Command:	0613000001020304000102
	(Address: 00, SpecialAddress1: 0001020304, SpecialAddress2: 000102)
Response:	0000
	(Result: fail, Data: )



# 1.5.5.21. TILF\_MUProgramPage

Command:	[0614][Byte: Address][Byte Array(5): WriteData]
Response:	[00][Bool: Result][Byte Array(7): ReadData]
Example	
Command:	06140048656C6C6F
	(Address: 00, WriteData: 48656C6C6F)
Response:	0000
	(Result: fail, ReadData: )

### ${\bf 1.5.5.22.}\ \ {\bf TILF\_MUS} elective Program Page$

Command:	[0615][Byte: Address][Byte: SelectiveAddress][Byte Array(5): WriteData]
Response:	[00][Bool: Result][Byte Array(7): ReadData]
Example	
Command:	0615000048656C6C6F
	(Address: 00, SelectiveAddress: 00, WriteData: 48656C6C6F)
Response:	0000
	(Result: fail, ReadData: )

#### 1.5.5.23. TILF\_MUSpecialProgramPage

Command:	[0616][Byte: Address][Byte Array(5): SpecialAddress1][Byte Array(3): SpecialAddress2][Byte Array(5): WriteData]
Response:	[00][Bool: Result][Byte Array(7): ReadData]
Example	
Command:	061600000102030400010248656C6C6F
	(Address: 00, SpecialAddress1: 0001020304, SpecialAddress2: 000102, WriteData: 48656C6C6F)
Response:	0000
	(Result: fail, ReadData: )



# 1.5.5.24. TILF\_MULockPage

Command:	[0617][Byte: Address]
Response:	[00][Bool: Result][Byte Array(7): ReadData]
Example	
Command:	061700
	(Address: 00)
Response:	0000
	(Result: fail, ReadData: )

# 1.5.5.25. TILF\_MUSelectiveLockPage

Command:	[0618][Byte: Address][Byte: SelectiveAddress]
Response:	[00][Bool: Result][Byte Array(7): ReadData]
Example	
Command:	06180000
	(Address: 00, SelectiveAddress: 00)
Response:	0000
	(Result: fail, ReadData: )

#### 1.5.5.26. TILF\_MUSpecialLockPage

Command:	[0619][Byte: Address][Byte Array(5): SpecialAddress1][Byte Array(3): SpecialAddress2]
Response:	[00][Bool: Result][Byte Array(7): ReadData]
Example	
Command:	061900001020304000102
	(Address: 00, SpecialAddress1: 0001020304, SpecialAddress2: 000102)
Response:	0000
	(Result: fail, ReadData: )



#### 1.5.6. API HITAG1S

### 1.5.6.1. Hitag1S\_ReadPage

Command:	[0701][Byte: PageAddress]
Response:	[00][Bool: Result][Byte Array(4): Data]
Example	
Command:	070104
	(PageAddress: 04)
Response:	0001FF8CA64A
	(Result: true, Data: FF8CA64A)

### 1.5.6.2. Hitag1S\_ReadBlock

Command:	[0702][Byte: BlockAddress]
Response:	[00][Bool: Result][Byte Array(Var): Data]
Example	
Command:	070204
	(BlockAddress: 04)
Response:	0001100001020398F8C802FFFFFFFFFFFFFF
	(Result: true, Data: 0001020398F8C802FFFFFFFFFFFFFF)

### 1.5.6.3. Hitag1S\_WritePage

Command:	[0703][Byte: PageAddress][Byte Array(4): Data]
Response:	[00][Bool: Result]
Example	
Command:	07030407040400
	(PageAddress: 04, Data: 07040400)
Response:	0001
	(Result: true)



### 1.5.6.4. Hitag1S\_WriteBlock

Command:	[0704][Byte: BlockAddress][Byte Array(16): Data]
Response:	[00][Bool: Result][Byte: BytesWritten]
Example	
Command:	070404000000000000000000000000000000000
	(BlockAddress: 04, Data: 00000000000000000000000000000000000
Response:	000110
	(Result: true, BytesWritten: 16)

### 1.5.6.5. Hitag1S\_Halt

Command:	[0705]
Response:	[00][Bool: Result]
Example	
Command:	0705
Response:	0001
	(Result: true)

### 1.5.7. API HITAG2

#### 1.5.7.1. Hitag2\_ReadPage

Command:	[0801][Byte: PageAddress]
Response:	[00][Bool: Result][Byte Array(4): Data]
Example	
Command:	080104
	(PageAddress: 04)
Response:	0001FF800000
	(Result: true, Data: FF800000)



### 1.5.7.2. Hitag2\_WritePage

Command:	[0802][Byte: PageAddress][Byte Array(4): Data]
Response:	[00][Bool: Result]
Example	
Command:	080204FF800000
	(PageAddress: 04, Data: FF800000)
Response:	0001
	(Result: true)

### 1.5.7.3. Hitag2\_Halt

Command:	[0803]
Response:	[00][Bool: Result]
Example	
Command:	0803
Response:	0001
	(Result: true)

### 1.5.7.4. Hitag2\_SetPassword

Command:	[0804][Byte Array(4): Password]
Response:	[00]
Example	
Command:	080400010203
	(Password: 00010203)
Response:	00

#### 1.5.8. API SM4X00

#### 1.5.8.1. SM4X00\_GenericRaw

Command:	[0900][Byte Array(Var): TXData][Byte: MaxRXDataLength][UInt16: Timeout]
Response:	[00][Bool: Result][Byte Array(Var): RXData]
Example	
Command:	090005040A00000040B80B
	(TXData: 040A000000, MaxRXDataLength: 40, Timeout: B80B)
Response:	00010D0A000009010501001801030100
	(Result: true, RXData: 0A000009010501001801030100)



# 1.5.8.2. SM4X00\_Generic

Command:	[0901][Byte Array(Var): TXData][Byte: MaxRXDataLength][UInt16: Timeout]
Response:	[00][Bool: Result][Byte Array(Var): RXData]
Example	
Command:	0901020A0040B80B
	(TXData: 0A00, MaxRXDataLength: 40, Timeout: B80B)
Response:	0001100F0A000009010501001801030100EB63
	(Result: true, RXData: 0F0A000009010501001801030100EB63)

#### 1.5.9. API I2C

#### 1.5.9.1. I2CInit

Command:	[0A00][UInt16: <i>Mode</i> ]
Response:	[00][Bool: Result]
Example	
Command:	0A000000
	(Mode: 0000)
Response:	0001
	(Result: true)

#### 1.5.9.2. I2CDeInit

Command:	[0A01]
Response:	[00]
Example	
Command:	0A01
Response:	00

#### 1.5.9.3. I2CMasterStart

Command:	[0A02]
Response:	[00]
Example	
Command:	0A02
Response:	00



### 1.5.9.4. I2CMasterStop

Command:	[0A03]
Response:	[00]
Example	
Command:	0A03
Response:	00

#### 1.5.9.5. I2CMasterTransmitByte

Command:	[0A04][Byte: Data]
Response:	[00]
Example	
Command:	0A0400
	(Data: 00)
Response:	00

### 1.5.9.6. I2CMasterReceiveByte

Command:	[0A05]
Response:	[00][Byte: <i>Data</i> ]
Example	
Command:	0A05
Response:	0000
	(Data: 0)

# 1.5.9.7. I2CMasterBeginWrite

Command:	[0A06][Byte: Address]
Response:	[00]
Example	
Command:	0A0630
	(Address: 30)
Response:	00



### 1.5.9.8. I2CMasterBeginRead

Command:	[0A07][Byte: Address]
Response:	[00]
Example	
Command:	0A0730
	(Address: 30)
Response:	00

#### 1.5.9.9. I2CMasterSetAck

Command:	[0A08][Byte: SetOn]
Response:	[00]
Example	
Command:	0A0801
	(SetOn: 01)
Response:	00

#### 1.5.10. API MIFARECLASSIC

### 1.5.10.1. MifareClassic\_Login

Command:	[0B00][Byte Array(6): Key][Byte: KeyType][Byte: Sector]
Response:	[00][Bool: Result]
Example	
Command:	0B00A0A1A2A3A4A50000
	(Key: A0A1A2A3A4A5, KeyType: 00, Sector: 00)
Response:	0001
	(Result: true)

### ${\bf 1.5.10.2.}\ \ Mifare Classic\_ReadBlock$

Command:	[0B01][Byte: <i>Block</i> ]
Response:	[00][Bool: Result][Byte Array(16): Data]
Example	
Command:	0B0102
	(Block: 02)
Response:	000100000000000000000000000000000000000
	(Result: true, Data: 00000000000000000000000000000000000



### 1.5.10.3. MifareClassic\_WriteBlock

Command:	[0B02][Byte: Block][Byte Array(16): Data]
Response:	[00][Bool: Result]
Example	
Command:	0B020200000000000000000000000000000000
	(Block: 02, Data: 00000000000000000000000000000000000
Response:	0001
	(Result: true)

### 1.5.10.4. MifareClassic\_ReadValueBlock

Command:	[0B03][Byte: Block]
Response:	[00][Bool: Result][UInt32: Value]
Example	
Command:	0B0302
	(Block: 02)
Response:	000101000000
	(Result: true, Value: 1)

### ${\bf 1.5.10.5.}\ Mifare Classic\_Write Value Block$

Command:	[0B04][Byte: Block][UInt32: Value]
Response:	[00][Bool: Result]
Example	
Command:	0B040201000000
	(Block: 02, Value: 01000000)
Response:	0001
	(Result: true)

## ${\bf 1.5.10.6.}\ Mifare Classic\_Increment Value Block$

Command:	[0B05][Byte: Block][UInt32: Value]
Response:	[00][Bool: Result]
Example	
Command:	0B050201000000
	(Block: 02, Value: 01000000)
Response:	0001
	(Result: true)



## ${\bf 1.5.10.7.\ Mifare Classic\_Decrement Value Block}$

Command:	[0B06][Byte: Block][UInt32: Value]
Response:	[00][Bool: Result]
Example	
Command:	0B060201000000
	(Block: 02, Value: 01000000)
Response:	0001
	(Result: true)

## 1.5.10.8. MifareClassic\_CopyValueBlock

Command:	[0B07][Byte: SourceBlock][Byte: DestBlock]
Response:	[00][Bool: Result]
Example	
Command:	0B07090A
	(SourceBlock: 09, DestBlock: 0A)
Response:	0001
	(Result: true)

#### 1.5.11. API MIFAREULTRALIGHT

# 1.5.11.1. MifareUltralight\_ReadPage

Command:	[0C00][Byte: <i>Page</i> ]
Response:	[00][Bool: Result][Byte Array(16): Data]
Example	
Command:	0C0004
	(Page: 04)
Response:	000100010203147870672E636F6D3A636172
	(Result: true, Data: 00010203147870672E636F6D3A636172)



### 1.5.11.2. MifareUltralight\_WritePage

Command:	[0C01][Byte: Page][Byte Array(4): Data]
Response:	[00][Bool: Result]
Example	
Command:	0C010400010203
	(Page: 04, Data: 00010203)
Response:	0001
	(Result: true)

### 1.5.11.3. MifareUltralightC\_Authenticate

Command:	[0C02][Byte Array(16): <i>Key</i> ]
Response:	[00][Bool: Result]
Example	
Command:	0C0249454D4B41455242214E4143554F5946
	(Key: 49454D4B41455242214E4143554F5946)
Response:	0001
	(Result: true)

#### 1.5.11.4. MifareUltralightC\_SAMAuthenticate

Command:	[0C03][Byte: KeyNo][Byte: KeyVersion][Byte Array(Var): DIVInput]
Response:	[00][Bool: Result]
Example	
Command:	0C03010000
	(KeyNo: 01, KeyVersion: 00, DIVInput: )
Response:	0001
	(Result: true)

### 1.5.11.5. MifareUltralightC\_WriteKeyFromSAM

Command:	[0C04][Byte: KeyNo][Byte: KeyVersion][Byte Array(Var): DIVInput]
Response:	[00][Bool: Result]
Example	
Command:	0C04010000
	(KeyNo: 01, KeyVersion: 00, DIVInput: )
Response:	0000
	(Result: fail)



## 1.5.11.6. MifareUltralightEV1\_FastRead

Command:	[0C05][Byte: StartPage][Byte: NumberOfPages]
Response:	[00][Bool: Result][Byte Array(Var): Data]
Example	
Command:	0C050401
	(StartPage: 04, NumberOfPages: 01)
Response:	0001040000000
	(Result: true, Data: 00000000)

## ${\bf 1.5.11.7.}\ \ \textbf{Mifare Ultralight EV1\_Inc Counter}$

Command:	[0C06][Byte: CounterAddr][UInt32: IncrValue]
Response:	[00][Bool: Result]
Example	
Command:	0C06000000000
	(CounterAddr: 00, IncrValue: 00000000)
Response:	0001
	(Result: true)

### 1.5.11.8. MifareUltralightEV1\_ReadCounter

Command:	[0C07][Byte: CounterAddr]
Response:	[00][Bool: Result][UInt32: CounterValue]
Example	
Command:	0C0700
	(CounterAddr: 00)
Response:	000102000000
	(Result: true, CounterValue: 2)



### 1.5.11.9. MifareUltralightEV1\_ReadSig

Command:	[0C08]
Response:	[00][Bool: Result][Byte Array(32): ECCSig]
Example	
Command:	0C08
Response:	00013A4F2622AF2039E47F8AA1BF84C52EE949860DD07125BEF75EC4- 17833B80C105
	(Result: true, ECCSig:
	3A4F2622AF2039E47F8AA1BF84C52EE949860DD07125BEF75EC417833B80C105)

#### 1.5.11.10. MifareUltralightEV1\_GetVersion

Command:	[0C09]
Response:	[00][Bool: Result][Byte Array(8): Version]
Example	
Command:	0C09
Response:	00010004030101000E03
	(Result: true, Version: 0004030101000E03)

## 1.5.11.11. MifareUltralightEV1\_PwdAuth

Command:	[0C0A][Byte Array(4): Password][Byte Array(2): PwdAck]
Response:	[00][Bool: Result]
Example	
Command:	0C0AFFFFFF0000
	(Password: FFFFFFF, PwdAck: 0000)
Response:	0001
	(Result: true)

### 1.5.11.12. MifareUltralightEV1\_CheckTearingEvent

Command:	[0C0B][Byte: CounterAddr]
Response:	[00][Bool: Result][Byte: ValidFlag]
Example	
Command:	0C0B00
	(CounterAddr: 00)
Response:	0001BD
	(Result: true, ValidFlag: 189)



#### 1.5.12. API ISO15693

### 1.5.12.1. ISO15693\_GenericCommand

Command:	[0D00][Byte: Flags][Byte: Command][Byte Array(Var): Data][Byte: BufferSize]
Response:	[00][Bool: Result][Byte Array(Var): Data]
Example	
Command:	0D001020010020
	(Flags: 10, Command: 20, Data: 00, BufferSize: 20)
Response:	0001040000000
	(Result: true, Data: 00000000)

#### 1.5.12.2. ISO15693\_GetSystemInformation

Command:	[0D01]
Response:	[00][Bool: Result][Byte Array(15): SystemInfo]
Example	
Command:	0D01
Response:	0001EF50781B06013C16E002000442000F
	(Result: true, SystemInfo: EF50781B06013C16E002000442000F)

### ${\bf 1.5.12.3.\ ISO15693\_GetSystemInformationExt}$

Command:	[0D02]
Response:	[00][Bool: Result][Byte Array(15): SystemInfo]
Example	
Command:	0D02
Response:	0001EF7D50C3ED084402E0000004000844
	(Result: true, SystemInfo: EF7D50C3ED084402E0000004000844)

### 1.5.12.4. ISO15693\_GetTagTypeFromUID

Command:	[0D03][Byte Array(8): UID]
Response:	[00][Byte: TagType]
Example	
Command:	0D03E0163C01061B7850
	(UID: E0163C01061B7850)
Response:	00FF
	(TagType: 255)



### ${\bf 1.5.12.5.}\ ISO15693\_GetTagTypeFromSystemInfo$

Command:	[0D04][Byte Array(15): SystemInfo]
Response:	[00][Byte: TagType]
Example	
Command:	0D04EF7D50C3ED084402E0000004000844
	(SystemInfo: EF7D50C3ED084402E0000004000844)
Response:	0043
	(TagType: 67)

### 1.5.12.6. ISO15693\_ReadSingleBlock

Command:	[0D05][UInt16: BlockNumber][Byte: BufferSize]
Response:	[00][Bool: Result][Byte Array(Var): BlockData]
Example	
Command:	0D050500FF
	(BlockNumber: 0500, BufferSize: FF)
Response:	0001040000000
	(Result: true, BlockData: 00000000)

#### 1.5.12.7. ISO15693\_ReadSingleBlockExt

Command:	[0D06][UInt16: BlockNumber][Byte: BufferSize]
Response:	[00][Bool: Result][Byte Array(Var): BlockData]
Example	
Command:	0D060000FF
	(BlockNumber: 0000, BufferSize: FF)
Response:	00010401020304
	(Result: true, BlockData: 01020304)

### 1.5.12.8. ISO15693\_WriteSingleBlock

Command:	[0D07][UInt16: BlockNumber][Byte Array(Var): BlockData]
Response:	[00][Bool: Result]
Example	
Command:	0D0705000411223344
	(BlockNumber: 0500, BlockData: 11223344)
Response:	0001
	(Result: true)



# 1.5.12.9. ISO15693\_WriteSingleBlockExt

Command:	[0D08][UInt16: BlockNumber][Byte Array(Var): BlockData]
Response:	[00][Bool: Result]
Example	
Command:	0D08000004426C612E
	(BlockNumber: 0000, BlockData: 426C612E)
Response:	0001
	(Result: true)

### 1.5.13. API CRYPTO

### 1.5.13.1. Crypto\_Init

Command:	[0E00][Byte: CryptoEnv][Byte: CryptoMode][Byte Array(Var): Key]
Response:	[00]
Example	
Command:	0E000000100000000000000000000000000000
	(CryptoEnv: 00, CryptoMode: 00, Key: 000000000000000000000000000000000000
Response:	00

#### 1.5.13.2. Encrypt

Command:	[0E01][Byte: CryptoEnv][Byte Array(Var): PlainBlock]
Response:	[00][Byte Array(Var): CipheredBlock]
Example	
Command:	0E0100108000000000000000000000000000000
	(CryptoEnv: 00, PlainBlock: 8000000000000000000000000000000000000
Response:	00103AD78E726C1EC02B7EBFE92B23D9EC34
	(CipheredBlock: 3AD78E726C1EC02B7EBFE92B23D9EC34)



## 1.5.13.3. Decrypt

Command:	[0E02][Byte: CryptoEnv][Byte Array(Var): CipheredBlock]
Response:	[00][Byte Array(Var): PlainBlock]
Example	
Command:	0E0200103AD78E726C1EC02B7EBFE92B23D9EC34
	(CryptoEnv: 00, CipheredBlock: 3AD78E726C1EC02B7EBFE92B23D9EC34)
Response:	001080000000000000000000000000000000000
	(PlainBlock: 8000000000000000000000000000000000000

## 1.5.13.4. CBC\_ResetInitVector

Command:	[0E03][Byte: CryptoEnv]
Response:	[00]
Example	
Command:	0E0300
	(CryptoEnv: 00)
Response:	00

#### **1.5.14. API DESFIRE**

#### 1.5.14.1. DESFire\_GetApplicationIDs

Command:	[0F00][Byte: CryptoEnv][Byte: MaxAIDCnt]
Response:	[00][Bool: Result][variable number of UInt32: AIDs]
Example	
Command:	0F00001C
	(CryptoEnv: 00, MaxAIDCnt: 1C)
Response:	00010133221100
	(Result: true, AIDs: 00112233)



# 1.5.14.2. DESFire\_CreateApplication

Command:	[0F01][Byte: CryptoEnv][UInt32: AID][4 Bit: ChangeKeyAccessRights][1 Bit: ConfigurationChangeable][1 Bit: FreeCreateDelete][1 Bit: FreeDirectoryList][1 Bit: AllowChange-MasterKey][UInt32: NumberOfKeys][UInt32: KeyType]
Response:	[00][Bool: Result]
Example	
Command:	0F0100907856000F01000000000000
	(CryptoEnv: 00, AID: 90785600, ChangeKeyAccessRights: 15, ConfigurationChangeable: 1, FreeCreateDelete: 1, FreeDirectoryList: 1, AllowChangeMasterKey: 1, NumberOfKeys: 01000000, KeyType: 00000000)
Response:	0001
	(Result: true)

## 1.5.14.3. DESFire\_DeleteApplication

Command:	[0F02][Byte: CryptoEnv][UInt32: AID]
Response:	[00][Bool: Result]
Example	
Command:	0F020090785600
	(CryptoEnv: 00, AID: 90785600)
Response:	0001
	(Result: true)

### 1.5.14.4. DESFire\_SelectApplication

Command:	[0F03][Byte: CryptoEnv][UInt32: AID]
Response:	[00][Bool: Result]
Example	
Command:	0F030033221100
	(CryptoEnv: 00, AID: 33221100)
Response:	0001
	(Result: true)



# 1.5.14.5. DESFire\_Authenticate

Command:	[0F04][Byte: <i>CryptoEnv</i> ][Byte: <i>KeyNoTag</i> ][Byte Array(Var): <i>Key</i> ][Byte: <i>KeyType</i> ][Byte: <i>Mode</i> ]
Response:	[00][Bool: Result]
Example	
Command:	0F0400001000000000000000000000000000000
	(CryptoEnv: 00, KeyNoTag: 00, Key: 000000000000000000000000000000, KeyType: 00, Mode: 00)
Response:	0001
	(Result: true)

## 1.5.14.6. DESFire\_GetKeySettings

Command:	[0F05][Byte: CryptoEnv]
Response:	[00][Bool: Result][Byte: KeySettings][UInt32: NumberOfKeys][UInt32: KeyType]
Example	
Command:	0F0500
	(CryptoEnv: 00)
Response:	00010F01000000000000
	(Result: true, KeySettings: 15, NumberOfKeys: 1, KeyType: 0)

## 1.5.14.7. DESFire\_GetFileIDs

Command:	[0F06][Byte: CryptoEnv][Byte: MaxFileIDCount]
Response:	[00][Bool: Result][variable number of Bytes: FileIDList]
Example	
Command:	0F0600FF
	(CryptoEnv: 00, MaxFileIDCount: FF)
Response:	00010400010203
	(Result: true, FileIDList: 00, 01, 02, 03)



## 1.5.14.8. DESFire\_GetFileSettings

Command:	[0F07][Byte: CryptoEnv][Byte: FileNo]
Response:	[00][Bool: Result][Byte Array(20): FileSettings]
Example	
Command:	0F070000
	(CryptoEnv: 00, FileNo: 00)
Response:	00010000EEEE2000000000000000000000036322F50
	(Result: true, FileSettings: 0000EEEE200000000000000000000000036322F50)

## 1.5.14.9. DESFire\_ReadData

Command:	[0F08][Byte: CryptoEnv][Byte: FileNo][UInt16: Offset][Byte: Length][Byte: CommSet]
Response:	[00][Bool: Result][Byte Array(Var): Data]
Example	
Command:	0F0800000000300
	(CryptoEnv: 00, FileNo: 00, Offset: 0000, Length: 03, CommSet: 00)
Response:	000103001122
	(Result: true, Data: 001122)

### 1.5.14.10. DESFire\_WriteData

Command:	[0F09][Byte: <i>CryptoEnv</i> ][Byte: <i>FileNo</i> ][UInt16: <i>Offset</i> ][Byte Array(Var): <i>Data</i> ][Byte: <i>CommSet</i> ]
Response:	[00][Bool: Result]
Example	
Command:	0F0900000000300112200
	(CryptoEnv: 00, FileNo: 00, Offset: 0000, Data: 001122, CommSet: 00)
Response:	0001
	(Result: true)



## 1.5.14.11. DESFire\_GetValue

Command:	[0F0A][Byte: CryptoEnv][Byte: FileNo][Byte: CommSet]
Response:	[00][Bool: Result][UInt32: Value]
Example	
Command:	0F0A000000
	(CryptoEnv: 00, FileNo: 00, CommSet: 00)
Response:	00010000000
	(Result: true, Value: 0)

## 1.5.14.12. DESFire\_Credit

Command:	[0F0B][Byte: CryptoEnv][Byte: FileNo][UInt32: Value][Byte: CommSet]
Response:	[00][Bool: Result]
Example	
Command:	0F0B0004000000000
	(CryptoEnv: 00, FileNo: 04, Value: 00000000, CommSet: 00)
Response:	0001
	(Result: true)

### 1.5.14.13. DESFire\_Debit

Command:	[0F0C][Byte: CryptoEnv][Byte: FileNo][UInt32: Value][Byte: CommSet]
Response:	[00][Bool: Result]
Example	
Command:	0F0C0004000000000
	(CryptoEnv: 00, FileNo: 04, Value: 00000000, CommSet: 00)
Response:	0001
	(Result: true)

## 1.5.14.14. DESFire\_LimitedCredit

Command:	[0F0D][Byte: CryptoEnv][Byte: FileNo][UInt32: Value][Byte: CommSet]
Response:	[00][Bool: Result]
Example	
Command:	0F0D0004000000000
	(CryptoEnv: 00, FileNo: 04, Value: 00000000, CommSet: 00)
Response:	0001
	(Result: true)



## $1.5.14.15.\ DESFire\_FreeMem$

Command:	[0F0E][Byte: CryptoEnv]
Response:	[00][Bool: Result][UInt16: FreeMemory]
Example	
Command:	0F0E00
	(CryptoEnv: 00)
Response:	00016011
	(Result: true, FreeMemory: 4448)

## 1.5.14.16. DESFire\_FormatTag

Command:	[0F0F][Byte: CryptoEnv]
Response:	[00][Bool: Result]
Example	
Command:	0F0F00
	(CryptoEnv: 00)
Response:	0001
	(Result: true)

#### 1.5.14.17. DESFire\_CreateDataFile

Command:	[0F10][Byte: CryptoEnv][Byte: FileNo][Byte: FileType][Byte: CommSet][UInt16: Access-Rights][UInt32: FileSize]appending 0's]
Response:	[00][Bool: Result]
Example	
Command:	0F1000050000EEEE0F0000000000000000000000
	(CryptoEnv: 00, FileNo: 05, FileType: 00, CommSet: 00, AccessRights: EEEE, FileSize: 0F000000, appending 0's: 0000000000000000000000000000000000
Response:	0001
	(Result: true)



## 1.5.14.18. DESFire\_CreateValueFile

Command:	[0F11][Byte: CryptoEnv][Byte: FileNo][Byte: FileType][Byte: CommSet][UInt16: AccessRights][UInt32: LowerLimit][UInt32: UpperLimit][UInt32: LimitedCreditValue][1 Bit: FreeGetValue][1 Bit: LimitedCreditEnabled]
Response:	[00][Bool: Result]
Example	
Command:	0F1100040200EEEE00000000F0000000F00000001000000
	(CryptoEnv: 00, FileNo: 04, FileType: 02, CommSet: 00, AccessRights: EEEE, Lower-Limit: 00000000, UpperLimit: 0F000000, LimitedCreditValue: 0F000000, FreeGetValue: 1, LimitedCreditEnabled: 1)
Response:	0001
	(Result: true)

### 1.5.14.19. DESFire\_GetVersion

Command:	[0F12][Byte: CryptoEnv]
Response:	[00][Bool: Result][Byte Array(34): Version]
Example	
Command:	0F1200
	(CryptoEnv: 00)
Response:	00010401010100001000005040101010300100000050000000000
	(Result: true, Version:
	04010101000010000005040101010300100000050000000000

#### 1.5.14.20. DESFire\_DeleteFile

Command:	[0F13][Byte: CryptoEnv][Byte: FileNo]
Response:	[00][Bool: Result]
Example	
Command:	0F130005
	(CryptoEnv: 00, FileNo: 05)
Response:	0001
	(Result: true)



## 1.5.14.21. DESFire\_CommitTransaction

Command:	[0F14][Byte: CryptoEnv]
Response:	[00][Bool: Result]
Example	
Command:	0F1400
	(CryptoEnv: 00)
Response:	0001
	(Result: true)

#### 1.5.14.22. DESFire\_AbortTransaction

Command:	[0F15][Byte: CryptoEnv]
Response:	[00][Bool: Result]
Example	
Command:	0F1500
	(CryptoEnv: 00)
Response:	0001
	(Result: true)

### 1.5.14.23. DESFire\_GetUID

Command:	[0F16][Byte: CryptoEnv][Byte: BufferSize]
Response:	[00][Bool: Result][Byte Array(Var): UID]
Example	
Command:	0F1600FF
	(CryptoEnv: 00, BufferSize: FF)
Response:	000107045243523D2480
	(Result: true, UID: 045243523D2480)

## 1.5.14.24. DESFire\_GetKeyVersion

Command:	[0F17][Byte: CryptoEnv][Byte: KeyNo]
Response:	[00][Bool: Result][Byte Array(1): KeyVersion]
Example	
Command:	0F170000
	(CryptoEnv: 00, KeyNo: 00)
Response:	0001FF
	(Result: true, KeyVersion: FF)



## 1.5.14.25. DESFire\_ChangeKeySettings

Command:	[0F18][Byte: CryptoEnv][4 Bit: ChangeKeyAccessRights][1 Bit: ConfigurationChange-able][1 Bit: FreeCreateDelete][1 Bit: FreeDirectoryList][1 Bit: AllowChangeMasterKey][UInt32: NumberOfKeys][UInt32: KeyType]
Response:	[00][Bool: Result]
Example	
Command:	0F18000F00000000000000
	(CryptoEnv: 00, ChangeKeyAccessRights: 15, ConfigurationChangeable: 1, FreeCreateDelete: 1, FreeDirectoryList: 1, AllowChangeMasterKey: 1, NumberOfKeys: 00000000, KeyType: 00000000)
Response:	0001
	(Result: true)

## 1.5.14.26. DESFire\_ChangeKey

Command:	[0F19][Byte: CryptoEnv][Byte: KeyNo][Byte Array(Var): OldKey][Byte Array(Var): NewKey][Byte: KeyVersion][4 Bit: ChangeKeyAccessRights][1 Bit: ConfigurationChange-able][1 Bit: FreeCreateDelete][1 Bit: FreeDirectoryList][1 Bit: AllowChangeMasterKey][UInt32: NumberOfKeys][UInt32: KeyType]
Response:	[00][Bool: Result]
Example	
Command:	0F1900001000000000000000000000000000000
	(CryptoEnv: 00, KeyNo: 00, OldKey: 0000000000000000000000000000000, NewKey: 0000000000000000000000000000000, KeyVersion: 00, ChangeKeyAccessRights: 15, ConfigurationChangeable: 1, FreeCreateDelete: 1, FreeDirectoryList: 1, AllowChange-MasterKey: 1, NumberOfKeys: 01000000, KeyType: 00000000)
Response:	0001
	(Result: true)

### 1.5.14.27. DESFire\_ChangeFileSettings

Command:	[0F1A][Byte: CryptoEnv][Byte: FileNo][Byte: NewCommSet][UInt16: OldAccess-Rights][UInt16: NewAccessRights]
Response:	[00][Bool: Result]
Example	
Command:	0F1A000000EEEEEEE
	(CryptoEnv: 00, FileNo: 00, NewCommSet: 00, OldAccessRights: EEEE, NewAccess-Rights: EEEE)
Response:	0001
	(Result: true)



### 1.5.14.28. DESFire\_DisableFormatCard

Command:	[0F1B][Byte: CryptoEnv]
Response:	[00][Bool: Result]
Example	
Command:	0F1B00
	(CryptoEnv: 00)
Response:	0001
	(Result: true)

### 1.5.14.29. DESFire\_EnableRandomID

Command:	[0F1C][Byte: CryptoEnv]
Response:	[00][Bool: Result]
Example	
Command:	0F1C00
	(CryptoEnv: 00)
Response:	0001
	(Result: true)

### 1.5.14.30. DESFire\_SetDefaultKey

Command:	[0F1D][Byte: CryptoEnv][Byte Array(Var): Key][Byte: KeyVersion]
Response:	[00][Bool: Result]
Example	
Command:	0F1D00100000000000000000000000000000000
	(CryptoEnv: 00, Key: 000000000000000000000000000, KeyVersion: FF)
Response:	0001
	(Result: true)

### 1.5.14.31. DESFire\_SetATS

Command:	[0F1E][Byte: CryptoEnv][Byte Array(Var): ATS]
Response:	[00][Bool: Result]
Example	
Command:	0F1E0008087577810280CAFE
	(CryptoEnv: 00, ATS: 087577810280CAFE)
Response:	0001
	(Result: true)



# 1.5.14.32. DESFire\_CreateRecordFile

Command:	[0F1F][Byte: CryptoEnv][Byte: FileNo][Byte: FileType][Byte: CommSet][UInt16: Access-Rights][UInt32: RecordSize][UInt32: MaxNumberOfRecords]appending 0's]
Response:	[00][Bool: Result]
Example	
Command:	0F1F00050000EEEE0F0000001000000000000000
	(CryptoEnv: 00, FileNo: 05, FileType: 00, CommSet: 00, AccessRights: EEEE, RecordSize: 0F000000, MaxNumberOfRecords: 01000000, appending 0's: 000000000000000)
Response:	0001
	(Result: true)

#### 1.5.14.33. DESFire\_ReadRecords

Command:	[0F20][Byte: CryptoEnv][Byte: FileNo][UInt16: Offset][Byte: NumberOfRecords][Byte: RecordSize][Byte: CommSet]
Response:	[00][Bool: Result][Byte Array(Var): Data]
Example	
Command:	0F200000000030000
	(CryptoEnv: 00, FileNo: 00, Offset: 0000, NumberOfRecords: 03, RecordSize: 00, CommSet: 00)
Response:	000103001122
	(Result: true, Data: 001122)

#### 1.5.14.34. DESFire\_WriteRecord

Command:	[0F21][Byte: CryptoEnv][Byte: FileNo][UInt16: Offset][Byte Array(Var): Data][Byte: CommSet]
Response:	[00][Bool: Result]
Example	
Command:	0F2100000000300112200
	(CryptoEnv: 00, FileNo: 00, Offset: 0000, Data: 001122, CommSet: 00)
Response:	0001
	(Result: true)



## 1.5.14.35. DESFire\_ClearRecordFile

Command:	[0F22][Byte: CryptoEnv][Byte: FileNo]
Response:	[00][Bool: Result]
Example	
Command:	0F220005
	(CryptoEnv: 00, FileNo: 05)
Response:	0001
	(Result: true)

### 1.5.15. API ISO7816

### 1.5.15.1. ISO7816\_GetSlotStatus

Command:	[1000][Byte: Channel]
Response:	[00][Bool: Result][Byte Array(3): SlotStatus]
Example	
Command:	100020
	(Channel: 20)
Response:	0001000000
	(Result: true, SlotStatus: 000000)

### 1.5.15.2. ISO7816\_lccPowerOn

Command:	[1001][Byte: Channel][Byte: MaxATRByteCnt][Byte: bPowerSelect]
Response:	[00][Bool: Result][Byte Array(Var): ATR][Byte: bStatus][Byte: bError]
Example	
Command:	100120FF00
	(Channel: 20, MaxATRByteCnt: FF, bPowerSelect: 00)
Response:	00010F3B959680B1FE551FC74772616365130000
	(Result: true, ATR: 3B959680B1FE551FC7477261636513, bStatus: 0, bError: 0)



# 1.5.15.3. ISO7816\_IccPowerOff

Command:	[1002][Byte: Channel]
Response:	[00][Bool: Result][Byte Array(3): SlotStatus]
Example	
Command:	100220
	(Channel: 20)
Response:	0001010000
	(Result: true, SlotStatus: 010000)

## 1.5.15.4. ISO7816\_SetCommSettings

Command:	[1003][Byte: Channel][Byte Array(14): CommSettings]
Response:	[00][Bool: Result]
Example	
Command:	1003200100740101000000FF5500FE0000
	(Channel: 20, CommSettings: 0100740101000000FF5500FE0000)
Response:	0001
	(Result: true)

### 1.5.15.5. ISO7816\_Transceive

Command:	[1004][Byte: Channel][Byte Array(Var), 2 LB: TX][Byte: MaxRXByteCnt]
Response:	[00][Bool: Result][Byte Array(Var), 2 LB: RX]
Example	
Command:	100420050000C10120E0FF
	(Channel: 20, TX: 00C10120E0, MaxRXByteCnt: FF)
Response:	000102006E00
	(Result: true, RX: 6E00)



## 1.5.15.6. ISO7816\_ExchangeAPDU

Command:	[1005][Byte: Channel][Byte Array(9): Header][Byte Array(Var), 2 LB: TXData][UInt16: MaxRXByteCnt]
Response:	[00][Bool: Result][Byte Array(Var), 2 LB: RXData][UInt16: StatusWord]
Example	
Command:	10052000A40004020000000102003F008000
	(Channel: 20, Header: 00A400040200000001, TXData: 3F00, MaxRXByteCnt: 8000)
Response:	0001000006E
	(Result: true, RXData: , StatusWord: 28160)

## 1.5.15.7. ISO7816\_T0\_TPDU

Command:	[1006][Byte: Channel][Byte Array(5): Header][Byte Array(Var), 2 LB: TXData][UInt16: MaxRXByteCnt]
Response:	[00][Bool: Result][Byte Array(Var), 2 LB: RXData][UInt16: StatusWord]
Example	
Command:	10062000A400040202003F008000
	(Channel: 20, Header: 00A4000402, TXData: 3F00, MaxRXByteCnt: 8000)
Response:	0001000006E
	(Result: true, RXData: , StatusWord: 28160)

## 1.5.15.8. ISO7816\_CheckWellKnownCards

Command:	[1007][Byte: Channel]
Response:	[00][Bool: Result][Byte Array(4): CardType]
Example	
Command:	100720
	(Channel: 20)
Response:	000110000000
	(Result: true, CardType: 10000000)



#### 1.5.16. API ICLASS

### 1.5.16.1. ICLASS\_GetPACBits

Command:	[1100][Byte: MaxPACBytes]
Response:	[00][Bool: Result][Byte: PACBitCnt][Byte Array(Var): PAC]
Example	
Command:	1100FF
	(MaxPACBytes: FF)
Response:	00011A0405000980
	(Result: true, PACBitCnt: 26, PAC: 00140026)

### 1.5.16.2. ICLASS\_SelectPage

Command:	[1101][Byte: Book][Byte: Page]
Response:	[00][Bool: Result][Byte Array(8): ConfigBlock]
Example	
Command:	11010000
	(Book: 00, Page: 00)
Response:	000112FFFFFE91FFF3C
	(Result: true, ConfigBlock: 12FFFFFE91FFF3C)

### 1.5.16.3. ICLASS\_Authenticate

Command:	[1102][Byte Array(3): KeyReferenceOID][Byte: KeyType]
Response:	[00][Bool: Result]
Example	
Command:	110203002300
	(KeyReferenceOID: 030023, KeyType: 00)
Response:	0001
	(Result: true)



## 1.5.16.4. ICLASS\_ReadBlock

Command:	[1103][Byte: <i>Block</i> ]
Response:	[00][Bool: Result][Byte Array(8): BlockData]
Example	
Command:	110313
	(Block: 13)
Response:	00010000000000000
	(Result: true, BlockData: 000000000000000)

## 1.5.16.5. ICLASS\_WriteBlock

Command:	[1104][Byte: Block][Byte Array(8): BlockData]
Response:	[00][Bool: Result]
Example	
Command:	11041300000000000000
	(Block: 13, BlockData: 000000000000000)
Response:	0001
	(Result: true)

### 1.5.17. API ISO14443

### 1.5.17.1. ISO14443A\_GetATS

Command:	[1200][Byte: MaxATSByteCnt]
Response:	[00][Bool: Result][Byte Array(Var): ATS]
Example	
Command:	120020
	(MaxATSByteCnt: 20)
Response:	000106067577810280
	(Result: true, ATS: 067577810280)



### 1.5.17.2. ISO14443B\_GetATQB

Command:	[1201][Byte: MaxATQBByteCnt]
Response:	[00][Bool: Result][Byte Array(Var): ATQB]
Example	
Command:	1201FF
	(MaxATQBByteCnt: FF)
Response:	00010C5077FB13540000000B37171
	(Result: true, ATQB: 5077FB13540000000B37171)

#### 1.5.17.3. ISO14443\_4\_CheckPresence

Command:	[1202]
Response:	[00][Bool: Result]
Example	
Command:	1202
Response:	0001
	(Result: true)

#### 1.5.17.4. ISO14443\_4\_TDX

Command:	[1203][Byte Array(Var): TX][Byte: MaxRXByteCnt]
Response:	[00][Bool: Result][Byte Array(Var): RX]
Example	
Command:	1203016020
	(TX: 60, MaxRXByteCnt: 20)
Response:	0001026F00
	(Result: true, RX: 6F00)

#### 1.5.17.5. ISO14443A\_GetATQA

Command:	[1204]
Response:	[00][Bool: Result][Byte Array(2): ATQA]
Example	
Command:	1204
Response:	00010403
	(Result: true, ATQA: 0403)



### 1.5.17.6. ISO14443A\_GetSAK

Command:	[1205]
Response:	[00][Bool: Result][Byte Array(1): SAK]
Example	
Command:	1205
Response:	000120
	(Result: true, SAK: 20)

# 1.5.17.7. ISO14443B\_GetAnswerToATTRIB

Command:	[1206][Byte: MaxAnswerToATTRIBByteCnt]
Response:	[00][Bool: Result][Byte Array(Var): AnswerToATTRIB]
Example	
Command:	1206FF
	(MaxAnswerToATTRIBByteCnt: FF)
Response:	00010100
	(Result: true, AnswerToATTRIB: 00)

### 1.5.17.8. ISO14443\_3\_TDX

Command:	[1207][Byte Array(Var): TX][Byte: MaxRXByteCnt][UInt16: Timeout]
Response:	[00][Bool: Result][Byte Array(Var): RX]
Example	
Command:	1207041A004176FFFF00
	(TX: 1A004176, MaxRXByteCnt: FF, Timeout: FF00)
Response:	00010104
	(Result: true, RX: 04)

### 1.5.17.9. ISO14443A\_SearchMultiTag

Command:	[1208][Byte: MaxUIDListByteCnt]
Response:	[00][Bool: Result][Byte: UIDCnt][variable number of Bytes: UIDList]
Example	
Command:	1208FF
	(MaxUIDListByteCnt: FF)
Response:	000103180704D7A79A97378007042DA79A973780070450A79A973780
	(Result: true, UIDCnt: 3, UIDList: 04D7A79A973780, 042DA79A973780, 0450A79A973780)



### 1.5.17.10. ISO14443A\_SelectTag

Command:	[1209][Byte Array(Var): UID]
Response:	[00][Bool: Result]
Example	
Command:	12090704D7A79A973780
	(UID: 04D7A79A973780)
Response:	0001
	(Result: true)

#### 1.5.18. API AT55

#### 1.5.18.1. AT55\_Begin

Command:	[1500]
Response:	[00]
Example	
Command:	1500
Response:	00

### 1.5.18.2. AT55\_ReadBlock

Command:	[1501][Byte: Address]
Response:	[00][Bool: Result][Byte Array(4): Data]
Example	
Command:	150100
	(Address: 00)
Response:	0001F0148040
	(Result: true, Data: F0148040)

### 1.5.18.3. AT55\_ReadBlockProtected

Command:	[1502][Byte: Address][Byte Array(4): Password]
Response:	[00][Bool: Result][Byte Array(4): Data]
Example	
Command:	1502000000000
	(Address: 00, Password: 00000000)
Response:	0001B8A31C02
	(Result: true, Data: B8A31C02)



### 1.5.18.4. AT55\_WriteBlock

Command:	[1503][Byte: Address][Byte Array(4): Data]
Response:	[00][Bool: Result]
Example	
Command:	1503000010203
	(Address: 00, Data: 00010203)
Response:	0001
	(Result: true)

## 1.5.18.5. AT55\_WriteBlockProtected

Command:	[1504][Byte: Address][Byte Array(4): Data][Byte Array(4): Password]
Response:	[00][Bool: Result]
Example	
Command:	15040000102030000000
	(Address: 00, Data: 00010203, Password: 00000000)
Response:	0001
	(Result: true)

### 1.5.18.6. AT55\_WriteBlockAndLock

Command:	[1505][Byte: Address][Byte Array(4): Data]
Response:	[00][Bool: Result]
Example	
Command:	1505000010203
	(Address: 00, Data: 00010203)
Response:	0001
	(Result: true)

### ${\bf 1.5.18.7.\ AT55\_WriteBlockProtectedAndLock}$

Command:	[1506][Byte: Address][Byte Array(4): Data][Byte Array(4): Password]
Response:	[00][Bool: Result]
Example	
Command:	15060000102030000000
	(Address: 00, Data: 00010203, Password: 00000000)
Response:	0001
	(Result: true)



#### **1.5.19. API NFCSNEP**

#### 1.5.19.1. SNEP\_Init

Command:	[1800]
Response:	[00][Bool: Result]
Example	
Command:	1800
Response:	0001
	(Result: true)

### 1.5.19.2. SNEP\_GetConnectionState

Command:	[1801]
Response:	[00][Byte: ConnectionState]
Example	
Command:	1801
Response:	0002
	(ConnectionState: 2)

### 1.5.19.3. SNEP\_GetFragmentByteCount

Command:	[1802][Byte: Direction]
Response:	[00][UInt16: ByteCount]
Example	
Command:	180201
	(Direction: 01)
Response:	000000
	(ByteCount: 0)

### 1.5.19.4. SNEP\_BeginMessage

Command:	[1803][UInt32: MsgByteCnt]
Response:	[00][Bool: Result]
Example	
Command:	1803FF000000
	(MsgByteCnt: FF000000)
Response:	0001
	(Result: true)



### 1.5.19.5. SNEP\_SendMessageFragment

Command:	[1804][Byte Array(Var), 2 LB: MsgFrag]
Response:	[00][Bool: Result]
Example	
Command:	18041500D101115501656C617465632D726669642E636F6D2F
	(MsgFrag: D101115501656C617465632D726669642E636F6D2F)
Response:	0001
	(Result: true)

### 1.5.19.6. SNEP\_TestMessage

Command:	[1805]
Response:	[00][Bool: Result][UInt32: MsgByteCnt]
Example	
Command:	1805
Response:	0000
	(Result: fail, MsgByteCnt: )

### 1.5.19.7. SNEP\_ReceiveMessageFragment

Command:	[1806][UInt16: FragByteCnt]
Response:	[00][Bool: Result][Byte Array(Var), 2 LB: MsgFrag]
Example	
Command:	1806FF00
	(FragByteCnt: FF00)
Response:	0000
	(Result: fail, MsgFrag: )

#### 1.5.19.8. SNEP\_RequestMessage

Command:	[1807][UInt32: MsgByteCnt][UInt32: AcceptableLength]
Response:	[00][Bool: Result]
Example	
Command:	1807FF000000FF000000
	(MsgByteCnt: FF000000, AcceptableLength: FF000000)
Response:	0001
	(Result: true)



#### 1.5.20. API EM4150

### 1.5.20.1. EM4150\_Login

Command:	[1900][Byte Array(4): Password]
Response:	[00][Bool: Result]
Example	
Command:	19000000000
	(Password: 00000000)
Response:	0001
	(Result: true)

### 1.5.20.2. EM4150\_ReadWord

Command:	[1901][Byte: <i>Address</i> ]
Response:	[00][Bool: Result][Byte Array(4): Word]
Example	
Command:	190101
	(Address: 01)
Response:	000100010203
	(Result: true, Word: 00010203)

### 1.5.20.3. EM4150\_WriteWord

Command:	[1902][Byte: Address][Byte Array(4): Word]
Response:	[00][Bool: Result]
Example	
Command:	19020100010203
	(Address: 01, Word: 00010203)
Response:	0001
	(Result: true)



# 1.5.20.4. EM4150\_WritePassword

Command:	[1903][Byte Array(4): ActualPassword][Byte Array(4): NewPassword]
Response:	[00][Bool: Result]
Example	
Command:	190300000001010101
	(ActualPassword: 00000000, NewPassword: 01010101)
Response:	0001
	(Result: true)

## 1.5.20.5. EM4150\_GetTagInfo

Command:	[1904]
Response:	[00][UInt32: <i>TagInfo</i> ]
Example	
Command:	1904
Response:	0001000000
	(TagInfo: 1)

#### **1.5.21. API FILESYS**

#### 1.5.21.1. FSMount

[1A00][Byte: StorageID][UInt32: Mode]
[00][Bool: Result]
1A000102000000
(StorageID: 01, Mode: 02000000)
0001
(Result: true)



#### 1.5.21.2. FSFormat

Command:	[1A01][Byte: StorageID][UInt32: MagicValue]
Response:	[00][Bool: Result]
Example	
Command:	1A0101446F4974
	(StorageID: 01, MagicValue: 446F4974)
Response:	0001
	(Result: true)

# 1.5.21.3. FSOpen

Command:	[1A02][Byte: FileEnv][Byte: StorageID][UInt32: FileID][Byte: Mode]
Response:	[00][Bool: Result]
Example	
Command:	1A0200013322110000
	(FileEnv: 00, StorageID: 01, FileID: 33221100, Mode: 00)
Response:	0001
	(Result: true)

#### 1.5.21.4. FSClose

Command:	[1A03][Byte: FileEnv]
Response:	[00][Bool: Result]
Example	
Command:	1A0300
	(FileEnv: 00)
Response:	0001
	(Result: true)

#### 1.5.21.5. FSCloseAll

Command:	[1A04]
Response:	[00]
Example	
Command:	1A04
Response:	00



#### 1.5.21.6. FSSeek

Command:	[1A05][Byte: FileEnv][Byte: Origin][UInt32: Pos]
Response:	[00][Bool: Result]
Example	
Command:	1A0500001000000
	(FileEnv: 00, Origin: 00, Pos: 01000000)
Response:	0001
	(Result: true)

#### 1.5.21.7. FSTell

Command:	[1A06][Byte: FileEnv][Byte: Origin]
Response:	[00][Bool: Result][UInt32: Pos]
Example	
Command:	1A060000
	(FileEnv: 00, Origin: 00)
Response:	000101000000
	(Result: true, Pos: 1)

## 1.5.21.8. FSReadBytes

Command:	[1A07][Byte: FileEnv][UInt16: ByteCount]
Response:	[00][Bool: Result][Byte Array(Var), 2 LB: Data]
Example	
Command:	1A07001E00
	(FileEnv: 00, ByteCount: 1E00)
Response:	000107004D792064617461
	(Result: true, Data: 4D792064617461)

## 1.5.21.9. FSWriteBytes

Command:	[1A08][Byte: FileEnv][Byte Array(Var), 2 LB: Data]
Response:	[00][Bool: Result][UInt16: BytesWritten]
Example	
Command:	1A080007004D792064617461
	(FileEnv: 00, Data: 4D792064617461)
Response:	00010700
	(Result: true, BytesWritten: 7)



#### 1.5.21.10. FSFindFirst

Command:	[1A09][Byte: StorageID]
Response:	[00][Bool: Result][Byte Array(8): FileInfo]
Example	
Command:	1A0901
	(StorageID: 01)
Response:	00013322110002000000
	(Result: true, FileInfo: 3322110002000000)

#### 1.5.21.11. FSFindNext

Command:	[1A0A]
Response:	[00][Bool: Result][Byte Array(8): FileInfo]
Example	
Command:	1A0A
Response:	00013422110002000000
	(Result: true, FileInfo: 3422110002000000)

#### 1.5.21.12. FSDelete

Command:	[1A0B][Byte: StorageID][UInt32: FileID]
Response:	[00][Bool: Result]
Example	
Command:	1A0B0133221100
	(StorageID: 01, FileID: 33221100)
Response:	0001
	(Result: true)

#### 1.5.21.13. FSRename

Command:	[1A0C][Byte: StorageID][UInt32: OldFileID][UInt32: NewFileID]
Response:	[00][Bool: Result]
Example	
Command:	1A0C017766554433221100
	(StorageID: 01, OldFileID: 77665544, NewFileID: 33221100)
Response:	0001
	(Result: true)



# 1.5.21.14. FSGetStorageInfo

Command:	[1A0D][Byte: StorageID]
Response:	[00][Bool: Result][Byte Array(9): StorageInfo]
Example	
Command:	1A0D01
	(StorageID: 01)
Response:	000101204B0000004B0000
	(Result: true, StorageInfo: 01204B0000004B0000)

#### 1.5.22. API MIFAREPLUS

### 1.5.22.1. MFP\_WritePerso

Command:	[1B00][UInt16: BlockNr][Byte Array(16): Data]
Response:	[00][Bool: Result]
Example	
Command:	1B0000400000000000000000000000000000000
	(BlockNr: 0040, Data: 00000000000000000000000000000000000
Response:	0001
	(Result: true)

# 1.5.22.2. MFP\_CommitPerso

Command:	[1B01]
Response:	[00][Bool: Result]
Example	
Command:	1B01
Response:	0001
	(Result: true)



# 1.5.22.3. MFP\_Authenticate

Command:	[1B02][Byte: CryptoEnv][UInt16: KeyBNr][Byte Array(16): Key]
Response:	[00][Bool: Result]
Example	
Command:	1B02000040000000000000000000000000000000
	(CryptoEnv: 00, KeyBNr: 0040, Key: 000000000000000000000000000000000000
Response:	0001
	(Result: true)

#### 1.5.22.4. MFP\_ReadBlock

Command:	[1B03][Byte: CryptoEnv][UInt16: Block]
Response:	[00][Bool: Result][Byte Array(16): Data]
Example	
Command:	1B03000400
	(CryptoEnv: 00, Block: 0400)
Response:	000101020304050607080900010203040506
	(Result: true, Data: 01020304050607080900010203040506)

# 1.5.22.5. MFP\_WriteBlock

Command:	[1B04][Byte: CryptoEnv][UInt16: Block][Byte Array(16): Data]
Response:	[00][Bool: Result]
Example	
Command:	1B0400040001020304050607080900010203040506
	(CryptoEnv: 00, Block: 0400, Data: 01020304050607080900010203040506)
Response:	0001
	(Result: true)

#### 1.5.22.6. MFP\_ReadValueBlock

Command:	[1B05][Byte: CryptoEnv][UInt16: Block]
Response:	[00][Bool: Result][UInt32: Value]
Example	
Command:	1B05000400
	(CryptoEnv: 00, Block: 0400)
Response:	00010000000
	(Result: true, Value: 0)



# 1.5.22.7. MFP\_WriteValueBlock

Command:	[1B06][Byte: CryptoEnv][UInt16: Block][UInt32: Value]
Response:	[00][Bool: Result]
Example	
Command:	1B060004000000000
	(CryptoEnv: 00, Block: 0400, Value: 00000000)
Response:	0001
	(Result: true)

# 1.5.22.8. MFP\_IncrementValueBlock

Command:	[1B07][Byte: CryptoEnv][UInt16: Block][UInt32: Value]
Response:	[00][Bool: Result]
Example	
Command:	1B0700040001000000
	(CryptoEnv: 00, Block: 0400, Value: 01000000)
Response:	0001
	(Result: true)

# ${\bf 1.5.22.9.}\ \ MFP\_DecrementValueBlock$

Command:	[1B08][Byte: CryptoEnv][UInt16: Block][UInt32: Value]
Response:	[00][Bool: Result]
Example	
Command:	1B0800040001000000
	(CryptoEnv: 00, Block: 0400, Value: 01000000)
Response:	0001
	(Result: true)

# 1.5.22.10. MFP\_CopyValueBlock

Command:	[1B09][Byte: CryptoEnv][UInt16: SourceBlock][UInt16: DestBlock]
Response:	[00][Bool: Result]
Example	
Command:	1B090004000500
	(CryptoEnv: 00, SourceBlock: 0400, DestBlock: 0500)
Response:	0001
	(Result: true)



#### 1.5.23. API ADC

#### 1.5.23.1. ADCInitChannel

Command:	[1C00][Byte: ADCChannel]
Response:	[00][Bool: Result]
Example	
Command:	1C0001
	(ADCChannel: 01)
Response:	0001
	(Result: true)

#### 1.5.23.2. ADCGetConversionValue

Command:	[1C01][Byte: ADCChannel]
Response:	[00][UInt16: Value]
Example	
Command:	1C0101
	(ADCChannel: 01)
Response:	003700
	(Value: 55)

### 1.5.24. API FELICA

#### 1.5.24.1. FeliCa\_TDX

Command:	[1D00][Byte Array(Var): TX][Byte: MaxRXByteCnt][Byte: MaximumResponseTime][Byte: NumberOfBlocks]
Response:	[00][Bool: Result][Byte Array(Var): RX]
Example	
Command:	1D00060600FFFF0000FFFF04
	(TX: 0600FFFF0000, MaxRXByteCnt: FF, MaximumResponseTime: FF, NumberOf-Blocks: 04)
Response:	000112120101010701450F16000120220427674EFF
	(Result: true, RX: 120101010701450F16000120220427674EFF)



# 1.5.24.2. FeliCa\_ReadWithoutEncryption

Command:	[1D01][variable number of UInt16: ServiceCodeList][variable number of UInt16: Block-List]
Response:	[00][Bool: Result][Byte Array(Var), 2 LB: Data]
Example	
Command:	1D01010B10010000
	(ServiceCodeList: 100B, BlockList: 0000)
Response:	000110000000000000000000000000000000000
	(Result: true, Data: 00000000000000000000000000000000000

# ${\bf 1.5.24.3.} \ \ \textbf{FeliCa\_WriteWithoutEncryption}$

Command:	[1D02][variable number of UInt16: ServiceCodeList][variable number of UInt16: Block-List][Byte Array(Var), 2 LB: Data]
Response:	[00][Bool: Result]
Example	
Command:	1D02010910010000100000000000000000000000
	(ServiceCodeList: 1009, BlockList: 0000, Data: 00000000000000000000000000000000000
Response:	0001
	(Result: true)

# 1.5.24.4. FeliCa\_RequestSystemCode

Command:	[1D03][Byte: MaxNumberOfSystemCodes]
Response:	[00][Bool: Result][variable number of UInt16: SystemCodeList]
Example	
Command:	1D0308
	(MaxNumberOfSystemCodes: 08)
Response:	000103030000FEA786
	(Result: true, SystemCodeList: 0003, FE00, 86A7)



# 1.5.24.5. FeliCa\_Poll

Command:	[1D04][UInt16: SystemCode]
Response:	[00][Bool: Result][Byte Array(8): IDm][Byte Array(8): PMm]
Example	
Command:	1D04FFFF
	(SystemCode: FFFF)
Response:	0001011603002D0CA50B03014B024F4993FF
	(Result: true, IDm: 011603002D0CA50B, PMm: 03014B024F4993FF)

# 1.5.24.6. FeliCa\_RequestService

Command:	[1D05][variable number of UInt16: ServiceCodeList]
Response:	[00][Bool: Result][variable number of UInt16: KeyVersionList]
Example	
Command:	1D05010000
	(ServiceCodeList: 0000)
Response:	0001010100
	(Result: true, KeyVersionList: 0001)

# 1.5.25. API SLE44XX

# 1.5.25.1. SLE44XX\_GetATR

Command:	[1F00][Byte: Channel]
Response:	[00][Bool: Result][Byte Array(4): ATR]
Example	
Command:	1F0028
	(Channel: 28)
Response:	0001FFFFFFF
	(Result: true, ATR: FFFFFFF)



# 1.5.25.2. SLE444X\_ReadMainMemory

Command:	[1F01][Byte: Channel][UInt16: Address][UInt16: ByteCnt]
Response:	[00][Bool: Result][Byte Array(Var), 2 LB: Data]
Example	
Command:	1F012800000100
	(Channel: 28, Address: 0000, ByteCnt: 0100)
Response:	00010100FF
	(Result: true, Data: FF)

# 1.5.25.3. SLE444X\_UpdateMainMemory

Command:	[1F02][Byte: Channel][UInt16: Address][Byte: Value]
Response:	[00][Bool: Result]
Example	
Command:	1F0228000000
	(Channel: 28, Address: 0000, Value: 00)
Response:	0001
	(Result: true)

#### 1.5.25.4. SLE444X\_ReadSecurityMemory

Command:	[1F03][Byte: Channel]
Response:	[00][Bool: Result][Byte Array(4): SecMemData]
Example	
Command:	1F0328
	(Channel: 28)
Response:	0001FFFFFFF
	(Result: true, SecMemData: FFFFFFF)

# 1.5.25.5. SLE444X\_UpdateSecurityMemory

Command:	[1F04][Byte: Channel][Byte: Address][Byte: SecMemData]
Response:	[00][Bool: Result]
Example	
Command:	1F042800FF
	(Channel: 28, Address: 00, SecMemData: FF)
Response:	0001
	(Result: true)



# 1.5.25.6. SLE444X\_ReadProtectionMemory

Command:	[1F05][Byte: Channel]
Response:	[00][Bool: Result][Byte Array(4): ProtMemData]
Example	
Command:	1F0528
	(Channel: 28)
Response:	0001FFFFFFF
	(Result: true, ProtMemData: FFFFFFF)

# 1.5.25.7. SLE444X\_WriteProtectionMemory

Command:	[1F06][Byte: Channel][Byte: Address][Byte: ProtMemData]
Response:	[00][Bool: Result]
Example	
Command:	1F062800FF
	(Channel: 28, Address: 00, ProtMemData: FF)
Response:	0001
	(Result: true)

#### 1.5.25.8. SLE444X\_CompareVerificationData

Command:	[1F07][Byte: Channel][Byte: Address][Byte: VerificationData]
Response:	[00][Bool: Result]
Example	
Command:	1F072800FF
	(Channel: 28, Address: 00, VerificationData: FF)
Response:	0001
	(Result: true)

#### 1.5.25.9. SLE44X8\_ReadMainMemory

Command:	[1F08][Byte: Channel][UInt16: Address][UInt16: ByteCnt]
Response:	[00][Bool: Result][Byte Array(Var), 2 LB: Data]
Example	
Command:	1F0828FD030300
	(Channel: 28, Address: FD03, ByteCnt: 0300)
Response:	00010300FFFFF
	(Result: true, Data: FFFFFF)



# ${\bf 1.5.25.10.~SLE44X8\_WriteErrorCounter}$

Command:	[1F09][Byte: Channel][UInt16: Address][Byte: ErrorCounter]
Response:	[00][Bool: Result]
Example	
Command:	1F0928FD03FE
	(Channel: 28, Address: FD03, ErrorCounter: FE)
Response:	0001
	(Result: true)

# 1.5.25.11. SLE44X8\_VerifyPSCByte

Command:	[1F0A][Byte: Channel][UInt16: Address][Byte: PSCByte]
Response:	[00][Bool: Result]
Example	
Command:	1F0A28FE03FF
	(Channel: 28, Address: FE03, PSCByte: FF)
Response:	0001
	(Result: true)

#### 1.5.25.12. SLE44X8\_UpdateMainMemory

Command:	[1F0B][Byte: Channel][UInt16: Address][Byte: Value]
Response:	[00][Bool: Result]
Example	
Command:	1F0B28FD03FF
	(Channel: 28, Address: FD03, Value: FF)
Response:	0001
	(Result: true)



# 1.5.26. API NTAG

# 1.5.26.1. NTAG\_Read

Command:	[2000][Byte: <i>Page</i> ]
Response:	[00][Bool: Result][Byte Array(16): Page]
Example	
Command:	200004
	(Page: 04)
Response:	000103B691028C537091016855016E78702E
	(Result: true, Page: 03B691028C537091016855016E78702E)

# 1.5.26.2. NTAG\_Write

Command:	[2001][Byte: Page][Byte Array(4): Data]
Response:	[00][Bool: Result]
Example	
Command:	2001040000000
	(Page: 04, Data: 00000000)
Response:	0001
	(Result: true)

#### 1.5.26.3. NTAG\_FastRead

Command:	[2002][Byte: StartPage][Byte: NumberOfPages]
Response:	[00][Bool: Result][Byte Array(Var): Data]
Example	
Command:	20020401
	(StartPage: 04, NumberOfPages: 01)
Response:	00010403B69102
	(Result: true, Data: 03B69102)



# 1.5.26.4. NTAG\_ReadCounter

Command:	[2003]
Response:	[00][Bool: Result][UInt32: CounterValue]
Example	
Command:	2003
Response:	000101000000
	(Result: true, CounterValue: 1)

# 1.5.26.5. NTAG\_ReadSig

Command:	[2004]
Response:	[00][Bool: Result][Byte Array(32): ECCSig]
Example	
Command:	2004
Response:	0001A9AC15AFB52080BA26A45B1DA442F363E31B41271AB12B3E6F67- 864615B05321
	(Result: true, ECCSig:
	A9AC15AFB52080BA26A45B1DA442F363E31B41271AB12B3E6F67864615B05321)

# 1.5.26.6. NTAG\_GetVersion

Command:	[2005]
Response:	[00][Bool: Result][Byte Array(8): Version]
Example	
Command:	2005
Response:	00010004040502011503
	(Result: true, Version: 0004040502011503)

#### 1.5.26.7. NTAG\_PwdAuth

Command:	[2006][Byte Array(4): Password][Byte Array(2): PwdAck]
Response:	[00][Bool: Result]
Example	
Command:	2006FFFFFF0000
	(Password: FFFFFFF, PwdAck: 0000)
Response:	0001
	(Result: true)



# 1.5.26.8. NTAG\_SectorSelect

Command:	[2007][Byte: Sector]
Response:	[00][Bool: Result]
Example	
Command:	200700
	(Sector: 00)
Response:	0001
	(Result: true)

# 1.5.27. API SRX

# 1.5.27.1. SRX\_ReadBlock

Command:	[2100][Byte: <i>Block</i> ]
Response:	[00][Bool: Result][Byte Array(4): Data]
Example	
Command:	210000
	(Block: 00)
Response:	00010000000
	(Result: true, Data: 00000000)

# 1.5.27.2. SRX\_WriteBlock

Command:	[2101][Byte: Block][Byte Array(4): Data]
Response:	[00][Bool: Result]
Example	
Command:	2101000000000
	(Block: 00, Data: 00000000)
Response:	0001
	(Result: true)



#### 1.5.28. API SAMAVX

#### 1.5.28.1. SAMAVx\_AuthenticateHost

Command:	[2200][Byte: CryptoEnv][Byte: KeyNo][Byte Array(Var): Key][Byte: KeyType]
Response:	[00][Bool: Result]
Example	
Command:	220000001000000000000000000000000000000
	(CryptoEnv: 00, KeyNo: 00, Key: 000000000000000000000000000000, KeyType: 00)
Response:	0001
	(Result: true)

# 1.5.28.2. SAMAVx\_GetKeyEntry

Command:	[2201][Byte: KeyNo]
Response:	[00][Bool: Result][Byte Array(13): TSAMAVxKeyEntryData]
Example	
Command:	220101
	(KeyNo: 01)
Response:	000100010200000000000FF0C00
	(Result: true, TSAMAVxKeyEntryData: 0001020000000000000FF0C00)

#### 1.5.29. API EM4102

### 1.5.29.1. EM4102\_GetTagInfo

Command:	[2300]
Response:	[00][UInt32: <i>TagInfo</i> ]
Example	
Command:	2300
Response:	0001000000
	(TagInfo: 1)



#### 1.5.30. API SPI

# 1.5.30.1. SPIInit

Command:	[2400][Byte: Mode][Byte: CPOL][Byte: CPHA][Byte: ClockRate][Byte: BitOrder]
Response:	[00][Bool: Result]
Example	
Command:	24000100000000
	(Mode: 01, CPOL: 00, CPHA: 00, ClockRate: 00, BitOrder: 00)
Response:	0001
	(Result: true)

#### 1.5.30.2. SPIDeInit

Command:	[2401]
Response:	[00]
Example	
Command:	2401
Response:	00

# 1.5.30.3. SPIMasterBeginTransfer

Command:	[2402]
Response:	[00]
Example	
Command:	2402
Response:	00

#### 1.5.30.4. SPIMasterEndTransfer

Command:	[2403]
Response:	[00]
Example	
Command:	2403
Response:	00



#### 1.5.30.5. SPITransmit

Command:	[2404][Byte Array(Var), 2 LB: TXData]
Response:	[00][Bool: Result]
Example	
Command:	2404010000
	(TXData: 00)
Response:	0001
	(Result: true)

#### 1.5.30.6. SPIReceive

Command:	[2405][UInt16: ByteCount]
Response:	[00][Bool: Result][Byte Array(Var), 2 LB: RXData]
Example	
Command:	24050100
	(ByteCount: 0100)
Response:	000101005A
	(Result: true, RXData: 5A)

#### 1.5.30.7. SPITransceive

Command:	[2406][Byte Array(Var), 2 LB: TXData]
Response:	[00][Bool: Result][Byte Array(Var), 2 LB: RXData]
Example	
Command:	2406010000
	(TXData: 00)
Response:	000101005A
	(Result: true, RXData: 5A)



#### 1.5.31. API BLE

# 1.5.31.1. BLEPresetConfig

Command:	[2500][Byte Array(17): BLEConfig]
Response:	[00][Bool: Result]
Example	
Command:	2500881300000A01A0000702020000D2040000
	(BLEConfig: 881300000A01A0000702020000D2040000)
Response:	0001
	(Result: true)

#### 1.5.31.2. BLEPresetUserData

Command:	[2501][Byte: ScanResp][Byte Array(Var): UserData]
Response:	[00][Bool: Result]
Example	
Command:	2501001E0201061AFF4C000215E2C56DB5DFFB48D2B060D0F5A71096- E00000000C3
	(ScanResp: 00, UserData:
	0201061AFF4C000215E2C56DB5DFFB48D2B060D0F5A71096E00000000C3)
Response:	0001
	(Result: true)

### 1.5.31.3. BLEInit

Command:	[2502][Byte: <i>Mode</i> ]
Response:	[00][Bool: Result]
Example	
Command:	250201
	(Mode: 01)
Response:	0001
	(Result: true)



#### 1.5.31.4. BLECheckEvent

Command:	[2503]
Response:	[00][Byte: <i>Event</i> ]
Example	
Command:	2503
Response:	0081000000
	(Event: BLE_EVENT_LE_GAP_SCAN_RESPONSE)

#### 1.5.31.5. BLEGetAddress

Command:	[2504]
Response:	[00][Bool: Result][Byte Array(6): DeviceAddress][Byte Array(6): RemoteAddress][Byte Array(1): RemoteType]
Example	
Command:	2504
Response:	000149D702570B009872F9F36D4601
	(Result: true, DeviceAddress: 49D702570B00, RemoteAddress: 9872F9F36D46, RemoteType: 01)

#### 1.5.31.6. BLEGetVersion

Command:	[2505]
Response:	[00][Bool: Result][Byte Array(16): HWVersion][Byte Array(12): BootString]
Example	
Command:	2505
Response:	000156312E30342C32382E30362E3230313702000400000018090000-0101
	(Result: true, HWVersion: 56312E30342C32382E30362E32303137, BootString: 020004000000180900000101)

#### 1.5.31.7. BLEGetEnvironment

Command:	[2506]
Response:	[00][Bool: <i>Result</i> ][Byte Array(1): <i>DeviceRole</i> ][Byte Array(1): <i>SecurityMode</i> ][Byte Array(1): <i>Rssi</i> ]
Example	
Command:	2506
Response:	0001000000
	(Result: true, DeviceRole: 00, SecurityMode: 00, Rssi: 00)



#### 1.5.31.8. BLEGetGattServerAttributeValue

Command:	[2507][UInt16: AttrHandle][Byte: MaxLen]
Response:	[00][Bool: Result][Byte Array(Var): Data]
Example	
Command:	2507120014
	(AttrHandle: 1200, MaxLen: 14)
Response:	0001104254312E3035454C2020202020202020
	(Result: true, Data: 4254312E3035454C2020202020202020)

#### 1.5.31.9. BLESetGattServerAttributeValue

Command:	[2508][UInt16: AttrHandle][UInt16: Offset][Byte Array(Var): Data]
Response:	[00][Bool: Result]
Example	
Command:	2508150000005000000000
	(AttrHandle: 1500, Offset: 0000, Data: 000000000)
Response:	0001
	(Result: true)

# 1.5.31.10. BLERequestRssi

Command:	[2509]
Response:	[00][Bool: Result]
Example	
Command:	2509
Response:	0001
	(Result: true)

# 1.5.31.11. BLERequestEndpointClose

Command:	[250A]
Response:	[00][Bool: Result]
Example	
Command:	250A
Response:	0001
	(Result: true)



#### 1.5.31.12. BLEGetGattServerCharacteristicStatus

Command:	[250B]
Response:	[00][Bool: Result][UInt16: AttrHandle][Byte: AttrStatusFlag][UInt16: AttrConfigFlag]
Example	
Command:	250B
Response:	0001000000000
	(Result: true, AttrHandle: 0, AttrStatusFlag: 0, AttrConfigFlag: 0)

#### 1.5.31.13. BLEFindGattServerAttribute

Command:	[250C][Byte Array(Var): UUID]
Response:	[00][Bool: Result][UInt16: AttrHandle]
Example	
Command:	250C02262A
	(UUID: 262A)
Response:	00011200
	(Result: true, AttrHandle: 18)

#### 1.5.31.14. BLEDiscover

Command:	[250D][Byte: DiscoverMode][UInt32: GattHandle][Byte Array(17): BLEUUID]
Response:	[00][Bool: Result]
Example	
Command:	250D00FFFF280010FA349B5F80000080001000001DB80000
	(DiscoverMode: 00, GattHandle: FFFF2800, BLEUUID: 10FA349B5F80000080001000001DB80000)
Response:	0001
	(Result: true)

# 1.5.31.15. BLECheckDiscoveredString

Command:	[250E][Byte: CheckMode][Byte Array(Var): CompareString]
Response:	[00][Bool: Result]
Example	
Command:	250E0006454C41544543
	(CheckMode: 00, CompareString: 454C41544543)
Response:	0001
	(Result: true)



#### 1.5.31.16. BLEConnectToDevice

Command:	[250F][Byte Array(6): Address][Byte: AddressType]
Response:	[00][Bool: Result]
Example	
Command:	250F9872F9F36D4601
	(Address: 9872F9F36D46, AddressType: 01)
Response:	0001
	(Result: true)

#### 1.5.31.17. BLEDisconnectFromDevice

Command:	[2510]
Response:	[00][Bool: Result]
Example	
Command:	2510
Response:	0001
	(Result: true)

#### 1.5.31.18. BLEGattGetAttribute

Command:	[2511]	
Response:	00][Bool: Result][Byte Array(17): BLEUUID][UInt32: GattHandle]	
Example		
Command:	2511	
Response:	000100574E340042312E30382F4E4346332E3100000000	
	(Result: true, BLEUUID: 00574E340042312E30382F4E4346332E31, GattHandle: 0)	

#### 1.5.31.19. BLEGattGetValue

Command:	[2512][Byte: ReadMode][UInt32: GattHandle][Byte Array(17): BLEUUID][Byte	e: MaxLen]
Response:	[00][Bool: Result][Byte: AttrOpcode][Byte Array(Var): Data]	
Example		
Command:	2512002A00000010FA349B5F80000080001000001DB8000010	
	(ReadMode: 00, GattHandle: 2A000000, 10FA349B5F80000080001000001DB80000, MaxLen: 10)	BLEUUID:
Response:	00010B10CD7CBE4FB6264731587303F12FB369FE	
	(Result: true, AttrOpcode: gatt_read_response, CD7CBE4FB6264731587303F12FB369FE)	Data:



#### 1.5.31.20. BLEGattSetValue

Command:	[2513][Byte: WriteMode][UInt32: GattHandle][UInt16: Offset][Byte Array(Var): Data]	
Response:	[00][Bool: Result]	
Example		
Command:	2513002C000000000F0102030405060708090A0B0C0D0E0F	
	(WriteMode: 00, GattHandle: 2C000000, Offset: 0000, Data: 0102030405060708090A0B0C0D0E0F)	
Response:	0001	
	(Result: true)	

#### 1.5.31.21. BLECommand

Command:	[2514][Byte: ConnMode][UInt32: Parameter]
Response:	[00][UInt16: Status]
Example	
Command:	251400FA000000
	(ConnMode: 00, Parameter: FA000000)
Response:	0001000000
	(Status: 1)

# 1.5.31.22. BLESecurity

Command:	[2515][Byte: SMMode][UInt32: Flag1][UInt32: Flag2]
Response:	[00][Bool: Result]
Example	
Command:	25150B40E201000000000
	(SMMode: 0B, Flag1: 40E20100, Flag2: 00000000)
Response:	0001
	(Result: true)



# 1.5.31.23. BLESecuritySetOob

Command:	[2516][Byte: SMOOBMode][Byte Array(Var): OobData]
Response:	[00][Bool: Result]
Example	
Command:	25170010000102030405060708090A0B0C0D0E0F
	(SMOOBMode: 00, OobData: 000102030405060708090A0B0C0D0E0F)
Response:	0001
	(Result: true)

# 1.5.31.24. BLESecurityUseScOob

Command:	[2517][Byte: Enable][Byte: MaxLength]
Response:	[00][Bool: Result][Byte Array(Var): OobData]
Example	
Command:	25180120
	(Enable: 01, MaxLength: 20)
Response:	000120209678F5BF6EE4EA4F49FA2D22163C57B9A87F40D20183C187- 7A93B010A6F2F5
	(Result: true, OobData:
	209678F5BF6EE4EA4F49FA2D22163C57B9A87F40D20183C1877A93B010A6F2F5)

# 1.5.31.25. BLESetStreamingUUID

Command:	[2518][Byte Array(Var): ServiceUUID][Byte Array(Var): CharacUUID]
Response:	[00][Bool: Result]
Example	
Command:	2518108EDFAE3D9BCD0E887442124104C0445A1052C79E169D4822AA- 434C0A2FDF9EC243
	(ServiceUUID: 8EDFAE3D9BCD0E887442124104C0445A, CharacUUID: 52C79E169D4822AA434C0A2FDF9EC243)
Response:	0001
	(Result: true)



# 1.5.31.26. BLESetStreamingMode

Command:	[2519][Byte: ConnMode][Byte: GattMode][Byte: TransferMode]
Response:	[00][Bool: Result]
Example	
Command:	2519010000
	(ConnMode: 01, GattMode: 00, TransferMode: 00)
Response:	0001
	(Result: true)

#### 1.5.31.27. BLEGetDiscoveredData

Command:	[251A][Byte: MaxLen]
Response:	[00][Bool: Result][Byte Array(Var): Data]
Example	
Command:	251A40
	(MaxLen: 40)
Response:	00011F02011A03036FFD17166FFD2EACD0A563838173CB517FFD702A- C8D6B68B7AAD
	(Result: true, Data:
	02011A03036FFD17166FFD2EACD0A563838173CB517FFD702AC8D6B68B7AAD)

#### 1.5.32. API I2CCARD

# 1.5.32.1. I2CCard\_Read

Command:	[2800][Byte: Channel][UInt16: Addr][Byte: ByteCnt]
Response:	[00][Bool: Result][Byte Array(Var): Data]
Example	
Command:	28002800000A
	(Channel: 28, Addr: 0000, ByteCnt: 0A)
Response:	00010A001122849A2789DFD54342
	(Result: true, Data: 001122849A2789DFD543)



# 1.5.32.2. I2CCard\_Write

Command:	[2801][Byte: Channel][UInt16: Addr][Byte Array(Var): Data]
Response:	[00][Bool: Result]
Example	
Command:	28012800000401020304
	(Channel: 28, Addr: 0000, Data: 01020304)
Response:	0001
	(Result: true)

# 1.5.33. API TOPAZ

# 1.5.33.1. TopazRID

Command:	[2900]
Response:	[00][Bool: Result][Byte: HR0][Byte: HR1][Byte Array(4): UID]
Example	
Command:	2900
Response:	0001124CA9747300
	(Result: true, HR0: 18, HR1: 76, UID: A9747300)

#### 1.5.33.2. TopazReadByte

Command:	[2901][Byte Array(4): <i>UID</i> ][Byte: <i>ADD</i> ]
Response:	[00][Bool: Result][Byte: Data]
Example	
Command:	2901A97473000A
	(UID: A9747300, ADD: 0A)
Response:	000133
	(Result: true, Data: 51)



# 1.5.33.3. TopazReadAllBlocks

Command:	[2902][Byte Array(4): <i>UID</i> ]
Response:	[00][Bool: Result][Byte: HR0][Byte: HR1][Byte Array(120): Data]
Example	
Command:	2902A9747300
	(UID: A9747300)
Response:	0001124CA974730000102500E11033000103F230330203F002030319- D1011555036A7562617465632E65752F6E66632D746167732F2D7461- 67732F00AB00110000000000000000000000000000000
	(Result: true, HR0: 18, HR1: 76, Data:
	A974730000102500E11033000103F230330203F002030319D101155-5036A7562617465632E65752F6E66632D746167732F2D746167732F-00AB00110000000000000000000000000000000

# ${\bf 1.5.33.4.}\ \ {\bf TopazWriteByteWithErase}$

Command:	[2903][Byte Array(4): <i>UID</i> ][Byte: <i>ADD</i> ][Byte: <i>Data</i> ]
Response:	[00][Bool: Result]
Example	
Command:	2903A97473000A11
	(UID: A9747300, ADD: 0A, Data: 11)
Response:	0001
	(Result: true)

# 1.5.33.5. TopazWriteByteNoErase

Command:	[2904][Byte Array(4): <i>UID</i> ][Byte: <i>ADD</i> ][Byte: <i>Data</i> ]		
Response:	[00][Bool: Result]		
Example			
Command:	2904A97473000A22		
	(UID: A9747300, ADD: 0A, Data: 22)		
Response:	0001		
	(Result: true)		



# 1.5.34. API CTS

# 1.5.34.1. CTS\_ReadBlock

Command:	[2A00][Byte: <i>Block</i> ]		
Response:	[00][Bool: Result][Byte Array(2): Data]		
Example			
Command:	2A0000		
	(Block: 00)		
Response:	00016002		
	(Result: true, Data: 6002)		

# 1.5.34.2. CTS\_WriteBlock

Command:	[2A01][Byte: Block][Byte Array(2): Data]		
Response:	[00][Bool: Result]		
Example			
Command:	2A01000000		
	(Block: 00, Data: 0000)		
Response:	0001		
	(Result: true)		

# 1.5.34.3. CTS\_UpdateBlock

Command:	[2A02][Byte: Block][Byte Array(2): Data]	
Response:	[00][Bool: Result]	
Example		
Command:	2A02000000	
	(Block: 00, Data: 0000)	
Response:	0001	
	(Result: true)	



#### 1.5.35. API EM4305

# 1.5.35.1. EM4305\_Begin

Command:	[2F00]
Response:	[00]
Example	
Command:	2F00
Response:	00

#### 1.5.35.2. EM4305\_Read

Command:	[2F01][Byte: Address]	
Response:	[00][Bool: Result][Byte Array(4): Data]	
Example		
Command:	2F0100	
	(Address: 00)	
Response:	000100000001	
	(Result: true, Data: 00000001)	

# 1.5.35.3. EM4305\_Write

Command:	[2F02][Byte: Address][Byte Array(4): Data]		
Response:	[00][Bool: Result]		
Example			
Command:	2F0205003A36BA		
	(Address: 05, Data: 003A36BA)		
Response:	0001		
	(Result: true)		

# 1.5.35.4. EM4305\_Login

Command:	[2F03][Byte Array(4): Password]		
Response:	[00][Bool: Result]		
Example			
Command:	2F030000000		
	(Password: 00000000)		
Response:	0001		
	(Result: true)		



# 1.5.35.5. EM4305\_Protect

Command:	[2F04][Byte Array(4): <i>Data</i> ]
Response:	[00][Bool: Result]
Example	
Command:	2F040000000
	(Data: 00000000)
Response:	0001
	(Result: true)

# 1.5.35.6. EM4305\_Disable

Command:	[2F05]
Response:	[00][Bool: Result]
Example	
Command:	2F05
Response:	0001
	(Result: true)



# A. How to Set Specific Tags in Simple Protocol

The firmware function SetTagTypes() enables you to set specific transponder types to search for these types only. To set a specific transponder type, you need the definition for this type, which can be found in the table below.

### A.1. Example with Enabling Only MIFARE

For a MIFARE transponder, the definition is as following:

With the TAGMASK definition (1 « (Tagtype & 0x1F)) we can calculate:

```
1 << (0x80 \& 0x1F)
```

Result from (0x80 & 0x1F) is 0, so we shift 1 to the left for 0 places and we get 00000001 in binary, which is 00000001h.

Now we take this result and put it in SetTagTypes command from Simple Protocol.

```
[0502] [UInt32: TagTypesLF] [UInt32: TagTypesHF]
```

In this command it is stated that HFTagTypes is UInt32. Simple Protocol works with little endian, so instead of 00000001h it needs to be 01000000h.

Therefore to enable only Mifare following command should be sent (without the spaces):

0502 0000000000 01000000

#### where

0502 - command code

00000000 - means that none low frequency technology is enabled

01000000 - means that only Mifare from high frequency technologies is enabled

# A.2. Example with Felica and HID Prox Only

Felica and HID Prox have the following definitions:

HFTAG_FELICA	0x85
LFTAG_HIDPROX	0x49

High Frequency:



With the TAGMASK definition (1 « (Tagtype & 0x1F)) we can calculate:

```
1 << (0x85 & 0x1F)
```

Result from (0x85 & 0x1F) is 5, so we shift 1 to the left for 5 places and we get 00100000 in binary, which is 00000020h.

HFTagTypes [UInt32] in little endian is now 20000000.

Low Frequency:

With the TAGMASK definition (1  $\ll$  (Tagtype & 0x1F)) we can calculate:

```
1 << (0x49 \& 0x1F)
```

Result from (0x85 & 0x1F) is 9, so we shift 1 to the left for 9 places and we get 0000001000000000 in binary, which is 00000200h.

LFTagTypes [UInt32] in little endian is now 00020000.

Correct command is (without the spaces):

0502 00020000 20000000

The following definitions can also be found in twn4.sys.h, which is part of the TWN4 Development Pack.



Technology	Definition	Tagtype
	LFTAG_EM4102	0x40
	LFTAG_HITAG1S	0x41
	LFTAG_HITAG2	0x42
	LFTAG_EM4150	0x43
	LFTAG_AT5555	0x44
	LFTAG_ISOFDX	0x45
	LFTAG_EM4026	0x46
	LFTAG_HITAGU	0x47
	LFTAG_EM4305	0x48
	LFTAG_HIDPROX	0x49
	LFTAG_TIRIS	0x4A
	LFTAG_COTAG	0x4B
	LFTAG_IOPROX	0x4C
LF	LFTAG_INDITAG	0x4D
	LFTAG_HONEYTAG	0x4E
	LFTAG_AWID	0x4F
	LFTAG_GPROX	0x50
	LFTAG_PYRAMID	0x51
	LFTAG_KERI	0x52
	LFTAG_DEISTER	0x53
	LFTAG_CARDAX	0x54
	LFTAG_NEDAP	0x55
	LFTAG_PAC	0x56
	LFTAG_IDTECK	0x57
	LFTAG_ULTRAPROX	0x58
	LFTAG_ICT	0x59
	LFTAG_ISONAS	0x5A
	HFTAG_MIFARE	0x80
	HFTAG_ISO14443B	0x81
	HFTAG_ISO15693	0x82
	HFTAG_LEGIC	0x83
	HFTAG_HIDICLASS	0x84
HF	HFTAG_FELICA	0x85
	HFTAG_SRX	0x86
	HFTAG_NFCP2P	0x87
	HFTAG_BLE	0x88
	HFTAG_TOPAZ	0x89
	HFTAG_CTS	0x8A
	HFTAG_BLELC	0x8B



# **B.** Disclaimer

ELATEC reserves the right to change any information or data in this document without prior notice. The distribution and the update of this document is not controlled. ELATEC declines all responsibility for the use of product with any other specifications but the ones mentioned above. Any additional requirement for a specific custom application has to be validated by the customer himself at his own responsibility. Where application information is given, it is only advisory and does not form part of the specification.

All referenced brands, product names, service names and trademarks mentioned in this document are the property of their respective owners.