Institute for System Programming of the Russian Academy of Sciences

MicroTESK User Guide (UNDER DEVELOPMENT)

Contents

1	Inst	tallation	•				
	1.1	System Requirements	,				
	1.2	Running MicroTESK					
	1.3	Command-Line Options					
	1.4	Overview					
2	Test Templates						
	2.1	Introduction					
	2.2	Test Template Structure					
	2.3	Reusing Test Templates					
	2.4	Test Template Settings					
3	Appendixes						
	3.1	References	1				
		Bibliography	1				

Chapter 1

Installation

1.1 System Requirements

MicroTESK is a set of Java-based utilities that are run from the command line. It can be used on *Windows*, *Linux* and *OS X* machines that have *JDK 1.7 or later* installed. To build MicroTESK from source code or to build the generated Java models, *Apache Ant version 1.8 or later* is required. To generate test data based on constraints, MicroTESK needs the *Microsoft Research Z3* or *CVC4* solver that can work under the corresponding operating system.

1.2 Running MicroTESK

To generate a Java model of a microprocessor from its nML specification, a user needs to run the compile.sh script (Unix, Linux, OS X) or the compile.bat script (Windows). For example, the following command generates a model for the miniMIPS specification:

sh bin/compile.sh arch/minimips/model/minimips.nml

NOTE: Models for all demo specifications are already built and included in the MicroTESK distribution package. So a user can start working with MicroTESK from generating test programs for these models.

To generate a test program, a user needs to use the generate.sh script (Unix, Linux, OS X) or the generate.bat script (Windows). The scripts require the following parameters:

1. model name

- 2. test template file
- 3. target test program source code file

For example, the command below runs the euclid.rb test template for the miniMIPS model generated by the command from the previous example and saves the generated test program to an assembler file. The file name is based on values of the –code-file-prefix and –code-file-extension options.

```
sh bin/generate.sh minimips arch/minimips/templates/euclid.rb
```

To specify whether Z3 or CVC4 should be used to solve constraints, a user needs to specify the -s or -solver command-line option as z3 or cvc4 respectively. By default, Z3 will be used. Here is an example:

```
sh bin/generate.sh -s cvc4 minimips arch/minimips/templates/constraint.rb
```

More information on command-line options can be found on the Command-Line Options section.

1.3 Command-Line Options

MicroTESK works in two modes: specification translation and test generation, which are enabled with the –translate (used by default) and –generate keys correspondingly. In addition, the –help key prints information on the command-line format.

The –translate and –generate keys are inserted into the commandline by compile.sh/compile.bat and generate.sh/generate.bat scripts correspondingly. Other options should be specified explicitly to customize the behavior of MicroTESK. Here is the list of options:

Full name	Short	Description	Requires
	name		
-help	-h	Shows help message	
-verbose	-V	Enables printing diag-	
		nostic messages	
-translate	-t	Translates formal speci-	
		fications	
-generate	-g	Generates test pro-	
		grams	
-output-dir <arg></arg>	-od	Sets where to place gen-	
		erated files	
-include <arg></arg>	-i	Sets include files direc-	-translate
		tories	
-extension-dir	-ed	Sets directory that	-translate
<arg></arg>		stores user-defined Java	
l G.		code	
-random-seed	-rs	Sets seed for randomizer	-generate
$<$ arg $>$			
-solver <arg></arg>	-S	Sets constraint solver	-generate
		engine to be used	0
-branch-exec-limit	-bel	Sets the limit on control	-generate
<arg></arg>		transfers to detect end-	0
l and		less loops	
-solver-debug	-sd	Enables debug mode for	-generate
		SMT solvers	0
-tarmac-log	-tl	Saves simulator log in	-generate
100		Tarmac format	001101000
-self-checks	-sc	Inserts self-checking	generate
		code into test programs	Serierade
-arch-dirs <arg></arg>	-ad	Home directories for	-generate
		tested architectures	00-1-01-00-0
-rate-limit <arg></arg>	-rl	Generation rate limit,	-generate
1000 1111110 (018)		causes error when bro-	001101000
		ken	
-code-file-	-cfe	The output file exten-	generate
extension <arg></arg>		sion	001101000
-code-file-prefix	-cfp	The output file prefix	generate
code me prenx carg>		(file names are as fol-	001101000
\		lows prefix xxxx.ext,	
		where xxxx is a 4-digit	
		decimal number)	
-data-file-	-dfe	The data file extension	-generate
extension <arg></arg>		The data ine extension	801101000
data file profes	dfn	The data file profes	

1.4 Overview

Chapter 2

Test Templates

2.1 Introduction

MicroTESK generates test programs on the basis of test templates that provide an abstract description of scenarios to be reproduced by the generated programs. Test templates are created using the test template description language. It is a Ruby-based domain-specific language that provides facilities to describe test cases using symbolic names (that refer to a set of data satisfying certain conditions) instead of concrete input data and to manage the structure of the generated test programs. The language is implemented as a library that includes functionality for describing test templates and for further processing these test templates to produce a test program. MicroTESK uses the JRuby interpreter to process Ruby files. This allows Ruby libraries to interact with other components of MicroTESK written in Java.

2.2 Test Template Structure

A test template is implemented as a class inherited from the Template library class that provides access to all features of the library. Information on the location of the Template class is stored in the TEM-PLATE environment variable. So, the definition of a test template class looks like this:

```
require ENV['TEMPLATE']

class MyTemplate < Template
```

Test template classes should contain implementations of the following methods:

- 1. initialize (optional) specifies settings for the given test template;
- 2. pre (optional) specifies the initialization code for the test program;
- 3. post (optional) specifies the finalization code for the test program;
- 4. run specifies the main code of the test program (test cases).

The definitions of optional methods can be skipped. In this case, the default implementations provided by the parent class will be used. The default implementation of the initialize method initializes the settings with default values. The default implementations of the pre and post methods do nothing.

The full interface of a test template looks as follows:

```
require ENV['TEMPLATE']

class MyTemplate < Template

def initialize
    super
    # Initialize settings here
end

def pre
    # Place your initialization code here
end

def post
    # Place your finalization code here
end

def run
    # Place your test problem description here
end

end
```

2.3 Reusing Test Templates

It is possible to reuse code of existing test templates in other test templates. To do this, you need to subclass the template you want to reuse instead of the Template class. For example, the MyTemplate class below reuses code from the MyPrepost class that provides initialization and finalization code for similar test templates.

```
require ENV['TEMPLATE']
require_relative 'MyPrepost'

class MyTemplate < MyPrepost</pre>
```

```
def run
...
end
end
```

2.4 Test Template Settings

Test templates use the following settings:

- 1. Starting characters for single-line comments in the test program;
- 2. Starting characters for multi-line comments in the test program;
- 3. Terminating characters for multi-line comments in the test program;
- 4. Indentation token;
- 5. Token used in separator lines.

Here is how these settings are initialized with default values in the Template class:

```
@sl_comment_starts_with = "//"
@ml_comment_starts_with = "/*"
@ml_comment_ends_with = "*/"

@indent_token = "\t"
@separator_token = "="
```

The settings can be overridden in the initialize method of a test template. For example:

```
class MyTemplate < Template

def initialize
    super
    @sl_comment_starts_with = ";"
    @ml_comment_starts_with = "/="
    @ml_comment_ends_with = "=/"

    @indent_token = "____"
    @separator_token = "*"
    end
    ...
end
```

Chapter 3 Appendixes

3.1 References

Bibliography

[1] M. Freericks. *The nML Machine Description Formalism*. Technical Report TR SM-IMP/DIST/08, TU Berlin CS Department, 1993.