Sensitivity Calculations

Mohamed Kamal Abd Elrahman 6 October, Giza, Egypt

October 24, 2019

Sensitivities are used as measures of robustness for engineering systems. In many applications, one is interested about the system performance under small variations of a set of design parameters. In inverse device design, sensitivities guides the search within the space spanned by a set of design parameters.

Problem Formulation

Assuming **G** is a vector of design merits $(G_1[\mathbf{x}], G_2[\mathbf{x}], \dots, G_n[\mathbf{x}])$, where each component is a scaler function of m design parameters (x_1, x_2, \dots, x_m) . The goal is to find the sensitivity of the design merit G_i with respect to the design parameter x_j :

$$S_{ij} = \frac{dG_i}{dx_i} \tag{1}$$

The Jacobian S will be an $n \times m$ matrix, which maps m input parameters to n output merits.

Numerical Differentiation

Finite Difference Method

Complex Step Method

Automatic Differentiation

Automatic Forward-Mode Differentiation

Automatic Reverse-Mode Differentiation