

VR2CTool Software (beta)

Description

VR2CTool is a software utility that is provided in order to facilitate access to a VR2C connected to a PC communication port.

Note: Alternatively, any serial terminal program (Hyper Terminal...) can be used to send/receive ASCII commands to the VR2C.


System Requirements and Installation

VR2CTool requires Microsoft .NET framework 3.5 to be installed on the PC.

The VR2C CD contains a zipped VR2CTool installation archive. Unzip this archive into the desired working directory on your PC.

Usage

Open the VR2CTool.exe file that was extracted during the installation process. Use the two left drop down boxes in the Main Window to select the desired serial COM port and baud rate with which to access the VR2C. Click the “Connect” button to initialize the port, switch any connected devices to the selected baud rate and populate the VR2C serial number drop down box which appears on the right.



VR2CTool - Main Window