Install and Run Manual

for the

MYSTRAN General Purpose Finite Element Structural Analysis Computer Program

(Open Source Version)

Dr. Bill Case - Original Author

Subsequent User Manual Authors:
Brian Esp
Zach Lerner
Victor Kemp
Steve Doyle
Bruno Paschoalinoto



www.mystran.com

(September 2025)
Most consistent with MYSTRAN program version 17.0

Table of Contents

1	QUICK START GUIDE	1			
2	COMMAND WINDOW MESSAGES	2			
3	MYSTRAN FILES	4			
3.1	F06 text output file	4			
3.2	F04 text output file	4			
3.3	ERR text output file	4			
3.4	BUG text output file	4			
3.5	SEQ text output file	4			
3.6	SPC text output file	4			
3.7	ANS text output file	5			
3.8	PCH text output file	5			
3.9	L1A text output file	5			
3.10	NEU text output file	5			
3.11	Lij binary output files	5			
3.12	F2j binary output files	5			
4	MODIFYING THE QUICK START SETUP	6			
4.1	Changing directories where MYSTRAN executable resides				
4.1. 4.1.					
4.2 4.2 4.2 4.2 4.2	Changing the default extension for input files	7 7 8			
5	MYSTRAN MESSAGES	8			
5.1	Error messages				
5.2	Warning messages				

5.3	Info	rmation messages	9
6	APF	PENDIX A: DESCRIPTION OF LIJ AND F2J FILES ERRO	R! BOOKMARK NOT DEFINED.
6.1	Lij F	Files	Error! Bookmark not defined.
6.1.	1	L1B: Grid Data	Error! Bookmark not defined.
6.1.	2	L1C: Degree of freedom tables	.Error! Bookmark not defined.
6.1.	3	L1E: G-set loads	
6.1.	4	L1L: G-set stiffness matrix	
6.1.	5	L1R: G-set mass matrix	
6.1.	6	L2A: GMN constraint matrix	
6.1.	7	L2H: L-set loads	
6.1.	8	L2G: A-set stiffness matrix	
6.1.		L2I: L-set mass matrix	
6.1.		L2J: HMN constraint matrix	
6.1.		L3A: UL displacement matrix	
6.1.	12	L5A: UG displacement matrix	Error! Bookmark not defined.
6.2	F2j	Files	Error! Bookmark not defined.
6.2.	1	F21: Element thermal and pressure load matrices	Error! Bookmark not defined.
6.2.	2	F22: Element mass matrices	.Error! Bookmark not defined.
6.2.	3	F23: Element stiffness matrices	
6.2.	4	F24: Element stress recovery matrices	.Error! Bookmark not defined.
6.2.	5	F25: Element displacement, UE, and total load, PE, matrices	.Error! Bookmark not defined.

1 Quick Start Guide

Listed below are 3 options for running MYSTRAN. The first is the easiest and quickest way to get MYSTRAN to run. The third option is the most flexible.

OPTION 1 - SIMPLEST

Conditions:

MYSTRAN.exe and the input file (*filename.ext*) exist in the same directory Set a command prompt to the directory where MYSTRAN.exe and the input file exist.

Run

Command line (general input files including BDF and DAT files):

mystran filename.ext

Command line (allowed if input file extension is DAT)

mystran filename

Output:

The output files will be in the directory where mystran.exe and input file are located.

OPTION 2 - A LITTLE MORE FLEXIBLE

Conditions:

MYSTRAN.exe need not be in the same directory as the input file. Say it is in generic path Anypath1.

The command prompt can be set to any directory.

The input file exists in a generic path such as "C:\Anypath2".

Run:

Command line (general input files including BDF and DAT files):

"C:\Anypath1\mystran.exe" C:\Anypath2\filename.ext

If the input file extension is DAT. It need not be entered on the command line

This could also be run from a batch file, say MYSTRAN.bat, the 1 line of which is shown below:

"C:\Anypath1\mystran.exe" %1

Command line for running the MYSTRAN.bat file:

MYSTRAN filename.ext

Note: %1 is a wildcard in the bat file and is replaced by *filename.ext*. when the command is executed (if not entered MYSTRAN will prompt for it). If the batch file is executed from a folder different then where the input file exists then *filename.ext* must contain the relative path to the input file (ot the path must be in the bat file). Note: quote marks, above, are only needed if C:\Anypath1 contains blank spaces (e.g. C:\Anypath 1)

Output:

The output files will be in the same directory as the input.

OPTION 3 - MOST FLEXIBLE: ENVIRONMENT VARIABLES AND INI FILE

Section 4 has the details of this option but a few words about it here are in order. In Windows, the user can set up an environment variable called MYSTRAN_directory which gives the location in which MYSTRAN.exe is located. Then, using the MYSTRAN initialization file (MYSTRAN.INI), options such as changing the default extension (from the default dat) to something like bdf could be done. The INI file can also be used to accomplish several other tasks as described in Section 4..

Conditions:

MYSTRAN.exe and the input file can be anywhere. No bat file is needed.

Run:

Command line (file extension not needed if it is dat or is set to something else like bdf in the INI file):

MYSTRAN filename

Note that if the input is not in the same folder as the one in which the MYSTRAN command was executed then *filename* must contain the full path as well

Output:

The output will be in the same folder as the input.

2 Command window messages

When you ran the example problem in the command window (or terminal) you should have seen messages such as:

- >> MYSTRAN BEGIN:
- >> LINK i BEGIN

:

>> LINK i END

>> MYSTRAN END:

with several lines in between indicating the progress as MYSTRAN solves your problem. The MYSTRAN program is divided into several major subroutines (called LINK's) that solve the problem. Below is a list of these LINK's and what they do:

LINK0:

- o Read input data deck and check for errors and possible restart
- o Process grid and coordinate system input data
- o Process Case Control output requests
- Forms degree of freedom (DOF) tables
- Process concentrated mass input data
- Calculates rigid body mass properties (Grid Point Weight Generator)
- Process temperature and pressure load input data intp arrays needed for element load calculations

LINK1:

- o Process MPC's and rigid elements into sparse G-set1 array RMG
- Process all applied forces (including grid forces and moments, gravity, pressure, thermal, centrifugal, scalar) into sparse G-set load array PG
- Formulate the G-set sparse stiffness and mass arrays KGG and MGG
- o Formulate the G-set sparse differential stiffness array KGGD

LINK2:

Reduce the G-set stiffness, mass, load and constraint matrices to the L-set

¹ See Section 3.6 of the MYSTRAN Users Reference manual for a discussion of displacement set notation (which is the same as, or a subset of, that used in the NASTRAN program)

- LINK3 (for statics problems only):
 - Solve for the L-set displacements
- LINK4 (for eigenvalue problems only):
 - o Solve for the L-set eigenvalues and eigenvectors
- ❖ LINK5:
 - o Build the A-set displacements back up to the G-set through use of the constraint matrices
- ❖ LINK6 (for Craig-Bampton model generation only):
 - o Builds a Craig-Bampton model from the input physical model
- LINK9:
 - o Use the G-set displacements from LINK5 to solve for the outputs requested in Case Control.

If the job executes without error the last message from MYSTRAN (after >>>> LINK 9 END) is:

```
>> MYSTRAN END : 1/19/2006 at 15: 5: 3.8. The output file is:
    filename.F06
MYSTRAN terminated normally. Total CPU time = 1.56E-01 seconds
```

where filename is the name of the input file

3 MYSTRAN files

MYSTRAN produces several output files besides the F06 file (which contains the output of the answers to the problem). If *filename*.dat is the input file name, the output files are all *filename.ext* where *ext* is the extension of the output file. Each of the output files is discussed below under the heading of the extension for that file.

3.1 F06 text output file

The F06 output file has the answers for the problem submitted to MYSTRAN. It is a text file that can contain an echo of the input, messages that MYSTRAN outputs (warning, fatal error and information messages) as well as the outputs that were requested in Case Control. Appendix A of the MYSTRAN Users Reference Manual shows the F06 output file for example problem: 1 EXAMPLE1.F06).

3.2 F04 text output file

The F04, or log, output file can contain a list of the subroutines run along with the subroutine begin and end times. This text file is only produced if explicitly requested. That request must be made using the MYSTRAN initialization file discussed in a later section.

3.3 ERR text output file

A list of all warning and fatal error messages is printed in the F06 file as discussed above. However, since warning messages may be suppressed in the F06 file via the Bulk Data PARAM SUPMSG entry, a separate list of all warning and error messages is put into the ERR text file as well. This file only contains the warning and fatal error messages.

3.4 BUG text output file

If element debug information is requested in Case Control via the ELDATA command, a text file with extension BUG is created. The contents of that file are enumerated in the MYSTRAN Users Reference Manual under the Case Control ELDATA command discussion.

3.5 SEQ text output file

If Bulk data PARAM GRIDSEQ is set to BANDIT, then the SEQGP card images created by the automatic grid sequencer can be output to this file (see Bulk data PARAM entry for parameter GRIDSEQ).

3.6 SPC text output file

If Bulk data PARAM AUTOSPC = Y, then a file containing the SPC1 Bulk Data card images of the SPC's for the AUTOSPC'd DOF can be obtained by using a Bulk Data PARAM entry with a parameter name of PCHSPC1 whose value is Y.

3.7 ANS text output file

This file is generally only useful by the author in the checkout of test problem answers but it is described here for the sake of completeness. It contains all of the answers generated in LINK9, the same as the F06 text file, but none of the F06 info written prior to LINK9. It is only generated if a Bulk Data DEBUG entry is present (see User's Reference Manual for a list of all DEBUG entries).

3.8 PCH text output file

The PCH text file can contain some of the outputs in MYSTRAN (see section 6.3 of the MYSTRAN User's Reference Manual for details of which outputs are allowed)

3.9 L1A text output file

The L1A text file, as well as the Lij binary files (discussed below), are used to communicate data between the LINK's. The L1A file contains data needed to read the binary Lij files. Generally these files are deleted when MYSTRAN completes its execution, but they may be saved via the MYSTRAN initialization file, discussed in a later section

3.10 NEU text output file

The NEU file is created if there is a Bulk Data PARAM entry for parameter POST with a value of -1. This file is used by FEMAP for the post-processing of outputs (displacements, forces, stresses, etc) from MYSTRAN.

3.11 Lij binary output files

In addition to the above mentioned text files that contain output data, MYSTRAN also produces some files that are used to communicate data between the several LINK's of the program. These files all have an extension of three characters length beginning with L followed by a number and a letter (e.g. L2A). The contents of these files, and the details of the way data is written to them, are explained in Appendix A of this manual. Generally these files are deleted when MYSTRAN completes its execution, but they may be saved via the MYSTRAN initialization file, discussed in a later section.

3.12 F2j binary output files

The Case Control ELDATA entry can request output of several items to unformatted binary files in addition to printing of these items to the BUG file. See Appendix A to this manual for the fortran code to read these files.

4 Modifying the quick start setup

The quick start setup described in Section 1 was the easiest, but perhaps not the most convenient, way to run MYSTRAN. This section discusses moving the MYSTRAN.EXE program to some other directory. It also discusses the MYSTRAN initialization file which can be used to change from some of the default values built into MYSTRAN.

4.1 Changing directories where MYSTRAN executable resides

4.1.1 Windows version

The MYSTRAN executable can figure out what folder it is in through use of a Windows environment variable. In Windows 10 open Settings and, under "Find a setting" type "environment variables" and click on "Edit environment variables for your account" and create a new environment variable called "MYSTRAN_directory" and give it a value of the folder where you have put the MYSTRAN.EXE program. You can then run MYSTRAN from a command window by changing to the directory where your input file (e.g. dat file) is located and typing MYSTRAN followed by the input file name (e.g. EXAMPLE1). If you do not give the input file name, MYSTRAN will prompt you for the name.

4.1.2 Linux version

If it is desired to have more flexibility in choosing the directory where the executable resides (i.e. not in the same directory where the input dat file exists), the following must be done (let *mystran_folder* be the folder where you want the files mystran.exe and MYSTRAN.INI to be):

In the user's ".bashrc" file add the following 4 lines (the file set_MYSTRAN_directory.sh, below, was one of the files in the tar file downloaded from the MYSTRAN web site. File set_MYSTRAN_directory.sh is to be put into mystran_folder along with mystran.exe and MYSTRAN.INI

Run script to set MYSTRAN_directory source mystran_folder/set_MYSTRAN_directory.sh

Environment variables
MYSTRAN directory=mystran folder

 In the user's ".bash_profile" file add a line to include the directory where the mystran.exe and MYSTRAN.INI files reside (i.e. mystran_folder):

PATH=\$PATH:mystran_folder

4.2 The MYSTRAN initialization file

When MYSTRAN starts, it looks for an initialization file (MYSTRAN.INI) in the same directory that the MYSTRAN.EXE executable file is located. If this file does not exist, default values enumerated below will be used. The initialization file is a text file that is used to:

- Change the directory where MYSTRAN looks for the input files. The output files are put into this
 directory also. The default is that these files must be in the directory where the input dat file
 resides. Note, this is only needed if you did not create the environment variable "MYSTRAN
 directory" discussed in paragraph 4.1.2, and you are not in the directory of the dat file when you
 type MYSTRAN in the command window
- Change the default extension for input files. The default is dat
- Set the level of detail of subroutine begin/end times that is written to the log file. The default is no log file is produced.
- Save Lij files. The default is that no Lij files will be saved.

If any of these are to be changed from their default values, a MYSTRAN.INI file must be created. If there is no MYSTRAN.INI file, the default values discussed below will be used. MYSTRAN.INI is a text file containing commands, discussed below, that can change the default values.

Any line in the initialization file that begins with a \$ or that is a blank line is ignored.

4.2.1 Changing directories where the input and output files reside

Note: this is only needed if you did not create the environment variable "MYSTRAN_directory" discussed in paragraph 4.1.2.

The default for where MYSTRAN looks for the input file and where it puts the output files is the directory where you currently are when you run MYSTRAN. This can be changed with the DEF DIR command in the MYSTRAN.INI file. Say, for example, you want the input and output files to be in C:\RUNS\\PROJECT1 but you do not want to have to change to that directory to run MYSTRAN. The MYSTRAN.INI text file in order to accomplish this would contain the line:

DEF DIR C:\RUNS\PROJECT1

where DEF DIR must be in columns 1 through 7 of the line in MYSTRAN.INI and the default directory, C:\RUNS\PROJECT1 (where you want the input and output files) must begin no sooner than column 9 of that line. With this default directory defined, you only need to enter, at the command prompt when you execute MYSTRAN, the file name itself (EXAMPLE1 for the example problem). MYSTRAN will go to the defined default directory and look for the input data file and will put the output files in that directory also.

4.2.2 Changing the default extension for input files

The default extension for input files is dat which can be changed with the command:

DEF EXT ext

where DEF EXT must be in columns 1 through 7 and *ext* is a character name that must be in column 9 through column 16 and can only consist of 1 to 3 characters and or numbers that are valid for file names. If the extension for a job is not the same as the default extension (either the built in one of dat or one defined with DEF EXT) it must be entered with the file name when MYSTRAN is executed. For example, suppose that you have changed the default extension to D and you want to run EXAMPLE1 that has an extension that is INP. You can either modify the default extension to be INP in the initialization file or enter it with the file name on the command line when MYSTRAN is run (EXAMPLE1.INP).

4.2.3 Setting the level of detail for the log file

The initialization file can also change the level of detail that the log file has. This file contains the start and end times of subroutines. The variable that controls this level of detail is called WRT_LOG and has a default value of 0, which results in no log file at all. Values of WRT_LOG greater than 0 will result in a log file being written. To obtain a log file showing subroutine begin and end times, put the following line into the MYSTRAN.INI file:

```
WRT LOG n
```

where n is an integer > 0. WRT_LOG must begin in column 1 and n can be entered anywhere from column 9 thru column 16. The value n=1 will write begin/end times for the highest level of subroutine calls (LINK's). Successively larger values of n will print more detail. Almost all of the subroutines called in an execution can be shown in the log file by entering a high number for n. A value of n=11 gives about as much detail as can be obtained, but if you want to make sure you get the most detail, enter a higher number (e.g. 99).

5 MYSTRAN messages

MYSTRAN writes error, warning and information messages to the F06 file. The error and warning messages are also written to the ERR file.

5.1 Error messages

There are approximately 600 occurrences of more than 300 different fatal error messages that MYSTRAN has. Eventually, these cause MYSTRAN to abort in an orderly fashion with the following written to the F06 and ERR files:

```
*ERROR nnnn: error message
```

where nnnn is a 3 or 4 digit error number and *error message* is a description of what MYSTRAN found to be a fatal error. Sometimes, several fatal error messages will be written prior to MYSTRAN aborting the execution. A specific example of a fatal error message is:

```
*ERROR 1900: GRID xxxx ON ELEMENT yyyy TYPE type NOT DEFINED
```

where xxxx is a grid point number and yyyy is an element number and *type* is the element type (for example BAR).

5.2 Warning messages

There are approximately 60 warning messages that MYSTRAN has. None of these are fatal. The format of these is:

```
*WARNING : warning message
```

Warning messages have no message number. An example of the type of warning message that can be written is when MYSTRAN reads an entry from the input data deck but does not recognize the entry. A specific example of a warning message is:

*WARNING : ERROR READING SET ID ON CASE CONTROL SET CARD. CARD IGNORED

5.3 Information messages

There are approximately 100 information messages that MYSTRAN has. The format of these is:

```
*INFORMATION: information message
```

Information messages are written to tell various items of interest as MYSTRAN is executing. A specific example of an information message is:

```
*INFORMATION: GRID POINT xxxx DOF(s)yyyy ARE SINGULAR
```

where xxxx is a grid point number and yyyy are the displacement components at the grid that are singular.