LIGHT SYNC

The Function Block allows synchronized switch off of lights in a room, floor and whole building from any light button in a building in case lights are switched by a Wago 750-8xx PLC using my light control block "LICHT" or any other light function block which has an input for a toggle switch plus a dedicated input for switching off the light

Functionality

A light push button usually toggles one light by single clicks, this basic functionality is not touched by the LIGHT_SYNC function block. The added functionality can be reached by pressing the pushbutton longer. In this case it will switch off all lights of the room including the light assigned to the button. If pressed even longer, the lights of the whole floor and as a last step all lights in the building will go off.


There are parameters which change behavior:

- One which excludes the light which is assigned to the button from switching off (SELF_OFF = FALSE)
- One which disables the added functionality for the button assigned to the light, but the light can still be controlled through the other light's buttons (PASSIVE = TRUE)

Setup in Codesys

Three steps are required to make the function block working:

1. Add LIGHT_SYNC blocks and put them in front of the LICHT function block. The blocks have to be looped into the signals which are connected to the inputs TASTER and AUS_SOFORT (or alternatively AUS_MIT_ANKUENDIGUNG) of the LICHT function block. If there is nothing connected to AUS*, the input OFF_IN might be left without any connection, but the OFF_OUT must still be connected with AUS*. Just like that:



- 2. Create a new variable of type BYTE and connect it to lightSync_u8 IN_OUT pin of all LIGHT_SYNC blocks. It is used for interaction between the instances of the block. In case the PLC controls the lights of separated apartments you don't want to have interaction between the lights of different apartment (no global house lights off) just use a dedicated BYTE variable for each apartment. Please note that in case the blocks which need interaction are located in different programs, the BYTE variable has to be declared in the global variables area.
- 3. Configure the assignment of each LIGHT_SYNC block to rooms and floors. This is done through IDs (between 1 and 254) written into the parameters ID_ROOM and ID_FLOOR. Each room and each floor gets its own ID which must be absolutely unique (no overlap between floor and room IDs and no for room IDs on different floors).

Example for ID assignment:

- 1st floor ID_FL00R = 1
- 2nd Floor ID FLOOR = 2
- Ground FloorID_FL00R = 3
- 1st floor bath ID ROOM = 11
- 1st floor living room ID_R00M = 12
- 2nd floor bath ID_R00M = 21
- 2nd sleeping room ID_R00M = 22

Inputs

- PB_IN: BOOL; (Input for the pushbutton which shall toggle the light)
- OFF_IN: BOOL; (Input for the any logic which shall switch off the light. Can be left without any connection if there is not such logic)

Outputs

- PB_OUT: BOOL: FALSE; (Output to the pushbutton input of the LICHT function block. In case of PASSIVE = TRUE this is a modified routing through of PB_IN, otherwise PB_OUT will just go to TRUE for one cycle in case of a short pushbutton press and in case of a long press it will remain FALSE)
- OFF_OUT: BOOL:= FALSE; (The disjuction (=OR) of the OFF_IN signal and a request to switch off the light from a pushbutton connected locally or connected to other LIGHT_SYNC function blocks)

In-/Output


• lightSync_u8: BYTE; (externally variable of type BYTE which is connected to all LIGHT_SYNC blocks. It is used for communication between the instances of the block)

Parameters


- ID_ROOM: BYTE:= 0; (unique number for room between 1 and 254. Not same number as any ID_FLOOR)
- ID_FLOOR: BYTE:= 0; (unique number for floor between 1 and 254. Not same number as any ID_ROOM)
- T_ROOM: TIME:= t#500ms; (duration of button press to switch off light of whole room)
- T_FLOOR: TIME:= t#2000ms; (duration of button press to switch off light of whole floor. Must be higher than T_ROOM)
- T_ALL: TIME:= t#4000ms; (duration of button press to switch off all lights Must be higher than T_FLOOR)
- SELF_OFF: BOOL: TRUE; (Set to FALSE if long press of the pushbutton connected to this block should not switch off the light connected to this block but only the others in the room / floor / building. In case the switch off request comes from another LIGHT_SYNC block the light is still switched off)

Variants of Usage

If the light connected to the LIGHT_SYNC block should not be switched off through the block at all (also through the other blocks in difference to just setting parameter SELF_OFF = FALSE) just do not connect OFF_OUT to the light block (leave OFF_OUT unconnected). Any other logic that should switch off the light must be connected directly to the related input of the light functionblock.



If the block shall act passively only (receive switch off requests and react on it by switching off the connected light but do not send requests to others) just leave PB_IN and PB_OUT without connection and connect the pushbutton to the light function block directly.



Changelog

- 4.2.2019 ver 1.2: removed PASSIVE parameter as the functionality can be reached by not using PB_IN and PB_OUT
- 24.1.2019 ver 1.1: PASSIVE parameter handling implemented
- 10.1.2019 ver 1.0: initial tested version

Author: MacPiper