

Vicon DataStream SDK 1.6.0 Developer's Manual

Contents

| About the Vicon DataStream Software Development Kit (SDK) | 4 |
|---|---|
| Installing on Windows | 5 |
| Installing on Linux | 5 |
| Installing on Mac OSX | 5 |
| Application linking and redistribution | 5 |
| Windows – C++ | 5 |
| Windows – .NET | 5 |
| Windows – MATLAB | 7 |
| Linux – C++ | 7 |
| What's new in version 1.6.0 | 8 |
| Requirements | 8 |
| Function Result return values | |
| List of all SDK functions | g |
| Construction and Destruction | |
| Result | |
| GetVersion | _ |
| Connect | |
| ConnectToMulticast | |
| Disconnect | |
| IsConnected | |
| StartTransmittingMulticast | |
| StopTransmittingMulticast | |
| EnableSegmentData | |
| EnableMarkerData | |
| EnableUnlabeledMarkerData | |
| EnableMarkerRayData | |
| EnableDeviceData | |
| EnableCentroidData | |

© Copyright 2013–2016 Vicon Motion Systems Limited. All rights reserved.

Vicon DataStream SDK Developer's Manual May 2016 For use with Vicon DataStream SDK 1.6.0 and later.

Vicon® is a registered trademark of OMG plc. Vicon Blade™, Vicon Nexus™, Vicon Tracker™, Bonita™, Vicon MX™, and Vicon MX T-Series™ are trademarks of OMG plc. Other product and company names herein may be the trademarks of their respective owners. Vicon Motion Systems is an OMG plc company.

Email: support@vicon.com. Web: www.vicon.com.



| DisableSegmentData | |
|--|-----|
| DisableMarkerData | 27 |
| DisableUnlabeledMarkerData | |
| DisableMarkerRayData | 29 |
| DisableDeviceData | 30 |
| DisableCentroidData | 31 |
| IsSegmentDataEnabled | 32 |
| IsMarkerDataEnabled | |
| IsUnlabeledMarkerDataEnabled | 34 |
| IsMarkerRayDataEnabled | 35 |
| IsDeviceDataEnabled | 36 |
| IsCentroidDataEnabled | 37 |
| SetBufferSize | 38 |
| SetStreamMode | 39 |
| SetAxisMapping | 41 |
| GetAxisMapping | 43 |
| GetFrame | 44 |
| GetFrameNumber | 45 |
| GetLatencyTotal | 46 |
| GetLatencySampleCount | 47 |
| GetLatencySampleName | |
| GetLatencySampleValue | |
| GetTimecode | |
| GetFrameRate | 52 |
| GetSubjectCount | 53 |
| GetSubjectName | |
| GetSubjectRootSegmentName | |
| GetSegmentCount | |
| GetSegmentName | |
| GetSegmentChildCount | |
| GetSegmentChildName | |
| GetSegmentParentName | |
| GetSegmentStaticTranslation | |
| GetSegmentStaticRotationHelical | |
| GetSegmentStaticRotationMatrix | |
| GetSegmentStaticRotationQuaternion | |
| GetSegmentStaticRotationEulerXYZ | |
| GetSegmentGlobalTranslation | |
| GetSegmentGlobalRotationHelical | |
| GetSegmentGlobalRotationMatrix | |
| GetSegmentGlobalRotationQuaternion | |
| GetSegmentGlobalRotationEulerXYZ | |
| GetSegmentLocalTranslation | |
| GetSegmentLocalRotationHelical | |
| GetSegmentLocalRotationMatrix | |
| GetSegmentLocalRotationQuaternion | |
| GetSegmentLocalRotationEulerXYZ | |
| GetMarkerCount | |
| GetMarkerName | |
| GetMarkerParentName | |
| GetMarkerGlobalTranslation | |
| GetMarkerRayContributionCount | |
| Outridition (Appointmental Dutilion Countries and Countrie | 100 |



| | GetMarkerRayContribution | .108 |
|---|--|------|
| | GetUnlabeledMarkerCount | .111 |
| | GetUnlabeledMarkerGlobalTranslation | 112 |
| | GetDeviceCount | 114 |
| | GetDeviceName | .115 |
| | GetDeviceOutputCount | .117 |
| | GetDeviceOutputName | .119 |
| | GetDeviceOutputValue | 122 |
| | GetDeviceOutputSubsamples | 124 |
| | GetDeviceOutputValue ₂ | 126 |
| | GetForcePlateCount | 128 |
| | GetGlobalForceVector | 129 |
| | GetGlobalMomentVector | 131 |
| | GetGlobalCentreOfPressure | 133 |
| | GetForcePlateSubsamples | 135 |
| | GetGlobalForceVector ₂ | 137 |
| | GetGlobalMomentVector ₂ | 139 |
| | GetGlobalCentreOfPressure ₂ | 141 |
| | GetEyeTrackerCount | 143 |
| | GetEyeTrackerGlobalPosition | 144 |
| | GetEyeTrackerGlobalGazeVector | 146 |
| | GetCameraCount | 148 |
| | GetCameraName | 149 |
| | GetCentroidCount | .151 |
| | GetCentroidPosition | 153 |
| Α | ppendix A – What's New | 155 |
| | What's New in Version 1.0 | |
| | What's New in Version 1.0.1 | 155 |
| | What's New in Version 1.1.0 | |
| | What's New in Version 1.2.0 | |
| | What's New in Version 1.3.0 | |
| | What's New in Version 1.4.0 | |
| | What's new in version 1.5.0 | |



About the SDK SDK Functions Listing Appendix A: What's New

About the Vicon DataStream Software Development Kit (SDK)

The Vicon DataStream Software Development Kit (SDK) allows easy programmable access to the information contained in the Vicon DataStream. The function calls within the SDK allow users to connect to and request data from the Vicon DataStream. The following combinations of platforms and technologies are supported:

| | Windows x86 (32-bit) | Windows x64 (64-bit) | Linux x86 (32- bit) | Linux x64 (64- bit) | Mac OSX (64&32-bit) |
|--------|---|---|------------------------|------------------------|------------------------|
| C++ | ✓ | ✓ | ✓ | ✓ | |
| .NET | ✓ | ✓ | | | |
| MATLAB | ✓ (can be run on Windows 64-bit OS) | ✓ (requires Microsoft Professional compiler) | | | |

Important notes:

- Not all function calls contained within the SDK will return data when connected to certain Vicon Applications. For example, Vicon Blade does not support analog devices, and therefore will not output device information into the DataStream.
- The current DataStream format is supported by Vicon Nexus 1.4+, Vicon Blade 1.6+, and Tracker 1.0+. These applications may also output an additional stream in the legacy "Tarsus" format. This DataStream SDK only accesses the DataStream format.
- The current intention is that all future Vicon applications will support the DataStream format.
- Example files are supplied as unsupported examples only.
- The SDK only supports axis transformations into right handed co-ordinate systems.
- The SDK is designed to allow multiple instances of a Client within a single process which can connect to multiple DataStreams.

The SDK is supplied as shared libraries – DLLs on Windows and SOs on Linux. The shared libraries and supporting files are required to be copied alongside your client executable.



SDK Functions Listing

Appendix A: What's New

Installing on Windows

There are separate installers for the 32-bit and 64-bit SDKs. The 64-bit installer will only work on a 64-bit version of Windows. The default install directories are:

64-bit Windows

- 32-bit SDK: C:\Program Files (x86)\Vicon\DataStream SDK\Win32
- 64-bit SDK: C:\Program Files\Vicon\DataStream SDK\Win64

32-bit Windows

32-bit SDK: C:\Program Files\Vicon\DataStream SDK\Win32

The SDK is supported on Windows 7.

Installing on Linux

The SDK is provided as a compressed archive. Extract the archive into a convenient location on your system.

Installing on Mac OSX

The dylibs should be placed in /usr/lib and marked as executable:

```
sudo cp libViconDataStreamSDK_CPP.dylib /usr/lib
sudo cp libDebugServices.dylib /usr/lib
sudo chmod 755 /usr/lib/libViconDataStreamSDK_CPP.dylib
sudo chmod 755 /usr/lib/libDebugServices.dylib
```

Application linking and redistribution

Windows - C++

The SDK was built using Visual Studio 2013. Your application should

- #include "DataStreamClient.h"
- Link against "ViconDataStreamSDK_CPP.lib"
- Redistribute:
 - "ViconDataStreamSDK CPP.dll"
 - "DebugServices.dll"
 - "boost *-vc120-mt-1_58.dll"
 - "Microsoft.VC12.CRT"

Windows - .NET

Your application should

- Link against the assembly "ViconDataStreamSDK_DotNET.dll".
- Redistribute:
 - "ViconDataStreamSDK DotNET.dll"



SDK Functions Listing

Appendix A: What's New

- "ViconDataStreamSDK_CPP.dll"
- "DebugServices.dll"
- "boost_*-vc120-mt-1_58.dll"
- "Microsoft.VC12 CRT"
- Have the .NET Framework 4.5 or later installed.

The managed code in this assembly requires the unmanaged code in the C++ SDK



SDK Functions Listing

Appendix A: What's New

Windows - MATLAB

Your application M file should be in the same directory as

- "Client.m"
- "DeviceType.m"
- "Direction.m"
- Result.m"
- "StreamMode.m"
- "TimecodeStandard.m"
- "Unit.m"
- "ViconDataStreamSDK_MATLAB.dll"
- "ViconDataStreamSDK_MATLAB.h"
- "DebugServices.dll"
- "boost_*-vc120-mt-1_58.dll
- "Microsoft.VC12.CRT"

Linux - C++

Your application should

- #include "Client.h"
- Link against "libViconDataStreamSDK_CPP.so"
- Redistribute
 - "libViconDataStreamSDK_CPP.so"
 - "libDebugServices.so"
 - "libboost_*-mt.so.1.xx.0"

The SDK was compiled with gcc version 4.8.2 (Red Hat 4.8.2-15 from devtools-2 for CentOS 5)



SDK Functions Listing

Appendix A: What's New

What's new in version 1.6.0

- New function calls:
 - EnableMarkerRayData
 - DisableMarkerRayData
 - IsMarkerRayDataEnabled
 - GetMarkerRayContributionCount
 - GetMarkerRayContribution

Requirements

- A compatible licensed version of Vicon Blade, Vicon Nexus, or Vicon Tracker must be present.
- LabVIEW will make use of the .NET dll, and has been found to function in versions 7.1 and 8.
- The MATLAB dll has been found to function in versions 7 and 8.
- The SDK has not been designed to allow access from Simulink.
- The Linux SDK has been specifically verified on CentOS 5.5, Ubuntu 8.04, Ubuntu 9.04, Fedora 9, and Fedora 11. It should also work on any platform supporting glibc 2.5 or later.

Function Result return values

Every function returns a data structure containing elements specified in the Output section of each method reference. Most functions return a Result item, which indicates the success or cause of failure for the function and useful for debugging purposes.

When a function has returned false, the output arguments are set to an appropriate default value:

- Booleans will be set to false.
- Integers will be set to zero.
- Doubles will be set to zero.
- Strings will be set to zero length.
- When the output argument is an array, all elements are set in this manner.

SDK Functions Listing

Appendix A: What's New

List of all SDK functions

Construction and Destruction

You can create many instances of the Vicon DataStream Client which can connect to multiple Vicon DataStream Servers

```
DataStream Servers.
C++
              C++ is object oriented, so use the class constructor.
                ViconDataStreamSDK::CPP::Client StackClient;
                Output SomeFunction Output = StackClient.SomeFunction();
              } // Client is implicitly destroyed as it goes out of scope
              ViconDataStreamSDK::CPP::Client * pHeapClient =
                                    new ViconDataStreamSDK::CPP::Client();
              Output SomeFunction Output = pHeapClient->SomeFunction(Input);
              delete pHeapClient;
MATLAB
              The MATLAB SDK is object oriented, and needs to be explicitly loaded and
              unloaded.
              Client.LoadViconDataStreamSDK();
              pHeapClient = Client();
              Output = pHeapClient.SomeFunction( Input );
              Client.UnloadViconDataStreamSDK();
.NET
              .NET is object oriented, so use the class constructor. Because objects are lazily
              garbage collected, your instance may outlive the last reference to it for some time. If
              the instance is pre-fetching frame data for you, then it can still use CPU and network
              bandwidth. Consider explicitly disconnecting prior to destruction.
              ViconDataStreamSDK.DotNET.Client pHeapClient =
                                     new ViconDataStreamSDK.DotNET.Client();
              Output SomeFunction Output = pHeapClient.SomeFunction( InputParam );
              // Signal to the garbage collector that it can clean up
              pHeapClient.Disconnect();
              pHeapClient = null;
```

SDK Functions Listing

Appendix A: What's New

Result

| The Result | code indicates the success or failure of a | function. |
|------------|--|---|
| | Unknown | The result is unknown. Treat it as a failure. |
| | NotImplemented | The function called has not been implemented in this version of the SDK. |
| | Success | The function call succeeded. |
| | InvalidHostName | The "HostName" parameter passed to Connect() is invalid. |
| | InvalidMulticastIP | The "MulticastIP" parameter was not in the range "224.0.0.0" – "239.255.255.255" |
| | ClientAlreadyConnected | Connect() was called whilst already connected to a DataStream. |
| | ClientConnectionFailed | Connect() could not establish a connection to the DataStream server. |
| | ServerAlreadyTransmittingMultcast | StartTransmittingMulticast() was called when the current DataStream server was already transmitting multicast on behalf of this client. |
| | ServerNotTransmittingMulticast | StopTransmittingMulticast() was called when the current DataStream server was not transmitting multicasr on behalf of this client. |
| | NotConnected | You have called a function which requires a connection to the DataStream server, but do not have a connection. |
| | NoFrame | You have called a function which requires a frame to be fetched from the DataStream server, but do not have a frame. |
| | InvalidIndex | An index you have passed to a function is out of range. |
| | InvalidCameraName | The Camera Name you passed to a function is invalid in this frame |
| | InvalidSubjectName | The Subject Name you passed to a function is invalid in this frame. |
| | InvalidSegmentName | The Segment Name you passed to a |



About the SDK SDK Functions Listing Appendix A: What's New

| | | function is invalid in this frame. |
|-----|---|---|
| | InvalidMarkerName | The Marker Name you passed to a function is invalid in this frame. |
| | InvalidDeviceName | The Device Name you passed to a function is invalid in this frame. |
| | InvalidDeviceOutputName | The Device Output Name you passed to a function is invalid in this frame. |
| | InvalidLatencySampleName The Latency Sample Name you past function is invalid in this frame. CoLinearAxes The directions passed to SetAxisMa contain input which would cause tw axis to lie along the same line, e.g. "Down" are on the same line. LeftHandedAxes The directions passed to SetAxisMa would result in a left handed co-ord system. This is not supported in the | |
| | | |
| | | |
| | HapticAlreadySet | Haptic feedback is already set |
| C++ | <pre>namespace ViconDataStreamSDK { namespace CPP { namespace Result { enum Enum { Unknown, NotImplemented, Success, InvalidHostName, InvalidMulticastIP, ClientAlreadyConnected, ClientConnectionFailed, ServerAlreadyTransmittingMulticast, ServerNotTransmittingMulticast, NotConnected, NoFrame, InvalidIndex, InvalidCameraName, InvalidSubjectName, InvalidSegmentName, InvalidDeviceName, InvalidDeviceOutputName, InvalidDeviceOutputName, InvalidLatencySampleName, CoLinearAxes, LeftHandedAxes, HapticAlreadySet }; }</pre> | |

SDK Functions Listing

Appendix A: What's New

```
classdef Result
MATLAB
              properties (Constant = true)
                Unknown
                                                   = 1;
                NotImplemented
                                                   = 2;
                Success
                InvalidHostName
                                                   = 3:
                InvalidMulticastIP
                ClientAlreadyConnected
                                                   = 6;
                 ClientConnectionFailed
                 ServerAlreadyTransmittingMulticast = 8;
                 ServerNotTransmittingMulticast = 9;
                NotConnected
                NoFrame
                                                   = 11;
                InvalidIndex
InvalidCameraName =13;
                                                   = 12;
                 InvalidSubjectName
                                                   = 14;
                 InvalidSegmentName
                                                   = 15;
                                                   = 16;
                InvalidMarkerName
                 InvalidDeviceName
                                                   = 17;
                InvalidDeviceOutputName
                                                  = 18;
                InvalidLatencySampleName
                                                  = 19;
                                                   = 20;
                CoLinearAxes
                                                   = 21;
                 LeftHandedAxes
                                                 = 22;
                HapticAlreadySet
              end
              properties
                Value
              end
              methods
                function obj = Result( value )
                  obj.Value = value;
                end% Constructor
              end% methods
             end% classdef
            namespace ViconDataStreamSDK
.NET
            namespace DotNET
            public enum class Result
                Unknown,
                NotImplemented,
                Success,
                InvalidHostName,
                InvalidMulticastIP,
                ClientAlreadyConnected,
                 ClientConnectionFailed,
                ServerAlreadyTransmittingMulticast,
                 ServerNotTransmittingMulticast,
                NotConnected,
                NoFrame,
                InvalidIndex,
                 InvalidCameraName
                 InvalidSubjectName,
                 InvalidSegmentName,
                 InvalidMarkerName,
                 InvalidDeviceName,
                 InvalidDeviceOutputName,
                 InvalidLatencySampleName,
                CoLinearAxes,
                LeftHandedAxes
              };
             \} // End of namespace DotNET
             } // End of namespace ViconDataStreamSDK
```

SDK Functions Listing

Appendix A: What's New

GetVersion

| Get the version of the Vicon DataStream SDK | | | | |
|---|--|---|--|--|
| Input | | | | |
| Output | Major | unsigned int | The major version number. When this number increases we break backwards compatibility with previous major versions. | |
| | Minor | unsigned int | The minor version number. When this number increases we have probably added new functionality to the SDK without breaking backwards compatibility with previous versions. | |
| | Point | unsigned int | The point version number. When this number increases, we have introduced a bug fix or performance enhancement without breaking backwards compatibility. | |
| C++ | <pre>// { // public: // unsigned : // unsigned : // unsigned : // }; // // Output_GetVet</pre> | <pre>// public: // unsigned int Major; // unsigned int Minor; // unsigned int Point; // }; // Output_GetVersion GetVersion() const; ViconDataStreamSDK::CPP::Client MyClient;</pre> | | |
| MATLAB | MyClient = Clie | <pre>% [Output] = GetVersion() MyClient = Client(); Output = MyClient.GetVersion();</pre> | | |
| .NET | <pre>// { // public uir // public uir // public uir // }; // // Output_GetVe</pre> | <pre>// public uint Major; // public uint Minor; // public uint Point; // };</pre> | | |
| l | Output_GetVers: | <pre>new ViconDataStreamSDK.DotNET.Client(); Output_GetVersion Output = MyClient.GetVersion();</pre> | | |

SDK Functions Listing

Appendix A: What's New

Connect

Establish a dedicated connection to a Vicon DataStream Server See Also: ConnectToMulticast, Disconnect, IsConnected

| See Also: ConnectToMulticast, Disconnect, IsConnected | | | | |
|---|--|--------|--|--|
| Input | Host Name | string | The DNS identifiable name, or IP address of the PC hosting the DataStream server. The function defaults to connecting on port 801. You can specify an alternate port number after a colon. "localhost" "MyViconPC:804" "10.0.0.2" | |
| Output | Result | Result | Result.Success Result.InvalidHostName Result.ClientAlreadyConnected Result.ClientConnectionFailed | |
| C++ | <pre>// class Output_Connect // { // public:</pre> | | | |
| MATLAB | <pre>% [Output] = Connect() MyClient = Client(); Output = MyClient.Connect('locahost:801');</pre> | | | |
| .NET | <pre>// class Output_Connect // {</pre> | | | |

SDK Functions Listing

Appendix A: What's New

ConnectToMulticast

Connect to a Vicon DataStream Server's Multicast stream. The stream content is managed by a client who calls StartTransmittingMulticast().

See Also: Connect, Disconnect, IsConnected, StartTransmittingMulticast, StopTransmittingMulticast

| Stop i ransmittingiviuiticast | | | |
|-------------------------------|---|--|---|
| Input | LocalIP | The DNS identifiable name, or IP address of the local Ethernet interface on which you wish to receive multicast data. You should not specify a port (any port specified will be ignored). e.g. "localhost" "10.0.0.2" | |
| | Multicast IP | string | The IP Address of the Multicast group on which data will be received. The address should be in the range "224.0.0.0" – "239.255.255.255" You may also specify a port by appending it to the end of the IP Address after a colon. e.g. 224.0.0.0:30001. If you do not specify a port it will default to 44801. |
| Output | Result | Result | Result.Success Result.InvalidHostName Result.InvalidMulticastIP Result.ClientAlreadyConnected Result.ClientConnectionFailed |
| C++ | <pre>// class Output_ConnectToMulticast // { // public: // Result::Enum Result; // }; // // Output_ConnectToMulticast // ConnectToMulticast (const String & LocalIP, // const String & MulticastIP); ViconDataStreamSDK::CPP::Client MyClient; Output_ConnectToMulticast Output = MyClient.ConnectToMulticast("localhost", "224.0.0.0");</pre> | | |
| MATLAB | <pre>% [Output] = ConnectToMulticast() MyClient = Client(); Output = MyClient.ConnectToMulticast('locahost', '224.0.0.0');</pre> | | |
| .NET | <pre>// class Output_ConnectToMulticast // { public Result Result; // }; // Output_ConnectToMulticast ConnectToMulticast (string LocalIP,</pre> | | |



SDK Functions Listing

Appendix A: What's New

Disconnect

| Disconnect from the Vicon DataStream Server. See Also : Connect, IsConnected | | | | |
|--|---|--|--|--|
| Input | | | | |
| Output | Result Result Result.Success Result.NotConnected | | | |
| C++ | <pre>// class Output_Disconnect // { // public: // Result::Enum Result; // }; // // Output_Disconnect Disconnect(); ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect("localhost"); Output Disconnect Output = MyClient.Disconnect();</pre> | | | |
| MATLAB | <pre>% [Output] = Connect() MyClient = Client(); MyClient.Connect("localhost"); Output = MyClient.Disconnect();</pre> | | | |
| .NET | <pre>// public class Output_Disconnect // { // public Result Result; // }; // // Output_Disconnect Disconnect() ViconDataStreamSDK.DotNET.Client MyClient =</pre> | | | |

SDK Functions Listing

Appendix A: What's New

IsConnected

| Discover whether client is connected to the Vicon DataStream Server. See Also: Connect, Disconnect | | | | |
|---|--|---|---|--|
| Input | | | | |
| Output | Connected | boolean | True if you are connected to the stream, otherwise false. | |
| C++ | <pre>// { // public: // bool Connect // }; // // Output_IsConnect ViconDataStreamSI Output_IsConnecte MyClient.Connect</pre> | <pre>// public: // bool Connected; // };</pre> | | |
| MATLAB | MyClient = Client Output = MyClient MyClient.Connect(| <pre>% [Output] = IsConnected() MyClient = Client(); Output = MyClient.IsConnected()</pre> | | |
| .NET | <pre>// { // public bool C // }; // // Output_IsConne ViconDataStreamSI Output_IsConnecte MyClient.Connect()</pre> | <pre>// public bool Connected; //);</pre> | | |

SDK Functions Listing

Appendix A: What's New

StartTransmittingMulticast

Ask the DataStream Server to start transmitting the data you are receiving directly to a Multicast address as well. This allows multiple clients to connect to your stream (via ConnectToMulticast()) whilst minimizing network bandwidth use and frame delivery latency.

See Also: Connect, ConnectToMulticast, Disconnect, StopTransmittingMulticast

| Input | ServerIP | string | The IP Address of the server Ethernet interface from which the Multicast data will be sent. You should not specify a port number (any port number specified will be ignored) | |
|--------|---|--------|--|--|
| | MulticastIP | string | The IP Address of the Multicast group to which multicast data will be sent. The address should be in the range "224.0.0.0" – "239.255.255.255" You may also specify the port the data will be sent to by appending it to the IP Address after a colon e.g. 224.0.0.0:30001. If you do not specify a port it will default to 44801. | |
| Output | Result | Result | Result.Success Result.NotConnected Result.InvalidMulticastIP Result.ServerAlreadyTransmittingMulticast | |
| C++ | <pre>// class Output_StartTransmittingMulticast // { // public: // Result::Enum Result; // }; // Output_StartTransmittingMulticast // StartTransmittingMulticast (const String & ServerIP,</pre> | | | |
| MATLAB | <pre>% [Output] = StartTransmittingMulticast () MyClient = Client(); MyClient.Connect("localhost"); MyClient.StartTransmittingMulticast('10.0.0.1', '224.0.0.0');</pre> | | | |
| .NET | <pre>// public class Output_StartTransmittingMulticast // { // public Result Result; // }; // Output_StartTransmittingMulticast // StartTransmittingMulticast(string ServerIP, string MulticastIP); ViconDataStreamSDK.DotNET.Client MyClient =</pre> | | | |

SDK Functions Listing

Appendix A: What's New

StopTransmittingMulticast

Ask the DataStream Server to stop transmitting the data you are receiving directly to a Multicast address as well. You must previously have started a transmission via StartTransmittingMulticast.

See Also: Connect, ConnectToMulticast, Disconnect, StartTransmittingMulticast

| Input | | | | | | |
|--------|---|---|--|--|--|--|
| Output | Result | Result | Result.Success Result.NotConnected Result.ServerNotTransmittingMulticast | | | |
| C++ | <pre>// class Output_StopTransmittingMulticast // { // public: // Result::Enum Result; // }; // Output_StopTransmittingMulticast // StopTransmittingMulticast () const;</pre> | | | | | |
| | MyClient.Conne MyClient.Start // Do some stu | <pre>ViconDataStreamSDK::CPP::CPP::Client MyClient; MyClient.Connect("localhost"); MyClient.StartTransmittingMulticast("10.0.0.1", "224.0.0.0"); // Do some stuff MyClient.StopTransmittingMulticast();</pre> | | | | |
| MATLAB | % [Output] = S | topTransmittingM | Multicast () | | | |
| | <pre>MyClient = Client(); MyClient.Connect("localhost"); MyClient.StartTransmittingMulticast('10.0.0.1', '224.0.0.0'); % Do some stuff MyClient.StopTransmittingMulticast();</pre> | | | | | |
| .NET | <pre>// public class Output_StopTransmittingMulticast // { // public Result Result; // }; // // Output_StopTransmittingMulticast // StopTransmittingMulticast(); ViconDataStreamSDK.DotNET.Client MyClient =</pre> | | | | | |
| | MyClient.Start // Do some stu | TransmittingMult | ricast("10.0.0.1", "224.0.0.0"); | | | |

SDK Functions Listing

Appendix A: What's New

EnableSegmentData

Enable kinematic segment data in the Vicon DataStream. You should call this function on startup, after connecting to the server, and before trying to read local or global segment data.

See Also: IsSegmetnDataEnabled, DisableSegmentData, EnableMarkerData, EnableUnlabelledMarkerData, EnableDeviceData, GetSegmentCount, GetSegmentName, GetSegmentGlobalTranslation, GetSegmentGlobalRotationXXX, GetSegmentLocalTranslation, GetSegmentLocalRotationXXX

| Input | | | |
|--------|---|--------|------------------------------------|
| Output | Result | Result | Result.NotConnected Result.Success |
| C++ | <pre>// class Output_EnableSegmentData // { // public: // Result::Enum Result; // }; // Output_EnableSegmentData EnableSegmentData(); ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect("localhost"); Output EnableSegmentData Output = MyClient.EnableSegmentData();</pre> | | |
| MATLAB | <pre>% [Output] = EnableSegmentData() MyClient = Client(); MyClient.Connect("localhost"); Output = MyClient.EnableSegmentData();</pre> | | |
| .NET | <pre>// public class Output_EnableSegmentData // { // public Result Result; // }; // Output_EnableSegmentData EnableSegmentData(); ViconDataStreamSDK.DotNET.Client MyClient =</pre> | | |

SDK Functions Listing

Appendix A: What's New

EnableMarkerData

Enable labeled reconstructed marker data in the Vicon DataStream. Call this function on startup, after connecting to the server, and before trying to read labeled marker data.

See Also: IsMarkerDataEnabled, DisableMarkerData, EnableSegmentData, EnableUnlabelledMarkerData, EnableDeviceData, GetMarkerCount, GetMarkerName, GetMarkerGlobalTranslation

| Input | | | |
|--------|---|--------|---------------------------------------|
| Output | Result | Result | Result.NotConnected Result.Success |
| C++ | <pre>// class Output_EnableMarkerData // { // public: // Result::Enum Result; // }; // Output_EnableMarkerData EnableMarkerData(); ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect("localhost"); Output EnableMarkerData Output = MyClient.EnableMarkerData();</pre> | | |
| MATLAB | <pre>% [Output] = EnableMarkerData() MyClient = Client(); MyClient.Connect("localhost"); Output = MyClient.EnableMarkerData();</pre> | | |
| .NET | <pre>// public class Output_EnableMarkerData // { // public Result Result; // }; // Output_EnableMarkerData EnableMarkerData(); ViconDataStreamSDK.DotNET.Client MyClient =</pre> | | |

SDK Functions Listing

Appendix A: What's New

EnableUnlabeledMarkerData

Enable unlabeled reconstructed marker data in the Vicon DataStream. You should call this function on startup, after connecting to the server, and before trying to read global unlabeled marker data.

See Also: IsUnlabeledMarkerDataEnabled, DisableUnlabeledMarkerData, EnableSegmentData, EnableMarkerData, EnableDeviceData, GetUnlabeledMarkerCount, GetUnlabeledMarkerGlobalTranslation

| Input | | | | |
|--------|--|--------|---------------------------------------|--|
| Output | Result | Result | Result.NotConnected Result.Success | |
| C++ | <pre>// class Output_EnableUnlabeledMarkerData // { // public: // Result::Enum Result; // }; // // Output_EnableUnlabeledMarkerData EnableUnlabeledMarkerData(); ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect("localhost"); Output EnableUnlabeledMarkerData Output =</pre> | | | |
| MATLAB | <pre>% [Output] = EnableUnlabeledMarkerData() MyClient = Client(); MyClient.Connect("localhost"); Output = MyClient.EnableUnlabeledMarkerData();</pre> | | | |
| .NET | <pre>// public class Output_EnableUnlabeledMarkerData // { // public Result Result; // }; // // Output_EnableUnlabeledMarkerData EnableUnlabeledMarkerData(); ViconDataStreamSDK.DotNET.Client MyClient =</pre> | | | |

SDK Functions Listing

Appendix A: What's New

EnableMarkerRayData

Enable information about the rays contributing toward each labelled marker in the Vicon DataStream. You should call this function on startup, after connecting to the server, and before trying to read global unlabeled marker data.

See Also: IsMarkerRayDataEnabled, DisableMarkerRayData, EnableSegmentData, EnableMarkerData, EnableDeviceData, GetUnlabeledMarkerCount, GetUnlabeledMarkerGlobalTranslation

| Input | | | |
|--------|---|--------|------------------------------------|
| Output | Result | Result | Result.NotConnected Result.Success |
| C++ | <pre>// class Output_EnableMarkerRayData // { // public: // Result::Enum Result; // }; // Output_EnableMarkerRayData EnableMarkerRayData(); ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect("localhost"); Output_EnableMarkerRayData Output =</pre> | | |
| MATLAB | <pre>% [Output] = EnableMarkerRayData() MyClient = Client(); MyClient.Connect("localhost"); Output = MyClient.EnableMarkerRayData();</pre> | | |
| .NET | <pre>// public class Output_EnableMarkerRayData // {</pre> | | |

SDK Functions Listing

Appendix A: What's New

EnableDeviceData

Enable ForcePlate, EMG, and other device data in the Vicon DataStream. You should call this function on startup, after connecting to the server, and before trying to read device information.

See Also: IsDeviceDataEnabled, DisableDeviceData, EnableSegmentData, EnableMarkerData, EnableUnlabeledMarkerData, GetDeviceCount, GetDeviceName, GetDeviceOutputCount, GetDeviceOutputName,GetDeviceOutputValue

| Input | | | | |
|--------|---|--------|---------------------------------------|--|
| Output | Result | Result | Result.NotConnected Result.Success | |
| C++ | <pre>// class Output_EnableDeviceData // { // public: // Result::Enum Result; // }; // Output_EnableDeviceData EnableDeviceData(); ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect("localhost"); Output EnableDeviceData Output = MyClient.EnableDeviceData();</pre> | | | |
| MATLAB | <pre>% [Output] = EnableDeviceData() MyClient = Client(); MyClient.Connect("localhost"); Output = MyClient.EnableDeviceData();</pre> | | | |
| .NET | <pre>// public class Output_EnableDeviceData // { // public Result Result; // }; // Output_EnableDeviceData EnableDeviceData(); ViconDataStreamSDK.DotNET.Client MyClient =</pre> | | | |



SDK Functions Listing

Appendix A: What's New

EnableCentroidData

Enable centroid data in the Vicon DataStream. You should call this function on startup, after connecting to the server, and before trying to read centroid information.

See Also: IsCentroidDataEnabled, DisableCentroidData

| Input | | | |
|--------|--|--------|---------------------------------------|
| Output | Result | Result | Result.NotConnected Result.Success |
| C++ | <pre>// class Output_EnableCentroidData // { // public: // Result::Enum Result; // }; // Output_EnableCentroidData EnableCentroidData(); ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect("localhost"); Output EnableCentroidData Output = MyClient.EnableCentroidData();</pre> | | |
| MATLAB | <pre>% [Output] = EnableCentroidData () MyClient = Client(); MyClient.Connect("localhost"); Output = MyClient.EnableCentroidData ();</pre> | | |
| .NET | <pre>// public class Output_EnableCentroidData // { // public Result Result; // }; // Output_EnableCentroidData EnableCentroidData (); ViconDataStreamSDK.DotNET.Client MyClient =</pre> | | |

SDK Functions Listing

Appendix A: What's New

DisableSegmentData

Disable kinematic segment data in the Vicon DataStream.

See Also: IsSegmetnDataEnabled, EnableSegmentData, EnableMarkerData, EnableUnlabelledMarkerData, EnableDeviceData, GetSegmentCount, GetSegmentName, GetSegmentGlobalTranslation, GetSegmentGlobalRotationXXX, GetSegmentLocalTranslation, GetSegmentLocalRotationXXX

| Input | | | |
|--------|--|--------|---------------------------------------|
| Output | Result | Result | Result.NotConnected Result.Success |
| C++ | <pre>// class Output_DisableSegmentData // { public:</pre> | | |
| MATLAB | <pre>% [Output] = DisableSegmentData() MyClient = Client(); MyClient.Connect("localhost"); Output = MyClient.DisableSegmentData();</pre> | | |
| .NET | <pre>// public class Output_DisableSegmentData // { // public Result Result; // }; // Output_DisableSegmentData DisableSegmentData(); ViconDataStreamSDK.DotNET.Client MyClient =</pre> | | |

SDK Functions Listing

Appendix A: What's New

DisableMarkerData

Disable labeled reconstructed marker data in the Vicon DataStream.

See Also: IsMarkerDataEnabled, EnableMarkerData, EnableSegmentData, EnableUnlabelledMarkerData, EnableDeviceData, GetMarkerCount, GetMarkerName, GetMarkerGlobalTranslation

| Input | | | |
|--------|---|--------|---------------------------------------|
| Output | Result | Result | Result.NotConnected Result.Success |
| C++ | <pre>// class Output_DisableMarkerData // { // public: // Result::Enum Result; // }; // Output_DisableMarkerData DisableMarkerData(); ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect("localhost"); Output DisableMarkerData Output = MyClient.DisableMarkerData();</pre> | | |
| MATLAB | <pre>% [Output] = DisableMarkerData() MyClient = Client(); MyClient.Connect("localhost"); Output = MyClient.DisableMarkerData();</pre> | | |
| .NET | <pre>// public class Output_DisableMarkerData // { // public Result Result; // }; // // Output_DisableMarkerData DisableMarkerData(); ViconDataStreamSDK.DotNET.Client MyClient =</pre> | | |

SDK Functions Listing

Appendix A: What's New

DisableUnlabeledMarkerData

Disable unlabeled reconstructed marker data in the Vicon DataStream.

See Also: IsUnlabeledMarkerDataEnabled, EnableUnlabeledMarkerData, EnableSegmentData, EnableMarkerData, EnableDeviceData, GetUnlabeledMarkerCount, GetUnlabeledMarkerGlobalTranslation

| | | | Т | |
|--------|--|--------|---------------------------------------|--|
| Input | | | | |
| Output | Result | Result | Result.NotConnected Result.Success | |
| C++ | <pre>// class Output_DisableUnlabeledMarkerData // { // public: // Result::Enum Result; // }; // // Output_DisableUnlabeledMarkerData DisableUnlabeledMarkerData(); ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect("localhost"); Output_DisableUnlabeledMarkerData Output = MyClient.DisableUnlabeledMarkerData();</pre> | | | |
| MATLAB | <pre>% [Output] = DisableUnlabeledMarkerData() MyClient = Client(); MyClient.Connect("localhost"); Output = MyClient.DisableUnlabeledMarkerData();</pre> | | | |
| .NET | <pre>// public class Output_DisableUnlabeledMarkerData // { public Result Result; // }; // Output_DisableUnlabeledMarkerData DisableUnlabeledMarkerData(); ViconDataStreamSDK.DotNET.Client MyClient =</pre> | | | |

SDK Functions Listing

Appendix A: What's New

DisableMarkerRayData

Disable unlabeled reconstructed marker data in the Vicon DataStream.

See Also: IsMarkerRayDataEnabled, EnableMarkerRayData, EnableSegmentData, EnableMarkerData, EnableDeviceData, GetUnlabeledMarkerCount, GetUnlabeledMarkerGlobalTranslation

| | 1 | | | |
|--------|---|--------|---------------------------------------|--|
| Input | | | | |
| Output | Result | Result | Result.NotConnected Result.Success | |
| C++ | <pre>// class Output_DisableMarkerRayData // { // public: // Result::Enum Result; // }; // Output_DisableMarkerRayData DisableMarkerRayData(); ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect("localhost"); Output_DisableMarkerRayData Output =</pre> | | | |
| MATLAB | <pre>% [Output] = DisableMarkerRayData() MyClient = Client(); MyClient.Connect("localhost"); Output = MyClient.DisableMarkerRayData();</pre> | | | |
| .NET | <pre>// public class Output_DisableMarkerRayData // {</pre> | | | |

SDK Functions Listing

Appendix A: What's New

DisableDeviceData

Disable ForcePlate, EMG, and other device data in the Vicon DataStream.

See Also: IsDeviceDataEnabled, EnableDeviceData, EnableSegmentData, EnableMarkerData, EnableUnlabeledMarkerData, GetDeviceCount, GetDeviceName, GetDeviceOutputCount, GetDeviceOutputName,GetDeviceOutputValue

| Input | | | | |
|--------|---|--------|---------------------------------------|--|
| Output | Result | Result | Result.NotConnected Result.Success | |
| C++ | <pre>// class Output_DisableDeviceData // { // public: // Result::Enum Result; // }; // Output_DisableDeviceData DisableDeviceData(); ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect("localhost"); Output DisableDeviceData Output = MyClient.DisableDeviceData();</pre> | | | |
| MATLAB | <pre>% [Output] = DisableDeviceData() MyClient = Client(); MyClient.Connect("localhost"); Output = MyClient.DisableDeviceData();</pre> | | | |
| .NET | <pre>// public class Output_DisableDeviceData // { // public Result Result; // }; // // Output_DisableDeviceData DisableDeviceData(); ViconDataStreamSDK.DotNET.Client MyClient =</pre> | | | |



SDK Functions Listing

Appendix A: What's New

DisableCentroidData

| Disable Centroid data in the Vicon DataStream. See Also: IsCentroidDataEnabled, EnableCentroidData | | | | |
|--|---|---|------------------------------------|--|
| Input | | | | |
| Output | Result | Result | Result.NotConnected Result.Success | |
| C++ | <pre>// { // public: // Result::En // }; // // Output_Disabl ViconDataStreamS MyClient.Connect</pre> | <pre>// public: // Result::Enum Result; // };</pre> | | |
| MATLAB | MyClient = Clien MyClient.Connect | <pre>% [Output] = DisableCentroidData () MyClient = Client(); MyClient.Connect("localhost"); Output = MyClient.DisableCentroidData ();</pre> | | |
| .NET | <pre>// public class Output_DisableCentroidData // { // public Result Result; // }; // Output_DisableCentroidData DisableCentroidData (); ViconDataStreamSDK.DotNET.Client MyClient =</pre> | | | |

SDK Functions Listing

Appendix A: What's New

IsSegmentDataEnabled

Return whether kinematic segment data is enabled in the Vicon DataStream.

See Also: EnableSegmentData, DisableSegmentData, IsMarkerDataEnabled. IsUnlabeledMarkerDataEnabled. IsDeviceDataEnabled

| isoniabeledivia | IsUnlabeledMarkerDataEnabled, IsDeviceDataEnabled | | | |
|-----------------|---|---------|------------------------------|--|
| Input | | | | |
| Output | Enabled | boolean | Whether the data is enabled. | |
| C++ | <pre>// class Output_IsSegmentDataEnabled // { // public: // bool Enabled; // }; // Output_IsSegmentDataEnabled IsSegmentDataEnabled() const; ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect("localhost"); Output_IsSegmentDataEnabled Output = MyClient.IsSegmentDataEnabled();</pre> | | | |
| MATLAB | <pre>% [Output] = IsSegmentDataEnabled() MyClient = Client(); MyClient.Connect("localhost"); Output = MyClient.IsSegmentDataEnabled(); % Output.Enabled == false MyClient.EnableSegmentData(); Output = MyClient.IsSegmentDataEnabled(); % Output.Enabled == true</pre> | | | |
| .NET | <pre>// public class Output_IsSegmentDataEnabled // { // public bool Enabled; // }; // Output_IsSegmentDataEnabled IsSegmentDataEnabled(); ViconDataStreamSDK.DotNET.Client MyClient = new ViconDataStreamSDK.DotNET.Client(); MyClient.Connect("localhost"); Output_IsSegmentDataEnabled Output = MyClient.IsSegmentDataEnabled();</pre> | | | |

SDK Functions Listing

Appendix A: What's New

IsMarkerDataEnabled

Return whether labeled reconstructed marker data is enabled in the DataStream.

See Also: EnableMarkerData, DisableMarkerData, IsSegmentDataEnabled. IsUnlabeledMarkerDataEnabled, IsDeviceDataEnabled

| | ISOTIIADEIEUWAI NEI DAIALTIADIEU, ISDEVICEDAIALTIADIEU | | | |
|--------|--|---------|------------------------------|--|
| Input | | | | |
| Output | Enabled | boolean | Whether the data is enabled. | |
| C++ | <pre>// class Output_IsMarkerDataEnabled // { // public: // bool Enabled; // }; // Output_IsMarkerDataEnabled IsMarkerDataEnabled() const; ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect("localhost"); Output_IsMarkerDataEnabled Output = MyClient.IsMarkerDataEnabled(); // Output.Enabled == false MyClient.EnableMarkerData(); Output_IsMarkerDataEnabled Output = MyClient.IsMarkerDataEnabled(); // Output.Enabled == true</pre> | | | |
| MATLAB | <pre>% [Output] = IsMarkerDataEnabled() MyClient = Client(); MyClient.Connect("localhost"); Output = MyClient.IsMarkerDataEnabled(); % Output.Enabled == false MyClient.EnableMarkerData(); Output = MyClient.IsMarkerDataEnabled(); % Output.Enabled == true</pre> | | | |
| .NET | <pre>// public class Output_IsMarkerDataEnabled // { public bool Enabled; // }; // Output_IsMarkerDataEnabled IsMarkerDataEnabled(); ViconDataStreamSDK.DotNET.Client MyClient = new ViconDataStreamSDK.DotNET.Client(); MyClient.Connect("localhost"); Output_IsMarkerDataEnabled Output = MyClient.IsMarkerDataEnabled();</pre> | | | |

SDK Functions Listing

Appendix A: What's New

IsUnlabeledMarkerDataEnabled

Return whether unlabeled marker data is enabled in the DataStream.

See Also: EnableUnlabeledMarkerData, IsSegmentDataEnabled. IsMarkerDataEnabled. IsDeviceDataEnabled

| IsMarkerDataEnabled, IsDeviceDataEnabled | | | |
|--|--|---------|------------------------------|
| Input | | | |
| Output | Enabled | boolean | Whether the data is enabled. |
| C++ | <pre>// class Output_IsUnlabeledMarkerDataEnabled // { // public: // bool Enabled; // }; // // Output_IsUnlabeledMarkerDataEnabled // IsUnlabeledMarkerDataEnabled() const; ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect("localhost"); Output_IsUnlabeledMarkerDataEnabled Output = MyClient.IsUnlabeledMarkerDataEnabled(); // Output.Enabled == false MyClient.EnableUnlabeledMarkerData(); Output_IsUnlabeledMarkerDataEnabled Output = MyClient.IsUnlabeledMarkerDataEnabled(); // Output.Enabled == true</pre> | | |
| MATLAB | <pre>% [Output] = IsUnlabeledMarkerDataEnabled() MyClient = Client(); MyClient.Connect("localhost"); Output = MyClient.IsUnlabeledMarkerDataEnabled(); % Output.Enabled == false MyClient.EnableUnlabeledMarkerData(); Output = MyClient.IsUnlabeledMarkerDataEnabled(); % Output.Enabled == true</pre> | | |
| .NET | <pre>// public class Output_IsUnlabeledMarkerDataEnabled // { // public bool Enabled; // }; // // Output_IsUnlabeledMarkerDataEnabled IsUnlabeledMarkerDataEnabled(); ViconDataStreamSDK.DotNET.Client MyClient = new ViconDataStreamSDK.DotNET.Client(); MyClient.Connect("localhost"); Output_IsUnlabeledMarkerDataEnabled Output =</pre> | | |

SDK Functions Listing

Appendix A: What's New

IsMarkerRayDataEnabled

Return whether unlabeled marker data is enabled in the DataStream.

See Also: EnableMarkerRayData, IsSegmentDataEnabled. IsMarkerDataEnabled. IsDeviceDataEnabled

| IsMarkerDataEnabled, IsDeviceDataEnabled | | | |
|--|--|---------|------------------------------|
| Input | | | |
| Output | Enabled | boolean | Whether the data is enabled. |
| C++ | <pre>// class Output_IsMarkerRayDataEnabled // { // public: // bool Enabled; // }; // // Output_IsMarkerRayDataEnabled // IsMarkerRayDataEnabled() const; ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect("localhost"); Output_IsMarkerRayDataEnabled Output =</pre> | | |
| MATLAB | % [Output] = IsMarkerRayDataEnabled() | | |
| | <pre>MyClient = Client(); MyClient.Connect("localhost"); Output = MyClient.IsMarkerRayDataEnabled(); % Output.Enabled == false MyClient.EnableMarkerRayData(); Output = MyClient.IsMarkerRayDataEnabled(); % Output.Enabled == true</pre> | | |
| .NET | <pre>// public class Output_IsMarkerRayDataEnabled // {</pre> | | |

SDK Functions Listing

Appendix A: What's New

IsDeviceDataEnabled

Return whether ForcePlate, EMG, and other device data is enabled in the data stream.

See Also: EnableDeviceData, DisableDeviceData, IsSegmentDataEnabled. IsMarkerDataEnabled.

See Also: EnableDeviceData, DisableDeviceData, IsSegmentDataEnabled. IsMarkerDataEnabled, IsUnlabeledMarkerDataEnabled

| Input | | | | |
|--------|---|---|------------------------------|--|
| Output | Enabled | boolean | Whether the data is enabled. | |
| C++ | <pre>// class Output_IsDeviceDataEnabled // { // public: // bool Enabled; // }; // Output_IsDeviceDataEnabled IsDeviceDataEnabled() const;</pre> | | | |
| | MyClient.Connect(Output_IsDeviceDaMyClient.EnableDe | <pre>mSDK::CPP::Client MyClient; ct("localhost"); eDataEnabled Output = MyClient.IsDeviceDataEnabled();</pre> | | |
| MATLAB | <pre>% [Output] = IsDeviceDataEnabled() MyClient = Client(); MyClient.Connect("localhost"); Output = MyClient.IsDeviceDataEnabled(); % Output.Enabled == false MyClient.EnableDeviceData(); Output = MyClient.IsDeviceDataEnabled(); % Output.Enabled == true</pre> | | | |
| .NET | <pre>// public class Output_IsDeviceDataEnabled // { // public bool Enabled; // }; // Output_IsDeviceDataEnabled IsDeviceDataEnabled(); ViconDataStreamSDK.DotNET.Client MyClient = new ViconDataStreamSDK.DotNET.Client(); MyClient.Connect("localhost"); Output_IsDeviceDataEnabled Output = MyClient.IsDeviceDataEnabled();</pre> | | | |

SDK Functions Listing

Appendix A: What's New

IsCentroidDataEnabled

Return whether Centroid data is enabled in the data stream. See Also: EnableCentroidData, DisableCentroidData Input Output Enabled Whether the data is enabled. boolean // class Output IsCentroidDataEnabled C++ // { // public: // bool Enabled; // }; // Output IsCentroidDataEnabled IsCentroidDataEnabled () const; ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect("localhost"); Output IsCentroidDataEnabled Output = MyClient.IsCentroidDataEnabled // Output.Enabled == false MyClient.EnableCentroidData(); Output IsCentroidDataEnabled Output = MyClient.IsCentroidDataEnabled (); // Output.Enabled == true % [Output] = IsCentroidDataEnabled () **MATLAB** MyClient = Client();
MyClient.Connect("localhost"); Output = MyClient.IsCentroidDataEnabled (); % Output.Enabled == false MyClient.EnableCentroidData(); Output = MyClient.IsCentroidDataEnabled (); % Output.Enabled == true // public class Output IsCentroidDataEnabled .NET // { public bool Enabled; // }; // // Output IsCentroidDataEnabled IsCentroidDataEnabled (); ViconDataStreamSDK.DotNET.Client MyClient = new ViconDataStreamSDK.DotNET.Client(); MyClient.Connect("localhost"); Output IsCentroidDataEnabled Output = MyClient.IsCentroidDataEnabled // Output.Enabled == false MyClient.EnableCentroidData(); Output IsCentroidDataEnabled Output = MyClient.IsCentroidDataEnabled (); // Output.Enabled == true



SDK Functions Listing

Appendix A: What's New

SetBufferSize

Set the number of frames the client should buffer.

The default value is 1, which always supplies the latest frame.

Choose a higher number to reduce the risk of missing frames between calls to GetFrame. Higher numbers may introduce latency when frames are late.

See: GetFrame

| Input | BufferSize | Integer | The maximum number of frames to buffer. |
|-------|--|---------|---|
| C++ | <pre>ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect("localhost"); MyClient.SetBufferSize(10);</pre> | | |

SDK Functions Listing

Appendix A: What's New

SetStreamMode

There are three modes that the SDK can operate in. Each mode has a different impact on the Client, Server, and network resources used.

- In "ServerPush" mode, the Server pushes every new frame of data over the network to the Client. The Server will try not to drop any frames. This results in the lowest latency we can achieve. If the Client is unable to read data at the rate it is being sent, then it is buffered, firstly in the Client, then on the TCP/IP connection, and then at the Server. Once all buffers have filled up then frames may be dropped at the Server and the performance of the Server may be affected. The GetFrame() method will return the most recently received frame if available, or block the calling thread if the most recently received frame has already been processed.
- In "ClientPull" mode, the Client waits for a call to GetFrame(), and then request the latest frame of data from the Server. This increases latency, because we need to send a request over the network to the Server, the Server has to prepare the frame of data for the Client, and then we need to send the data back over the network. Network bandwidth is kept to a minimum, because the Server only sends what you need. We are very unlikely to fill up our buffers, and Server performance is unlikely to be affected. The GetFrame() method blocks the calling thread until the frame has been received.
- "ClientPullPreFetch" is an enhancement to "ClientPull" mode. A thread in the SDK continuously and preemptively does a "ClientPull" on your behalf, storing the latest requested frame in memory. When you next call GetFrame(), the SDK returns the last requested frame which we had cached in memory. GetFrame() does not need to block the calling thread. As with normal "ClientPull", buffers are unlikely to fill up, Server performance is unlikely to be affected. Latency is slightly reduced, but network traffic may increase if we request frames on behalf of the Client which are never used.

The stream defaults to "ClientPull" mode as this is considered the safest option. If performance is a problem, then try "ClientPullPreFetch" followed by "ServerPush".

See Also: GetFrame, GetLatencyTotal

| Input | Mode | StreamMode | StreamMode.ServerPush StreamMode.ClientPull StreamMode.ClientPullPreFetch |
|--------|---|------------|---|
| Output | Result | Result | Result.Success Result.NotConnected |
| C++ | <pre>// class Output_SetStreamMode // { // public: // Result::Enum Result; // }; // Output_SetStreamMode SetStreamMode(const StreamMode::Enum Mode); ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect("localhost"); MyClient.SetStreamMode(ViconDataStreamSDK::CPP::StreamMode::ServerPush); MyClient.SetStreamMode(ViconDataStreamSDK::CPP::StreamMode::ClientPull); MyClient.SetStreamMode(ViconDataStreamSDK::CPP::StreamMode::ClientPull);</pre> | | |
| MATLAB | <pre>% [Output] = SetStreamMode(Mode); MyClient = Client(); MyClient.Connect('localhost'); MyClient.SetStreamMode(StreamMode.ServerPush); MyClient.SetStreamMode(StreamMode.ClientPull); MyClient.SetStreamMode(StreamMode.ClientPullPreFetch);</pre> | | |



SDK Functions Listing

Appendix A: What's New

SDK Functions Listing

Appendix A: What's New

SetAxisMapping

Remaps the 3D axis.

Vicon Data uses a right handed co-ordinate system, with +X forward, +Y left, and +Z up. Other systems use different co-ordinate systems. The SDK can transform its data into any valid right-handed co-ordinate system by re-mapping each axis.

Specify the direction of your X, Y, and Z axis relative to yourself as the observer. Valid directions are "Up", "Down", "Left", "Right", "Forward", and "Backward". Note that "Forward" means moving away from you, and "Backward" is moving towards you.

Common usages are

- Z-up : SetAxisMapping(Forward, Left, Up)
- Y-up: SetAxisMapping(Forward, Up, Right)

See Also: GetAxisMapping

| Y | KAxis YAxis | Direction | |
|----------|---|------------------------------------|--|
| | YAxis | Direction | |
| Z | | | |
| | ZAxis | Direction | |
| Output R | Result | Result | Result.Success Result.CoLinearAxes Result.LeftHandedAxes |
| V | <pre>// class Output_SetAxisMapping // { // public: // Result::Enum Result; // }; // Output_SetAxisMapping SetAxisMapping(const Direction::Enum XAxis,</pre> | | |
| WATLAB 8 | <pre>% [Output] = SetAxisMapping(XAxis,</pre> | | |
| .NET // | <pre>// { // public Result // }; // Output_SetAxis // // Output_SetAxis</pre> | Mapping SetAxisMapping(Dir Dir | ection XAxis, ection YAxis, ection ZAxis); |



| About the SDK | SDK Functions Listing | Appendix A: What's New |
|---------------|--|--|
| MyClient.Se | tAxisMapping(ViconDataStreamSDI ViconDataStreamSDI | StreamSDK.DotNET.Client(); K.DotNET.Direction.Forward, K.DotNET.Direction.Left, K.DotNET.Direction.Up); |



SDK Functions Listing

Appendix A: What's New

GetAxisMapping

```
Get the current Axis mapping.
See Also: SetAxisMapping
Input
               XAxis
Output
                                 Direction
               YAxis
                                 Direction
               ZAxis
                                 Direction
               // class Output GetAxisMapping
C++
               // public:
               // Direction::Enum XAxis;
// Direction::Enum YAxis;
               // Direction::Enum ZAxis;
               // };
               // Output GetAxisMapping GetAxisMapping() const;
               ViconDataStreamSDK::CPP::Client MyClient;
               Output_GetAxisMapping Output = MyClient.GetAxisMapping();
                 // Output.XAxis == ViconDataStreamSDK::CPP::Direction::Forward
                 // Output.YAxis == ViconDataStreamSDK::CPP::Direction::Left
                 // Output.ZAxis == ViconDataStreamSDK::CPP::Direction::Up
               % [Output] = GetAxisMapping()
MATLAB
               MyClient = Client();
               Output = MyClient.GetAxisMapping();
                 % Output.XAxis == Direction.Forward
                 % Output.YAxis == Direction.Left
                 % Output.ZAxis == Direction.Up
               // public class Output_GetAxisMapping
.NET
                  public Direction XAxis;
               // public Direction YAxis;
              // public Direction ZAxis;
// );
               // Output GetAxisMapping GetAxisMapping();
               ViconDataStreamSDK.DotNET.Client MyClient =
                                            new ViconDataStreamSDK.DotNET.Client();
               Output GetAxisMapping Output = MyClient.GetAxisMapping();
                // Output.XAxis == ViconDataStreamSDK.DotNET.Direction.Forward
                 // Output.YAxis == ViconDataStreamSDK.DotNET.Direction.Left
                 // Output.ZAxis == ViconDataStreamSDK.DotNET.Direction.Up
```

SDK Functions Listing

Appendix A: What's New

GetFrame

Reguest a new frame to be fetched from the Vicon DataStream Server. See Also: SetStreamMode Input Result.Success Output Result Result Result.NotConnected // class Output GetFrame C++ // { // public: // Result::Enum Result; // }; // Output GetFrame GetFrame(); ViconDataStreamSDK::CPP::Client MyClient; Output GetFrame Output; Output = MyClient.GetFrame(); // Output.Result == NotConnected MyClient.Connect("localhost"); Output = MyClient.GetFrame(); // Output.Result == Success % [Output] = GetFrame() **MATLAB** MyClient = Client(); Output = MyClient.GetFrame(); // Output.Result == NotConnected
MyClient.Connect("localhost"); Output = MyClient.GetFrame(); // Output.Result == Success // public class Output GetFrame .NET // public Result Result; // }; // Output GetFrame GetFrame(); ViconDataStreamSDK.DotNET.Client MyClient = new ViconDataStreamSDK.DotNET.Client(); Output_GetFrame Output; Output = MyClient.GetFrame(); // Output.Result == NotConnected MyClient.Connect("localhost"); Output = MyClient.GetFrame(); // Output.Result == Success

SDK Functions Listing

Appendix A: What's New

GetFrameNumber

Return the number of the last frame retrieved from the DataStream. See Also: GetFrame, GetTimecode Input Result.Success Output Result Result Result NotConnected Result.NoFrame Frame Number unsigned integer The frame number // class Output_GetFrameNumber C++// public: // Result::Enum Result; unsigned int FrameNumber; // }; // // Output_GetFrameNumber GetFrameNumber() const; ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect("localhost"); Output GetFrameNumber Output; Output = MyClient.GetFrameNumber(); // Output.Result == NoFrame // Output.FrameNumber == 0 MyClient.GetFrame(); Output = MyClient.GetFrameNumber(); // Output.Result == Success // Output.FrameNumber >= 1 % [Output] = GetFrameNumber() **MATLAB** MyClient = Client(); MyClient.Connect("localhost"); Output = MyClient.GetFrameNumber(); % Output.Result == NoFrame % Output.FrameNumber == 0 MyClient.GetFrame(); Output = MyClient.GetFrameNumber(); % Output.Result == Success % Output.FrameNumber >= 1 // class Output_GetFrameNumber .NET // { // public Result Result; public uint FrameNumber; // }; // Output GetFrameNumber GetFrameNumber(); ViconDataStreamSDK.DotNET.Client MyClient = new ViconDataStreamSDK.DotNET.Client(); MyClient.Connect("localhost"); Output GetFrameNumber Output; Output = MyClient.GetFrameNumber(); // Output.Result == NoFrame // Output.FrameNumber == 0 MyClient.GetFrame(); Output = MyClient.GetFrameNumber(); // Output.Result == Success // Output.FrameNumber >= 1

SDK Functions Listing

Appendix A: What's New

GetLatencyTotal

Return the total latency in seconds introduced at various stages of the real-time pipeline. If no latency information is available then all latencies will be reported as 0.0.

See Also: GetFrame, GetTimecode, GetLatencySampleCount, GetLatencySampleName, GetLatencySampleValue

| | 1 | | Т |
|--------|--|--------|---|
| Input | | | |
| Output | Result | Result | Result.Success Result.NotConnected Result.NoFrame |
| | Total | double | The total latency in seconds made from summing the other latencies. |
| C++ | <pre>// class Output_GetLatencyTotal // { // public: // Result::Enum Result; // double Total; // }; // // Output_GetLatencyTotal GetLatencyTotal() const; ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect("localhost"); MyClient.GetFrame(); Output GetLatencyTotal Output = MyClient.GetLatencyTotal();</pre> | | |
| MATLAB | <pre>% [Output] = GetLatencyTotal() MyClient = Client(); MyClient.Connect('localhost'); MyClient.GetFrame(); Output = MyClient.GetLatencyTotal();</pre> | | |
| .NET | <pre>// class Output_GetLatencyTotal // {</pre> | | |

SDK Functions Listing

Appendix A: What's New

GetLatencySampleCount

Return the number of latency measurements that were taken at various stages of the real-time pipeline. This value can be passed into GetLatencySampleName().

See Also: GetFrame, GetTimecode, GetLatencyTotal, GetLatencySampleName, GetLatencySampleValue

| Input | | | | | |
|--------|--|--------------|---|--|--|
| Output | Result | Result | Result.Success Result.NotConnected Result.NoFrame | | |
| | Count | unsigned int | The number of samples taken. | | |
| C++ | <pre>// class Output_GetLatencySampleCount // { // public: // Result::Enum Result; // unsigned int Count; // }; // // Output_GetLatencySampleCount GetLatencySampleCount() const; ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect("localhost"); MyClient.GetFrame(); Output GetLatencySampleCount Output = MyClient.GetLatencySampleCount();</pre> | | | | |
| MATLAB | <pre>% [Output] = GetLatencySampleCount() MyClient = Client(); MyClient.Connect('localhost'); MyClient.GetFrame(); Output = MyClient.GetLatencySampleCount();</pre> | | | | |
| .NET | <pre>// class Output_GetLatencySampleCount // { public Result Result; public uint Count; // }; // Output_GetLatencySampleCount GetLatencySampleCount(); ViconDataStreamSDK.DotNET.Client MyClient =</pre> | | | | |

SDK Functions Listing

Appendix A: What's New

GetLatencySampleName

Return the name of a latency sample. This value can be passed into GetLatencySampleValue(). See Also: GetFrame, GetTimecode, GetLatencyTotal, GetLatencySampleCount, GetLatencySampleValue

| Getzatorioy Gampie value | | | | |
|--------------------------|--|--------------|---|--|
| Input | LatencySampleIndex | Unsigned int | The index of the name. | |
| Output | Result | Result | Result.Success Result.NotConnected Result.NoFrame Result.InvalidIndex | |
| | Name | string | The name of the latency sample. | |
| C++ | A valid Latency Sample Index is between 0 and GetLatencySampleCount()-1 // class Output_GetLatencySampleName // { // public: // Result::Enum Result; // String Name; // }; // Output_GetLatencySampleName // GetLatencySampleName(const unsigned int LatencySampleIndex) const; ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect("localhost"); MyClient.GetFrame(); Output_GetLatencySampleName Output = MyClient.GetLatencySampleName(0); // Output.Name == "Data Collected" | | | |
| MATLAB | A valid Latency Sample Index is between 1 and GetLatencySampleCount() % [Output] = GetLatencySampleName() MyClient = Client(); MyClient.Connect('localhost'); MyClient.GetFrame(); Output = MyClient.GetLatencySampleName(1); % Output.Name == 'Data Collected' | | | |
| .NET | A valid Latency Sample Index is between 0 and GetLatencySampleCount()-1 // class Output_GetLatencySampleName // public Result Result; // public string Name; // }; // Output_GetLatencySampleName // GetLatencySampleName(uint LatencySampleIndex); ViconDataStreamSDK.DotNET.Client MyClient = | | | |

SDK Functions Listing

Appendix A: What's New

GetLatencySampleValue

Return the duration of a named latency sample in seconds. This value can be passed into GetLatencySampleValue().

See Also: GetFrame, GetTimecode, GetLatencyTotal, GetLatencySampleCount, GetLatencySampleValue

| Input | LatencySampleName | string | The name of the latency sample. |
|--------|--|--------|---|
| Output | Result | Result | Result.Success Result.NotConnected Result.NoFrame Result.InvalidLatencySampleName |
| | Value | double | The duration of the latency in seconds. |
| C++ | <pre>// class Output_GetLatencySampleValue // { // public: // Result::Enum Result; // double Value; // }; // Output_GetLatencySampleValue // GetLatencySampleValue (const String & LatencySampleName) const; ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect("localhost"); MyClient.GetFrame(); Output_GetLatencySampleValue Output = MyClient.GetLatencySampleValue("Data Collected"); // Output.Value == 0.1</pre> | | |
| MATLAB | <pre>% [Output] = GetLatencySampleValue() MyClient = Client(); MyClient.Connect('localhost'); MyClient.GetFrame(); Output = MyClient.GetLatencySampleValue('Data Collected'); % Output.Value == 0.1</pre> | | |
| .NET | <pre>// class Output_GetLatencySampleValue // {</pre> | | |

SDK Functions Listing

Appendix A: What's New

GetTimecode

Return the timecode information for the last frame retrieved from the DataStream. If the stream is valid but timecode is not available the Output will be Result.Success and the Standard will be None.

See Also: GetFrame, GetFrameNumber

| GCC AISO . GCLI Tamer amber | | | | |
|-----------------------------|---|---|---|--|
| Input | | | | |
| Output | Result | Result | Result.Success Result.NotConnected Result.NoFrame | |
| | Hours | Unsigned integer | | |
| | Minutes | Unsigned integer | | |
| | Seconds | Unsigned integer | | |
| | Frames | Unsigned integer | | |
| | SubFrame | Unsigned integer | | |
| | FieldFlag | Boolean | | |
| | Standard | TimecodeStandard | None PAL NTSC NTSCDrop Film | |
| | SubFramesPerFrame | Unsigned integer | | |
| | UserBits | Unsigned integer | | |
| C++ | <pre>// unsigned int // unsigned int // }; //</pre> | Result; Hours; Minutes; Seconds; Frames; SubFrame; FieldFlag; d::Enum Standard; SubFramesPerFrame; UserBits; de GetTimecode() const; | | |



About the SDK SDK Functions Listing Appendix A: What's New

```
ViconDataStreamSDK::CPP::Client MyClient;
             MyClient.Connect( "localhost" );
             MyClient.GetFrame();
             Output GetTimecode Output = MyClient.GetTimecode();
             % [Output] = GetTimecode()
MATLAB
             MyClient = Client();
             MyClient.Connect( "localhost" );
             MyClient.GetFrame();
             Output = MyClient.GetTimecode();
             // class Output GetTimecode
.NET
             // {
             //
                 public Result
                                        Result:
             //
                 public uint
                                        Hours;
                public uint
public uint
                                       Minutes;
Seconds;
             //
             //
                                       Frames;
             //
                 public uint
             //
                //
             //
                 public TimecodeStandard Standard;
             //
                 public uint SubFramesPerFrame;
                 public uint
             //
                                        UserBits;
             // };
             // Output GetTimecode GetTimecode();
             ViconDataStreamSDK.DotNET.Client MyClient =
                                         new ViconDataStreamSDK.DotNET.Client();
             MyClient.Connect( "localhost" );
             MyClient.GetFrame();
             Output_GetTimecode Output = MyClient.GetTimecode();
```

SDK Functions Listing

Appendix A: What's New

GetFrameRate

Return the Vicon camera system frame rate (in Hz) at the time of the last frame retrieved from the DataStream.

| See Also : GetFrame, GetFrameNumber, GetTimecode | | | | |
|--|--|---|---|--|
| Input | | | | |
| Output | Result | Result | Result.Success Result.NotConnected Result.NoFrame | |
| | FrameRateHz | double | | |
| C++ | <pre>// { // public: // Result::Enum // double // }; // // Output_GetFrame ViconDataStreamSDE MyClient.Connect(MyClient.GetFrame</pre> | <pre>// public: // Result::Enum Result; // double FrameRateHz; // };</pre> | | |
| MATLAB | MyClient = Client MyClient.Connect(MyClient.GetFrame | <pre>% [Output] = GetFrameRate() MyClient = Client(); MyClient.Connect("localhost"); MyClient.GetFrame(); Output = MyClient.GetFrameRate ();</pre> | | |
| .NET | <pre>// class Output_GetTimecode // { // public Result Result; // public double FrameRateHz; // }; // // Output_GetFrameRate GetFrameRate (); ViconDataStreamSDK.DotNET.Client MyClient =</pre> | | | |

SDK Functions Listing

Appendix A: What's New

GetSubjectCount

Return the number of subjects in the DataStream. This information can be used in conjunction with GetSubjectName

| GetSubjectN See Also : G | GetSubjectName | | | |
|-----------------------------|---|--|---|--|
| Input | | | | |
| Output | Result | Result | Result.Success Result.NotConnected Result.NoFrame | |
| | Subject Count | unsigned integer | The number of subjects | |
| C++ | <pre>// { // public: // Result::Enum // unsigned int // }; // // Output_GetSubj ViconDataStreamSI MyClient.Connect Output_GetSubject Output = MyClient MyClient.GetFrame</pre> | <pre>// public: // Result::Enum Result; // unsigned int SubjectCount; // };</pre> | | |
| MATLAB | MyClient = Client MyClient.Connect Output = MyClient MyClient.GetFrame | <pre>% [Output] = GetSubjectCount() MyClient = Client(); MyClient.Connect('localhost'); Output = MyClient.GetSubjectCount(); % Output.Result == NoFrame</pre> | | |
| .NET | <pre>// { // public Resul // public uint // }; // // Output_GetSubj // // Output_GetSubj ViconDataStreamSI MyClient.Connect of Output_GetSubject Output = MyClient MyClient.GetFrame</pre> | <pre>// public Result Result; // public uint SubjectCount; // }; // Output_GetSubjectCount GetSubjectCount();</pre> | | |

SDK Functions Listing

Appendix A: What's New

GetSubjectName

Return the name of a subject. This can be passed into segment and marker functions.

See Also: GetSubjectCount

| Input | Subject Index | unsigned integer | The index of the subject. |
|--------|---------------|------------------|---|
| Output | Result | Result | Result.Success Result.NotConnected Result.NoFrame Result.InvalidIndex |
| | Subject Name | string | The name of the subject |

C++ A valid Subject Index is between 0 and GetSubjectCount()-1

```
// class Output GetSubjectName
// {
// public:
// Result::Enum Result;
// String SubjectName;
// };
//
// Output GetSubjectName GetSubjectName(
                          const unsigned int SubjectIndex ) const;
ViconDataStreamSDK::CPP::Client MyClient;
MyClient.Connect( "localhost" );
MyClient.GetFrame();
Output GetSubjectCount OutputGSC;
OutputGSC = MyClient.GetSubjectCount(); // OutputGSC.Result == Success
                                         // OutputGSC.SubjectCount == 2
Output GetSubjectName OutputGSN;
OutputGSN = MyClient.GetSubjectName(0);// OutputGSN.Result == Success
                                        // OutputGSN.SubjectName == "Al"
OutputGSN = MyClient.GetSubjectName(1);// OutputGSN.Result == Success
                                        // OutputGSN .SubjectName ==
"Bob"
OutputGSN = MyClient.GetSubjectName(2);// OutputGSN.Result ==
InvalidIndex
                                        // OutputGSN.SubjectName == ""
```

MATLAB

A valid Subject Index is between 1 and GetSubjectCount()

SDK Functions Listing

Appendix A: What's New

.NET

A valid Subject Index is between 0 and GetSubjectCount()-1

```
// public class Output GetSubjectName
// public Result Result;
// public string SubjectName;
// };
// Output_GetSubjectName GetSubjectName( uint SubjectIndex );
ViconDataStreamSDK.DotNET.Client MyClient =
                              new ViconDataStreamSDK.DotNET.Client();
MyClient.Connect( "localhost" );
MyClient.GetFrame();
Output_GetSubjectCount OutputGSC;
OutputGSC = MyClient.GetSubjectCount(); // OutputGSC.Result == Success
                                         // OutputGSC.SubjectCount == 2
Output GetSubjectName OutputGSN;
OutputGSN = MyClient.GetSubjectName(0);// OutputGSN.Result == Success
                                        // OutputGSN.SubjectName == "Al"
OutputGSN = MyClient.GetSubjectName(1);// OutputGSN.Result == Success
                                        // OutputGSN .SubjectName ==
"Bob"
OutputGSN = MyClient.GetSubjectName(2);// OutputGSN.Result ==
InvalidIndex
                                        // OutputGSN.SubjectName == ""
```

SDK Functions Listing

Appendix A: What's New

GetSubjectRootSegmentName

Return the name of the root segment for a specified subject. This can be passed into segment functions. The root segment is the ancestor of all other segments in the subject.

See Also: GetSegmentCount, GetSegmentParentName, GetSegmentChildCount, GetSegmentChildName

| Input | Subject Name | string | The name of the subject |
|--------|--|--------|---|
| Output | Result | Result | Result.Success Result.NotConnected Result.NoFrame Result.InvalidSubjectName |
| | Segment Name | string | The name of the root segment |
| C++ | <pre>// class Output_GetSubjectRootSegmentName // { // public: // Result::Enum Result; // String SegmentName; // }; // Output_GetSubjectRootSegmentName GetSubjectRootSegmentName(// const String & SubjectName) const ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect("localhost"); MyClient.EnableSegmentData(); MyClient.GetFrame(); Output_GetSubjectRootSegmentName Output; Output = MyClient.GetSubjectRootSegmentName("Bob");</pre> | | |
| MATLAB | <pre>% [Output] = GetSubjectRootSegmentName(SubjectName) MyClient = Client(); MyClient.Connect("localhost"); MyClient.EnableSegmentData(); MyClient.GetFrame(); Output = MyClient.GetSubjectRootSegmentName("Bob");</pre> | | |
| .NET | <pre>// public class Output_GetSubjectRootSegmentName // { public Result Result; public string SegmentName; // }; // Output_GetSubjectRootSegmentName GetSubjectRootSegmentName(</pre> | | |



About the SDK SDK Functions Listing Appendix A: What's New

SDK Functions Listing

Appendix A: What's New

GetSegmentCount

Return the number of segments for a specified subject in the DataStream. This information can be used in conjunction with GetSegmentName

See Also: GetSubjectName, GetSegmentName

| Input | Subject Name | string | The name of the subject | | | | |
|--------|---|--|--|--|--|--|--|
| Output | Result | Result | Result.Success Result.NotConnected Result.NoFrame Result.InvalidSubjectName | | | | |
| | Segment Count | unsigned integer | The number of segments | | | | |
| C++ | <pre>// { // public: // Result::Enum // unsigned int // }; // // Output_GetSegm // ViconDataStreamSI MyClient.EnableSe MyClient.Connect() Output GetSegment</pre> | <pre>// public: // Result::Enum Result; // unsigned int SegmentCount; // }; // Output_GetSegmentCount GetSegmentCount(</pre> | | | | | |
| | _ | <pre>Output = MyClient.GetSegmentCount("Bob"); // Output.Result == NoFrame</pre> | | | | | |
| | InvalidSubjectNam | ne | // Output.SegmentCount == 0 | | | | |
| | Output = MyClient | | <pre>// Output.Result == Success // Output.SegmentCount >= 0</pre> | | | | |
| MATLAB | <pre>% [Output] = GetSegmentCount(SubjectName) MyClient = Client(); MyClient.EnableSegmentData(); MyClient.Connect("localhost");</pre> | | | | | | |
| | | <pre>Output = MyClient.GetSegmentCount("Bob"); % Output.Result == NoFrame</pre> | | | | | |
| | Output = MyClient InvalidSubjectNam | ne | 8 | | | | |
| | Output = MyClient | c.GetSegmentCount("Bob"); | <pre>% Output.SegmentCount == 0 % Output.Result == Success % Output.SegmentCount >= 0</pre> | | | | |
| .NET | // { | // public class Output_GetSegmentCount | | | | | |

SDK Functions Listing

Appendix A: What's New

SDK Functions Listing

Appendix A: What's New

GetSegmentName

Return the name of a subject segment specified by index.

See Also: GetSegmentCount, GetSegmentChildCount, GetSegmentChildName, GetSubjectRootSegmentName

| Getsubjecti | RootSegmentName | , | | |
|-------------|--|---|---|--|
| Input | Subject Name | string | The name of the subject | |
| | Segment Index | unsigned int | The index of the segment | |
| Output | Result | Result | Result.Success Result.NotConnected Result.NoFrame Result.InvalidSubjectName Result.InvalidIndex | |
| | Segment Name | string | The name of the parent segment or an empty string if it is the root segment. | |
| C++ | <pre>// { // public: // Result::Enu // String // }; // // Output_GetSeg // // ViconDataStreamS MyClient.Connect MyClient.EnableS MyClient.GetFram Output_GetSegmen // SegmentIndex</pre> | <pre>// public: // Result::Enum Result; // String SegmentName; // }; // Output_GetSegmentName GetSegmentName(// const String & SubjectName,</pre> | | |
| MATLAB | MyClient = Clien MyClient.Connect MyClient.EnableS MyClient.GetFram % SegmentIndex s | <pre>% [Output] = GetSegmentName(SubjectName, SegmentIndex) MyClient = Client(); MyClient.Connect("localhost"); MyClient.EnableSegmentData(); MyClient.GetFrame(); % SegmentIndex should be between 1 and GetSegmentCount() Output = MyClient.GetSegmentName("Bob", 1);</pre> | | |
| .NET | <pre>// { // public Resu // public unsi // }; // // Output_GetSeg // //</pre> | <pre>// public Result Result; // public unsiged int SegmentIndex; // }; // Output_GetSegmentName GetSegmentName(// string SubjectName,</pre> | | |



About the SDK SDK Functions Listing Appendix A: What's New

```
MyClient.Connect( "localhost" );
MyClient.EnableSegmentData();
MyClient.GetFrame();

Output_GetSegmentParentName Output;

// SegmentIndex should be between 0 and GetSegmentCount() - 1
Output = MyClient.GetSegmentName( "Bob", 0 );
```

SDK Functions Listing

Appendix A: What's New

GetSegmentChildCount

Return the name of a child segment for a specified subject segment. This can be passed into segment functions.

See Also: GetSegmentCount

| Input | Subject Name | string | The name of the subject |
|--------|---------------|------------------|---|
| | Segment Name | string | The name of the parent segment. |
| | Segment Index | unsigned integer | The index of the child segment. |
| Output | Result | Result | Result.Success Result.NotConnected Result.NoFrame Result.InvalidSubjectName Result.InvalidSegmentName Result.InvalidIndex |
| | Segment Name | string | The name of the child segment |
| | | | _ |

C++ A valid Segment Index is between 0 and GetSegmentChildCount()-1

```
// class Output GetSegmentChildName
// {
// public:
   Result::Enum Result;
//
//
    String
                SegmentName;
// };
11
// Output GetSegmentChildName GetSegmentName(
11
                      //
                       const unsigned int SegmentIndex ) const
ViconDataStreamSDK::CPP::Client MyClient;
MyClient.Connect( "localhost" );
MyClient.EnableSegmentData();
MyClient.GetFrame();
Output_GetSegmentChildCount OutputGSCC;
OutputGSCC = MyClient.GetSegmentChildCount( "Bob", "Pelvis" );
                          // OutputGSCC.Result == Success
                          // OutputGSCC.SegmentCount == 2
Output GetSegmentChildName OutputGSCN;
OutputGSCN = MyClient.GetSegmentName( "Alice", 0 );
                          // OutputGSN.Result == InvalidSubjectName
                          // OutputGSN.SegmentName == ""
OutputGSCN = MyClient.GetSegmentName( "Bob", "Pelvis", 0 );
                          // OutputGSCN.Result == Success
                          // OutputGSCN.SegmentName == "LFemur"
OutputGSCN = MyClient.GetSegmentName( "Bob", "Pelvis", 1 );
                          // OutputGSCN.Result == Success
                          // OutputGSCN.SegmentName == "RFemur"
OutputGSCN = MyClient.GetSegmentName( "Bob", "Pelvis", 2 );
                          // OutputGSCN.Result == InvalidIndex
                          // OutputGSCN.SegmentName == ""
                          // (no third segment)
```

SDK Functions Listing

Appendix A: What's New

```
MATLAB
              A valid Segment Index is between 1 and GetSegmentChildCount()
               [Output] = GetSegmentChildName( SubjectName, SegmentName, SegmentIndex
             MyClient = Client();
              MyClient.Connect( "localhost" );
              MyClient.EnableSegmentData();
             MyClient.GetFrame();
              OutputGSCC = MyClient.GetSegmentChildCount( "Bob", "Pelvis" );
                                         % OutputGSCC.Result == Success
                                         % OutputGSCC.SegmentCount == 2
              OutputGSCN = MyClient.GetSegmentChildName( "Alice", "Pelvis", 1 );
                                         % OutputGSCN.Result == InvalidSubjectName
                                         % OutputGSCN.SegmentName == ""
              OutputGSCN = MyClient.GetSegmentChildName( "Bob", "Pelvis", 1 );
                                         % OutputGSCN.Result == Success
                                         % OutputGSCN.SegmentName == "LFemur"
              OutputGSCN = MyClient.GetSegmentChildName( "Bob", "Pelvis", 2 );
                                         % OutputGSCN.Result == Success
                                         % OutputGSCN.SegmentName == "RFemur"
              OutputGSCN = MyClient.GetSegmentChildName( "Bob", "Pelvis", 3 );
                                         % OutputGSCN.Result == InvalidIndex
                                         % OutputGSCN.SegmentName == ""
                                         % (no third segment)
.NET
              A valid Segment Index is between 0 and GetSegmentChildCount()-1
              // public class Output GetSegmentChildName
              // {
              //
                  public Result Result;
              //
                 public string SegmentName;
              // };
              // Output GetSegmentChildName GetSegmentChildName( string SubjectName,
              //
                                                                 string SegmentName,
              //
                                                                 uint
                                                                         SegmentIndex
              );
              ViconDataStreamSDK.DotNET.Client MyClient =
                                           new ViconDataStreamSDK.DotNET.Client();
              MyClient.Connect( "localhost" );
             MyClient.EnableSegmentData();
             MyClient.GetFrame();
              Output GetSegmentChildCount OutputGSCC;
              OutputGSCC = MyClient.GetSegmentChildCount( "Bob", "Pelvis" );
                                         // OutputGSCC.Result == Success
                                         // OutputGSCC.SegmentCount == 2
              Output GetSegmentChildName OutputGSCN;
              OutputGSCN = MyClient.GetSegmentChildName( "Alice", "Pelvis", 0 );
                                         // OutputGSCN.Result == InvalidSubjectName
                                         // OutputGSCN.SegmentName == ""
              OutputGSCN = MyClient.GetSegmentChildName( "Bob", "Pelvis", 0 );
                                         // OutputGSCN.Result == Success
                                         // OutputGSCN.SegmentName == "LFemur"
              OutputGSCN = MyClient.GetSegmentChildName( "Bob", "Pelvis", 1 );
                                         // OutputGSCN.Result == Success
                                         // OutputGSCN.SegmentName == "RFemur"
              OutputGSCN = MyClient.GetSegmentChildName( "Bob", "Pelvis", 2 );
                                         // OutputGSCN.Result == InvalidIndex
                                         // OutputGSCN.SegmentName == ""
                                         // (no third segment)
```

SDK Functions Listing

Appendix A: What's New

GetSegmentChildName

Return the name of the child segment for a specified subject segment and index. See Also: GetSegmentCount, GetSegmentChildCount, GetSegmentChildName, GetSubjectRootSegmentName

| GetSubjectRo | GetSubjectRootSegmentName | | | | |
|--------------|---|--------------|---|--|--|
| Input | Subject Name | string | The name of the subject | | |
| | Segment Name | string | The name of the segment | | |
| | Segment Index | unsigned int | The index of the child segment | | |
| Output | Result | Result | Result.Success Result.NotConnected Result.NoFrame Result.InvalidSubjectName Result.InvalidSegmentName Result.InvalidIndex | | |
| | Segment Name | string | The name of the child segment | | |
| C++ | <pre>// class Output_GetSegmentChildName // { // public: // Result::Enum Result; // String</pre> | | | | |
| MATLAB | <pre>% [Output] = GetSegmentChildName(SubjectName, SegmentName) MyClient = Client(); MyClient.Connect("localhost"); MyClient.EnableSegmentData(); MyClient.GetFrame(); // Segment index should be between 1 and GetSegmentChildCount() Output = MyClient.GetSegmentChildName("Bob", "Pelvis", 1);</pre> | | | | |
| .NET | <pre>// public class Output_GetSegmentChildName // {</pre> | | | | |



About the SDK SDK Functions Listing Appendix A: What's New

```
// string SegmentName );

ViconDataStreamSDK.DotNET.Client MyClient = new ViconDataStreamSDK.DotNET.Client();

MyClient.Connect( "localhost" );

MyClient.EnableSegmentData();

MyClient.GetFrame();

Output_GetSegmentChildName Output;

// Segment index should be between 0 and GetSegmentChildCount() - 1
Output = MyClient.GetSegmentChildName( "Bob", "Pelvis", 0 );
```

SDK Functions Listing

Appendix A: What's New

GetSegmentParentName

Return the name of the parent segment for a specified subject segment. If the specified segment is the root segment of the subject then it will return an empty string.

See Also: GetSegmentCount, GetSegmentChildCount, GetSegmentChildName, GetSubjectRootSegmentName

| Input | Subject Name | string | The name of the subject | |
|--------|--|---|---|--|
| | Segment Name | string | The name of the segment | |
| Output | Result | Result | Result.Success Result.NotConnected Result.NoFrame Result.InvalidSubjectName Result.InvalidSegmentName | |
| | Segment Name | string | The name of the parent segment or an empty string if it is the root segment. | |
| C++ | <pre>// { // public: // Result::Enu // String // }; // Output_GetSeg // // ViconDataStreamS MyClient.Connect MyClient.EnableS MyClient.GetFram Output_GetSegmen Output = MyClien</pre> | <pre>// public: // Result::Enum Result; // String SegmentName; // }; // Output_GetSegmentParentName GetSegmentParentName(// const String & SubjectName,</pre> | | |
| MATLAB | MyClient = Clien MyClient.Connect MyClient.EnableS MyClient.GetFram Output = MyClien | <pre>// Output.SegmentName == "Pelvis" % [Output] = GetSegmentParentName(SubjectName, SegmentName) MyClient = Client(); MyClient.Connect("localhost"); MyClient.EnableSegmentData(); MyClient.GetFrame(); Output = MyClient.GetSegmentParentName("Bob", "Pelvis");</pre> | | |
| .NET | // public class // { | <pre>// public class Output_GetSegmentParentName // {</pre> | | |

SDK Functions Listing

Appendix A: What's New

```
public Result Result;
//
    public string SegmentName;
// };
//
// Output GetSegmentParentName GetSegmentParentName(
//
                                           string SubjectName,
//
                                           string SegmentName );
ViconDataStreamSDK.DotNET.Client MyClient =
                              new ViconDataStreamSDK.DotNET.Client();
MyClient.Connect( "localhost" );
MyClient.EnableSegmentData();
MyClient.GetFrame();
Output GetSegmentParentName Output;
Output = MyClient.GetSegmentParentName( "Bob", "Pelvis");
                            // Output.Result == Success
                            // Output.SegmentName == ""
                            // This is the root segment
Output = MyClient.GetSegmentParentName( "Bob", "LFemur");
// Output.Result == Success
                            // Output.SegmentName == "Pelvis"
```

SDK Functions Listing

Appendix A: What's New

GetSegmentStaticTranslation

Return the static pose translation of a subject segment.

See Also: GetSegmentStaticRotationHelical, GetSegmentStaticRotationMatrix, GetSegmentStaticRotationQuaternion, GetSegmentStaticRotationEulerXYZ, GetSegmentLocalTranslation, GetSegmentLocalRotationHelical, GetSegmentLocalRotationQuaternion, GetSegmentLocalRotationEulerXYZ

| Input | Subject Name string The name of the subject | | | | |
|--------|--|--|---|--|--|
| r | | <u> </u> | , | | |
| | Segment Name | string | The name of the segment. | | |
| Output | Result | Result | Result.Success Result.NotConnected Result.NoFrame Result.InvalidSubjectName Result.InvalidSegmentName | | |
| | Translation | double[3] | The translation of the segment | | |
| C++ | <pre>// { // public: // Result::Enum // double // }; // // Output_GetSegm // const S // const S ViconDataStreamSD MyClient.Connect(MyClient.EnableSe MyClient.GetFrame</pre> | <pre>// public: // Result::Enum Result; // double Translation[3]; // }; // Output_GetSegmentStaticTranslation GetSegmentStaticTranslation(</pre> | | | |
| MATLAB | MyClient = Client MyClient.Connect(MyClient.EnableSe MyClient.GetFrame | <pre>% [Output] = GetSegmentStaticTranslation(SubjectName, SegmentName) MyClient = Client(); MyClient.Connect("localhost"); MyClient.EnableSegmentData(); MyClient.GetFrame(); Output = MyClient.GetSegmentStaticTranslation("Alice", "Pelvis");</pre> | | | |
| .NET | <pre>// { // public Resul // public doubl // }; // // Output_GetSegm // string // string ViconDataStreamSD</pre> | <pre>// public Result Result; // public double[] Translation; // }; // // Output_GetSegmentStaticTranslation GetSegmentStaticTranslation(// string SubjectName,</pre> | | | |



| About the SDK | SDK Functions Listing | Appendix A: What's New |
|---------------|-----------------------|------------------------|
|---------------|-----------------------|------------------------|

```
MyClient.EnableSegmentData();
MyClient.GetFrame();

Output_GetSegmentStaticTranslation Output =
    MyClient.GetSegmentStaticTranslations( "Alice", "Pelvis" );
```

SDK Functions Listing

Appendix A: What's New

GetSegmentStaticRotationHelical

Return the static pose rotation of a subject segment in helical co-ordinates.

The helical co-ordinates represent a vector whose length is the amount of rotation in radians, and the direction is the axis about which to rotate.

See Also: GetSegmentStaticTranslation, GetSegmentStaticRotationMatrix, GetSegmentStaticRotationQuaternion, GetSegmentStaticRotationEulerXYZ, GetSegmentLocalTranslation, GetSegmentLocalRotationHelical, GetSegmentLocalRotationMatrix, GetSegmentLocalRotationQuaternion, GetSegmentLocalRotationEulerXYZ

| Input | Subject Name | string | The name of the subject | |
|--------|--|---|---|--|
| | Segment Name | string | The name of the segment. | |
| Output | Result | Result | Result.Success Result.NotConnected Result.NoFrame Result.InvalidSubjectName Result.InvalidSegmentName | |
| | Rotation | double[3] | The rotation of the segment | |
| C++ | <pre>// { // public: // Result::Enum // double // }; // // Output_GetSegm // GetSegmentSt // const S // const S // WiconDataStreamSI MyClient.Connect(MyClient.GetFrame</pre> | <pre>// public: // Result::Enum Result; // double Rotation[3]; // }; // Output_GetSegmentStaticRotationHelical // GetSegmentStaticRotationHelical(// const String & SubjectName,</pre> | | |
| MATLAB | <pre>% [Output] = GetSegmentStaticRotationHelical(SubjectName, SegmentName) MyClient = Client(); MyClient.Connect("localhost"); MyClient.GetFrame(); Output = MyClient.GetSegmentStaticRotationHelical("Alice", "Pelvis");</pre> | | | |
| .NET | <pre>// public class 0 // { // public Resul // public doubl // }; // // Output_GetSegm // GetSegmentSt //</pre> | <pre>// public Result Result; // public double[] Rotation; // }; // // Output_GetSegmentStaticRotationHelical // GetSegmentStaticRotationHelical(string SubjectName,</pre> | | |



About the SDK SDK Functions Listing Appendix A: What's New

```
new ViconDataStreamSDK.DotNET.Client();
MyClient.Connect( "localhost" );
MyClient.GetFrame();

Output_GetSegmentStaticRotationHelical Output =
    MyClient.GetSegmentStaticRotationHelical( "Alice", "Pelvis" );
```

SDK Functions Listing

Appendix A: What's New

GetSegmentStaticRotationMatrix

Return the static pose rotation of a subject segment as a 3x3 row-major matrix.

See Also: GetSegmentStaticTranslation, GetSegmentStaticRotationHelical, GetSegmentStaticRotationQuaternion, GetSegmentStaticRotationEulerXYZ, GetSegmentLocalTranslation, GetSegmentLocalRotationHelical, GetSegmentLocalRotationQuaternion, GetSegmentLocalRotationEulerXYZ

| Input | Subject Name | string | The name of the subject | |
|--------|---|--|---|--|
| | Segment Name | string | The name of the segment. | |
| Output | Success | Result | Result.Success Result.NotConnected Result.NoFrame Result.InvalidSubjectName Result.InvalidSegmentName | |
| | Rotation | double[9] | The rotation of the segment | |
| C++ | <pre>// { // public: // Result::Enum // double // }; // // Output_GetSegm // GetSegmentSt // const S // const S ViconDataStreamSI MyClient.Connect(MyClient.GetFrame Output_GetSegment</pre> | <pre>// public: // Result::Enum Result; // double Rotation[9]; // }; // Output_GetSegmentStaticRotationMatrix // GetSegmentStaticRotationMatrix(// const String & SubjectName,</pre> | | |
| MATLAB | MyClient = Client MyClient.Connect(MyClient.GetFrame | <pre>% [Output] = GetSegmentStaticRotationMatrix(SubjectName, SegmentName) MyClient = Client(); MyClient.Connect("localhost"); MyClient.GetFrame(); Output = MyClient.GetSegmentStaticRotationMatrix("Alice", "Pelvis");</pre> | | |
| .NET | <pre>// { // public Resul // public doubl // }; // // Output_GetSegm // GetSegmentSt // ViconDataStreamSI MyClient.Connect()</pre> | <pre>// public Result Result; // public double[] Rotation; // }; // // Output_GetSegmentStaticRotationMatrix // GetSegmentStaticRotationMatrix(string SubjectName,</pre> | | |



| About the SDK | SDK Functions Listing | Appendix A: What's New |
|---|-----------------------|------------------------|
| | | |
| Output_GetSegmentStaticRotationMatrix Output = MyClient.GetSegmentStaticRotationMatrix("Alice", "Pelvis"); | | |

SDK Functions Listing

Appendix A: What's New

GetSegmentStaticRotationQuaternion

Return the static pose rotation of a subject segment in quaternion co-ordinates.

The quaternion is of the form (x, y, z, w) where w is the real component and x, y & z are the imaginary components. **N.B. This is different from that used in many other applications, which use (w, x, y, z).**

See Also: GetSegmentStaticTranslation, GetSegmentStaticRotationHelical, GetSegmentStaticRotationMatrix, GetSegmentStaticRotationEulerXYZ, GetSegmentLocalTranslation, GetSegmentLocalRotationHelical, GetSegmentLocalRotationQuaternion, GetSegmentLocalRotationEulerXYZ

| Input | Subject Name | string | The name of the subject |
|--------|---|-----------|---|
| Прис | Cubject Name | Sumg | The hame of the subject |
| | Segment Name | string | The name of the segment. |
| Output | Result | Result | Result.Success Result.NotConnected Result.NoFrame Result.InvalidSubjectName Result.InvalidSegmentName |
| | Rotation | double[4] | The rotation of the segment |
| C++ | <pre>// class Output_GetSegmentStaticRotationQuaternion // { // public: // Result::Enum Result; // double Rotation[4]; // }; // // Output_GetSegmentStaticRotationQuaternion // GetSegmentStaticRotationQuaternion(// const String & SubjectName, // const String & SegmentName) const ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect("localhost"); MyClient.GetFrame(); Output GetSegmentStaticRotationQuaternion Output =</pre> | | |
| MATLAB | <pre>% [Output] = GetSegmentStaticRotationQuaternion(SubjectName, SegmentName) MyClient = Client(); MyClient.Connect("localhost"); MyClient.GetFrame(); Output = MyClient.GetSegmentStaticRotationQuaternion("Alice", "Pelvis");</pre> | | |
| .NET | <pre>// public class Output_GetSegmentStaticRotationQuaternion // {</pre> | | |



About the SDK SDK Functions Listing Appendix A: What's New

SDK Functions Listing

Appendix A: What's New

GetSegmentStaticRotationEulerXYZ

Return the static pose rotation of a subject segment in EulerXYZ co-ordinates.

See Also: GetSegmentStaticTranslation, GetSegmentStaticRotationHelical, GetSegmentStaticRotationMatrix, GetSegmentStaticRotationQuaternion, GetSegmentLocalTranslation, GetSegmentLocalRotationHelical, GetSegmentLocalRotationQuaternion, GetSegmentLocalRotationEulerXYZ

| Input | Subject Name | string | The name of the subject | |
|--------|---|---|---|--|
| | Segment Name | string | The name of the segment. | |
| Output | Result | Result | Result.Success Result.NotConnected Result.NoFrame Result.InvalidSubjectName Result.InvalidSegmentName | |
| | Rotation | double[3] | The rotation of the segment | |
| C++ | <pre>// { // public: // Result::Enum // double // }; // // Output_GetSegm // GetSegmentSt // const S // const S ViconDataStreamSI MyClient.Connect(MyClient.GetFrame</pre> | <pre>// public: // Result::Enum Result; // double Rotation[3]; // }; // Output_GetSegmentStaticRotationEulerXYZ // GetSegmentStaticRotationEulerXYZ(// const String & SubjectName,</pre> | | |
| MATLAB | MyClient = Client MyClient.Connect(MyClient.GetFrame | <pre>MyClient = Client(); MyClient.Connect("localhost"); MyClient.GetFrame(); Output = MyClient.GetSegmentStaticRotationEulerXYZ("Alice", "Pelvis"</pre> | | |
| .NET | <pre>// public class Output_GetSegmentStaticRotationEulerXYZ // { public Result Result; public double[] Rotation; // }; // Output_GetSegmentStaticRotationEulerXYZ // GetSegmentStaticRotationEulerXYZ(string SubjectName,</pre> | | | |



| About the SDK | SDK Functions Listing | Appendix A: What's New |
|---------------------------------|---|------------------------|
| <pre>MyClient.GetFrame();</pre> | | |
| | Output_GetSegmentStaticRotationEulerXYZ Output = MyClient.GetSegmentStaticRotationEulerXYZ("Alice", "Pelvis"); | |

SDK Functions Listing

Appendix A: What's New

GetSegmentGlobalTranslation

Return the translation of a subject segment in global co-ordinates.

The Translation is of the form (x, y, z) where x, y & z are in Millimeters with respect to the global origin.

See Also: GetSegmentGlobalRotationHelical, GetSegmentGlobalRotationMatrix, GetSegmentGlobalRotationQuaternion, GetSegmentGlobalRotationEulerXYZ, GetSegmentLocalTranslation, GetSegmentLocalRotationHelical, GetSegmentLocalRotationQuaternion, GetSegmentLocalRotationEulerXYZ

| | , | | |
|--------|---|-----------|---|
| Input | Subject Name | string | The name of the subject |
| | Segment Name | string | The name of the segment. |
| Output | Result | Result | Result.Success Result.NotConnected Result.NoFrame Result.InvalidSubjectName Result.InvalidSegmentName |
| | Translation | double[3] | The translation of the segment |
| | Occluded | boolean | True if the segment was absent at this frame. In this case the Translation will be [0,0,0] |
| C++ | <pre>// class Output_GetSegmentGlobalTranslation // { // public: // Result::Enum Result; // double Translation[3]; // bool Occluded; // }; // // Output_GetSegmentGlobalTranslation GetSegmentGlobalTranslation(// const String & SubjectName, // const String & SegmentName) const; ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect("localhost"); MyClient.EnableSegmentData(); MyClient.GetFrame(); Output_GetSegmentGlobalTranslation Output = MyClient.GetSegmentGlobalTranslation("Alice", "Pelvis");</pre> | | |
| MATLAB | <pre>% [Output] = GetSegmentGlobalTranslation(SubjectName, SegmentName) MyClient = Client(); MyClient.Connect("localhost"); MyClient.EnableSegmentData(); MyClient.GetFrame(); Output = MyClient.GetSegmentGlobalTranslation("Alice", "Pelvis");</pre> | | |
| .NET | // public class Output_GetSegmentGlobalTranslation // { | | |

SDK Functions Listing

SDK Functions Listing

Appendix A: What's New

GetSegmentGlobalRotationHelical

Return the rotation of a subject segment in global helical co-ordinates.

See Also: GetSegmentGlobalTranslation, GetSegmentGlobalRotationMatrix, GetSegmentGlobalRotationQuaternion, GetSegmentGlobalRotationEulerXYZ, GetSegmentLocalTranslation, GetSegmentLocalRotationHelical, GetSegmentLocalRotationMatrix, GetSegmentLocalRotationQuaternion, GetSegmentLocalRotationEulerXYZ

| Cotoognicine Souli Volution & action of the Cotoognicine Souli Volution Editor X 12 | | | | |
|---|--|---|---|--|
| Input | Subject Name | string | The name of the subject | |
| | Segment Name | string | The name of the segment. | |
| Output | Result | Result | Result.Success Result.NotConnected Result.NoFrame Result.InvalidSubjectName Result.InvalidSegmentName | |
| | Rotation | double[3] | The rotation of the segment | |
| | Occluded | boolean | True if the segment was absent at this frame. In this case the Rotation will be [0,0,0] | |
| C++ | <pre>// { // public: // Result::Enu // double // bool // }; // // Output_GetSeg // GetSegmentG // const // const ViconDataStreamS MyClient.Connect MyClient.GetFram Output_GetSegmen MyClient.GetSegmen MyClient.GetSe</pre> | <pre>// public: // Result::Enum Result; // double Rotation[3]; // bool Occluded; // }; // Output_GetSegmentGlobalRotationHelical // GetSegmentGlobalRotationHelical(// const String & SubjectName,</pre> | | |
| MATLAB | <pre>% [Output] = GetSegmentGlobalRotationHelical(SubjectName, SegmentName) MyClient = Client(); MyClient.Connect("localhost"); MyClient.GetFrame(); Output = MyClient.GetSegmentGlobalRotationHelical("Alice", "Pelvis");</pre> | | | |
| .NET | <pre>// public class Output_GetSegmentGlobalRotationHelical // { // public Result Result; // public double[] Rotation; // public bool Occluded; // }; // Output_GetSegmentGlobalRotationHelical</pre> | | | |



SDK Functions Listing

SDK Functions Listing

Appendix A: What's New

GetSegmentGlobalRotationMatrix

Return the rotation of a subject segment as a 3x3 row-major matrix in global co-ordinates.

See Also: GetSegmentGlobalTranslation, GetSegmentGlobalRotationHelical, GetSegmentGlobalRotationQuaternion, GetSegmentGlobalRotationEulerXYZ, GetSegmentLocalTranslation, GetSegmentLocalRotationHelical, GetSegmentLocalRotationEulerXYZ

| Input | Subject Name | string | The name of the subject |
|--------|--|-----------|---|
| | Segment Name | string | The name of the segment. |
| Output | Success | Result | Result.Success Result.NotConnected Result.NoFrame Result.InvalidSubjectName Result.InvalidSegmentName |
| | Rotation | double[9] | The rotation of the segment |
| | Occluded | boolean | True if the segment was absent at this frame. |
| C++ | <pre>// class Output_GetSegmentGlobalRotationMatrix // { // public: // Result::Enum Result; // double Rotation[9]; // bool Occluded; // }; // // Output_GetSegmentGlobalRotationMatrix // GetSegmentGlobalRotationMatrix(// const String & SubjectName, // const String & SegmentName) const; ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect("localhost"); MyClient.GetFrame(); Output_GetSegmentGlobalRotationMatrix Output = MyClient.GetSegmentGlobalRotationMatrix("Alice", "Pelvis");</pre> | | |
| MATLAB | <pre>% [Output] = GetSegmentGlobalRotationMatrix(SubjectName, SegmentName) MyClient = Client(); MyClient.Connect("localhost"); MyClient.GetFrame(); Output = MyClient.GetSegmentGlobalRotationMatrix("Alice", "Pelvis");</pre> | | |
| .NET | <pre>// public class Output_GetSegmentGlobalRotationMatrix // { public Result Result; public double[] Rotation; public bool Occluded; // }; // Output_GetSegmentGlobalRotationMatrix // GetSegmentGlobalRotationMatrix(string SubjectName,</pre> | | |



About the SDK SDK Functions Listing Appendix A: What's New

SDK Functions Listing

Appendix A: What's New

GetSegmentGlobalRotationQuaternion

Return the rotation of a subject segment in global quaternion co-ordinates.

The quaternion is of the form (x, y, z, w) where w is the real component and x, y & z are the imaginary components. **N.B. This is different from that used in many other applications, which use (w, x, y, z).**

See Also: GetSegmentGlobalTranslation, GetSegmentGlobalRotationHelical, GetSegmentGlobalRotationMatrix, GetSegmentGlobalRotationEulerXYZ, GetSegmentLocalTranslation, GetSegmentLocalRotationHelical, GetSegmentLocalRotationMatrix, GetSegmentLocalRotationQuaternion, GetSegmentLocalRotationEulerXYZ

| Input | Subject Name | string | The name of the subject |
|--------|---|-----------|---|
| | Segment Name | string | The name of the segment. |
| Output | Result | Result | Result.Success Result.NotConnected Result.NoFrame Result.InvalidSubjectName Result.InvalidSegmentName |
| | Rotation | double[4] | The rotation of the segment |
| | Occluded | boolean | True if the segment was absent at this frame. In this case the Rotation will be [0,0,0,0] |
| C++ | <pre>// class Output_GetSegmentGlobalRotationQuaternion // { // public: // Result::Enum Result; // double Rotation[4]; // bool</pre> | | |
| MATLAB | <pre>% [Output] = GetSegmentGlobalRotationQuaternion(SubjectName,</pre> | | |
| .NET | <pre>// public class Output_GetSegmentGlobalRotationQuaternion // {</pre> | | |

SDK Functions Listing

SDK Functions Listing

Appendix A: What's New

GetSegmentGlobalRotationEulerXYZ

Return the rotation of a subject segment in global EulerXYZ co-ordinates.

See Also: GetSegmentGlobalTranslation, GetSegmentGlobalRotationHelical, GetSegmentGlobalRotationMatrix, GetSegmentGlobalRotationQuaternion, GetSegmentLocalTranslation, GetSegmentLocalRotationHelical, GetSegmentLocalRotationQuaternion, GetSegmentLocalRotationEulerXYZ

| Cotoognicinesoun totalion quaternion, Cotoognicinesoun totalion end 772 | | | |
|---|--|-----------|---|
| Input | Subject Name | string | The name of the subject |
| | Segment Name | string | The name of the segment. |
| Output | Result | Result | Result.Success Result.NotConnected Result.NoFrame Result.InvalidSubjectName Result.InvalidSegmentName |
| | Rotation | double[3] | The rotation of the segment |
| | Occluded | boolean | True if the segment was absent at this frame. In this case the Rotation will be [0,0,0] |
| C++ | <pre>// class Output_GetSegmentGlobalRotationEulerXYZ // { // public: // Result::Enum Result; // double Rotation[3]; // bool</pre> | | |
| MATLAB | <pre>% [Output] = GetSegmentGlobalRotationEulerXYZ(SubjectName, SegmentName) MyClient = Client(); MyClient.Connect("localhost"); MyClient.GetFrame(); Output = MyClient.GetSegmentGlobalRotationEulerXYZ("Alice", "Pelvis");</pre> | | |
| .NET | <pre>// public class Output_GetSegmentGlobalRotationEulerXYZ // { // public Result Result; // public double[] Rotation; // public bool Occluded; // }; //</pre> | | |



SDK Functions Listing

SDK Functions Listing

Appendix A: What's New

GetSegmentLocalTranslation

Return the translation of a subject segment in local co-ordinates relative to its parent segment.

See Also: GetSegmentLocalRotationHelical, GetSegmentLocalRotationMatrix, GetSegmentLocalRotationQuaternion, GetSegmentLocalRotationEulerXYZ, GetSegmentGlobalTranslation,GetSegmentGlobalRotationHelical, GetSegmentGlobalRotationMatrix, GetSegmentGlobalRotationQuaternion, GetSegmentGlobalRotationEulerXYZ

| Input | Subject Name | string | The name of the subject |
|--------|--|-----------|---|
| | Segment Name | string | The name of the segment. |
| Output | Result | Result | Result.Success Result.NotConnected Result.NoFrame Result.InvalidSubjectName Result.InvalidSegmentName |
| | Translation | double[3] | The translation of the segment |
| | Occluded | boolean | True if the segment was absent at this frame. In this case the Translation will be [0,0,0] |
| C++ | <pre>// class Output_GetSegmentLocalTranslation // { // public: // Result::Enum Result; // double</pre> | | |
| MATLAB | <pre>% [Output] = GetSegmentLocalTranslation(SubjectName, SegmentName) MyClient = Client(); MyClient.Connect("localhost"); MyClient.EnableSegmentData(); MyClient.GetFrame(); Output = MyClient.GetSegmentLocalTranslation("Alice", "Pelvis");</pre> | | |
| .NET | <pre>// public class Output_GetSegmentLocalTranslation // { // public Result Result; // public double[] Translation; // public bool Occluded; // };</pre> | | |



SDK Functions Listing

SDK Functions Listing

Appendix A: What's New

GetSegmentLocalRotationHelical

Return the rotation of a subject segment in local helical co-ordinates relative to its parent segment.

See Also: GetSegmentLocalTranslation, GetSegmentLocalRotationMatrix, GetSegmentLocalRotationQuaternion, GetSegmentLocalRotationEulerXYZ, GetSegmentGlobalTranslation,GetSegmentGlobalRotationHelical, GetSegmentGlobalRotationMatrix, GetSegmentGlobalRotationQuaternion, GetSegmentGlobalRotationEulerXYZ

| Input | Subject Name | string | The name of the subject |
|--------|---|-----------|---|
| | Segment Name | string | The name of the segment. |
| Output | Result | Result | Result.Success Result.NotConnected Result.NoFrame Result.InvalidSubjectName Result.InvalidSegmentName |
| | Rotation | double[3] | The rotation of the segment |
| | Occluded | boolean | True if the segment was absent at this frame. In this case the Rotation will be [0,0,0] |
| C++ | <pre>// class Output_GetSegmentLocalRotationHelical // { // public: // Result::Enum Result; // double Rotation[3]; // bool Occluded; // }; // // Output_GetSegmentLocalRotationHelical // GetSegmentLocalRotationHelical(// const String & SubjectName, // const String & SegmentName) const ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect("localhost"); MyClient.GetFrame(); Output_GetSegmentLocalRotationHelical Output = MyClient.GetSegmentLocalRotationHelical("Alice", "Pelvis");</pre> | | |
| MATLAB | <pre>% [Output] = GetSegmentLocalRotationHelical(SubjectName, SegmentName) MyClient = Client(); MyClient.Connect("localhost"); MyClient.GetFrame(); Output = MyClient.GetSegmentLocalRotationHelical("Alice", "Pelvis");</pre> | | |
| .NET | <pre>// public class Output_GetSegmentLocalRotationHelical // { // public Result Result; // public double[] Rotation; // public bool Occluded; // }; //</pre> | | |



SDK Functions Listing

SDK Functions Listing

Appendix A: What's New

GetSegmentLocalRotationMatrix

Return the rotation row-major matrix of a subject segment in local co-ordinates relative to its parent segment.

See Also: GetSegmentLocalTranslation, GetSegmentLocalRotationQuaternion, GetSegmentLocalRotationEulerXYZ,

GetSegmentGlobalTranslation,GetSegmentGlobalRotationHelical,

 ${\it GetSegmentGlobalRotationMatrix}\ ,\ {\it GetSegmentGlobalRotationQuaternion},$

GetSegmentGlobalRotationEulerXYZ

| Input | Subject Name | string | The name of the subject |
|--------|--|-----------|---|
| | Segment Name | string | The name of the segment. |
| Output | Result | Result | Result.Success Result.NotConnected Result.NoFrame Result.InvalidSubjectName Result.InvalidSegmentName |
| | Rotation | double[9] | The rotation of the segment |
| | Occluded | boolean | True if the segment was absent at this frame. |
| C++ | <pre>// class Output_GetSegmentLocalRotationMatrix // { // public: // Result::Enum Result; // double Rotation[9]; // bool Occluded; // }; // // Output_GetSegmentLocalRotationMatrix // GetSegmentLocalRotationMatrix (// const String & SubjectName, // const String & SegmentName) const; ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect("localhost"); MyClient.GetFrame(); Output_GetSegmentLocalRotationMatrix Output = MyClient.GetSegmentLocalRotationMatrix("Alice", "Pelvis");</pre> | | |
| MATLAB | <pre>% [Output] = GetSegmentLocalRotationMatrix(SubjectName, SegmentName) MyClient = Client(); MyClient.Connect("localhost"); MyClient.GetFrame(); Output = MyClient.GetSegmentLocalRotationMatrix("Alice", "Pelvis");</pre> | | |
| .NET | <pre>// public class Output_GetSegmentLocalRotationMatrix // { // public Result Result; // public double[] Rotation; // public bool Occluded; // }; //</pre> | | |



SDK Functions Listing

SDK Functions Listing

Appendix A: What's New

GetSegmentLocalRotationQuaternion

Return the rotation of a subject segment in local quaternion co-ordinates relative to its parent segment.

The quaternion is of the form (x, y, z, w) where w is the real component and x, y & z are the imaginary components. **N.B. This is different from that used in many other applications, which use** (w, x, y, z).

See Also: GetSegmentLocalTranslation, GetSegmentLocalRotationHelical, GetSegmentLocalRotationMatrix, GetSegmentLocalRotationEulerXYZ, GetSegmentGlobalTranslation,GetSegmentGlobalRotationHelical, GetSegmentGlobalRotationMatrix, GetSegmentGlobalRotationQuaternion, GetSegmentGlobalRotationEulerXYZ

| | | 1 | T |
|--------|---|-----------|---|
| Input | Subject Name | string | The name of the subject |
| | Segment Name | string | The name of the segment. |
| Output | Result | Result | Result.Success Result.NotConnected Result.NoFrame Result.InvalidSubjectName Result.InvalidSegmentName |
| | Rotation | double[4] | The rotation of the segment |
| | Occluded | boolean | True if the segment was absent at this frame. In this case the Rotation will be [0,0,0,0] |
| C++ | <pre>// class Output_GetSegmentLocalRotationQuaternion // { // public: // Result::Enum Result; // double Rotation[4]; // bool Occluded; // }; // Output_GetSegmentLocalRotationQuaternion // GetSegmentLocalRotationQuaternion(// const String & SubjectName, // const String & SegmentName) const ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect("localhost"); MyClient.GetFrame(); Output_GetSegmentLocalRotationQuaternion Output = MyClient.GetSegmentLocalRotationQuaternion("Alice", "Pelvis");</pre> | | |
| MATLAB | <pre>% [Output] = GetSegmentLocalRotationQuaternion(SubjectName, SegmentName) MyClient = Client(); MyClient.Connect("localhost"); MyClient.GetFrame();</pre> | | |
| | <pre>Output = MyClient.GetSegmentLocalRotationQuaternion("Alice", "Pelvis");</pre> | | |

SDK Functions Listing

SDK Functions Listing

Appendix A: What's New

GetSegmentLocalRotationEulerXYZ

Return the rotation of a subject segment in local EulerXYZ co-ordinates relative to its parent segment.

See Also: GetSegmentLocalTranslation, GetSegmentLocalRotationHelical, GetSegmentLocalRotationMatrix, GetSegmentLocalRotationQuaternion, GetSegmentGlobalTranslation,GetSegmentGlobalRotationHelical, GetSegmentGlobalRotationMatrix, GetSegmentGlobalRotationQuaternion,GetSegmentGlobalRotationEulerXYZ

| | 1 | T | T |
|--------|--|-----------|---|
| Input | Subject Name | string | The name of the subject |
| | Segment Name | string | The name of the segment. |
| Output | Result | Result | Result.Success Result.NotConnected Result.NoFrame Result.InvalidSubjectName Result.InvalidSegmentName |
| | Rotation | double[3] | The rotation of the segment |
| | Occluded | boolean | True if the segment was absent at this frame. In this case the Rotation will be [0,0,0] |
| C++ | <pre>// class Output_GetSegmentLocalRotationEulerXYZ // { // public: // Result::Enum Result; // double Rotation[3]; // bool Occluded; // }; // Output_GetSegmentLocalRotationEulerXYZ // GetSegmentLocalRotationEulerXYZ(// const String & SubjectName, // const String & SegmentName) const ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect("localhost"); MyClient.GetFrame(); Output_GetSegmentLocalRotationEulerXYZ Output = MyClient.GetSegmentLocalRotationEulerXYZ("Alice", "Pelvis");</pre> | | |
| MATLAB | <pre>% [Output] = GetSegmentLocalRotationEulerXYZ(SubjectName, SegmentName) MyClient = Client(); MyClient.Connect("localhost"); MyClient.GetFrame(); Output = MyClient.GetSegmentLocalRotationEulerXYZ("Alice", "Pelvis");</pre> | | |
| .NET | <pre>// public class Output_GetSegmentLocalRotationEulerXYZ // { // public Result Result; // public double[] Rotation; // public bool Occluded; // };</pre> | | |



SDK Functions Listing

SDK Functions Listing

Appendix A: What's New

GetMarkerCount

Return the number of markers for a specified subject in the DataStream. This information can be used in conjunction with GetMarkerName

See Also: GetSubjectName, GetMarkerName

| See Also : GetSubjectName, GetMarkerName | | | | |
|--|--|---|--|--|
| Input | Subject Name | string | The name of the subject | |
| Output | Result | Result | Result.Success Result.NotConnected Result.NoFrame Result.InvalidSubjectName | |
| | Marker Count | unsigned integer | The number of markers | |
| C++ | <pre>// }; // Output_GetMark // const Stri ViconDataStreamSI MyClient.EnableMa MyClient.Connect() Output_GetMarker() Output = MyClient MyClient.GetFrame Output = MyClient InvalidSubjectNam</pre> | n Result; t MarkerCount; terCount GetMarkerCoung & SubjectName) OK::CPP::Client MyCourkerData(); ("localhost"); Count Output; t.GetMarkerCount(" e(); t.GetMarkerCount(" ne | <pre>const; lient; Bob"); // Output.Result == NoFrame</pre> | |
| | Output = MyClient.GetMarkerCount("Bo | | Bob"); // Output.Result == Success // Output.MarkerCount >= 0 | |
| MATLAB | MyClient = Client MyClient.EnableMa MyClient.Connect(Output = MyClient MyClient.GetFrame | <pre>arkerData(); ("localhost"); c.GetMarkerCount(" e(); c.GetMarkerCount(" ne</pre> | Bob"); % Output.Result == NoFrame % Output.MarkerCount == 0 | |
| | Output = MyClient | | % (no "Alice") Bob"); % Output.Result == Success % Output.MarkerCount >= 0 | |

SDK Functions Listing

```
// public class Output_GetMarkerCount
.NET
            // public Result Result;
// public uint MarkerCount;
             //
             // Output GetMarkerCount GetMarkerCount( string SubjectName );
             ViconDataStreamSDK.DotNET.Client MyClient =
                                       new ViconDataStreamSDK.DotNET.Client();
             MyClient.EnableMarkerData();
             MyClient.Connect( "localhost" );
             Output GetMarkerCount Output;
             Output = MyClient.GetMarkerCount( "Bob" ); // Output.Result == NoFrame
                                                    // Output.MarkerCount == 0
             MyClient.GetFrame();
             Output = MyClient.GetMarkerCount( "Alice" );
                                             // Output.Result ==
             InvalidSubjectName
                                             // Output.MarkerCount == 0
                                             // (no "Alice")
```

SDK Functions Listing

Appendix A: What's New

GetMarkerName

Return the name of a marker for a specified subject. This can be passed into GetMarkerGlobalTranslation.

See Also: GetMarkerCount, GetMarkerGlobalTranslation

| Input | Subject Name | string | The name of the subject | | |
|--------|--|--|---|--|--|
| | Marker Index | unsigned integer | The index of the marker. | | |
| Output | Result | Result | Result.Success Result.NotConnected Result.NoFrame Result.InvalidSubjectName Result.InvalidIndex | | |
| | Marker Name | string | The name of the marker | | |
| C++ | <pre>// class Output_ // { // public: // Result::Enu // String // }; // Output_GetMar // const Str // const uns ViconDataStreamS MyClient.Connect MyClient.EnableM MyClient.GetFram Output_GetMarker Output_GetMarker OutputGMN = MyCl InvalidSubjectNa OutputGMN = MyCl OutputGMN = MyCl OutputGMN = MyCl</pre> | A valid Marker Index is between 0 and GetMarkerCount()-1 // class Output_GetMarkerName // { // public: // Result::Enum Result; // String MarkerName; // }; // Output_GetMarkerName GetMarkerName(// const String & SubjectName, | | | |
| MATLAB | | A valid Marker Index is between 1 and GetMarkerCount() % [Output] = GetMarkerName(SubjectName, MarkerIndex) | | | |

```
MyClient = Client();
              MyClient.Connect( "localhost" );
              MyClient.EnableMarkerData();
              MyClient.GetFrame();
              OutputGMC = MyClient.GetMarkerCount( "Bob" );
                                                       // OutputGMC.Result == Success
                                                       // OutputGMC.MarkerCount == 2
              OutputGMN = MyClient.GetMarkerName( "Alice", 1 );
                                                 // OutputGMN.Result ==
              InvalidSubjectName
                                                 // OutputGMN.MarkerName == ""
                                                 // (no "Alice")
              OutputGMN = MyClient.GetMarkerName( "Bob", 1 );
                                                   // OutputGMN.Result == Success
                                                   // OutputGMN.MarkerName == "LASI"
              OutputGMN = MyClient.GetMarkerName( "Bob", 2 );
                                                   // OutputGMN.Result == Success
                                                   // OutputGMN.MarkerName == "RASI"
              OutputGMN = MyClient.GetMarkerName( "Bob", 3 );
                                                   // OutputGMN.Result == InvalidIndex
                                                   // OutputGMN.MarkerName == ""
                                                   // (no third marker)
.NET
              A valid Marker Index is between 0 and GetMarkerCount()-1
              // public class Output GetMarkerName
              //
                   public Result Result;
              //
                   public string MarkerName;
              // };
              // Output GetMarkerName GetMarkerName( string SubjectName,
                                                      uint
                                                             MarkerIndex );
              ViconDataStreamSDK.DotNET.Client MyClient =
                                            new ViconDataStreamSDK.DotNET.Client();
              MyClient.Connect( "localhost" );
              MyClient.EnableMarkerData();
              MyClient.GetFrame();
              Output GetMarkerCount OutputGMC;
              OutputGMC = MyClient.GetMarkerCount( "Bob" );
                                                       // OutputGMC.Result == Success
                                                       // OutputGMC.MarkerCount == 2
              Output_GetMarkerName OutputGMN;
              OutputGMN = MyClient.GetMarkerName( "Alice", 0 );
                                                 // OutputGMN.Result ==
              InvalidSubjectName
                                                 // OutputGMN.MarkerName == ""
                                                 // (no "Alice")
              OutputGMN = MyClient.GetMarkerName( "Bob", 0 );
                                                   // OutputGMN.Result == Success
                                                   // OutputGMN.MarkerName == "LASI"
              OutputGMN = MyClient.GetMarkerName( "Bob", 1 );
                                                   // OutputGMN.Result == Success
                                                   // OutputGMN.MarkerName == "RASI"
              OutputGMN = MyClient.GetMarkerName( "Bob", 2 );
                                                   // OutputGMN.Result == InvalidIndex
                                                   // OutputGMN.MarkerName == ""
                                                   // (no third marker)
```

SDK Functions Listing

Appendix A: What's New

GetMarkerParentName

Return the name of the segment which is the parent of this marker.

See Also: GetMarkerCount, GetMarkerName, GetMarkerGlobalTranslation

| See Also : GetMarkerCount, GetMarkerName, GetMarkerGlobalTranslation | | | | |
|--|--|--|--|--|
| Input | Subject Name | string | The name of the subject | |
| | Marker Name | string | The name of the marker. | |
| Output | Result | Result | Result.Success Result.NotConnected Result.NoFrame Result.InvalidSubjectName Result.InvalidMarkerName | |
| | Segment Name | string | The name of the parent segment. | |
| C++ | <pre>// { // public: // Result::Enum // String // }; // // Output_GetMark // const Stri // const Stri ViconDataStreamSI MyClient.Connect(MyClient.EnableMa MyClient.GetFrame Output_GetMarkerI</pre> | <pre>// public: // Result::Enum Result; // String SegmentName; // }; // Output_GetMarkerParentName GetMarkerParentName(// const String & SubjectName,</pre> | | |
| MATLAB | MyClient = Client MyClient.Connect(MyClient.EnableMa MyClient.GetFrame | <pre>% [Output] = GetMarkerParentName(SubjectName, MarkerName) MyClient = Client(); MyClient.Connect("localhost"); MyClient.EnableMarkerData(); MyClient.GetFrame(); Output = MyClient.GetMarkerParentName("Bob", "LFHD");</pre> | | |
| .NET | <pre>// { // public Resul // public strin // }; // // Output_GetMark //</pre> | <pre>// public Result Result; // public string SegmentName; // }; // Output_GetMarkerParentName GetMarkerParentName(string SubjectName,</pre> | | |



SDK Functions Listing

SDK Functions Listing

Appendix A: What's New

GetMarkerGlobalTranslation

Return the translation of a subject marker in global co-ordinates.

The Translation is of the form (x, y, z) where x, y & z are in Millimeters with respect to the global origin.

See Also: GetMarkerName

| | | | _ |
|--------|--|-----------|--|
| Input | Subject Name | string | The name of the subject |
| | Marker Name | string | The name of the marker. |
| Output | Result | Result | Result.Success Result.NotConnected Result.NoFrame Result.InvalidSubjectName Result.InvalidMarkerName |
| | Translation | double[3] | The translation of the marker |
| | Occluded | boolean | True if the marker was absent at this frame. In this case the Translation will be [0,0,0] |
| C++ | <pre>// class Output_GetMarkerGlobalTranslation // { // public: // Result::Enum Result; // double</pre> | | |
| MATLAB | <pre>% [Output] = GetMarkerGlobalTranslation(SubjectName, MarkerName) MyClient = Client(); MyClient.Connect("localhost"); MyClient.EnableMarkerData(); MyClient.GetFrame(); Output = MyClient.GetMarkerGlobalTranslation("Alice", "LASI");</pre> | | |
| .NET | <pre>// public class Output_GetMarkerGlobalTranslation // { // public Result Result; // public double[] Translation[]; // public bool Occluded; // }; // Output_GetMarkerGlobalTranslation</pre> | | |



SDK Functions Listing

SDK Functions Listing

Appendix A: What's New

GetMarkerRayContributionCount

Return the number of rays that are contributing to a labelled marker in the data stream. This information can be used in conjunction with GetMarkerRayContribution

See Also: GetMarkerRayContribution, EnableMarkerRayData, DisableMarkerRayData, IsMarkerRayDataEnabled

| Input | Subject Name | string | The name of the subject | |
|--------|---|---|--|--|
| | Cabjest Hame | - Curring | The name of the caspet | |
| | Marker Name | string | The name of the marker. | |
| Output | Result | Result | Result.Success Result.NotConnected Result.NoFrame Result.InvalidSubjectName Result.InvalidMarkerName | |
| | RayContributionCount | unsigned integer | The number of rays | |
| C++ | <pre>// { // public: // Result::Enum Re // unsigned int Ra // }; // // Output_GetMarkerR // const Stri // const Stri ViconDataStreamSDK:: MyClient.Connect("l MyClient.EnableMarke MyClient.GetFrame(); Output_GetMarkerRayC</pre> | <pre>// public: // Result::Enum Result; // unsigned int RayContributionCount; // }; // // Output_GetMarkerRayContributionCount GetMarker RayContributionCount (</pre> | | |
| MATLAB | <pre>% [Output] = GetMarkerRayContributionCount (SubjectName, MarkerName) MyClient = Client(); MyClient.Connect("localhost"); MyClient.EnableMarkerRayData(); MyClient.GetFrame(); Output = MyClient.GetMarkerRayContributionCount ("Alice", "LASI");</pre> | | | |
| .NET | <pre>// public class Output_GetMarkerRayContributionCount // {</pre> | | | |



| About the SDK | SDK Functions Listing | Appendix A: What's New |
|---------------|----------------------------------|------------------------|
| Output_GetMa | rkerRayContributionCount Output | = |
| MyClient.0 | etMarkerRayContributionCount("Æ | Alice", "LASI"); |

SDK Functions Listing

Appendix A: What's New

GetMarkerRayContribution

Return the camera id for an indexed ray that is contributing to a labelled marker in the data stream. This information can be used in conjunction with GetMarkerRayContributionCount

See Also: GetMarkerRayContributionCount, EnableMarkerRayData, DisableMarkerRayData, IsMarkerRayDataEnabled

| Subject Name | string | The name of the subject |
|--|--|--|
| Marker Name | string | The name of the marker. |
| MarkerRayContributionIndex | unsigned int | The index of the ray required |
| Result | Result | Result.Success Result.NotConnected Result.NoFrame Result.InvalidSubjectName Result.InvalidMarkerName Result.InvalidIndex |
| CameralD | unsigned integer | The Camera ID of the camera producing the ray |
| CentroidIndex | unsigned integer | The index of the centroid resulting from the ray |
| A valid Ray Index is between 0 and GetMarkerRayContributionCount()-1 // class Output_GetMarkerRayContribution // { public: | | |
| <pre>A valid Ray Index is between 1 and GetMarkerRayContributionCount() % [Output] = GetMarkerRayContributionCount (SubjectName, MarkerName, MarkerRayContributionIndex) MyClient = Client(); MyClient.Connect("localhost"); MyClient.EnableMarkerRayData(); MyClient.GetFrame();</pre> | | |
| | Marker Name MarkerRayContributionIndex Result CameralD CentroidIndex A valid Ray Index is between // class Output_GetMarkerF // { // public: // Result::Enum Result; // unsigned int CameralF // unsigned int Centroid // }; // Output_GetMarkerRayCont // const String & S // const String & S // unsigned int Mar ViconDataStreamSDK::CPP::C MyClient.Connect("localho MyClient.EnableMarkerRayDa MyClient.GetFrame(); Output_GetMarkerRayContrib MyClient.GetFrame(); Output_GetMarkerRayContrib MyClient.GetFrame(); Output_GetMarkerRayContrib MyClient.GetFrame(); MyClient.GetFrame(); MyClient.GetFrame(); | Marker Name MarkerRayContributionIndex Result Result Result CameralD unsigned integer CentroidIndex unsigned integer A valid Ray Index is between 0 and GetMarkerRay(// class Output_GetMarkerRayContribution // { // public: // Result::Enum Result; // unsigned int CameraID; // unsigned int CentroidIndex; // // unsigned int CentroidIndex; // // const String & SubjectName, // const String & SubjectName, // const String & MarkerName, // unsigned int MarkerRayContribution ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect("localhost"); MyClient.GetFrame(); Output GetMarkerRayContribution Output = |



About the SDK SDK Functions Listing Appendix A: What's New

SDK Functions Listing

```
.NET
             A valid Ray Index is between 0 and GetMarkerRayContributionCount()-1
             // public class Output_GetMarkerRayContribution
             // {
             // public Result Result;
// unsigned int CameraID;
// unsigned int CentroidIndex
             // };
//
             // Output_GetMarkerRayContribution
             //
                  GetMarkerRayContributionCount(
             //
                                               string SubjectName,
                                               string MarkerName,
             11
                                               unsigned int MarkerRayContributionIndex );
             ViconDataStreamSDK.DotNET.Client MyClient =
                                            new ViconDataStreamSDK.DotNET.Client();
             MyClient.Connect( "localhost" );
             MyClient.EnableMarkerRayData();
             MyClient.GetFrame();
             Output_GetMarkerRayContribution Output =
               MyClient.GetMarkerRayContribution( "Alice", "LASI", 0 );
```

SDK Functions Listing

Appendix A: What's New

GetUnlabeledMarkerCount

Return the number of unlabeled markers in the data stream. This information can be used in conjunction with GetGlobalUnlabeledMarkerTranslation

See Also: GetGlobalUnlabeledMarkerTranslation

| See Also : G | GetGlobalUnlabeledMark | ker i ranslation | | |
|--------------|--|--|---|--|
| Input | | | | |
| Output | Result | Result | Result.Success Result.NotConnected Result.NoFrame | |
| | MarkerCount | unsigned integer | The number of markers | |
| C++ | <pre>// { // public: // Result::Enum // unsigned int // }; // Output_GetUnla ViconDataStreamSI MyClient.EnableUr MyClient.Connect(MyClient.GetFrame Output_GetUnlabel</pre> | <pre>// public: // Result::Enum Result; // unsigned int MarkerCount;</pre> | | |
| MATLAB | MyClient = Client MyClient.EnableUr MyClient.Connect(| <pre>% [Output] = GetUnlabeledMarkerCount(); MyClient = Client(); MyClient.EnableUnlabeledMarkerData(); MyClient.Connect("localhost"); MyClient.GetFrame();</pre> | | |
| | Output = MyClient Success | <pre>Output = MyClient.GetUnlabeledMarkerCount(); // Output.Result == Success</pre> | | |
| .NET | <pre>// Output.MarkerCount // public class Output_GetUnlabeledMarkerCount // { // public Result Result; // public uint MarkerCount; // }; // Output_GetUnlabeledMarkerCount GetUnlabeledMarkerCount(); ViconDataStreamSDK.DotNET.Client MyClient = new ViconDataStreamSDK.DotNET.Client(); MyClient.EnableUnlabeledMarkerData(); MyClient.Connect("localhost"); MyClient.GetFrame(); Output_GetUnlabeledMarkerCount Output = MyClient.GetUnlabeledMarkerCount(); // Output.Result == Success</pre> | | | |

SDK Functions Listing

Appendix A: What's New

GetUnlabeledMarkerGlobalTranslation

Return the translation of an unlabeled marker in global co-ordinates.

The Translation is of the form (x, y, z) where x, y & z are in Millimeters with respect to the global origin.

See Also: GetUnlabelledMarkerCount

| Input | Marker Index | unsigned integer | The index of the marker. |
|--------|--|------------------|---|
| Output | Result | Result | Result.Success Result.NotConnected Result.NoFrame Result.InvalidIndex |
| | Translation | double[3] | The translation of the marker |
| C++ | A valid Marker Index is between 0 and GetUnlabeledMarkerCount()-1 // class Output_GetUnlabeledMarkerGlobalTranslation // { // public: // Result::Enum Result; // double Translation[3]; // }; // // Output_GetUnlabeledMarkerGlobalTranslation // GetUnlabeledMarkerGlobalTranslation(// const unsigned int MarkerIndex) const; ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect("localhost"); MyClient.EnableUnlabeledMarkerData(); MyClient.GetFrame(); Output GetUnlabeledMarkerGlobalTranslation Output = | | |
| MATLAB | A valid Marker Index is between 1 and GetUnlabeledMarkerCount() % [Output] = GetUnlabeledMarkerGlobalTranslation(MarkerIndex) MyClient = Client(); MyClient.Connect("localhost"); MyClient.EnableUnlabeledMarkerData(); MyClient.GetFrame(); Output = MyClient.GetUnlabeledMarkerGlobalTranslation(1); | | |
| .NET | A valid Marker Index is between 0 and GetUnlabeledMarkerCount()-1 // public class Output_GetUnlabeledMarkerGlobalTranslation // { // public Result Result; // public double[] Translation; // }; // // Output_GetUnlabeledMarkerGlobalTranslation // GetUnlabeledMarkerGlobalTranslation(uint MarkerIndex) const; ViconDataStreamSDK.DotNET.Client MyClient = new ViconDataStreamSDK.DotNET.Client(); MyClient.Connect("localhost"); MyClient.EnableUnlabeledMarkerData(); | | |



| About the SDK | | SDK Functions Listing | Appendix A: What's New |
|---------------|--|-----------------------|------------------------|
| MyCli | <pre>MyClient.GetFrame();</pre> | | |
| | <pre>Output_GetUnlabeledMarkerGlobalTranslation Output = MyClient.GetUnlabeledMarkerGlobalTranslation(0);</pre> | | |

SDK Functions Listing

Appendix A: What's New

GetDeviceCount

Return the number of ForcePlates, EMGs, and other devices in the DataStream. This information can be used in conjunction with GetDeviceName

See Also: GetDeviceName

| See Also . Get | DeviceName | | |
|----------------|--|------------------|---|
| Input | | | |
| Output | Result | Result | Result.Success Result.NotConnected Result.NoFrame |
| | Device Count | unsigned integer | The number of devices |
| C++ | <pre>// class Output_GetDeviceCount // { // public: // Result::Enum Result; // unsigned int DeviceCount; // }; // Output_GetDeviceCount GetDeviceCount() const; ViconDataStreamSDK::CPP::Client MyClient; MyClient.EnableDeviceData(); MyClient.Connect("localhost"); MyClient.GetFrame(); Output_GetDeviceCount Output = MyClient.GetDeviceCount();</pre> | | |
| MATLAB | <pre>% [Output] = GetDeviceCount() MyClient = Client(); MyClient.EnableDeviceData(); MyClient.Connect("localhost"); MyClient.GetFrame(); Output = MyClient.GetDeviceCount(); // Output.Result == Success</pre> | | |
| .NET | <pre>// public class Output_GetDeviceCount // { // public Result Result; // public uint DeviceCount; // }; // Output_GetDeviceCount GetDeviceCount(); ViconDataStreamSDK.DotNET.Client MyClient = new ViconDataStreamSDK.DotNET.Client(); MyClient.EnableDeviceData(); MyClient.Connect("localhost"); MyClient.GetFrame(); Output_GetDeviceCount Output = MyClient.GetDeviceCount();</pre> | | |

SDK Functions Listing

Appendix A: What's New

GetDeviceName

Return the name and type of a device. This name can be passed into device functions. See Also: GetDeviceCount, GetDeviceOutputCount, GetDeviceOutputValue

| Input | Device Index | unsigned integer | The index of the device. |
|--------|--|---|---|
| Output | Result | Result | Result.Success Result.NotConnected Result.NoFrame Result.InvalidIndex |
| | Device Name | string | The name of the device |
| | Device Type | DeviceType | Unknown ForcePlate |
| C++ | <pre>// class Output_ // { // public: // Result::Enu // String // DeviceType: // }; // Output_GetDev // GetDeviceNa ViconDataStreamS MyClient.Connect MyClient.EnableD MyClient.GetFram Output_GetDevice OutputGDC = MyCl "ZeroWire" OutputGDN = MyCl "ZeroWire" OutputGDN = MyCl ForcePlate</pre> | m Result; DeviceName; :Enum DeviceType; riceName ame(const unsigned int Decorate (Const unsigned int | eviceIndex) const; diceCount); cputGDC.Result == Success cputGDN.Result == Success cputGDN.DeviceName == cputGDN.DeviceName == "AMTI #1" cputGDN.DeviceType == cputGDN.DeviceType == cputGDN.DeviceType == cputGDN.DeviceName == "AMTI #1" cputGDN.DeviceType == |
| | | // Out | tputGDN.DeviceType == Unknown |

SDK Functions Listing

```
MyClient = Client();
              MyClient.Connect( "localhost" );
              MyClient.EnableDeviceData();
              MyClient.GetFrame();
              OutputGDC = MyClient.GetDeviceCount( DeviceCount );
                                                  % OutputGDC.Result == Success
                                                  % OutputGDC.DeviceCount == 2
              OutputGDN = MyClient.GetDeviceName( 1 );
                                                  % OutputGDN.Result == Success
                                                  % OutputGDN.DeviceName == "ZeroWire"
                                                  % OutputGDN.DeviceType == Unknown
              OutputGDN = MyClient.GetDeviceName( 2 );
                                                  % OutputGDN.Result == Success
                                                  % OutputGDN.DeviceName == "AMTI #1"
                                                  % OutputGDN.DeviceType == ForcePlate
              OutputGDN = MyClient.GetDeviceName( 3 );
                                                  % OutputGDN.Result == InvalidIndex
                                                  % OutputGDN.DeviceName == ""
                                                  % OutputGDN.DeviceType == Unknown
.NET
              A valid Device Index is between 0 and GetDeviceCount()-1
              // public class Output GetDeviceName
              //
                   public Result
                                     Result:
              //
                   public string
                                     DeviceName;
                   public DeviceType DeviceType;
              // };
              //
              // Output GetDeviceName
                   GetDeviceName( uint DeviceIndex );
              ViconDataStreamSDK.DotNET.Client MyClient =
                                           new ViconDataStreamSDK.DotNET.Client();
              MyClient.Connect( "localhost" );
              MyClient.EnableDeviceData();
              MyClient.GetFrame();
              Output GetDeviceCount OutputGDC;
              OutputGDC = MyClient.GetDeviceCount( DeviceCount );
                                        // OutputGDC.Result == Success
                                        // OutputGDC.DeviceCount == 2
              Output GetDeviceName OutputGDN;
              OutputGDN = MyClient.GetDeviceName( 0 );
                                          // OutputGDN.Result == Success
                                          // OutputGDN.DeviceName == "ZeroWire"
                                          // OutputGDN.DeviceType == Unknown
              OutputGDN = MyClient.GetDeviceName( 1 );
                                          // OutputGDN.Result == Success
                                          // OutputGDN.DeviceName == "AMTI #1"
                                          // OutputGDN.DeviceType == ForcePlate
              OutputGDN = MyClient.GetDeviceName( 2 );
                                          // OutputGDN.Result == InvalidIndex
                                          // OutputGDN.DeviceName == ""
                                          // OutputGDN.DeviceType == Unknown
```

SDK Functions Listing

Appendix A: What's New

GetDeviceOutputCount

Return the number of outputs for a device in the data stream. This information can be used in conjunction with GetDeviceOutputName

See Also: GetDeviceName, GetDeviceOutputName

| Input | Device Name | string | The device name |
|--------|--|---|--|
| Output | Result | Result | Result.Success Result.NotConnected Result.NoFrame Result.InvalidDeviceName |
| | Device Output Count | unsigned integer | The number of device outputs |
| C++ | <pre>// { // public: // Result::Enum // unsigned int // }; // // Output_GetDevi // ViconDataStreamSI MyClient.Connect MyClient.EnableDe MyClient.GetFrame Output_GetDevice(Output_ MyClient InvalidDeviceName</pre> | <pre>// public: // Result::Enum Result; // unsigned int DeviceOutputCount; // }; // // Output_GetDeviceOutputCount GetDeviceOutputCount(</pre> | |
| MATLAB | MyClient = Client MyClient.Connect MyClient.EnableDe MyClient.GetFrame Output = MyClient InvalidDeviceName | <pre>% [Output] = GetDeviceOutputCount(DeviceName) MyClient = Client(); MyClient.Connect("localhost"); MyClient.EnableDeviceData(); MyClient.GetFrame(); Output = MyClient.GetDeviceOutputCount("DataGlove");</pre> | |
| .NET | // public class (| - | ut.DeviceOutputCount == 6 |
| .141.1 | <pre>// { // public Result Result; // public uint DeviceOutputCount;</pre> | | |

SDK Functions Listing

SDK Functions Listing

Appendix A: What's New

GetDeviceOutputName

Return the name and SI unit of a device output. This name can be passed into GetDeviceOutputValue.

See Also: GetDeviceCount, GetDeviceOutputCount, GetDeviceOutputValue

| Input | Device Name | string | The device name |
|--------|---------------------|---------|---|
| | Device Output Index | integer | The index of the device output. |
| Output | Result | Result | Result.Success Result.NotConnected Result.NoFrame Result.InvalidDeviceName Result.InvalidIndex |
| | Device Output Name | string | The name of the device output, e.g. "Fx" - Force X "Fy" - Force Y "Fz" - Force Z "Mx" - Moment X "My" - Moment Y "Mz" - Moment Z "Cx" - Centre Of Pressure X "Cy" - Centre Of Pressure Y "Cz" - Centre Of Pressure Z "Pin1" - Analog Input 1 "Pin2" - Analog Input 2 |
| | Device Output Unit | Unit | The unit of the device output. Unit.Unknown Unit.Volt Unit.Newton Unit.NewtonMeter Unit.Meter Unit.Kilogram Unit.Second Unit.Ampere Unit.Kelvin Unit.Mole Unit.Candela Unit.Radian Unit.Steradian Unit.MeterSquared Unit.MeterCubed |



About the SDK SDK Functions Listing Appendix A: What's New

| <pre>// class Output_GetDeviceOutputName // { // public: // Result::Enum Result; // String</pre> | | |
|---|--------|--|
| <pre>// const unsigned int DeviceOutputIndex) const; ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect("localhost"); MyClient.EnableDeviceData(); MyClient.GetFrame(); Output_GetDeviceOutputName Output = MyClient.GetDeviceOutputName("AMTI", 0);</pre> | C++ | Unit.MeterPerSecondSquared Unit.RadianPerSecond Unit.RadianPerSecondSquared Unit.Hertz Unit.Joule Unit.Watt Unit.Pascal Unit.Lux Unit.Coulomb Unit.Coulomb Unit.Farad Unit.Farad Unit.Henry Unit.Siemens Unit.Becquerel Unit.Gray Unit.Sievert Unit.Sievert Unit.Katal A valid Device Output Index is between 0 and GetDeviceOutputCount()-1 // class Output_GetDeviceOutputName // { // public: // Result::Enum Result; // String DeviceOutputName; // Unit::Enum DeviceOutputName // { // Output_GetDeviceOutputName GetDeviceOutputName (|
| Unit. Siemens Unit. Becquerel Unit. Gray Unit. Sievert Unit. Katal C++ A valid Device Output Index is between 0 and GetDeviceOutputCount()-1 // class Output_GetDeviceOutputName // { // public: // Result::Enum Result; // String DeviceOutputName; // Unit::Enum DeviceOutputName; // Unit::Enum DeviceOutputUnit; // }; // Output_GetDeviceOutputName GetDeviceOutputName (// const String & DeviceName, // const unsigned int DeviceOutputIndex) const; ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect("localhost"); MyClient.GetFrame(); MyClient.GetFrame(); Output_GetDeviceOutputName Output = | | Unit.Tesla |
| Unit.Becquerel Unit.Gray Unit.Sievert Unit.Katal C++ A valid Device Output Index is between 0 and GetDeviceOutputCount()-1 // class Output_GetDeviceOutputName // { // public: // Result::Enum Result; // String DeviceOutputName; // Unit::Enum DeviceOutputUnit; // }; // Output_GetDeviceOutputName GetDeviceOutputName(// const String & DeviceName, // const string & DeviceOutputIndex) const; ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect("localhost"); MyClient.GetFrame(); Output_GetDeviceOutputName Output = MyClient.GetFrame(); Output.GetDeviceOutputName ("AMTI", 0); // Output.Result == Success // Output.DeviceOutputName == "Fx" // Output.DeviceOutputUnit == Newton MATLAB A valid Device Output Index is between 1 and GetDeviceOutputCount() | | |
| C++ A valid Device Output Index is between 0 and GetDeviceOutputCount()-1 // class Output_GetDeviceOutputName // { // public: // Result::Enum Result; // String DeviceOutputName; // Unit::Enum DeviceOutputUnit; // }; // Output_GetDeviceOutputName GetDeviceOutputName(// const String & DeviceOutputName) ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect("localhost"); MyClient.GetFrame(); Output_GetDeviceOutputName Output = MyClient.GetDeviceOutputName("AMTI", 0); // Output.Result == Success // Output.DeviceOutputName == "Fx" // Output.DeviceOutputName == "Fx" // Output.DeviceOutputUnit == Newton MATLAB A valid Device Output Index is between 1 and GetDeviceOutputCount() | | |
| C++ A valid Device Output Index is between 0 and GetDeviceOutputCount()-1 // class Output_GetDeviceOutputName // { // public: // Result::Enum Result; // String DeviceOutputName; // Unit::Enum DeviceOutputName; // // Output_GetDeviceOutputName GetDeviceOutputName (// const String & DeviceName, // const unsigned int DeviceOutputIndex) const; ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect("localhost"); MyClient.EnableDeviceData(); MyClient.GetFrame(); Output_GetDeviceOutputName Output = MyClient.GetDeviceOutputName ("AMTI", 0); // Output.Result == Success // Output.DeviceOutputName == "Fx" // Output.DeviceOutputName == "Fx" // Output.DeviceOutputUnit == Newton MATLAB A valid Device Output Index is between 1 and GetDeviceOutputCount() | | · · · · · · · · · · · · · · · · · · · |
| C++ A valid Device Output Index is between 0 and GetDeviceOutputCount()-1 // class Output_GetDeviceOutputName // { // public: // Result::Enum Result; // String DeviceOutputName; // Unit::Enum DeviceOutputUnit; // // // Output_GetDeviceOutputName GetDeviceOutputName(// const String & DeviceOutputIndex) const; ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect("localhost"); MyClient.EnableDeviceData(); MyClient.GetFrame(); Output_GetDeviceOutputName Output = MyClient.GetDeviceOutputName("AMTI", 0); // Output.Result == Success // Output.DeviceOutputName == "Fx" // Output.DeviceOutputName == "Fx" // Output.DeviceOutputUnit == Newton MATLAB A valid Device Output Index is between 1 and GetDeviceOutputCount() | | |
| <pre>// class Output_GetDeviceOutputName // { // public: // Result::Enum Result; // String</pre> | | Unit.Katal |
| · · · · · · · · · · · · · · · · · · · | C++ | <pre>// class Output_GetDeviceOutputName // { // public: // Result::Enum Result; // String DeviceOutputName; // Unit::Enum DeviceOutputUnit; // }; // // Output_GetDeviceOutputName GetDeviceOutputName(// const String & DeviceName, // const unsigned int DeviceOutputIndex) const; ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect("localhost"); MyClient.EnableDeviceData(); MyClient.GetFrame(); Output_GetDeviceOutputName Output = MyClient.GetDeviceOutputName("AMTI", 0);</pre> |
| <pre>% [Output] = GetDeviceOutputName(DeviceName, DeviceOutputIndex)</pre> | MATLAB | A valid Device Output Index is between 1 and GetDeviceOutputCount() % [Output] = GetDeviceOutputName(DeviceName, DeviceOutputIndex) |
| <pre>MyClient = Client();</pre> | | <pre>MyClient = Client();</pre> |

SDK Functions Listing

```
MyClient.Connect( "localhost" );
               MyClient.EnableDeviceData();
               MyClient.GetFrame();
               Output = MyClient.GetDeviceOutputName( "AMTI", 0 );
                                              % Output.Result == Success
                                              % Output.DeviceOutputName == "Fx"
                                              % Output.DeviceOutputUnit == Newton
.NET
               A valid Device Output Index is between 0 and GetDeviceOutputCount()-1
                // public class Output GetDeviceOutputName
               // {
               // {
    // public Result Result;
    // public string DeviceOutputName;
    // public Unit DeviceOutputUnit;
               // };
               //
               // Output GetDeviceOutputName GetDeviceOutputName(
               //
                                                       string DeviceName,
               //
                                                       uint DeviceOutputIndex );
               ViconDataStreamSDK.DotNET.Client MyClient =
                                               new ViconDataStreamSDK.DotNET.Client();
               MyClient.Connect( "localhost" );
               MyClient.EnableDeviceData();
               MyClient.GetFrame();
               Output GetDeviceOutputName Output =
                  MyClient.GetDeviceOutputName( "AMTI", 0 );
                                             // Output.Result == Success
                                             // Output.DeviceOutputName == "Fx"
                                             // Output.DeviceOutputUnit == Newton
```

SDK Functions Listing

Appendix A: What's New

GetDeviceOutputValue

Return the value of a device output. If there are multiple samples for a frame, then the first sample is returned.

The force plate data provided in the individual device channels is in a coordinate system local to the plate aligned Z upwards, Y towards the front of the plate. This coordinate system is located at the center of the top surface of the plate. Any plate origin offset has been accounted for in the moment data. These are forces not reactions.

See Also: GetDeviceCount, GetDeviceOutputCount, GetDeviceOutputName

| | | | • |
|--------|---|---|---|
| Input | Device Name | string | The device name |
| | Device Output Name | string | The name of the device output. |
| Output | Result | Result | Result.Success Result.NotConnected Result.NoFrame Result.InvalidDeviceName Result.InvalidDeviceOutputName |
| | Value | double | The value of the device output |
| | Occluded | boolean | True if the value was absent at this frame. In this case the Value will be 0. |
| C++ | <pre>// { // public: // Result::Enum // double // bool // }; // // Output_GetDev // GetDeviceO // const S // const S ViconDataStreamS MyClient.Connect MyClient.EnableD MyClient.GetFram Output GetDevice</pre> | <pre>// class Output_GetDeviceOutputValue // { // public: // Result::Enum Result; // double Value; // bool Occluded; // }; // Output_GetDeviceOutputValue // GetDeviceOutputValue (// const String & DeviceName,</pre> | |
| MATLAB | MyClient = Clien MyClient.Connect | nt.Connect("localhost"); nt.EnableDeviceData(); nt.GetFrame(); | |
| | output - myorren | | Output.Result == Success |



SDK Functions Listing

```
// Output.Value == ?
                                                           // Output.Occluded = ?
                // public class Output_GetDeviceOutputValue
// {
// public Result Result;
.NET
                // public double Value;
// public bool Occluded;
                // };
//
                // Output_GetDeviceOutputValue
// GetDeviceOutputValue( str
                       GetDeviceOutputValue( string DeviceName,
                //
                                                string DeviceOutputName );
                ViconDataStreamSDK.DotNET.Client MyClient =
                                                 new ViconDataStreamSDK.DotNET.Client();
                MyClient.Connect( "localhost" );
                MyClient.EnableDeviceData();
                MyClient.GetFrame();
                Output GetDeviceOutputValue Output =
                  MyClient.GetDeviceOutputValue( "AMTI", "Fx" );
                                                           // Output.Result == Success
                                                           // Output.Value == ?
                                                           // Output.Occluded = ?
```

SDK Functions Listing

Appendix A: What's New

GetDeviceOutputSubsamples

Return the number of samples available the specified device for the current frame. If an analogue device is sampling at 1000 Hz and the system is running at 100 Hz then this function will return 10.

The samples can accessed by supplying the subsample index to GetDeviceOutputValue. See below.

See Also: GetDeviceOutputCount, GetDeviceOutputValue

| Input | Device Name | string | The device name | |
|--------|--|--|---|--|
| | Device Output Name | string | The name of the device output. | |
| Output | Result | Result | Result.Success Result.NotConnected Result.NoFrame Result.InvalidIndex Result.InvalidDeviceName Result.InvalidDeviceOutputName | |
| | DeviceOutputSubsamples | Uint | The number of subsamples for this device output. | |
| | Occluded | boolean | True if the value was absent at this frame. In this case the Value will be 0. | |
| C++ | <pre>// { // public: // Result::Enum Result; // unsigned int DeviceO // bool Occlude // }; // // Output_GetDeviceOutp String & DeviceName, // String & DeviceOutputName ViconDataStreamSDK::CPP::C MyClient.Connect("localho MyClient.EnableDeviceData(MyClient.GetFrame(); Output_GetDeviceOutputSubs</pre> | <pre>// { // public: // Result::Enum Result; // unsigned int DeviceOutputSubsamples; // bool Occluded; // }; // Output_GetDeviceOutputSubsamples GetDeviceOutputSubsamples(const String & DeviceName, // const String & DeviceOutputName) const; ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect("localhost"); MyClient.EnableDeviceData();</pre> | | |
| MATLAB | <pre>// [Output] = GetDeviceOutputSubsamples(DeviceName, DeviceOutputName) MyClient = Client(); MyClient.Connect("localhost"); MyClient.EnableDeviceData(); MyClient.GetFrame(); Output = MyClient. GetDeviceOutputSubsamples ("AMTI", "Fx");</pre> | | | |



SDK Functions Listing

```
// Output.Occluded = ?
                // public class Output GetDeviceOutputSubsamples
.NET
                //
                    public Result Result;
               // unsigned int DeviceOutputSubsamples;
// public bool Occluded;
                // };
                //
                // Output GetDeviceOutputSubsamples^ GetDeviceOutputSubsamples( String^
               DeviceName,
                String^ DeviceOutputName )
               mew ViconDataStreamSDK.DotNET.Client();
MyClient.Connect( "localhost" );
MyClient.EnableDeviceData()
               MyClient.GetFrame();
                Output GetDeviceOutputSubsamples Output =
                  MyClient.GetDeviceOutputSubsamples( "AMTI", "Fx" );
                                                         // Output.Result == Success
                                                         // Output.DeviceOutputSubsamples
                == ?
                                                         // Output.Occluded = ?
```

SDK Functions Listing

Appendix A: What's New

GetDeviceOutputValue₂

Return the value of a device output. This override allows access to the individual subsamples for the current frame of data. See GetDeviceOutputValue for information about the meaning of the force plate channels.

See Also: GetDeviceOutputSubsamples, GetDeviceOutputValue

| Input | Device Name | string | The device name |
|--------|--|----------------------------|---|
| | Device Output Name | string | The name of the device output. |
| | Subsample | unsigned int | The subsample to access. |
| Output | Result | Result | Result.Success Result.NotConnected Result.NoFrame Result.InvalidIndex Result.InvalidDeviceName Result.InvalidDeviceOutputName |
| | Value | double | The value of the device output |
| | Occluded | boolean | True if the value was absent at this frame. In this case the Value will be 0. |
| C++ | <pre>// class Output_GetDeviceOutputValue // { // public: // Result::Enum Result; // double Value; // bool Occluded; // }; // // Output_GetDeviceOutputValue // GetDeviceOutputValue // const String & DeviceName, // const String & DeviceOutputName) const; ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect("localhost"); MyClient.EnableDeviceData(); MyClient.GetFrame(); Output_GetDeviceOutputValue Output = MyClient.GetDeviceOutputValue("AMTI", "Fx", 6); // Output.Result == Success // Output.Value == ? // Output.Occluded = ?</pre> | | |
| MATLAB | <pre>// [Output] = GetDeviceOutputValue(DeviceName, DeviceOutputName) MyClient = Client(); MyClient.Connect("localhost"); MyClient.EnableDeviceData(); MyClient.GetFrame();</pre> | | viceName, DeviceOutputName) |
| | Output = MyClient | t.GetDeviceOutputValue(// | "AMTI", "Fx", 6); Output.Result == Success |



SDK Functions Listing

```
// Output.Value == ?
                                                           // Output.Occluded = ?
                // public class Output_GetDeviceOutputValue
// {
// public Result Result;
.NET
                // public double Value;
// public bool Occluded;
                // };
//
                // Output_GetDeviceOutputValue
// GetDeviceOutputValue( str
                       GetDeviceOutputValue( string DeviceName,
                //
                                                string DeviceOutputName );
                ViconDataStreamSDK.DotNET.Client MyClient =
                                                 new ViconDataStreamSDK.DotNET.Client();
                MyClient.Connect( "localhost" );
                MyClient.EnableDeviceData();
                MyClient.GetFrame();
                Output GetDeviceOutputValue Output =
                  MyClient.GetDeviceOutputValue( "AMTI", "Fx", 6 );
                                                           // Output.Result == Success
                                                           // Output.Value == ?
                                                           // Output.Occluded = ?
```

SDK Functions Listing

Appendix A: What's New

GetForcePlateCount

Return the number of ForcePlates available in the DataStream. See Also: GetGlobalForceVector, GetGlobalMomentVector, GetGlobalCentreOfPressure Input Result.Success Output Result Result Result NotConnected Result.NoFrame Force Plate Count | unsigned integer The number of force plates // class Output_GetForcePlateCount C++// { // public: // Result::Enum Result; // Result::Enum Result;
// unsigned int ForcePlateCount; // }; // // Output GetForcePlateCount GetForcePlateCount() const; ViconDataStreamSDK::CPP::Client MyClient; MyClient.EnableDeviceData(); MyClient.Connect("localhost"); MyClient.GetFrame(); Output GetForcePlateCount Output = MyClient. GetForcePlateCount (); // Output.Result == Success // Output. ForcePlateCount >= 0 % [Output] = GetForcePlateCount() **MATLAB** MyClient = Client(); MyClient.EnableDeviceData(); MyClient.Connect("localhost"); MyClient.GetFrame(); Output = MyClient.GetForcePlateCount(); // Output.Result == Success // Output.ForcePlateCount >= 0 // public class Output_GetForcePlateCount .NET // { // public Result Result; public uint ForcePlateCount; // }; // Output GetForcePlateCount GetForcePlateCount(); ViconDataStreamSDK.DotNET.Client MyClient = new ViconDataStreamSDK.DotNET.Client(); MyClient.EnableDeviceData(); MyClient.Connect("localhost"); MyClient.GetFrame(); Output_GetForcePlateCount Output = MyClient.GetForcePlateCount(); // Output.Result == Success // Output.ForcePlateCount >= 0

SDK Functions Listing

Appendix A: What's New

GetGlobalForceVector

Return the force vector for the plate in global co-ordinates.

The vector is in Newtons and is with respect to the global coordinate system regardless of the orientation of the plate. The vector represents the force exerted upon the plate, not the reaction force.

If multiple sub-samples are available this function returns the first subsample. See the alternate version of this function to access all of the analogue data.

See Also: GetGlobalMomentVector, GetGlobalCentreOfPressure

| Input | Force Plate Index | unsigned integer | The index of the plate |
|--------|---|------------------|---|
| Output | Result | Result | Result.Success Result.NotConnected Result.NoFrame Result.InvalidIndex |
| | ForceVector | double[3] | The force on the plate |
| C++ | A valid ForcePlateIndex is between 0 and GetForcePlateCount()-1 // class Output_GetGlobalForceVector // { // public: // Result::Enum Result; // double ForceVector[3]; // // // Output_GetGlobalForceVector // GetGlobalForceVector (// const unsigned int ForcePlateIndex) const; ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect("localhost"); MyClient.EnableDeviceData (); MyClient.GetFrame(); Output_GetGlobalForceVector Output = MyClient.GetGlobalForceVector(0); | | |
| MATLAB | <pre>A valid ForcePlateIndex is between 1 and GetForcePlateCount() % [Output] = GetGlobalForceVector(ForcePlateIndex) MyClient = Client(); MyClient.Connect("localhost"); MyClient.EnableDeviceData (); MyClient.GetFrame(); Output = MyClient. GetGlobalForceVector(1);</pre> | | |
| .NET | A valid ForcePlateIndex is between 0 and GetForcePlateCount() - 1 // public ref class Output_GetGlobalForceVector // { // public: // Result Result; // array< double >^ ForceVector; // }; // Output_GetGlobalForceVector // GetGlobalForceVector(uint ForcePlateIndex) const; | | |



SDK Functions Listing

```
ViconDataStreamSDK.DotNET.Client MyClient = new
ViconDataStreamSDK.DotNET.Client();
MyClient.Connect( "localhost" );
MyClient.EnableUnlabeledMarkerData();
MyClient.GetFrame();

Output_ GetGlobalForceVector Output = MyClient. GetGlobalForceVector(
0 );
```

SDK Functions Listing

Appendix A: What's New

GetGlobalMomentVector

Return the moment vector for the plate in global co-ordinates.

The vector is in Newton-Meters and is with respect to the global coordinate system regardless of the orientation of the plate.

The vector represents the moment exerted upon the plate, not the reaction moment. Any force plate origin offset is accounted for in the moments so they are acting about the exact centre of the top surface of the plate.

If multiple sub-samples are available this function returns the first subsample. See the alternate version of this function to access all of the analogue data.

See Also: GetGlobalForceVector, GetGlobalCentreOfPressure

| Input | Plate Index | unsigned integer | The index of the force plate | |
|--------|--|--|---|--|
| Output | Result | Result | Result.Success Result.NotConnected Result.NoFrame Result.InvalidIndex | |
| | MomentVector | double[3] | The moment exterted on the plate | |
| C++ | <pre>// class Output_0 // { // public: // Result::Enum // double // }; // // Output_GetGlod // const um ViconDataStreamSI MyClient.Connect MyClient.EnableI MyClient.GetFrame</pre> | <pre>// public: // Result::Enum Result; // double</pre> | | |
| MATLAB | <pre>% [Output] = Get() MyClient = Client MyClient.Connect MyClient.EnableI MyClient.GetFrame</pre> | A valid ForcePlateIndex is between 1 and GetForcePlateCount() % [Output] = GetGlobalMomentVector(ForcePlateIndex) MyClient = Client(); MyClient.Connect("localhost"); MyClient. EnableDeviceData (); MyClient.GetFrame(); Output = MyClient. GetGlobalMomentVector(1); | | |
| .NET | <pre>// public ref cl // { // public: // Result</pre> | <pre>// public: // Result Result; // array< double >^ MomentVector;</pre> | | |



SDK Functions Listing

```
// Output_GetGlobalMomentVector
// GetGlobalMomentVector( uint ForcePlateIndex ) const;

ViconDataStreamSDK.DotNET.Client MyClient = new
ViconDataStreamSDK.DotNET.Client();
MyClient.Connect( "localhost" );
MyClient. EnableDeviceData ();
MyClient.GetFrame();

Output_ GetGlobalMomentVector Output = MyClient.GetGlobalMomentVector(
0 );
```

SDK Functions Listing

Appendix A: What's New

GetGlobalCentreOfPressure

Return the centre of pressure for the plate in global co-ordinates.

The position is in millimeters and is with respect to the global coordinate system.

If multiple sub-samples are available this function returns the first subsample. See the alternate version of this function to access all of the analogue data.

See Also: GetGlobalForceVector, GetGlobalMomentVector

| Input | Plate Index | unsigned integer | The index of the force plate |
|--------|--|------------------|---|
| Output | Result | Result | Result.Success Result.NotConnected Result.NoFrame Result.InvalidIndex |
| | CentreOfPressure | double[3] | The CoP. |
| C++ | A valid ForcePlateIndex is between 0 and GetForcePlateCount()-1 // class Output_GetGlobalCentreOfPressure // { // public: // Result::Enum Result; // double | | |
| MATLAB | A valid ForcePlateIndex is between 1 and GetForcePlateCount() % [Output] = GetGlobalCentreOfPressure(ForcePlateIndex) MyClient = Client(); MyClient.Connect("localhost"); MyClient. EnableDeviceData (); MyClient.GetFrame(); Output = MyClient. GetGlobalCentreOfPressure(1); | | |
| .NET | A valid ForcePlateIndex is between 0 and GetForcePlateCount() - 1 // public class Output_ GetGlobalCentreOfPressure // { // public: // Result Result; // array< double >^ CentreOfPressure; // }; // // Output_GetGlobalCentreOfPressure // GetGlobalCentreOfPressure(uint ForcePlateIndex) const; ViconDataStreamSDK.DotNET.Client MyClient = new ViconDataStreamSDK.DotNET.Client(); | | |



About the SDK SDK Functions Listing Appendix A: What's New

```
MyClient.Connect( "localhost" );
MyClient. EnableDeviceData ();
MyClient.GetFrame();

Output_ GetGlobalCentreOfPressure Output =
MyClient.GetGlobalCentreOfPressure( 0 );
```

SDK Functions Listing

Appendix A: What's New

GetForcePlateSubsamples

Return the number of subsamples available for a specified plate in the current frame. Additional versions of GetGlobalForceVector, GetGlobalMomentVector GetGlobalCentreOfPressure take the subsample index to allow access of all the force plate data.

See Also: GetGlobalForceVector, GetGlobalMomentVector, GetGlobalCentreOfPressure

| Input | Plate Index | unsigned integer | The index of the force plate |
|--------|--|------------------|---|
| Output | Result | Result | Result.Success Result.NotConnected Result.NoFrame Result.InvalidIndex |
| | ForcePlateSubsamples | unsigned integer | The number of subsamples. |
| C++ | A valid ForcePlateIndex is between 0 and GetForcePlateCount()-1 // class Output_GetForcePlateSubsamples // { // public: // Result::Enum Result; // unsigned int ForcePlateSubsamples; // // // Output_GetForcePlateSubsamples // GetForcePlateSubsamples(const unsigned int ForcePlateIndex) const; ViconDataStreamSDK::CPP::Client MyClient; MyClient.EnableDeviceData(); MyClient.Connect("localhost"); MyClient.GetFrame(); Output_GetForcePlateSubsamples Output = MyClient.GetForcePlateSubsamples (0); // Output.Result == Success /// | | |
| MATLAB | A valid ForcePlateIndex is between 1 and GetForcePlateCount() % [Output] = GetForcePlateSubsamples() MyClient = Client(); MyClient.EnableDeviceData(); MyClient.Connect("localhost"); MyClient.GetFrame(); Output = MyClient. GetForcePlateSubsamples(1); // Output.Result == Success // Output. ForcePlateSubsamples >= 0 | | |
| .NET | A valid ForcePlateIndex is between 0 and GetForcePlateCount()-1 // public class Output_GetForcePlateSubsamples // { // public Result Result; // public uint ForcePlateSubsamples; // }; // Output_GetForcePlateCount GetForcePlateSubsamples(unsigned int ForcePlateIndex); | | |



SDK Functions Listing

SDK Functions Listing

Appendix A: What's New

GetGlobalForceVector₂

Return the force vector for the plate in global co-ordinates. This version takes a subsample index that allows access to all of the force information.

The vector is in Newtons and is with respect to the global coordinate system regardless of the orientation of the plate. The vector represents the force exerted upon the plate, not the reaction force.

See Also: GetGlobalMomentVector, GetGlobalCentreOfPressure

| Input | Force Plate Index | unsigned integer | The index of the plate | |
|--------|--|---|---|--|
| | Subsample | unsigned integer | The subsample to access | |
| Output | Result | Result | Result.Success Result.NotConnected Result.NoFrame Result.InvalidIndex | |
| | ForceVector | double[3] | The force on the plate | |
| C++ | A valid ForcePlateIndex is between 0 and GetForcePlateCount()-1 A valid Subsample is between 0 and GetForcePlateSubsamples()-1 // class Output_GetGlobalForceVector // { // public: // Result::Enum Result; // double ForceVector[3]; // }; // // Output_GetGlobalForceVector // GetGlobalForceVector // GetGlobalForceVector // Const unsigned int ForcePlateIndex, const unsigned int Subsample) const; ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect("localhost"); MyClient.EnableDeviceData (); MyClient.GetFrame(); const unsigned int Index(0); const unsigned int Samples = MyClient.GetForcePlateSubsamples (index).ForcePlateSubsamples; for (unsigned int Sample = 0; Sample < Samples; ++ Sample) { Output_GetGlobalForceVector Output = MyClient.GetGlobalForceVector (Index, Sample); } | | | |
| MATLAB | A valid Subsample % [Output] = Get0 MyClient = Client MyClient.Connect MyClient.EnableI MyClient.GetFrame Index = 0; | A valid ForcePlateIndex is between 1 and GetForcePlateCount() A valid Subsample is between 1 and GetForcePlateSubsamples() % [Output] = GetGlobalForceVector(ForcePlateIndex, Subsample) MyClient = Client(); MyClient.Connect("localhost"); MyClient. EnableDeviceData (); MyClient.GetFrame(); Index = 0; Output_GetForcePlateSubsamples = MyClient.GetForcePlateSubsamples() | | |



SDK Functions Listing

```
Index );
              for Sample = 1:Output_GetForcePlateSubsamples.ForcePlateSubsamples
                  Output = MyClient. GetGlobalForceVector( Index, Sample );
.NET
              A valid ForcePlateIndex is between 0 and GetForcePlateCount() - 1
              A valid Subsample is between 0 and GetForcePlateSubsamples()-1
              // public ref class Output_GetGlobalForceVector
// {
              // public:
              //
                   Result
                                      Result;
                    array< double >^ ForceVector;
              //
              // };
              //
              // Output_GetGlobalForceVector
              // GetGlobalForceVector( uint ForcePlateIndex, uint Subsample )
              const;
              ViconDataStreamSDK.DotNET.Client MyClient = new
              ViconDataStreamSDK.DotNET.Client();
              MyClient.Connect( "localhost" );
              MyClient.EnableUnlabeledMarkerData();
              MyClient.GetFrame();
              uint Index = 0;
              uint Samples =
              MyClient.GetForcePlateSubsamples(ForcePlateIndex).ForcePlateSubsamples;
              for (uint Sample = 0; Sample < Samples; ++ Sample)</pre>
                  Output GetGlobalForceVector Output = MyClient.GetGlobalForceVector(
              Index, Sample );
```

SDK Functions Listing

Appendix A: What's New

GetGlobalMomentVector₂

Return the moment vector for the plate in global co-ordinates. This version takes a subsample index that allows access to all of the force information.

The vector is in Newton-Meters and is with respect to the global coordinate system regardless of the orientation of the plate.

The vector represents the moment exerted upon the plate, not the reaction moment. Any force plate origin offset is accounted for in the moments so they are acting about the exact centre of the top surface of the plate.

See Also: GetGlobalForceVector, GetGlobalCentreOfPressure

| Input | Plate Index | unsigned integer | The index of the force plate |
|--------|---|------------------|---|
| | Subsample | unsigned integer | The subsample to access |
| Output | Result | Result | Result.Success Result.NotConnected Result.NoFrame Result.InvalidIndex |
| | MomentVector | double[3] | The moment exterted on the plate |
| C++ | A valid ForcePlateIndex is between 0 and GetForcePlateCount()-1 A valid Subsample is between 0 and GetForcePlateSubsamples()-1 // class Output_GetGlobalMomentVector // { // public: // Result::Enum Result; // double MomentVector[3]; /// // Output_GetGlobalMomentVector GetGlobalMomentVector (// const unsigned int ForcePlateIndex, const unsigned int Subsample) const; ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect("localhost"); MyClient.EnableDeviceData (); MyClient.GetFrame(); const unsigned int Index(0); const unsigned int Samples = MyClient.GetForcePlateSubsamples(index).ForcePlateSubsamples; for(unsigned int Sample = 0; Sample < Samples; ++ Sample) { Output_GetGlobalMomentVector Output = MyClient.GetGlobalMomentVector(Index, Sample); } | | |
| MATLAB | A valid ForcePlateIndex is between 1 and GetForcePlateCount() A valid Subsample is between 1 and GetForcePlateSubsamples() % [Output] = GetGlobalMomentVector(ForcePlateIndex, Subsample) MyClient = Client(); MyClient.Connect("localhost"); MyClient. EnableDeviceData (); | | |

SDK Functions Listing

```
MyClient.GetFrame();
              Index = 0;
              Output GetForcePlateSubsamples = MyClient.GetForcePlateSubsamples(
              Index );
              for Sample = 1:Output GetForcePlateSubsamples.ForcePlateSubsamples
                  Output = MyClient. GetGlobalMomentVector ( Index, Sample );
.NET
              A valid ForcePlateIndex is between 0 and GetForcePlateCount() - 1
              A valid Subsample is between 0 and GetForcePlateSubsamples()-1
              // public ref class Output_GetGlobalMomentVector
              // public:
              //
                    Result
                                      Result;
              //
                   array< double >^ MomentVector;
              // };
              // Output GetGlobalMomentVector
              // GetGlobalMomentVector( uint ForcePlateIndex, uint Subsample )
              ViconDataStreamSDK.DotNET.Client MyClient = new
              ViconDataStreamSDK.DotNET.Client();
              MyClient.Connect( "localhost" );
              MyClient. EnableDeviceData ();
              MyClient.GetFrame();
              uint Index = 0;
              uint Samples =
              MyClient.GetForcePlateSubsamples(ForcePlateIndex).ForcePlateSubsamples;
              for (uint Sample = 0; Sample < Samples; ++ Sample)</pre>
                  Output GetGlobalMomentVector Output =
              MyClient.GetGlobalMomentVector( Index, Sample );
```

SDK Functions Listing

Appendix A: What's New

GetGlobalCentreOfPressure₂

Return the centre of pressure for the plate in global co-ordinates. This version takes a subsample index that allows access to all of the force information.

The position is in millimeters and is with respect to the global coordinate system.

See Also: GetGlobalForceVector, GetGlobalMomentVector

| Input | Plate Index | unsigned integer | The index of the force plate |
|--------|---|-------------------|---|
| | Subsample | unsigned integer | The subsample to access |
| Output | Result | Result | Result.Success Result.NotConnected Result.NoFrame Result.InvalidIndex |
| | CentreOfPressure | double[3] | The CoP. |
| C++ | A valid ForcePlateIndex is between 0 and GetForcePlateCount()-1 A valid Subsample is between 0 and GetForcePlateSubsamples()-1 // class Output_GetGlobalCentreOfPressure // { // public: // Result::Enum Result; // double | | |
| MATLAB | A valid Subsample i % [Output] = GetG. MyClient = Client MyClient.Connect(| (); "localhost"); | , |
| | <pre>MyClient. EnableDeviceData (); MyClient.GetFrame(); Index = 0; Output_GetForcePlateSubsamples = MyClient.GetForcePlateSubsamples(Index); for Sample = 1:Output_GetForcePlateSubsamples.ForcePlateSubsamples</pre> | | |

SDK Functions Listing

```
Output = MyClient.GetGlobalCentreOfPressure( Index, Sample );
               end
.NET
               A valid ForcePlateIndex is between 0 and GetForcePlateCount() - 1
               A valid Subsample is between 0 and GetForcePlateSubsamples()-1
               // public class Output GetGlobalCentreOfPressure
              // {
// public:
// Result
              // Result
                                      Result;
                    array< double >^ CentreOfPressure;
               // };
               //
               // Output GetGlobalCentreOfPressure
               // GetGlobalCentreOfPressure( uint ForcePlateIndex, uint Subsample )
               const;
               ViconDataStreamSDK.DotNET.Client MyClient = new
               ViconDataStreamSDK.DotNET.Client();
               MyClient.Connect( "localhost" );
               MyClient. EnableDeviceData ();
              MyClient.GetFrame();
              uint Index = 0;
               uint Samples =
               MyClient.GetForcePlateSubsamples(ForcePlateIndex).ForcePlateSubsamples;
               for (uint Sample = 0; Sample < Samples; ++ Sample)</pre>
                 Output GetGlobalCentreOfPressure Output = MyClient.
               GetGlobalCentreOfPressure (Index, Sample);
```

SDK Functions Listing

Appendix A: What's New

GetEyeTrackerCount

Return the number of eye trackers available in the DataStream.

See Also: GetEyeTrackerGlobalGazeVector, GetEyeTrackerGlobalGazeVector

| See Also : GetEyeTrackerGlobalGazeVector, GetEyeTrackerGlobalGazeVector | | | | |
|---|--|--|---|--|
| Input | | | | |
| Output | Result | Result | Result.Success Result.NotConnected Result.NoFrame | |
| | Eye Tracker Count | unsigned integer | The number of eye trackers | |
| C++ | <pre>// { // public: // Result::Enum // unsigned int // }; // Output_GetEyeT ViconDataStreamSI MyClient.EnableDe MyClient.GetFrame Output_GetDeviceO</pre> | <pre>// public: // Result::Enum Result; // unsigned int EyeTrackerCount; // };</pre> | | |
| MATLAB | <pre>% [Output] = GetE MyClient = Client MyClient.EnableDe MyClient.Connect(MyClient.GetFrame Output = MyClient</pre> | <pre>% [Output] = GetEyeTrackerCount() MyClient = Client(); MyClient.EnableDeviceData(); MyClient.Connect("localhost"); MyClient.GetFrame(); Output = MyClient.GetEyeTrackerCount(); // Output.Result == Success</pre> | | |
| .NET | // public class 0 // { // public Resul // public uint // }; // Output_GetEyeT ViconDataStreamSI ViconDataStreamSI MyClient.EnableDe MyClient.Connect(MyClient.GetFrame Output_GetEyeTrac // Output.Result | <pre>// public Result Result; // public uint EyeTrackerCount; // };</pre> | | |

SDK Functions Listing

Appendix A: What's New

${\sf GetEyeTrackerGlobalPosition}$

Returns the location of the eye. The position is in Millimeters with respect to the global origin. The segment and device data need to be enabled to get the position.

See Also: GetEyeTrackerCount, GetEyeTrackerGlobalGazeVector

| Input | EyeTrackerIndex | unsigned integer | The index of the eye tracker | |
|--------|--|---|---|--|
| Output | Result | Result | Result.Success Result.NotConnected Result.NoFrame Result.InvalidIndex | |
| | Position | double[3] | The eye position | |
| | Occluded | boolean | This is true if the segment that has the eye tracker attached is not visible. If true the position will be (0,0,0). | |
| C++ | // class Output_ // { // public: // Result::Enu // double // bool // }; // Output_GetEye // const unsigned in ViconDataStreamSI MyClient.Connect MyClient. EnableS MyClient. EnableS MyClient. GetFrame | <pre>// { // public: // Result::Enum Result; // double Position[3]; // bool Occluded; //); // Output_GetEyeTrackerGlobalPosition GetEyeTrackerGlobalPosition(// const unsigned int EyeTrackerIndex) const; ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect("localhost"); MyClient. EnableSegmentData (); MyClient. EnableDeviceData (); MyClient. GetFrame(); Output_GetEyeTrackerGlobalPosition Output =</pre> | | |
| MATLAB | <pre>% [Output] = GetE MyClient = Client MyClient.Connect MyClient. EnableS MyClient. EnableI MyClient.GetFrame</pre> | A valid EyeTrackerIndex is between 1 and GetEyeTrackerCount() % [Output] = GetEyeTrackerGlobalPosition (EyeTrackerIndex) MyClient = Client(); MyClient.Connect("localhost"); MyClient. EnableSegmentData (); MyClient. EnableDeviceData (); MyClient.GetFrame(); Output = MyClient. GetEyeTrackerGlobalPosition (1); | | |
| .NET | <pre>// public ref cl // { // public: // Result</pre> | <pre>// { // public: // Result Result; // array< double >^ Position;</pre> | | |



SDK Functions Listing

SDK Functions Listing

Appendix A: What's New

GetEyeTrackerGlobalGazeVector

Returns the gaze direction as a unit vector in global coordinates. The gaze vector will be marked as occluded if the segment that has the eye tracker attached is not visible, the eye tracker is not calibrated or the pupil is not found. The segment and device data need to be enabled to get the gaze vector.

See Also: GetEyeTrackerCount, GetEyeTrackerGlobalPosition

| Input | EyeTrackerIndex | unsigned integer | The index of the eye tracker | | |
|--------|--|---|---|--|--|
| Output | Result | Result | Result.NotConnected Result.NoFrame Result.InvalidIndex | | |
| | GazeVector | double[3] | The gaze direction vector | | |
| | Occluded | boolean | This is true if gaze vector could not be calculated. If false the position will be (0,0,0). | | |
| C++ | // class Output // { // public: // Result::End // double // bool // }; // Output_GetEye // EyeTrackerIndex) ViconDataStreamSI MyClient.Connect MyClient. EnableS MyClient. EnableS MyClient. GetFrame Output_GetEyeTrace | <pre>// { // public: // Result::Enum Result; // double GazeVector [3]; // bool Occluded; // }; // Output_GetEyeTrackerGlobalGazeVector GetEyeTrackerGlobalGazeVector(</pre> | | | |
| MATLAB | <pre>% [Output] = GetE MyClient = Client MyClient.Connect MyClient. EnableS MyClient. EnableI MyClient.GetFrame</pre> | A valid EyeTrackerIndex is between 1 and GetEyeTrackerCount() % [Output] = GetEyeTrackerGlobalGazeVector (EyeTrackerIndex) MyClient = Client(); MyClient.Connect("localhost"); MyClient. EnableSegmentData (); MyClient. EnableDeviceData (); MyClient.GetFrame(); Output = MyClient. GetEyeTrackerGlobalGazeVector (1); | | | |
| .NET | <pre>// public ref cl // { // public: // Result</pre> | <pre>// { // public: // Result Result;</pre> | | | |



SDK Functions Listing

SDK Functions Listing

Appendix A: What's New

GetCameraCount

Return the number of camera available in the DataStream. See Also: GetCameraName, GetCentroidCount, GetCentroidPosition Input Result.Success Result Result Output Result NotConnected Result.NoFrame CameraCount unsigned integer The number of cameras class Output_GetCameraCount C++ // // public: Result::Enum Result; // unsigned int CameraCount; // }; // Output GetCameraCount GetCameraCount() ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect("localhost"); MyClient. EnableCentroidData (); MyClient.GetFrame(); Output GetCameraCount Output = MyClient.GetCameraCount(); // Output.Result == Success // Output.CameraCount >= 0 % [Output] = GetCameraCount() **MATLAB** MyClient = Client(); MyClient.Connect("localhost"); MyClient. EnableCentroidData(); MyClient.GetFrame(); Output = MyClient. GetCameraCount(); % Output.Result == Success, Output.CameraCount >= 0 // public ref class Output GetCameraCount .NET // { // public: // Result Result: unsigned int CameraCount; // }; // Output_GetCameraCount GetCameraCount() ViconDataStreamSDK.DotNET.Client MyClient = new ViconDataStreamSDK.DotNET.Client(); MyClient.Connect("localhost"); MyClient. EnableCentroidData (); MyClient.GetFrame(); Output GetCameraCount Output = MyClient.GetCameraCount(); // Output.Result == Success // Output.CameraCount >= 0

SDK Functions Listing

Appendix A: What's New

GetCameraName

Return the name of a camera. This name can be passed into centroid functions. See Also: GetCameraCount. GetCentroidCount. GetCentroidPosition

| Input | EyeTrackerIndex | unsigned integer | The index of the eye tracker | | |
|--------|--|---|---|--|--|
| Output | Result | Result | Result.Success Result.NotConnected Result.NoFrame Result.InvalidIndex | | |
| | CameraName | string | The name of the camera | | |
| C++ | <pre>// class Output // { // public: // Result::End // String // }; // Output_GetCam) const; ViconDataStreamSI MyClient.Connect MyClient.Enable(MyClient.GetFrame Output_GetCamera(Output_GetCamera()</pre> | <pre>// { // public: // Result::Enum Result; // String CameraName; // }; // Output_GetCameraName GetCameraName(const unsigned int CameraIndex</pre> | | | |
| MATLAB | <pre>% [Output] = Get() MyClient = Client MyClient.Connect MyClient.Enable() MyClient.GetFrame OutputGCC = MyCl:</pre> | A valid CameraIndex is between 1 and GetCameraCount() % [Output] = GetCameraName (CameraIndex) MyClient = Client(); MyClient.Connect("localhost"); MyClient. EnableCentroidData (); MyClient.GetFrame(); OutputGCC = MyClient.GetCameraCount (1); % OutputGCC.Result == Success % OutputGCC.CameraCount == 1 OutputGCN = MyClient.GetCameraName(1); | | | |
| .NET | <pre>// public ref ci // { // public: // Result // String^ // }; // Output_Get() ViconDataStreamSI</pre> | DK.DotNET.Client MyClie DK.DotNET.Client(); | ame(unsigned int CameraIndex) | | |



SDK Functions Listing

SDK Functions Listing

Appendix A: What's New

GetCentroidCount

Returns the number of centroids reported by a named camera. The centroid data needs to be enabled to get the number of centroids.

See Also: GetCameraCount, GetCameraName, GetCentroidPosition

| Input | CameraName | string | The name of the camera | |
|--------|---|---|--|--|
| Output | Result | Result | Result.Success Result.NotConnected Result.NoFrame Result.InvalidCameraName | |
| | CentroidCount | unsigned integer | The number of centroids | |
| C++ | <pre>// class Output_GetCentroidCount // { // public: // Result::Enum Result; // unsigned int CentroidCount; // }; // Output_GetCentroidCount GetCentroidCount(const std::string & CameraName) const ViconDataStreamSDK::CPP::Client MyClient; MyClient.Connect("localhost"); MyClient.EnableCentroidData (); MyClient.GetFrame(); Output_GetCameraCount OutputGCC = MyClient.GetCameraCount(); for(unsigned int CameraIndex = 0; CameraIndex < OutputGCC.CameraCount; ++CameraIndex) { Output_GetCameraName OutputGCN = MyClient.GetCameraName(CameraIndex); Output_GetCentroidCount OutputGCeC = MyClient.GetCentroidCount(OutputGCN.CameraName); // OutputGCeC.Result == Success // OutputGCeC.CentroidCount</pre> | | | |
| MATLAB | MyClient = Client MyClient.Connect MyClient.Enable MyClient.GetFrame OutputGCC = MyCli for CameraIndex = OutputGCN = MyC | <pre>("localhost"); CentroidData(); e(); Lent.GetCameraCount(); = 1:OutputGCC.CameraCount Client.GetCameraName(CameraI yClient.GetCentroidCount(Out %</pre> | | |
| .NET | <pre>// public ref class Output_GetCentroidCount // {</pre> | | | |

SDK Functions Listing

```
// public:
     Result
                       Result;
     unsigned int CentroidCount;
// };
     Output GetCentroidCount GetCentroidCount( String^ CameraName )
ViconDataStreamSDK.DotNET.Client MyClient = new
ViconDataStreamSDK.DotNET.Client();
MyClient.Connect( "localhost" );
MyClient. EnableCentroidData ();
MyClient.GetFrame();
Output GetCameraCount OutputGCC = MyClient.GetCameraCount();
for( unsigned int CameraIndex = 0; CameraIndex < OutputGCC.CameraCount;</pre>
++CameraIndex )
  OutputGCN = MyClient.GetCameraName( CameraIndex );
  OutputGCeC = MyClient.GetCentroidCount( OutputGCN.CameraName )
                                             % OutputGCeC.Result ==
Success
                                             % OutputGCeC.CentroidCount
>= 0
```

SDK Functions Listing

Appendix A: What's New

GetCentroidPosition

Returns the position and radius of the centroid in camera coordinates. The centroid data needs to be enabled to get the centroid position and radius.

See Also: GetCameraCount, GetCameraName, GetCentroidCount

| Input | CameraName | string | The name of the camera | | |
|--------|--|--|--|--|--|
| | CentroidIndex | unsigned integer | The index of the centroid | | |
| Output | Result | Result | Result.Success Result.NotConnected Result.NoFrame Result.InvalidCameraName Result.InvalidIndex | | |
| | CentroidPosition | double[2] | The position of the centroid | | |
| | Radius | double | The radius of the centroid | | |
| C++ | A valid CentroidInd // class Output_ // { // public: // Result::End // double // double // }; // Output_GetCer //) const; ViconDataStreamSI MyClient.Connect MyClient.EnableC MyClient.GetFrame Output_GetCameral Output_GetCentroid | <pre>// { // public: // Result::Enum Result; // double CentroidPosition [2]; // double Radius; // }; // Output_GetCentroidPosition GetCentroidPosition (//const std::string & CameraName // const unsigned int CentroidIndex</pre> | | | |
| MATLAB | A valid CentroidInd % [Output] = GetC MyClient = Client MyClient.Connect MyClient.EnableC MyClient.GetFrame OutputGCN = MyClient | A valid CameraName is obtained from GetCameraName(CameraIndex) A valid CentroidIndex is between 1 and GetCentroidCount(CameraName) % [Output] = GetCentroidPosition(CameraName, CentroidIndex) MyClient = Client(); MyClient.Connect("localhost"); MyClient.EnableCentroidData (); MyClient.GetFrame(); OutputGCN = MyClient.GetCameraName(1); Output = MyClient.GetCentroidPosition(OutputGCN.CameraName, 1); | | | |
| .NET | A valid CameraNar | A valid CameraName is obtained from GetCameraName(CameraIndex) | | | |

SDK Functions Listing

```
A valid CentroidIndex is between 0 and GetCentroidCount( CameraName )-1
    public ref class Output GetCentroidPosition
// public:
      Result
                         Result;
      array< double >^ Position;
//
      double
                                Radius;
//
   } ;
      Output GetCentroidPosition^ GetCentroidPosition(
//
                                             String^ CameraName
//
                                              unsigned int CentroidIndex )
ViconDataStreamSDK.DotNET.Client MyClient = new
ViconDataStreamSDK.DotNET.Client();
MyClient.Connect( "localhost" );
MyClient. EnableCentroidData ();
MyClient.GetFrame();
Output_GetCameraName OutputGCN = MyClient.GetCameraName( 0 );
Output_GetCentroidPosition Output = MyClient.GetCentroidPosition(
OutputGCN.CameraName, 0);
```

SDK Functions Listing

Appendix A: What's New

Appendix A - What's New

What's New in Version 1.0

- Full access to analog device data in Nexus. This can be scaled data or raw voltages.
- One SDK for all applications.
- Four segment rotation options: Quaternion, 3x3 row-major Matrix, Helical, and EulerXYZ format.
- Support streaming, request, and pre-fetch modes.
- Formats specific to C++, MATLAB and .NET.
- Version control.
- Result feedback for success criteria.

What's New in Version 1.0.1

- C++ programs that access the DS-SDK dll files can now be complied in Debug mode.
- New function calls for Vicon Tracker ***
 - ConnectToMulticast
 - StartTransmittingMulticast
 - StopTransmittingMulticast
 - GetLatencyTotal
 - GetLatencySampleCount
 - GetLatencySampleName
 - GetLatencySampleValue

What's New in Version 1.1.0

- Release of C++ and .NET SDKs on Windows x64.
- Release of C++ SDK on Linux x86.
- New function calls
 - DisableSegmentData
 - DisableMarkerData
 - DisableUnlabeledMarkerData
 - DisableDeviceData
 - GetMarkerParentName
 - GetSubjectRootSegmentName
 - GetSegmentParentName
 - GetSegmentChildCount
 - GetSegmentChildName
 - GetSegmentStaticTranslation
 - GetSegmentStaticRotationHelical
 - GetSegmentStaticRotationMatrix
 - GetSegmentStaticRotationQuaternion

^{***} These functions will not work with Vicon Nexus 1.4 and Vicon Blade 1.6.



SDK Functions Listing

Appendix A: What's New

- GetSegmentStaticRotationEulerXYZ
- Corrected some units. The values given by the SDK have not changed they were incorrectly labeled in previous versions.
 - "NewtonMillimetre" has become "NewtonMeter"
 - "Millimetre" has become "Meter"
- Corrected segment rotations following calls to SetAxisMapping()
- Added command-line options for the Test programs to specify a host to connect to.

What's New in Version 1.2.0

- Added C++ Linux x64 support
- Fix to support of .NET under Windows x64
- New function calls:
 - GetForcePlateCount
 - GetGlobalForceVector
 - GetGlobalMomentVector
 - GetGlobalCentreOfPressure
- Minor improvements to documentation.

What's New in Version 1.3.0

- New function calls:
 - GetFrameRate
 - GetEyeTrackerCount
 - GetEyeTrackerGlobalPosition
 - GetEyeTrackerGlobalGazeVector
 - GetDeviceOutputSubsamples
 - GetForcePlateSubsamples
- New overrides to function calls to allow access to all the analogue data:
 - GetDeviceOutputValue
 - GetGlobalForceVector
 - GetGlobalMomentVector
 - GetGlobalCentreOfPressure
- Minor improvements to documentation.
- Added Mac OSX support.

What's New in Version 1.4.0

- New function calls:
 - SetApexDeviceFeedback



SDK Functions Listing

Appendix A: What's New

What's new in version 1.5.0

- New function calls:
 - EnableCentroidData
 - DisableCentroidData
 - IsCentroidDataEnabled
 - GetCameraCount
 - GetCameraName
 - GetCentroidCount
 - GetCentroidPosition



SDK Functions Listing

Appendix A: What's New

What's new in version 1.6.0

SetAxisMapping() now works correctly with Blade (3.4+) regardless of whether the coordinate system in Blade is set to Y Up or Z Up.

New functions that Expose Marker Labels per Centroid information are now implemented. These allow the user to obtain data on the camera contributions of each marker within a client based upon the SDK.

- EnableMarkerRayData
- DisableMarkerRayData
- IsMarkerRayDataEnabled
- GetMarkerRayContributionCount
- GetMarkerRayContribution