```
Command, Type, Value, Text, Description,
/-action/clearsolo,,,,"Clear all solos",
/-action/initall,,,, "Reinitialize console ??",
/-action/savestate,,,,"Save current state ??",
/-action/setclock,,,, "Set clock",
/-action/updnet,,,,"Lan IP address ??"
/-action/wlanscan,,,,"Wireless scan ??",
/-prefs/ap/channel,,,,"WLan channel",
/-prefs/ap/key,,,,"Access Point key",
/-prefs/ap/security,,,,"Access Point security",
/-prefs/ap/ssid,,,,"Access Point ssid",
/-prefs/clockrate,,,, "Clock Rate",
/-prefs/dcamute,,,,"DCA groups mute Off/On",
/-prefs/hardmute,,,,"Hard mute Off/On",
/-prefs/is/addr,,,,,
/-prefs/is/gateway,,,,
/-prefs/is/key,,,,
/-prefs/is/mask,,,,
/-prefs/is/mode,,,,
/-prefs/is/security,,,,
/-prefs/is/ssid,,,,
/-prefs/lan/addr,,,,"Lan IP address",
/-prefs/lan/gateway,,,,"Lan IP gateway",
/-prefs/lan/mask,,,,"Lan IP mask",
/-prefs/lan/mode,,,,"Lan mode",
/-prefs/midiconfig,,,,"Midi config",
/-prefs/name,,,,"Mixer name",
/-prefs/playnext,,,,"USB player - play next ??",
/-prefs/ponmute,,,,
/-prefs/rta/decay,,,,
/-prefs/rta/det,,,,
/-prefs/usbifcmode,,,,
/-prefs/x/osc,,,,
/-snap/01/name,s,,,"Snapshot [0..63] name",
/-snap/01/scope,,,, "Snapshot [0..63] recall scope",
/-snap/delete,,,,"Snapshot (current) delete",
/-snap/index,i,,, "Snapshot (current) list index",
/-snap/load,,,, "Snapshot (current) load",
/-snap/name,s,,, "Snapshot (current) name"
/-snap/save,,,, "Snapshot (current) save",
/-snapstore/01/scope,,,,"Snapshot [0..63] recall scope",
/-snapstore/index,i,,, "Snapshot (current) list index",
/-snapstore/name,s,,,"Snapshot (current) name",
/-stat/autosave,,,,"Autosave ??",
/-stat/keysolo,,,,??,
/-stat/netmode,i,0..2, "Static, DHCP, DHCP Server", "Lan Mode",
/-stat/networks/01/flags,,,,,
/-stat/networks/01/ssid,,,,
/-stat/networks/01/strength,,,,
/-stat/rta/pos,,,,
/-stat/rta/source,i,,,"RTA source",
/-stat/solo,,,,"Solo status ??",
/-stat/solosw/01,i,0..1,"OFF, ON", "Solo switch [01..20??] status",
/-stat/tape/etime,,,,
/-stat/tape/file,,,,
/-stat/tape/rtime,,,,
/-stat/tape/state,,,,
/-stat/usb/001/name,s,,,"Name of file or subdirectory",
/-stat/usb/001/type,i,0-1,,"Returns 0 for a file, 1 for a subdirectory",
/-stat/usb/count,i,1-200,,"Number of entries in the current path",
/-stat/usb/path,s,,, "Gets or sets the directory path",
/-stat/usbmounted,i,0..1,,"USB mounted status",
/bus/1/config/color,i,0-15,"OFF, RD, GN, YE, BL, MG, CY, WH, OFFi, RDi, GNi, YEi, BLi, MGi, CYi,
WHi", "Mixbus color",
/bus/1/config/name,s,,,"Mixbus name",
```

```
/bus/1/dyn/attack,f,0.0-1.0,"0.0 - 120.0", "Mixbus compressor attack",
/bus/1/dyn/auto,i,0-1,"OFF, ON","Mixbus compressor auto",
/bus/1/dyn/det,i,0-1,"PEAK, RMS","Mixbus compressor ??", /bus/1/dyn/env,i,0-1,"LIN, LOG","Mixbus compressor envelope",
/bus/1/dyn/filter/f,f,0.0-1.0,"20 - 20000", "Mixbus compressor filter frequency",
/bus/1/dyn/filter/f,f,0.0-1.0,"20 - 20000", "Mixbus compressor filter frequency",
/bus/1/dyn/filter/on,i,0-1,"OFF, ON", "Mixbus compressor filter Off/On", /bus/1/dyn/filter/on,i,0-1,"OFF, ON", "Mixbus compressor filter Off/On",
/bus/1/dyn/filter/type,i,0-8,"LC6, LC12, HC6, HC12, 1.0, 2.0, 3.0, 5.0, 10.0","Mixbus compressor
filter type",
/bus/1/dyn/filter/type,i,0-5,"LCut, LShv, PEQ, VEQ, HShv, HCut", "Mixbus compressor filter type",
/bus/1/dyn/hold,f,0.0-1.0,"0.02 - 2000", "Mixbus compressor hold",
/bus/1/dyn/insert/fxslot,i,0-8,"OFF, Fx1A, Fx1B, Fx2A, Fx2B, Fx3A, Fx3B, Fx4A, Fx4B","Mixbus
compressor insert Fx slot",
/bus/1/dyn/insert/on,i,0-1,"OFF, ON", "Mixbus compressor insert Off/On",
/bus/1/dyn/keysrc,i,0-22, "SELF, Ch01-Ch16, Bus1-Bus6", "Mixbus compressor keysource",
/bus/1/dyn/knee,f,0.0-1.0,"0.0 - 5.0", "Mixbus compressor knee",
/bus/1/dyn/mgain,f,0.0-1.0,"0.0 - 24.0", "Mixbus compressor makeup gain",
/bus/1/dyn/mix,f,0.0-1.0,"0 - 100", "Mixbus compressor mix",
/bus/1/dyn/mode,i,0-1, "COMP, EXP", "Mixbus compressor mode",
/bus/1/dyn/on,i,0-1,"OFF, ON", "Mixbus compressor Off/On",
/bus/1/dyn/ratio,i,0-11,"1.1, 1.3, 1.5, 2.0, 2.5, 3.0, 4.0, 5.0, 7.0, 10, 20, 100", "Mixbus
compressor ratio",
/bus/1/dyn/release,f,0.0-1.0,"5.0 - 4000.0", "Mixbus compressor release",
/bus/1/dyn/thr,f,0.0-1.0,"-60.0 - 0.0", "Mixbus compressor threshold",
/bus/1/eq/1/f,f,0.0-1.0,"20 - 20000", "Mixbus EQ band frequency",
/bus/1/eq/1/g,f,0.0-1.0,"-15.0 - +15.0", "Mixbus EQ band gain",
\frac{1}{eq}\frac{1}{q}, f, 0.0-1.0, 10.0 - 9.3, Mixbus EQ band Q, 
/bus/1/eq/1/type,i,0-5,"LCut, LShv, PEQ, VEQ, HShv, HCut", "Mixbus EQ type",
/bus/1/eq/mode,i,0-2,"PEQ, GEQ, TEQ","Mixbus EQ mode",
/bus/1/eq/on,i,0-1,"OFF, ON", "Mixbus EQ Off/On",
/bus/1/geq/0,f,0.0-1.0,"-15.0 - +15.0", "Mixbus graphics EQ band level",
/bus/1/insert/fxslot,i,0-8,"OFF, Fx1A, Fx1B, Fx2A, Fx2B, Fx3A, Fx3B, Fx4A, Fx4B","Mixbus insert
Fx slot",
/bus/1/insert/on,i,0-1,"-15.0 - +15.0", "Mixbus insert Off/On",
/bus/1/mix/fader,f,0.0-1.0,"-oo - +10", "Mixbus fader level",
/bus/1/mix/lr,i,0-1,"OFF, ON", "Mixbus LR assignment",
/bus/1/mix/on,i,0-1,"OFF, ON", "Mixbus mute",
/bus/1/mix/pan,f,0.0-1.0,"-oo - +10", "Mixbus pan level",
/bus/grp/dca,i,0-,%0000,"Mixbus DCA assignment",
/bus/grp/mute,i,0-,%0000,"Mixbus mutegroup assignment",
/ch/01/automix/group,i,0-2,"OFF, X, Y","Channel automix assignment",
/ch/01/automix/weight,f,0.0-1.0,"-24 - +24", "Channel automix weight level",
/ch/01/config/color,i,0-15, "OFF, RD, GN, YE, BL, MG, CY, WH, OFFi, RDi, GNi, YEi, BLi, MGi, CYi,
WHi", "Channel scribble trip color",
/ch/01/config/insrc,i,0-15,"OFF, IN01-16","Channel input source",
/ch/01/config/name,s,,, "Channel scribble strip name",
/ch/01/config/rtnsrc,i,0-17,U01-18, "Channel USB input source",
/ch/01/dyn/attack,f,0.0-1.0,"0.0 - 120.0", "Channel compressor attack (ms)",
/ch/01/dyn/auto,i,0-1,"OFF, ON", "Channel compressor auto off/on",
/ch/01/dyn/det,i,0-1,"PEAK, RMS",,
/ch/01/dyn/env,i,0-1,"LIN, LOG", "Channel compressor envelope",
/ch/01/dyn/filter/f,f,0.0-1.0,"20 - 20000", "Channel compressor filter frequency (hz)",
/ch/01/dyn/filter/on,i,0-1,"OFF, ON", "Channel compressor filter off/on",
/ch/01/dyn/filter/type,i,0-8,"LC6, LC12, HC6, HC12, 1.0, 2.0, 3.0, 5.0, 10.0","Channel
compressor filter type",
/ch/01/dyn/hold, f, 0.0-1.0, "0.02 - 2000", "Channel compressor hold (ms)",
/ch/01/dyn/keysrc,i,0-22, "SELF, Ch01-Ch16, Bus1-Bus6", "Channel compressor key source",
/ch/01/dyn/knee,f,0.0-1.0,"0.0 - 5.0", "Channel compressor knee",
/ch/01/dyn/mgain,f,0.0-1.0,"0.0 - 24.0", "Channel compressor gain (db)",
/ch/01/dyn/mix,f,0.0-1.0,"0 - 100", "Channel compressor mix",
/ch/01/dyn/mode,i,0-1, "COMP, EXP", "Channel compressor mode",
/ch/01/dyn/on,i,0-1, "OFF, ON", "Channel compressor off/on",
/ch/01/dyn/ratio,i,0-11,"1.1, 1.3, 1.5, 2.0, 2.5, 3.0, 4.0, 5.0, 7.0, 10, 20, 100", "Channel
compressor ratio",
/ch/01/dyn/release,f,0.0-1.0,"5.0 - 4000.0", "Channel compressor release (ms)",
```

```
/ch/01/eq/1/g, f, 0.0-1.0, "-15.0 - +15.0", "Channel EQ band gain",
/ch/01/eq/1/q, f, 0.0-1.0, "10.0 - 0.3", "Channel EQ band Q",
/ch/01/eq/1/type,i,0-5,"LCut, LShv, PEQ, VEQ, HShv, HCut", "Channel EQ band type",
/ch/01/eq/on,i,0-1,"OFF, ON", "Channel EQ Off/On",
/ch/01/gate/attack,f,0.0-1.0,"0.0 - 120.0", "Channel gate attack (ms)",
/ch/01/gate/filter/f,f,0.0-1.0,"20.000 - 20000", "Channel gate filter frequency (hz)",
/ch/01/gate/filter/on,i,0-1,"OFF, ON", "Channel gate filter off/on",
/ch/01/gate/filter/type,i,0-8,"LC6, LC12, HC6, HC12, 1.0, 2.0, 3.0, 5.0, 10.0", "Channel gate
filter type",
/ch/01/gate/hold,f,0.0-1.0,"0.02 - 2000", "Channel gate hold (ms)",
/ch/01/gate/keysrc,i,0-22, "SELF, Ch01-Ch16, Bus1-Bus6", "Channel gate key source",
/ch/01/gate/mode,i,0-4, "GATE, EXP2, EXP3, EXP4, DUCK", "Channel gate mode",
/ch/01/gate/on,i,0-1,"OFF, ON", "Channel gate off/on",
/ch/01/gate/range,f,0.0-1.0,"3.0 - 60.0", "Channel gate range (db)",
/ch/01/gate/release,f,0.0-1.0,"5.0 - 4000.0", "Channel gate release (ms)",
/ch/01/gate/thr,f,0.0-1.0,"-80.0 - 0.0", "Channel gate threshold (db)",
/ch/01/geq/0,f,0.0-1.0,"-15.0 - +15.0", "Channel graphics EQ level",
/ch/01/grp/dca,i,0-,%0000, "Channel DCA assignment",
/ch/01/grp/mute,i,0-,%0000, "Channel mutegroup assignment",
/ch/01/insert/fxslot,i,0-8,"OFF, Fx1A, Fx1B, Fx2A, Fx2B, Fx3A, Fx3B, Fx4A, Fx4B","Channel insert
assignment",
/ch/01/insert/on,i,0-1,"OFF, ON", "Channel insert Off/On",
/ch/01/mix/01/grpon,i,0-1,"OFF, ON", "Channel mixbus sends group Off/On",
/ch/01/mix/01/level, f, 0.0-1.0, "-oo - +10", "Channel mixbus sends level",
/ch/01/mix/01/pan,f,0.0-1.0,"-100 - +100","Channel mixbus sends pan",
/ch/01/mix/01/tap,i,0-5,"IN, PREEQ, POSTEQ, PRE, POST, GRP", "Channel mixbus sends tap",
/ch/01/mix/fader,f,0.0-1.0,"-oo - +10", "Channel fader level",
/ch/01/mix/lr,i,0-1,"OFF, ON", "Channel LR assignment",
/ch/01/mix/on,i,0-1,"OFF, ON", "Channel mute",
/ch/01/mix/pan,f,0.0-1.0,"-100 - +100", "Channel pan value", /ch/01/preamp/hpf,f,0.0-1.0,"20 - 200", "Channel low cut frequency (hz)",
/ch/01/preamp/hpon,i,0-1,"OFF, ON", "Channel low cut off/on",
/ch/01/preamp/invert,i,0-1,"OFF, ON", "Channel preamp invert",
/ch/01/preamp/rtnsw,i,0-1,"OFF, ON", "Channel Return switch (preamp/USB)",
/ch/01/preamp/rtntrim,f,0.0-1.0,"-18 - +18","Channel USB preamp trim",
/config/amixenable/X,i,0-1, "OFF, ON", "Automix - Group X Off/On",
/config/amixenable/Y,i,0-1,"OFF, ON", "Automix - Group Y Off/On",
/config/amixlock/X,i,0-1,"OFF, ON","Automix - Lock X Off/On",
/config/amixlock/Y,i,0-1,"OFF, ON", "Automix - Lock Y Off/On",
/config/buslink/1-2,i,0-2,"1-2 .. 5-6", "Bus links (odd/even pairs 1-2, 3-4, etc)",
/config/chlink/1-2,i,0-7,"1-2 .. 15-16", "Channel links (odd/even pairs 1-2, 3-4, etc)",
/config/linkcfg/dyn,i,0-1,"OFF, ON","Link Pref - Dyn",
/config/linkcfg/eq,i,0-1,"OFF, ON","Link Pref - EQ",
/config/linkcfg/fdrmute,i,0-1,"OFF, ON","Link Pref - Fader, Mute, Sends",
/config/linkcfg/preamp,i,0-1, "OFF, ON", "Link Pref - preamp",
/config/mute/1,i,0-1,"OFF, ON", "Mutegroup [1..4] Off/On",
/config/solo/busmode,i,0-1,"PFL, AFL","Headphone source bus tap",
/config/solo/chmode,i,0-1,"PFL, AFL", "Headphone source channel tap",
/config/solo/dim,i,0-1,"OFF, ON", "Headphone Dim Off/On",
/config/solo/dimatt,f,0.0-1.0,"-40 - 0","Headphone Dim Gain",
/config/solo/dimpfl,i,0-1,"OFF, ON","Headphone PFL-Dim",
/config/solo/level,f,0.0-1.0,"-oo - +10.0","Headphone volume level",
/config/solo/mono,i,0-1,"OFF, ON","Headphone Mono Off/On",
/config/solo/mute,i,0-1,"OFF, ON", "Headphone Mute Off/On",
/config/solo/source,i,0-14,"OFF, LR, LRPFL, LRAFL, AUX, U1718, Bus1-6, Bus12, Bus34,
Bus56", "Headphone source",
/config/solo/sourcetrim,f,0.0-1.0,"-18.0 - +12.0","Headphone source trim",
/dca/1/config/color,i,0-15, "OFF, RD, GN, YE, BL, MG, CY, WH, OFFi, RDi, GNi, YEi, BLi, MGi, CYi,
WHi", "DCA color",
/dca/1/config/name,s,,,"DCA name",
/dca/1/fader,f,0.0-1.0,"-oo - +10","DCA fader level",
/dca/1/on,i,0-1,"OFF, ON","DCA [1..4] Off/On",
/fx/1/insert,i,0-1,"OFF, ON","Fx slot [1..4] insert",
/fx/1/par/01,i,,,"Fx slot [1..4] parameter value (see doc)",
```

/ch/01/dyn/thr, f, 0.0-1.0, "-60.0 - 0.0", "Channel compressor the shold (db)",

/ch/01/eq/1/f,f,0.0-1.0,"20 - 20000", "Channel EQ band frequency",

```
/fx/1/type,i,0-60,"61 Fx, see doc", "Fx slot [1..4] type (see doc)",
/fxsend/1/config/color,i,0-15,"OFF, RD, GN, YE, BL, MG, CY, WH, OFFi, RDi, GNi, YEi, BLi, MGi,
CYi, WHi", "Fx send color",
/fxsend/1/config/name,s,,,"Fx send name",
/fxsend/1/grp/dca,i,0-,%0000,"Fx send DCA assignment",
/fxsend/1/grp/mute,i,0-,%0000,"Fx send mutegroup assignment",
/fxsend/1/mix/fader,f,0.0-1.0,"-oo - +10","Fx send fader level",
/fxsend/1/mix/on,i,0-1,"OFF, ON","Fx send mute",
/headamp/01/gain,f,0.0-1.0,"-12 - +20","Headamp gain",
/headamp/01/phantom,i,0-1,"OFF, ON","Headamp phantom Off/On",
/lr/config/color/,i,0-15,"OFF, RD, GN, YE, BL, MG, CY, WH, OFFi, RDi, GNi, YEi, BLi, MGi, CYi,
WHi", "Main LR color",
/lr/config/name,s,,,"Main LR name",
/lr/dyn/attack,f,0.0-1.0,"0.0 - 120.0", "Main LR compressor attack",
/lr/dyn/auto,i,0-1,"OFF, ON", "Main LR compressor auto",
/lr/dyn/det,i,0-1, "PEAK, RMS", "Main LR compressor ??",
/lr/dyn/env,i,0-1,"LIN, LOG", "Main LR compressor envelope",
/lr/dyn/filter/f,f,0.0-1.0,"20 - 20000", "Main LR compressor filter frequency",
/lr/dyn/filter/on,i,0-1,"OFF, ON", "Main LR compressor filter Off/On",
/lr/dyn/filter/type,i,0-8,"LC6, LC12, HC6, HC12, 1.0, 2.0, 3.0, 5.0, 10.0","Main LR compressor
filter type",
/lr/dyn/hold,f,0.0-1.0,"0.02 - 2000", "Main LR compressor hold",
/lr/dyn/insert/fxslot,i,0-8,"OFF, Fx1A, Fx1B, Fx2A, Fx2B, Fx3A, Fx3B, Fx4A, Fx4B","Main LR
compressor insert Fx slot",
/lr/dyn/insert/on,i,0-1,"OFF, ON", "Main LR compressor insert Off/On",
/lr/dyn/keysrc,i,0-22, "SELF, Ch01-Ch16, Bus1-Bus6", "Main LR compressor keysource",
/lr/dyn/knee,f,0.0-1.0,"0.0 - 5.0", "Main LR compressor knee",
/lr/dyn/mgain,f,0.0-1.0,"0.0 - 24.0", "Main LR compressor makeup gain",
/lr/dyn/mix,f,0.0-1.0,"0 - 100", "Main LR compressor mix",
/lr/dyn/mode,i,0-1, "COMP, EXP", "Main LR compressor mode",
/lr/dyn/on,i,0-1,"OFF, ON", "Main LR compressor Off/On",
/lr/dyn/ratio,i,0-11,"1.1, 1.3, 1.5, 2.0, 2.5, 3.0, 4.0, 5.0, 7.0, 10, 20, 100","Main LR
compressor ratio",
/lr/dyn/release,f,0.0-1.0,"5.0 - 4000.0", "Main LR compressor release",
/lr/dyn/thr,f,0.0-1.0,"-60.0 - 0.0", "Main LR compressor threshold",
/lr/eq/1/f,f,0.0-1.0,"20 - 20000","Main LR EQ frequency",
/1r/eq/1/g, f, 0.0-1.0, "-15.0 - +15.0", "Main LR EQ gain",
/lr/eq/1/q, f, 0.0-1.0, "10.0 - 0.3", "Main LR EQ Q",
/lr/eq/1/type,i,0-5,"LCut, LShv, PEQ, VEQ, HShv, HCut", "Main LR EQ band type",
/lr/eq/mode,i,0-2, "PEQ, GEQ, TEQ", "Main LR EQ mode",
/lr/eq/on,i,0-1,"OFF, ON", "Main LR EQ Off/On",
/1r/geq/0,f,0.0-1.0,"-15.0 - +15.0","Main LR graphics EQ band level",
/lr/mix/fader,f,0.0-1.0,"-oo - +10", "Main LR fader level",
/lr/mix/on,i,0-1,"OFF, ON", "Main LR mute",
/lr/mix/pan,f,0.0-1.0,"-100 - +100", "Main LR pan level",
/routing/aux/01/pos,i,0-10,"AIN, AIN+M, IN, IN+M, PREEQ, PREEQ+M, POSTEQ, POSTEQ+M, PRE, PRE+M,
POST", "Routing Aux [1..6] tap",
/routing/aux/01/src,i,0-55, "Ch01-16, AuxL-R, Fx1L-Fx4R, Bus1-6, Send1-4, L, R, U1-18", "Routing
Aux [1..6] source",
/routing/main/01,i,0-10,"LR, MON, U0102-U1718", "Routing Main assignment",
/routing/p16/01/pos,i,0-10,"AIN, AIN+M, IN, IN+M, PREEQ, PREEQ+M, POSTEQ, POSTEQ+M, PRE, PRE+M,
POST", "Routing P16 [1..16] ??",
/routing/p16/01/src,i,0-55,"Ch01-16, AuxL-R, Fx1L-Fx4R, Bus1-6, Send1-4, L, R, U1-18","Routing
P16 [1..16] source",
/routing/usb/01/pos,i,0-10,"AIN, AIN+M, IN, IN+M, PREEQ, PREEQ+M, POSTEQ, POSTEQ+M, PRE, PRE+M,
POST", "Routing USB [1..36] ??",
/routing/usb/01/src,i,0-37, "Ch01-16, AuxL-R, Fx1L-Fx4R, Bus1-6, Send1-4, L, R", "Routing USB
[1..36] source",
/rtn/1/config/color,i,0-15, "OFF, RD, GN, YE, BL, MG, CY, WH, OFFi, RDi, GNi, YEi, BLi, MGi, CYi,
WHi", "Fx Return [1..4] color",
/rtn/1/config/name,s,,,"Fx Return [1..4] name",
/rtn/1/config/rtnsrc,i,0-8,"U0102, U0304, U0506, - U1718","Fx Return [1..4] source",
/rtn/1/eq/1/f,f,0.0-1.0,"20 - 20000","Fx Return [1..4] EQ band frequency",
/rtn/1/eq/1/g,f,0.0-1.0,"-15.0 - +15.0","Fx Return [1..4] EQ band gain",
/rtn/1/eq/1/q,f,0.0-1.0,"10.0 - 0.3","Fx Return [1..4] EQ band Q",
/rtn/1/eq/1/type,i,0-5,"LCut, LShv, PEQ, VEQ, HShv, HCut","Fx Return [1..4] EQ band type",
```

```
/rtn/1/mix/01/grpon,i,0-1,"OFF, ON", "Fx Return [1..4] mixbus sends group",
/rtn/1/mix/01/level,f,0.0-1.0,"-oo - +10", "Fx Return [1..4] mixbus sends level",
/rtn/1/mix/01/pan,f,0.0-1.0,"-100 - +100","Fx Return [1..4] mixbus sends pan",
/rtn/1/mix/01/tap,i,0-5,"IN, PREEQ, POSTEQ, PRE, POST, GRP", "Fx Return [1..4] mixbus sends tap",
/rtn/1/mix/fader,f,0.0-1.0,"-oo - +10", "Fx Return [1..4] fader level",
/rtn/1/mix/lr,i,0-1,"OFF, ON","Fx Return [1..4] LR assignment",
/rtn/1/mix/on,i,0-1,"OFF, ON", "Fx Return [1..4] mute",
/rtn/1/mix/pan,f,0.0-1.0,"-100 - +100","Fx Return [1..4] pan level",
/rtn/1/preamp/rtnsw,i,0-1,"OFF, ON", "Fx Return [1..4] preamp switch (preamp/USB)",
/\text{rtn/1/preamp/rtntrim}, f, 0.0-1.0, "-18.0 - +18.0", "Fx Return [1..4] preamp trim",
/rtn/aux/config/color,i,0-15, "OFF, RD, GN, YE, BL, MG, CY, WH, OFFi, RDi, GNi, YEi, BLi, MGi,
CYi, WHi", "Aux Return color",
/rtn/aux/config/name,s,,,"Aux Return name",
/rtn/aux/config/rtnsrc,i,0-8,"U0102, U0304, U0506, - U1718","Aux Return source",
"/rtn/aux/eq ON",i,0-1,"OFF, ON","Aux Return EQ Off/On",
/rtn/aux/eq/1/f,f,0.0-1.0,"20 - 20000", "Aux Return EQ band frequency",
/rtn/aux/eq/1/g,f,0.0-1.0,"-15.0 - +15.0", "Aux Return EQ band gain",
/rtn/aux/eq/1/q,f,0.0-1.0,"10 - 0.3","Aux Return EQ band Q",
/rtn/aux/eq/1/type,i,0-5,"LCut, LShv, PEQ, VEQ, HShv, HCut", "Aux Return EQ band type",
/rtn/aux/mix/01/grpon,i,0-1,"OFF, ON","Aux Return mixbus sends group Off/On",
/rtn/aux/mix/01/level,f,0.0-1.0,"-oo - +10","Aux Return mixbus sends level", /rtn/aux/mix/01/pan,f,0.0-1.0,"-100 - +100","Aux Return mixbus sends pan level",
/rtn/aux/mix/01/tap,i,0-5,"IN, PREEQ, POSTEQ, PRE, POST, GRP","Aux Return mixbus sends tap",
/rtn/aux/mix/fader,f,0.0-1.0,"-oo - +10","Aux Return fader level",
/rtn/aux/mix/lr,i,0-1,"OFF, ON","Aux Return LR assignment",
/rtn/aux/mix/on,i,0-1,"OFF, ON","Aux Return mute",
/rtn/aux/mix/pan,f,0.0-1.0,"-100 - +100","Aux Return pan level",
/rtn/aux/preamp/rtnsw,i,0-1,"OFF, ON","Aux Return switch (preamp/USB)",
/rtn/aux/preamp/rtntrim,f,0.0-1.0,"-18.0 - +18.0","Aux Return trim",
/xinfo,,,, "Returns info of the X-Air (eg firmware #, etc)",
```