



# PYMKEROS2\_NODE v1.0

Python ROS2 Node For MkE Point Cloud Publishing

Magik Eye Inc.

## COLLABORATORS

	TITLE:		
	PYMKEROS2_NODE v1.0		
ACTION	NAME	DATE	SIGNATURE
WRITTEN BY	Magik Eye Inc.	Jan 2021	

## REVISION HISTORY

NUMBER	DATE	DESCRIPTION	NAME
2101-01-EN-00	Jan 2021	Initial version	MEI

## **Contents**

1	Introduction			
2 Compilation				
	2.1	Dependencies	1	
	2.2	Installation	1	
3	Exe	cution	2	
	3.1	MkE Sensor Discovery	2	
	3.2	Launching	3	
		3.2.1 Launching the node with Command line paramters (CLI)	3	
		3.2.2 Launching the node using Launch file	3	
4	Serv	vices	4	
	4.1	Start Publishing	4	
	4.2	Stop Publishing	4	
5	Acc	essing The Point Cloud Data	5	
6	Bibliography			

#### 1 Introduction

This document describes v1.0 of pymkeros2 v1.0 ROS2 Package. This package contains ROS2 node pymkeros2\_node for publishing 3D point cloud data provided by Magik Eye sensors. Currently, pymkeros2\_node connects to Magik Eye devices that provide 3D data using the TCP/IP protocol. The pymkeros2\_node codebase depends on the MkE API[mkeapi] Python client implementation pymkeapi. The following table lists the officially supported platforms for pymkeros2\_node:

Ubuntu Version	ROS Distribution
Ubuntu 18.04 64bit	ROS Crystal
Ubuntu 20.04 64bit	ROS Foxy

#### Note

This document assumes that the reader has a working knowledge of ROS2 and the ROS2 package compilation procedure. Documentation or explanation of any of these topics is out of the scope of this document.

Upon launch, the pymkeros2\_node registers a new node pymkeros2\_node\_NAME, where NAME is the node's unique identifier that depends on the command line parameters passed to the node executable. It also publishes two services: pymkeros2\_startpublish\_NAME and pymkeros2\_stoppublish\_NAME. Once the pymkeros2\_startpublish\_NAME service is invoked, the node connects to a Magik Eye sensor via TCP/IP network and starts publishing the sensor's 3D data stream under the pymkeros2\_node\_pcd\_NAME topic. The topic is unpublished and the connection to the sensor closed upon invocation of the pymkeros2\_stoppublish\_NAME service.

## 2 Compilation

### 2.1 Dependencies

The pymkeros2\_node codebase depends on the MkE API[mkeapi] Python client implementation pymkeapi. Root path of the pymkeapi installation can be provided to the PYTHONPATH environment variable in the following manner

\$ export PYTHONPATH=\$PYTHONPATH:/path/to/pymkeapi/

#### 2.2 Installation

The pymkeros2\_node ROS2 node installation is based on the CMake build system and Colcon <sup>2</sup>. Let's suppose that the ROS2 distribution has been installed into the \${ROS2\_ROOT} directory and the pymkeros2\_node codebase resides in the \${PYMKEROS2\_ROOT} ROS2 Package. The \${PYMKEROS2\_ROOT} ROS2 package resides in the \${ROS2\_WS} ROS2 workspace. In order to install the package, run the following command:

<sup>&</sup>lt;sup>1</sup>ros2

<sup>&</sup>lt;sup>2</sup>https://colcon.readthedocs.io/en/released/user/quick-start.html

```
$ mkdir "${ROS2_WS}/build"
$ cd "${ROS2_WS}/build"
$ source ${ROS2_ROOT}/setup.bash
$ colcon build --symlink-install --packages-select pymkeros2 --base- 
    paths ..
```

This will create the installation directory install in the \${ROS2\_WS} ROS2 workspace. —symlink-install allows the installed files to be changed by changing the files in the source space (e.g. Python files or other not compiled resources) for faster iteration.

To test the pymkeros2\_node execution, execute the following commands:

```
$ source ${ROS2_WS}/build/install/setup.bash
$ ros2 run pymkeros2 pymkeros2_node --help
```

#### 3 Execution

Once compiled, the pymkeros2\_node can be invoked through the pymkeros2 package. The help parameter lists and describes the available command line parameters:

```
$ source ${ROS2_WS}/install/setup.bash
$ ros2 run pymkeros2 pymkeros2_node --help
```

#### 3.1 MkE Sensor Discovery

In order to connect to a Magik Eye sensor, the pymkeros2\_node executable needs to be provided with the IP address of unit ID of the sensor in question. Since all Magik Eye TCP/IP-enabled sensors implement network discovery using the SSDP protocol, pymkeros2\_node executable provides the discover command line option that will list all MagikEye sensors connected to the local TCP/IP network. In the following example, the pymkeros2\_node executable was able to discover two MagikEye sensors:

```
$ ros2 run pymkeros2 pymkeros2_node --discover
MagikEyeOne-0242be55:192.168.0.100
MagikEyeOne-0242ac2a:192.168.4.101
```

The list specifies the unit ID's and respective IP addresses of the discovered sensors.

The discover parameter can be also used in combination with the device parameter to check the availability of a particular sensor. The value of the device parameter can be an IP address or a unit ID:

#### 3.2 Launching

#### 3.2.1 Launching the node with Command line paramters (CLI).

The node pymkeros2\_node is launched if the launch and device parameters are provided:

The above will launch a node called pymkeros2\_node\_MagikEyeOne-0242be55 and start two services called pymkeros2\_startpublish\_MagikEyeOne\_0242be55 and pymkeros2\_stoppublish\_MagikEyeOne\_0242be55 respectively. Again, the device parameter can also contain the sensor's IP address. The sensor specific part of the node and services names can be overriden using the alias parameter:

#### Note

The node will *not* connect to the sensor upon launch, nor will it check the availability of the sensor. The connection will only be attempted upon invocation of the pymkeros2\_node\_startpublish\_*NAME* service. For an immediate check of the sensor's availability, use the discover parameter.

#### 3.2.2 Launching the node using Launch file.

The launch file present in \${PYMKEROS2\_ROOT}/launch/pymkeros2\_launch.py can be used to launch the pymkeros2\_node with default parameters described in \${PYMKEROS2\_ROOT}/config/pymkeros2\_config.yaml. The device parameter is mandatory to use the launch file. The device parameter should be provided with IP Address/Unit ID. The alias parameter is optional.

For example, the parameters described in pymkeros2\_config.yaml are as under:

```
# Default configurations
MKEROS_NODE:
ros__parameters:
   device : "MagikEyeOne-34cff660"
   alias : "sensor1"
```

Launching the launch file with above parameters can be done in the following manner:

```
$ ros2 launch pymkeros2 pymkeros2_launch.py

[INFO] [launch]: All log files can be found below /home/magikeye/.ros/ 
log/2021-02-11-11-31-42-559158-magikeye-Yoga-Slim-7-14IIL05-16338

[INFO] [launch]: Default logging verbosity is set to INFO

[INFO] [pymkeros2-1]: process started with pid [16340]

[pymkeros2-1] [INFO] [1613023303.031078917] [pymkeros2_node_sensor1]: 
Launching node: pymkeros2_node_sensor1

[pymkeros2-1] [INFO] [1613023303.031477020] [pymkeros2_node_sensor1]: 
Starting service: pymkeros2_startpublish_sensor1

[pymkeros2-1] [INFO] [1613023303.033186781] [pymkeros2_node_sensor1]: 
Starting service: pymkeros2_stoppublish_sensor1
```

#### 4 Services

Upon execution, the pymkeros2\_node binary publishes two services: pymkeros2\_startpublish\_NAME and pymkeros2\_stoppublish\_NAME.

#### 4.1 Start Publishing

Once the pymkeros2\_startpublish\_NAME service is invoked, the node connects to a Magik Eye sensor via TCP/IP network and starts publishing the sensor's 3D data stream under the pymkeros2\_node\_pcd\_NAME topic. If the sensor has been specified via its IP address, the node will try to connect to the sensor directly. In the case the sensor has been specified using its unit ID, the discovery procedure to recover its IP address will be performed. Once the connection is established, the pymkeros2\_node\_pcd\_NAME topic is published.

The pymkeros2\_node node provides a convenience parameter start to call the start service. The device can be specified via the device or alias options:

```
$ ros2 run pymkeros2 pymkeros2_node --start --alias s1
[INFO] [1612953661.365947423] [rclcpp]: Calling service: 
    pymkeros2_startpublish_sensor1
[INFO] [1612953662.439238763] [rclcpp]: Service called successfully: 
    pymkeros2_startpublish_sensor1
```

### 4.2 Stop Publishing

The pymkeros2\_node\_pcd\_NAME topic is unpublished and the connection to the sensor closed upon invocation of the pymkeros2\_stoppublish\_NAME service.

The pymkeros2\_node binary provides a convenience parameter stop to call the stop service. The device can be specified via the device or alias options:

```
$ ros2 run pymkeros2 pymkeros2_node --stop --alias s1
[INFO] [1612953665.295884780] [rclcpp]: Calling service: 
   pymkeros2_stoppublish_sensor1
[INFO] [1612953665.409713437] [rclcpp]: Service called successfully: 
   pymkeros2_stoppublish_sensor1
```

## 5 Accessing The Point Cloud Data

While publishing, the sensor data will be available on the topic called pymkeros2\_node\_pcd\_NAME. The message format of the data published on this topic is sensormsgs::PointCloud2.

# 6 Bibliography

• [] MagikEye API v1.0, 2020, Magik Eye Inc.