



MKEROS1_NODE v1.0

C++ ROS1 Node For MkE Point Cloud Publishing

Magik Eye Inc.

\sim	1 4	D	D A	$\Gamma \cap$	DC
COL	.LA	DU	'nΑ	ıv	пo

	TITLE :	4.0	
	MKEROS1_NODE v1.0		
ACTION	NAME	DATE	SIGNATURE
WRITTEN BY	Magik Eye Inc.	Jan 2021	

REVISION HISTORY

NUMBER	DATE	DESCRIPTION	NAME
2101-00-EN-00	Jan 2021	Initial version	MEI

Contents

1	Intr	oduction	1			
2	Compilation					
	2.1	Dependencies	1			
	2.2	Installation	2			
3	Exe	cution	2			
	3.1	MkE Sensor Discovery	2			
	3.2	Launching	3			
		3.2.1 Launching Through the Command Line	3			
		3.2.2 Launching Through a Launch File	4			
4	Serv	vices	4			
	4.1	Start Publishing	4			
	4.2	Stop Publishing	5			
5	Acc	essing The Point Cloud Data	5			
6	Bibl	liography	5			

1 Introduction

This document describes MKEROS1_NODE (also spelled mkeros1_node) v1.0, a ROS1 1 node present in mkeros package for publishing 3D point cloud data provided by Magik Eye sensors. Currently, mkeros1_node connects to Magik Eye devices that provide 3D data using the TCP/IP protocol. The mkeros1_node codebase depends on the MkE API[mkeapi] C++ client implementation libmkeclient. The following table lists the officially supported platforms for mkeros1_node:

Ubuntu Version	ROS Distribution
Ubuntu 18.04 64bit	ROS Melodic
Ubuntu 20.04 64bit	ROS Noetic

Note

This document assumes that the reader has a working knowledge of ROS and the ROS package compilation procedure. Documentation or explanation of any of these topics is out of the scope of this document.

Upon launch, the mkeros1_node binary registers a new node mkeros1_node_NAME, where NAME is the node's unique identifier that depends on the command line parameters passed to the node executable. It also publishes two services: mkeros1_startpublish_NAME and mkeros1_stoppublish_NAME. Once the mkeros1_startpublish_NAME service is invoked, the node connects to a Magik Eye sensor via TCP/IP network and starts publishing the sensor's 3D data stream under the mkeros1_node_pcd_NAME topic. The topic is unpublished and the connection to the sensor closed upon invocation of the mkeros1_stoppublish_NAME service.

2 Compilation

The mkeros1_node ROS node compilation is based on the CMake build system and Catkin ². Let's suppose that the ROS distribution has been installed into the \${ROS_ROOT} directory and the mkeros1_node codebase resides in the \${MKEROS_ROOT} ROS package of \${ROS1_WS} ROS workspace. The following BASH commands will compile the mkeros1_node into the \${ROS1_WS}/build/directory:

```
$ mkdir "${ROS1_WS}/build"
$ cd "${ROS1_WS}/build"
$ source ${ROS_ROOT}/setup.bash
$ catkin_make --pkg mkeros --source ..
```

2.1 Dependencies

The mkeros1_node codebase depends on the MkE API[mkeapi] C++ client implementation libmkeclient. In the case the libmkeclient library is not automatically found by the CMake system, a root path of the libmkeclient installation can be provided via the MKECLI_ROOT variable:

¹ros.org

²http://docs.ros.org/en/api/catkin/html

Alternatively, path to the source directory of libmkeclient can be provided:

2.2 Installation

The compiled mkeros1_node resides in the mkeros ROS package. In order to install the package, run the following command:

```
$ catkin_make --source .. install --cmake-args
```

This will create the installation directory install in the \${ROS1_WS}/build directory. Alternatively, the installation path can be changed using the CMAKE_INSTALL_PREFIX CMake option. Let's assume that the \${ROS1_WS_INST} variable points to the desired installation directory:

To test the mkeros1_node compilation, execute the following commads:

```
$ source ${ROS1_WS_INST}/setup.bash
$ rosrun mkeros mkeros1_node --help
```

3 Execution

Once installed, the mkeros1_node can be invoked through the mkeros package. The help parameter lists and describes the available command line parameters:

```
$ source ${ROS1_WS_INST}/setup.bash
$ rosrun mkeros mkeros1_node --help
```

3.1 MkE Sensor Discovery

In order to connect to a Magik Eye sensor, the mkerosl_node executable needs to be provided with the IP address of unit ID of the sensor in question. Since all Magik Eye TCP/IP-enabled sensors implement network discovery using the SSDP protocol, mkerosl_node executable provides the discover command line option that will list all MagikEye sensors connected to the local TCP/IP network. In the following example, the mkerosl_node executable was able to discover two Magik-Eye sensors:

```
$ rosrun mkeros mkeros1_node --discover
MagikEyeOne-0242be55:192.168.0.100
MagikEyeOne-0242ac2a:192.168.4.101
```

The list specifies the unit ID's and respective IP addresses of the discovered sensors.

The discover parameter can be also used in combination with the device parameter to check the availability of a particular sensor. The value of the device parameter can be an IP address or a unit ID:

```
$ rosrun mkeros mkeros1_node --discover --device MagikEyeOne-0242be55
$ echo $?
0
$ rosrun mkeros mkeros1_node --discover --device 192.168.0.100
$ echo $?
0
$ rosrun mkeros mkeros1_node --discover --device 192.168.0.102
$ echo $?
1
```

3.2 Launching

The mkeros1_node node can be launched either by providing the connection information through the command line parameters or through a launch file.

Note

The roscore (rosmaster) process must already be running in order for the roslaunch or rosrun commands to work.

3.2.1 Launching Through the Command Line

The node is launched if the launch and device parameters are provided:

The above will launch a node called mkeros1_node_MagikEyeOne-0242be55 and start two services called mkeros1_startpublish_MagikEyeOne_0242be55 and mkeros1_stoppublish_MagikEyeOne_0242be55 respectively. Again, the device parameter can also contain the sensor's IP address. The sensor specific part of the node and services names can be overriden using the alias parameter:

Note

The node will *not* connect to the sensor upon launch, nor will it check the availability of the sensor. The connection will only be attempted upon invocation of the mkeros1_startpublish_*NAME* service. For an immediate check of the sensor's availability, use the discover parameter.

3.2.2 Launching Through a Launch File

The launch file present \${MKEROS_ROOT}/launch/mkeros1_cpp.launch can used launch mkeros_node with default parameters the \${MKEROS_ROOT}/config/mkeros1_config.yaml. The device parameter is a mandatory of the launch file. The alias parameter is optional. Note that if the device parameter or the alias parameter is updated, the mkeros package needs to be reinstalled.

For example, the launch file mkeros1_config.yaml can look as follows:

```
# Default configurations
device : "192.168.0.117"
# alias : "s1"
```

Launching the node using a launch file with the above parameters can be done using the roslaunch command:

```
$ roslaunch mkeros mkeros1_cpp.launch
```

Note

If roslaunch is used to launch the mkeros1_node using the above method, then rosrun should not be invoked to launch start and stop services or for other CLI parameters.

4 Services

Upon execution, the mkeros1_node binary publishes two services: mkeros1_startpublish_NAME and mkeros1_stoppublish_NAME.

Note

If roslaunch is used to launch the mkeros1_node, then the services mkeros1_startpublish_NAME and mkeros1_stoppublish_NAME should be called using rosservice call command of ROS API.

4.1 Start Publishing

Once the mkeros1_startpublish_NAME service is invoked, the node connects to a Magik Eye sensor via TCP/IP network and starts publishing the sensor's 3D data stream under the mkeros1_node_pcd_NAME topic. If the sensor has been specified via its IP address, the node will try to connect to the sensor directly. In the case the sensor has been specified using its unit ID, the discovery procedure to recover its IP address will be performed. Once the connection is established, the mkeros1_node_pcd_NAME topic is published.

The mkeros1_node binary provides a convenience parameter start to call the start service. The device can be specified via the device or alias options:

```
$ rosrun mkeros mkeros1_node --start --alias s1
[ INFO] [...]: Calling service: mkeros1_startpublish_s1
[ INFO] [...]: Service called successfully: mkeros1_startpublish_s1
```

4.2 Stop Publishing

The mkeros1_node_pcd_NAME topic is unpublished and the connection to the sensor closed upon invocation of the mkeros1_stoppublish_NAME service.

The mkeros1_node binary provides a convenience parameter stop to call the stop service. The device can be specified via the device or alias options:

```
$ rosrun mkeros mkeros1_node --stop --alias s1
[ INFO] [...]: Calling service: mkeros1_stoppublish_s1
[ INFO] [...]: Service called successfully: mkeros1_stoppublish_s1
```

5 Accessing The Point Cloud Data

While publishing, the sensor data will be available on the topic called mkerosl_node_pcd_NAME. The message format of the data published on this topic is sensormsqs::PointCloud2.

6 Bibliography

• [] MagikEye API v1.0, 2020, Magik Eye Inc.