# SCAT Instruction Set Architecture

Working draft 2022-09-22

### **CPU Registers**

The CPU has 16 registers named R0 to R15, each 32 bits wide. Register R0 (aka zero) is hardwired with all bits equal to 0. All writes to R0 are discarded. Register R15 (aka PC) is the *Program Counter*, i.e. it holds the address of the current instruction. Other registers (R1 to R14) are general purpose, i.e. they are freely available for software. Typically though, register R13 is used as the *Stack Pointer* SP and R14 as the *Link Register* LR.

### **Instruction Format**

All instructions are 32 bits in length, and follow a similar format as illustrated below. Bits bits 28 to 31 are the *Type* field; they indicate how the rest of the instruction bits should be interpreted. Bits 24 to 27 are specific to each instruction type: opcode for ALU instructions, comparison code for conditional branches, etc. The next fields are the *destination* (rd) and *source* (rs1, rs2) registers. Most instruction types use just one source register. In that case, bits 0 to 15 encode a 16-bits *immediate value* that serves as an additional operand to the instruction.

ALU reg-reg ALU reg-imm Cond. jump Memory Subroutines

31 28	27 24	23 20	19 16	15 12	11 0
type 1	ор	rd	rs1	rs2	ignored
type 2	ор	rd	rs1		imm
type 3	comp	rd	rs1		imm
type 4	trans	rd	rs1		imm
type 5	ignored	rd	rs1		imm

Type 1: Arithmetic and Logic Register-Register Operations

· .			_		
	asm	Name	opcode	Description	Notes
	add	Addition	0000	rd = rs1 + rs2	
	sub	Subtraction	0001	rd = rs1 - rs2	
	mul	Multiplication	0010	rd = rs1 * rs2	
	div	Integer Division	0011	rd = rs1 / rs2	quotient of floored division
	mod	Modulo	0100	rd = rs1 % rs2	remainder of floored division
	or	Bitwise OR	0101	rd = rs1   rs2	
	and	Bitwise AND	0110	rd = rs1 & rs2	
	xor	Bitwise exclusive OR	0111	rd = rs1 ^ rs2	
	lsl	Logical Shift Left	1000	rd = rs1 << rs2	
	lsr	Logical Shift Right	1001	rd = rs1 >> rs2	
	asr	Arithmetic Shift Right	1010	rd = rs1 >> rs2	rs1 as a signed integer
	slt	Set Less Than	1011	rd = (rs1 < rs2)?1:0	rs1/rs2 as signed integers
	sltu	Set Less Than, Unsigned	1100	rd = (rs1 < rs2)?1:0	rs1/rs2 as unsigned integers

### Notes:

- In shift instructions, rs2 is always interpreted as a positive (unsigned) number. However, shifts only make sense when 0 < rs2 < 32.
- Multiplication discards the upper bits of the result.
- The div and mod instructions implement *floored division* semantics: the mathematical result is always rounded towards negative infinity. For example  $8 \div -3$  gives -3 with a remainder of -1.

## Type 2: Arithmetic and Logic Register-Immediate Operations

These instructions are similar to type 1 but the second operand is a sign-extended 16-bits immediate value.

asm	Name	op code	Description
addi	Addition	0000	rd = rs1 + sxt(imm)
subi	Subtraction	0001	rd = rs1 - sxt(imm)
muli	Multiplication	0010	rd = rs1 * sxt(imm)
divi	Integer Division	0011	rd = rs1 / sxt(imm)
modi	Modulo	0100	rd = rs1 % sxt(imm)
ori	Bitwise OR	0101	rd = rs1   sxt(imm)
andi	Bitwise AND	0110	rd = rs1 & sxt(imm)
xori	Bitwise exclusive OR	0111	rd = rs1 ^ sxt(imm)
lsli	Logical Shift Left	1000	rd = rs1 << imm
lsri	Logical Shift Right	1001	rd = rs1 >> imm
asri	Arithmetic Shift Right	1010	rd = rs1 >> imm
slti	Set Less Than	1011	rd = (rs1 < sxt(imm))?1:0
sltiu	Set Less Than, Unsigned	1100	rd = (rs1 < imm)?1:0

Note: Shift instructions only make sense with 0 < imm < 32.

## Type 3: Conditional Jumps aka Compare-And-Branch

These instructions compare the values of two registers and take a jump (i.e. change the value of PC) when the condition is verified.

asm	Name	comp code	Description
beq	Branch if equal	0000	if (rd == rs1) PC += sxt(imm)
bne	Branch if not equal	0001	if (rd != rs1) PC += sxt(imm)
blt	Branch if lower than	0010	if (rd < rs1) PC += sxt(imm)
bge	Branch if greater or equal	0011	if (rd >= rs1) PC += sxt(imm)
bltu	Branch if lower than, Unsigned	0100	if (rd < rs1) PC += sxt(imm)
bgeu	Branch if greater or equal, Unsigned	0101	if (rd >= rs1) PC += sxt(imm)

Note: blt/bge perform a signed comparison, whereas bltu/bgeu interpret both operands as unsigned numbers.

**Type 4: Memory transfers** 

asm	Name	trans code	Description
load rd, [rs1 + offset]	Load Word	0000	rd = MEM[rs1 + sxt(imm)]
store [rd + offset], rs	Store Word	0001	<pre>MEM[rd + sxt(imm)] = rs1</pre>

Type 5: Subroutine calls

asm	Name	trans code	Description
jal	Jump-And-Link	0000	rd = PC+4 ; PC = rs1 + sxt(imm)

Typically, jal is used with R14 (aka LR) as destination register. Returning from subroutine can be achieved with jal R0, LR.

#### **Pseudo Instructions**

$\begin{array}{c ccccccccccccccccccccccccccccccccccc$	asm	Base Instruction(s)	Description
leti rd, imm addi rd, zero, imm Assign constant (see below for large values) not rd, rs xori rd, rs, -1 One's complement aka bitwise NOT neg rd, rs sub rd, zero, rs Two's complement aka sign change seqz rd, rs sltiu rd, rs, 0 Set rd if $rs = 0$ snez rd, rs slt rd, zero, rs Set rd if $rs \neq 0$ stz rd, rs slt rd, rs, zero Set rd if $rs > 0$ set rd if $rs $	nop	addi r0, r0, 0	Preferred encoding for NOP
not rd, rs	mov rd, rs	addi rd, rs, 0	Copy a value from one register to another
neg rd, rs sub rd, zero, rs Two's complement aka sign change seqz rd, rs sltiu rd, rs, 0 Set rd if rs = 0 snez rd, rs slt rd, zero, rs Set rd if rs $\neq$ 0 sltz rd, rs slt rd, rs, zero Set rd if rs $<$ 0 sgtz rd, rs slt rd, zero, rs Set rd if rs $>$ 0 set rd if	leti rd, imm	addi rd, zero, imm	Assign constant (see below for large values)
seqz rd, rs sltiu rd, rs, 0 Set rd if rs = 0 snez rd, rs slt rd, zero, rs Set rd if rs $\neq$ 0 sltz rd, rs slt rd, rs, zero Set rd if rs $\neq$ 0 set rd if r $\neq$ 0 set rd if rs $\neq$ 0 se	not rd, rs	xori rd, rs, -1	One's complement aka bitwise NOT
snez rd, rs slt rd, zero, rs Set rd if rs $\neq 0$ sltz rd, rs slt rd, rs, zero Set rd if rs $< 0$ set rd if rs $> 0$ set rd if r	neg rd, rs	sub rd, zero, rs	Two's complement aka sign change
$\begin{array}{cccccccccccccccccccccccccccccccccccc$	seqz rd, rs	sltiu rd, rs, 0	Set rd if rs = 0
$\begin{array}{cccccccccccccccccccccccccccccccccccc$	snez rd, rs	slt rd, zero, rs	Set rd if rs $\neq 0$
bra offset addi R15, R15, offset Branch always beqz r, offset bhe r, zero, offset Branch if $r=0$ bhez r, offset bge zero, r, offset Branch if $r\neq 0$ blez r, offset bge zero, r, offset Branch if $r \neq 0$ blez r, offset bge r, zero, offset Branch if $r \geq 0$ bltz r, offset blt r, zero, offset Branch if $r > 0$ bltz r, offset blt zero, r, offset Branch if $r > 0$ bgt r1, r2, offset blt r2, r1, offset Branch if $r > 0$ bgt r1, r2, offset bge r2, r1, offset Branch if $r > 0$ bgt r1, r2, offset bge r2, r1, offset Branch if $r > 0$ bgt r1, r2, offset bge r2, r1, offset Branch if $r > 0$ bgt r1, r2, offset bge r2, r1, offset Branch if $r > 0$ bgt r1, r2, offset bge r2, r1, offset Branch if $r > 0$ bgt r1, r2, offset bge r2, r1, offset Branch if $r > 0$ bgt r1, r2, offset bge r2, r1, offset Branch if $r > 0$ bgt r1, r2, offset bge r2, r1, offset Branch if $r > 0$ bgt r1, r2, offset bge r2, r1, offset Branch if r1 $r > 0$ bgt r1, r2, offset bge r2, r1, offset Branch if r1 $r > 0$ bgt r1, r2, offset bge r2, r1, offset Branch if r1 $r > 0$ bgt r1, r2, offset bge r2, r1, offset Branch if r1 $r > 0$ bgt r1, r2, offset bge r2, r1, offset Branch if r1 $r > 0$ bgt r1, r2, offset bge r2, r1, offset Branch if r1 $r > 0$ bgt r1, r2, offset bge r2, r1, offset Branch if r1 $r > 0$ bgt r1, r2, offset bge r2, r1, offset Branch if r1 $r > 0$ bgt r1, r2, offset bge r2, r1, offset Branch if r1 $r > 0$ bgt r1, r2, offset Branch if r1 $r > 0$ bgt r1, r2, offset Branch if r1 $r > 0$ bgt r1, r2, offset Branch if r1 $r > 0$ bgt r1, r2, offset Branch if r1 $r > 0$ bgt r1, r2, offset Branch if r2 $r > 0$ bgt r1, r2, offset Branch if r1 $r > 0$ bgt r1, r2, offset Branch if r2 $r > 0$ bgt r1, r2, offset Branch if r2 $r > 0$ bgt r1, r2, offset Branch if r2 $r > 0$ bgt r1, r2, offset Branch if r2 $r > 0$ bgt r1, r2, offset Branch if r2 $r > 0$ bgt r1, r2, offset Branch if r2 $r > 0$ bgt r1, r2, offset Branch if r2 $r > 0$ bgt r1, r2, offset Branch if r2 $r > 0$ bgt r1, r2, offset Branch if r2 $r > 0$ bgt r1, r2, offset Branch if r2 $r > 0$ bgt r1,	sltz rd, rs	slt rd, rs, zero	Set rd if rs < 0
$\begin{array}{cccccccccccccccccccccccccccccccccccc$	sgtz rd, rs	slt rd, zero, rs	Set rd if $rs > 0$
bnez r, offset bne r, zero, offset Branch if $r \neq 0$ blez r, offset bge zero, r, offset Branch if $r \leq 0$ bgez r, offset bge r, zero, offset Branch if $r \geq 0$ bltz r, offset blt r, zero, offset Branch if $r < 0$ bgtz r, offset blt zero, r, offset Branch if $r > 0$ bgt r1, r2, offset blt r2, r1, offset Branch if r1 > r2 ble r1, r2, offset bge r2, r1, offset Branch if r1 > r2 bgtu r1, r2, offset bltu r2, r1, offset Branch if r1 > r2, both unsigned bleu r1, r2, offset bgeu r2, r1, offset Branch if r1 > r2, both unsigned bleu r1, r2, offset bgeu r2, r1, offset Branch if r1 > r2, both unsigned bleu r1, r2, offset bgeu r2, r1, offset Branch if r1 $\leq$ r2, both unsigned push reg subi r13, r13, 4 store [r13], reg Push onto stack (r13 is our stack pointer) pop reg load reg, [r13] addi r13, r13, 4 Pop from stack pointer) load reg, [r13] addi r13, r13, 4 Pop from stack Relative jump, return address discarded call offset jal R14, R15, offset Relative jump, return address saved to LR	bra offset	addi R15, R15, offset	Branch always
blez r, offset bge zero, r, offset Branch if $r\leqslant 0$ bgez r, offset bge r, zero, offset Branch if $r\geqslant 0$ bltz r, offset blt r, zero, offset Branch if $r<0$ bgtz r, offset blt zero, r, offset Branch if $r>0$ bgt r1, r2, offset blt r2, r1, offset Branch if $r1>r2$ ble r1, r2, offset bge r2, r1, offset Branch if $r1>r2$ bgtu r1, r2, offset bltu r2, r1, offset Branch if $r1>r2$ bgtu r1, r2, offset bgeu r2, r1, offset Branch if $r1>r2$ , both unsigned bleu r1, r2, offset bgeu r2, r1, offset Branch if $r1>r2$ , both unsigned push reg subi r13, r13, 4 store [r13], reg Push onto stack (r13 is our stack pointer) pop reg load reg, [r13] addi r13, r13, 4 Pop from stack pointer) in addi r13, r13, 4 Pop from stack Relative jump, return address discarded rall offset jal R14, R15, offset Relative jump, return address saved to LR	beqz r, offset	beq r, zero, offset	Branch if $r = 0$
bgez r, offset bge r, zero, offset Branch if $r\geqslant 0$ bltz r, offset blt r, zero, offset Branch if $r<0$ bgtz r, offset blt zero, r, offset Branch if $r>0$ bgt r1, r2, offset blt r2, r1, offset Branch if $r1>r2$ ble r1, r2, offset bge r2, r1, offset Branch if $r1>r2$ bgtu r1, r2, offset bltu r2, r1, offset Branch if $r1>r2$ bleu r1, r2, offset bltu r2, r1, offset Branch if $r1>r2$ , both unsigned bleu r1, r2, offset bgeu r2, r1, offset Branch if $r1>r2$ , both unsigned push reg subi r13, r13, 4 store [r13], reg Push onto stack (r13 is our stack pointer) load reg, [r13] addi r13, r13, 4 Pop from stack pointer) fight poffset jal zero, R15, offset Relative jump, return address discarded Relative jump, return address saved to LR	bnez r, offset	bne r, zero, offset	Branch if $r \neq 0$
bltz r, offset blt r, zero, offset Branch if $r < 0$ bgtz r, offset blt zero, r, offset Branch if $r > 0$ bgt r1, r2, offset blt r2, r1, offset Branch if $r1 > r2$ ble r1, r2, offset bge r2, r1, offset Branch if $r1 < r2$ bgtu r1, r2, offset bltu r2, r1, offset Branch if $r1 < r2$ bgtu r1, r2, offset bltu r2, r1, offset Branch if $r1 > r2$ , both unsigned bleu r1, r2, offset bgeu r2, r1, offset Branch if $r1 < r2$ , both unsigned push reg subi r13, r13, 4 store [r13], reg Push onto stack (r13 is our stack pointer) pop reg load reg, [r13] addi r13, r13, 4 Pop from stack [r13] reg Pop from stack Relative jump, return address discarded Relative jump, return address saved to LR	blez r, offset	bge zero, r, offset	Branch if $r \leqslant 0$
$\begin{array}{cccccccccccccccccccccccccccccccccccc$	bgez r, offset	bge r, zero, offset	Branch if $r \geqslant 0$
bgt r1, r2, offset blt r2, r1, offset Branch if r1 $>$ r2 ble r1, r2, offset bge r2, r1, offset Branch if r1 $>$ r2 bgtu r1, r2, offset bltu r2, r1, offset Branch if r1 $>$ r2, both unsigned bleu r1, r2, offset bgeu r2, r1, offset Branch if r1 $>$ r2, both unsigned push reg subi r13, r13, 4 store [r13], reg push onto stack (r13 is our stack pointer) pop reg load reg, [r13] addi r13, r13, 4 Pop from stack pointer) jal zero, R15, offset Relative jump, return address discarded Relative jump, return address saved to LR	bltz r, offset	blt r, zero, offset	Branch if $r < 0$
ble r1, r2, offset bge r2, r1, offset Branch if r1 $\leq$ r2 bgtu r1, r2, offset bltu r2, r1, offset Branch if r1 $>$ r2, both unsigned bleu r1, r2, offset bgeu r2, r1, offset Branch if r1 $\leq$ r2, both unsigned push reg subi r13, r13, 4 store [r13], reg Push onto stack (r13 is our stack pointer) load reg, [r13] addi r13, r13, 4 Pop from stack pointer) pop reg jal zero, R15, offset call offset jal R14, R15, offset Relative jump, return address saved to LR	bgtz r, offset	blt zero, r, offset	Branch if $r > 0$
bgtu r1, r2, offset bltu r2, r1, offset Branch if r1 > r2, both unsigned bleu r1, r2, offset bgeu r2, r1, offset Branch if r1 $\leq$ r2, both unsigned push reg subi r13, r13, 4 store [r13], reg Push onto stack (r13 is our stack pointer) pop reg load reg, [r13] addi r13, r13, 4 Pop from stack pointer) addi r13, r13, 4 Pop from stack pointer jal zero, R15, offset call offset jal R14, R15, offset Relative jump, return address saved to LR	bgt r1, r2, offset	blt r2, r1, offset	Branch if $r1 > r2$
bleu r1, r2, offset bgeu r2, r1, offset Branch if r1 $\leq$ r2, both unsigned push reg subi r13, r13, 4 store [r13], reg Push onto stack (r13 is our stack pointer) pop reg load reg, [r13] addi r13, r13, 4 Pop from stack jal zero, R15, offset call offset jal R14, R15, offset Relative jump, return address saved to LR	ble r1, r2, offset	bge r2, r1, offset	Branch if $r1 \leqslant r2$
push reg subi r13, r13, 4 store [r13], reg pop reg load reg, [r13] addi r13, r13, 4 pop from stack  jmp offset call offset jal R14, R15, offset Relative jump, return address discarded Relative jump, return address saved to LR	bgtu r1, r2, offset	bltu r2, r1, offset	Branch if $r1 > r2$ , both unsigned
store [r13], reg pop reg load reg, [r13] addi r13, r13, 4 Pop from stack  jmp offset jal zero, R15, offset Relative jump, return address discarded Relative jump, return address saved to LR	bleu r1, r2, offset	bgeu r2, r1, offset	Branch if $r1 \leqslant r2$ , both unsigned
pop reg load reg, [r13]  addi r13, r13, 4 Pop from stack  jmp offset jal zero, R15, offset Relative jump, return address discarded call offset jal R14, R15, offset Relative jump, return address saved to LR	push reg	subi r13, r13, 4	
addi r13, r13, 4 Pop from stack  jmp offset jal zero, R15, offset Relative jump, return address discarded call offset jal R14, R15, offset Relative jump, return address saved to LR		store [r13], reg	Push onto stack (r13 is our stack pointer)
jmp offsetjal zero, R15, offsetRelative jump, return address discardedcall offsetjal R14, R15, offsetRelative jump, return address saved to LR	pop reg	load reg, [r13]	
call offset jal R14, R15, offset Relative jump, return address saved to LR		addi r13, r13, 4	Pop from stack
	jmp offset	jal zero, R15, offset	Relative jump, return address discarded
ret jal zero, R14 Return from subroutine	call offset	jal R14, R15, offset	Relative jump, return address saved to LR
	ret	jal zero, R14	Return from subroutine

#### Immediates above 16 bits

The leti pseudo-instruction assigns a literal value to a register. When the number is between -32768 and 32767 (both included) it will simply be encoded in 16-bits two's complement, and used as the immediate operand in an addi instruction.

For larger values, the assembler will have to generate several instructions in a row. For example, writing leti r1, 0x12345678 will produce three instructions:

```
addi r1, zero, 0x1234
lsli r1, r1, 16 ; shift into upper half
addi r1, r1, 0x5678
```

This is often enough, but because addi always performs a sign-extension, some (rare) values are trickier to compute correctly. For example leti r1, 0x43218765 translates into no less than five instructions.

An alternative (manual) approach is to have the value somewhere as a named .word and load it through PC-indirect addressing, as illustrated below. Note: be sure to choose a "safe" place (e.g. just after an unconditional jump) where the CPU will not attempt to execute a value as an instruction.

```
load r1, [myvalue] ; assembled as [r15+8] jmp +0
myvalue: .word 0x43218765
```