
INPUT/OUTPUT ORGANIZATION

UNIT 5

Accessing I/O Devices, Interrupts –Interrupt Hardware, Enabling and Disabling Interrupts, Exceptions, Handling Multiple Devices, Controlling Device Requests, Buses, Direct Memory Access, Interface Circuits (parallel, Serial), Standard I/O Interfaces – PCI Bus, SCSI Bus, USB (Basics only)

Accessing I/O Devices

Accessing I/O devices




- •Multiple I/O devices may be connected to the processor and the memory via a bus.
- •Bus consists of three sets of lines to carry address, data and control signals.
- •Each I/O device is assigned an unique address.
- To access an I/O device, the processor places the address on the address lines.
- The device recognizes the address, and responds to the control signals.

Accessing I/O devices (contd..)

- I/O devices and the memory may share the same address space:
 - Memory-mapped I/O.
 - Any machine instruction that can access memory can be used to transfer data to or from an I/O device.
 - Simpler software.
- I/O devices and the memory may have different address spaces:
 - I/O-mapped I/O
 - Special instructions to transfer data to and from I/O devices.
 - I/O devices may have to deal with fewer address lines.
 - I/O address lines need not be physically separate from memory address lines.
 - In fact, address lines may be shared between I/O devices and memory, with a control signal to indicate whether it is a memory address or an I/O address.

Accessing I/O devices (contd..)



- •I/O device is connected to the bus using an I/O interface circuit which has:
 - Address decoder, control circuit, and data and status registers.
- •Address decoder decodes the address placed on the address lines thus enabling the device to recognize its address.
- •Data register holds the data being transferred to or from the processor.
- Status register holds information necessary for the operation of the I/O device.
- •Data and status registers are connected to the data lines, and have unique addresses.
- •I/O interface circuit coordinates I/O transfers.

Accessing I/O devices (contd..)


• Recall that the rate of transfer to and from I/O devices is slower than the speed of the processor. This creates the need for mechanisms to synchronize data transfers between them.

- Program-controlled I/O:
 - Processor repeatedly monitors a status flag to achieve the necessary synchronization.
 - Processor polls the I/O device.
- Two other mechanisms used for synchronizing data transfers between the processor and memory:
 - Interrupts.
 - Direct Memory Access.

Interrupts

Interrupts- Basics

- In program-controlled I/O, when the processor continuously monitors the status of the device, it does not perform any useful tasks.
- An alternate approach would be for the I/O device to alert the processor when it becomes ready.
 - Do so by sending a hardware signal called an interrupt to the processor.
 - At least one of the bus control lines, called an interrupt-request line is dedicated for this purpose.
- Processor can perform other useful tasks while it is waiting for the device to be ready.




- •Processor is executing the instruction located at address i when an interrupt occurs.
- •Routine executed in response to an interrupt request is called the interrupt-service routine.
- When an interrupt occurs, control must be transferred to the interrupt service routine.
- •But before transferring control, the current contents of the PC (i+1), must be saved in a known location.
- This will enable the return-from-interrupt instruction to resume execution at i+1.
- •Return address, or the contents of the PC are usually stored on the processor stack.

- When a processor receives an interrupt-request, it must branch to the interrupt service routine.
- It must also inform the device that it has recognized the interrupt request.
- This can be accomplished in two ways:
 - Some processors have an explicit *interrupt-acknowledge* control signal for this purpose.
 - In other cases, when the data transfer that takes place between the device and the processor, an instruction in ISR accesses the device status or data register.
 Accessing a device register implicitly informs the device that its request has been recognized.

- Treatment of an interrupt-service routine is very similar to that of a subroutine.
- However there are significant differences:
 - A subroutine performs a task that is required by the calling program.
 - Interrupt-service routine may not have anything in common with the program it interrupts.
 - Interrupt-service routine and the program that it interrupts may belong to different users.
 - As a result, before branching to the interrupt-service routine, not only the PC, but other information such as condition code flags, and processor registers used by both the interrupted program and the interrupt service routine must be stored.
 - This will enable the interrupted program to resume execution upon return from interrupt service routine.

- Saving and restoring information can be done automatically by the processor or explicitly by program instructions.
- Saving and restoring registers involves memory transfers:
 - Increases the total execution time.
 - Increases the delay between the time an interrupt request is received, and the start of execution of the interrupt-service routine. This delay is called <u>interrupt latency</u>.
- In order to reduce the interrupt latency, most processors save only the minimal amount of information:
 - This minimal amount of information includes Program Counter and processor status registers.
- Any additional information that must be saved, must be saved explicitly by the program instructions at the beginning of the interrupt service routine.

Interrupt Hardware



Interrupt Hardware

- A single interrupt request line may be used to serve n devices. All devices are connected to the line via switches to ground.
- To request an interrupt, a device closes its associated switch, the voltage on INTR line drops to 0(zero).
- If all the interrupt request signals (INTR1 to INTRn) are inactive, all switches are open and the voltage on INTR line is equal to Vdd.
- When a device requests an interrupt, the value of INTR is the logical OR of the requests from individual devices.
 - (ie) INTR = INTR1+....+INTRn
- **INTR** ¹ It is used to name the INTR signal on common line; it is active in the low voltage state.

Enabling & Disabling Interrupts – from a single device

- Interrupt-requests interrupt the execution of a program, and may alter the intended sequence of events:
 - Sometimes such alterations may be **undesirable**, and must not be allowed.
 - For example, the processor may not want to be interrupted by the same device while executing its interrupt-service routine.
- Processors generally provide the ability to enable and disable such interruptions as desired.

Enabling & Disabling Interrupts – solution1

- One simple way is to provide machine instructions such as *Interrupt-enable* and *Interrupt-disable* for this purpose.
- To avoid interruption by the same device during the execution of an interrupt service routine:
 - First instruction of an interrupt service routine can be Interrupt-disable.
 - Last instruction of an interrupt service routine can be Interrupt-enable.
 - This is done by the **programmer of ISR**.

Enabling & Disabling Interrupts – solution2

- The PS (Processor Status register) has a *interrupt* enable bit.
- An interrupt request is accepted only when this bit is 1
- Before starting the execution of ISR, the processor disables the interrupts by **clearing the** *interrupt enable* **bit.**
- After the completion of ISR interrupt enable bit is set to 1
- This is done by the **processor automatically**.

Handling Multiple Devices

- Multiple I/O devices may be connected to the processor and the memory via a bus.
- Some or all of these devices may be capable of generating interrupt requests.
 - Each device operates independently, and hence no definite order can be imposed on how the devices generate interrupt requests.


Handling Multiple Devices

- When several devices requests interrupt at the same time, it raises some questions. They are.
 - How does the processor know which device has generated an interrupt?
 (Device Identification)
 - How does the processor know which interrupt service routine needs to be executed? (vectored Interrupts)
 - When the processor is executing an interrupt service routine for one device, can other device interrupt the processor? (interrupt Nesting)
 - If two interrupt-requests are received simultaneously, then how to break the tie? (Simultaneous Requests)

Device Identification

- Consider a simple arrangement where all devices send their interrupt-requests over a single control line in the bus.
- When the processor receives an interrupt request over this control line, how does it know which device is requesting an interrupt?
- This information is available in the **status register** of the device requesting an interrupt:
 - The status register of each device has an IRQ bit which it sets to 1 when it requests an interrupt.
- Interrupt service routine can poll the I/O devices connected to the bus. The **first device** with *IRQ* equal to 1 is the one that is serviced.
- Polling mechanism is **easy**, but **time consuming** to query the status bits of all the I/O devices connected to the bus.

Registers in Key Board and Display Interface



- DIRQ -Interrupt Request for display.
- KIRQ -Interrupt Request for keyboard.
- KEN -keyboard enable.
- DEN -Display Enable.
- SIN, SOUT -status flags. For KB and display respectively
- For a KB, SIN = 1, when a character is entered at the keyboard; SIN = 0, once the char is read by processor.


Device Identification

- The device requesting an interrupt may **identify itself** directly to the processor.
 - Device can do so by sending a special code (4 to 8 bits) to the processor over the bus.
 - Code supplied by the device may represent a part of the starting address of the interrupt-service routine.
 - The remainder of the starting address is obtained by the processor based on other information such as the area in memory where the addresses for interrupt service routines are located.
- Usually the location pointed to by the interrupting device is used to store the starting address of the interrupt-service routine.

- Previously, before the processor started executing the interrupt service routine for a device, it disabled the interrupts from the same device.
- In general, same arrangement is used when multiple devices can send interrupt requests to the processor.
 - During the execution of an interrupt service routine of device, the processor **does not** accept interrupt requests from any other device.
 - Since the interrupt service routines are **usually short**, the delay of executing ISR is **generally acceptable**.
- However, for certain devices this delay may not be acceptable.
 - Which devices can be allowed to interrupt a processor when it is executing an interrupt service routine of another device?

- I/O devices are organized in a **priority** structure:
 - An interrupt request from a high-priority device is accepted while the processor is executing the interrupt service routine of a low priority device.
- A priority level is assigned to a processor that can be changed under program control.
 - Priority level of a processor is the priority of the program that is currently being executed.
 - When the processor starts executing the interrupt service routine of a device, its priority is raised to that of the device.
 - If the device sending an interrupt request has a **higher priority** than the processor, the processor **accepts the interrupt** request.

- Processor's priority is encoded in a few bits of the processor status register.
 - Priority can be changed by instructions that write into the processor status register.
 - Usually, these are privileged instructions, or instructions that can be executed only
 in the supervisor mode.
 - Privileged instructions cannot be executed in the user mode.
 - Prevents a user program from accidentally or intentionally changing the priority of the processor.
- If there is an attempt to execute a privileged instruction in the user mode, it causes a special type of interrupt called as privilege exception.



- •Each device has a separate interrupt-request and interrupt-acknowledge line.
- •Each interrupt-request line is assigned a different priority level.
- •Interrupt requests received over these lines are sent to a priority arbitration circuit in the processor.
- •If the interrupt request has a higher priority level than the priority of the processor, then the request is accepted.

Simultaneous Requests

(on a single interrupt line)


- Which interrupt request does the processor accept if it receives interrupt requests from two or more devices simultaneously?.
- If the I/O devices are organized in a priority structure, the processor accepts the interrupt request from a device with higher priority.
 - Each device has its own interrupt request and interrupt acknowledge line.
 - A different priority level is assigned to the interrupt request line of each device.
- However, if the devices share an interrupt request line, then how does the processor decide which interrupt request to accept?

Simultaneous Requests

Polling scheme:

- •If the processor uses a polling mechanism to poll the status registers of I/O devices to determine which device is requesting an interrupt.
- •In this case the priority is determined by the order in which the devices are polled.
- •The first device with status bit set to 1 is the device whose interrupt request is accepted.


Daisy chain scheme:



- •Devices are connected to form a daisy chain.
- •Devices share the interrupt-request line, and interrupt-acknowledge line is connected to form a daisy chain.
- •When devices raise an interrupt request, the interrupt-request line is activated.
- •The processor in response activates interrupt-acknowledge.
- •Received by device 1, if device 1 does not need service, it passes the signal to device 2.
- •Device that is electrically closest to the processor has the highest priority.

Simultaneous Requests

- •When I/O devices were organized into a priority structure, each device had its own interrupt-request and interrupt-acknowledge line.
- •When I/O devices were organized in a daisy chain fashion, the devices shared an interrupt-request line, and the interrupt-acknowledge propagated through the devices.
- •A combination of priority structure and daisy chain scheme can also used.



- •Devices are organized into groups.
- •Each group is assigned a different priority level.
- •All the devices within a single group share an interrupt-request line, and are connected to form a daisy chain.

Controlling Device Requests

- Only those devices that are being used in a program should be allowed to generate interrupt requests.
- To control which devices are allowed to generate interrupt requests, there are two independent mechanisms:
- At the Device end:
 - the interface circuit of each I/O device has an interrupt-enable bit.
 - Interrupt-enable bit in the device's interface circuit determines whether the device is allowed to generate an interrupt request.
 - If the interrupt-enable bit in the device interface is set to 1, then the device is allowed to generate an interrupt-request.
- At the processor end:
 - Interrupt-enable bit in the processor status register or the priority structure of the interrupts determines whether a given interrupt will be accepted.

Exceptions

- Interrupt is caused by interrupt-requests sent by I/O devices.
- Interrupts could be used in many other situations where the execution of one program needs to be suspended and execution of another program needs to be started.
- In general, the term *exception* is used to refer to any event that causes an interruption.
 - Interrupt-requests from I/O devices is one type of an exception.
- Other types of exceptions are:
 - Recovery from errors
 - Debugging
 - Privilege exception

Exceptions -Recovery from errors

- Many sources of errors in a processor. For example:
 - Error in the data stored.
 - Error during the execution of an instruction.
- When such errors are detected, exception processing is initiated.
 - Processor takes the same steps as in the case of I/O interrupt-request.
 - It suspends the execution of the current program, and starts executing an exception-service routine.
- Difference between handling I/O interruptrequest and handling exceptions due to errors:
 - In case of I/O interrupt-request, the processor usually completes the execution of an instruction in progress before branching to the interrupt-service routine.
 - In case of exception processing however, the execution of an instruction in progress usually cannot be completed.

Exceptions-Debugging

- Debugger program uses exceptions to provide important features:
 - Trace,
 - Breakpoints.

• Trace mode:

- Exception occurs after the execution of every instruction.
- Enables user to examine the contents of the variables that he likes.
- Debugging program is used as the exception-service routine.

• Breakpoints:

- Exception occurs only at specific points selected by the user.
- An instruction called the *Trap* (or) *software interrupt* is inserted at the point where program is to be interrupted.
- Debugging program is used as the exception-service routine.

Exceptions-Privilege exception

- Certain instructions can be executed only when the processor is in the supervisor mode. These are called **privileged instructions**.
 - An instruction that changes the priority level of the processor
- If an attempt is made to execute a privileged instruction in the user mode, a privilege exception occurs.
- Privilege exception causes:
 - Processor to switch to the supervisor mode,
 - Execution of an appropriate exception-servicing routine.

Direct Memory Access

Direct Memory Access (contd..)


- Direct Memory Access (DMA):
 - A special control unit may be provided to transfer a block of data directly between an I/O device and the main memory, without continuous intervention by the processor.

• Control unit which performs these transfers is a part of the I/O device's interface circuit. This control unit is called as a **DMA controller**.

Direct Memory Access (contd..)


- DMA controller can transfer a block of data from an external device to the processor, without any intervention from the processor.
 - However, the operation of the DMA controller must be under the control of a program executed by the processor. That is, the processor must initiate the DMA transfer.
- To initiate the DMA transfer, the processor informs the DMA controller of:
 - Starting address,
 - Number of words in the block.
 - Direction of transfer (I/O device to the memory, or memory to the I/O device).
- Once the DMA controller completes the DMA transfer, it informs the processor by raising an interrupt signal.

Direct Memory Access



- •DMA controller connects a high-speed network to the computer bus.
- •Disk controller, which controls two disks also has DMA capability. It provides two DMA channels.
- •It can perform two independent DMA operations.

Registers in a DMA Interface



Registers in a DMA Interface

- The DMA controller includes several registers :-
 - The **DMA Address Register** contains the starting address of the memory location to be used in the data transfer.
 - The **DMA Count Register**, also called Word Count Register, contains the no. of bytes of data to be transferred.
 - The **DMA Status Register and Control Register** accepts commands from the CPU.

Registers in a DMA Interface

- R/W Determines the direction of transfer.
- When R/W = 1, DMA controller read data from memory to I/O device.
- R/W =0, DMA controller perform write operation.
- Done Flag=1, the controller has completed transferring a block of data and is ready to receive another command.
- IE=1, it causes the controller to raise an interrupt (interrupt Enabled) after it has completed transferring the block of data.
- IRQ=1, it indicates that the controller has requested an interrupt.

Process of DMA Transfer

- To initiate a DMA transfer, the CPU loads the address of the first memory location of the memory block (to be read from or written into) into the DMA address register.
- It then writes the no. of bytes to be transferred into the DMA count register.
- Finally, it writes one or more commands to the DMA control register.

Process of DMA Transfer

- These commands specify transfer options such as the DMA transfer mode, the direction of the transfer- either from I/O to memory or from memory to I/O.
- The last command causes the DMA controller to initiate the transfer.
- When the DMA transfer is completed, the Done flag of Status and Control register is set.
- At the same time the IE bit is set and the DMA controller sends the interrupt request to the processor by setting the IRQ bit.

DMA Transfer Modes

BURST mode

- Sometimes called Block Transfer Mode.
- An entire block of data is transferred in one contiguous sequence. Once the DMA controller is granted access to the system buses by the CPU, it transfers all bytes of data in the data block before releasing control of the system buses back to the CPU.
- This mode is useful for loading programs or data files into memory, but it does render the CPU inactive for relatively long periods of time.

DMA Transfer Modes

- CYCLE STEALING Mode
 - Viable alternative for systems in which the CPU should not be disabled for the length of time needed for Burst transfer modes.
 - DMA controller obtains access to the system bus as in burst mode. However, it transfers one byte of data and, returns control of the system bus to the CPU. It continually issues request for system bus, transferring one byte of data per request, until it has transferred it's entire block of data.

DMA Transfer Modes


• CYCLE STEALING Mode

- By continually obtaining and releasing control of the system buses, the DMA controller essentially interleaves instruction execution & data transfers. The CPU processes an instruction, then the DMA controller transfers a data value, and so on.
- The data block is not transferred as quickly as in burst mode, but the CPU is not idled for as long as in that mode.
- Useful for controllers monitoring data in real time.

Bus arbitration

- Processor and DMA controllers both need to initiate data transfers on the bus and access main memory.
- The device that is allowed to initiate transfers on the bus at any given time is called the **bus master**.
- When the current bus master relinquishes its status as the bus master, another device can acquire this status.
 - The process by which the next device to become the bus master is selected and bus mastership is transferred to it is called bus arbitration.
- Centralized arbitration:
 - A **single** bus arbiter performs the arbitration.
- Distributed arbitration:
 - All devices participate in the selection of the next bus master.


Centralized Bus Arbitration



Centralized Bus Arbitration(cont.,)

- Bus arbiter may be the processor or a separate unit connected to the bus.
- Normally, the processor is the bus master, unless it grants bus membership to one of the DMA controllers.
- DMA controller requests the control of the bus by asserting the **Bus** Request (BR) line.
- In response, the processor activates the **Bus-Grant1** (**BG1**) line, indicating that the **controller may use the bus when it is free**.
- BG1 signal is connected to all DMA controllers in a **daisy chain** fashion.
- **BBSY** signal is **0**, it indicates that the **bus is busy**. When BBSY becomes **1**, the DMA controller which asserted BR can **acquire** control of the bus.


Centralized arbitration (contd..)



Distributed arbitration

- All devices waiting to use the bus share the responsibility of carrying out the arbitration process.
 - Arbitration process does not depend on a central arbiter and hence distributed arbitration has higher reliability.
- Each device is assigned a 4-bit ID number.
- All the devices are connected using 5 lines, 4 arbitration lines to transmit the ID, and one line for the Start-Arbitration signal.
- To request the bus, a device:
 - Asserts the Start-Arbitration signal.
 - Places its 4-bit ID number on the arbitration lines.
- The pattern that appears on the arbitration lines is the logical-OR of all the 4-bit device IDs placed on the arbitration lines.

Distributed arbitration



Distributed arbitration(Contd.,)

• Arbitration process:

- Each device compares the pattern that appears on the arbitration lines to its own ID, starting with MSB.
- If it detects a difference at a bit position, it transmits zero for that and all lower bit positions.
- The pattern that appears on the arbitration lines is the logical-OR of all the 4-bit device IDs placed on the arbitration lines.

Distributed arbitration (contd..)

- Device A has the ID 5 and wants to request the bus:
 - Transmits the pattern **0101** on the arbitration lines.
- •Device B has the ID 6 and wants to request the bus:
 - Transmits the pattern **0110** on the arbitration lines.
- •Pattern that appears on the arbitration lines is the logical OR of the patterns:
 - Pattern 0111 appears on the arbitration lines.

<u> Arbitration process:</u>

- •Each device compares the pattern that appears on the arbitration lines to its own ID, starting with MSB.
- •If it detects a difference, it transmits zeros on the arbitration lines for that and all lower bit positions.
- •Device A compares its ID 5 with a pattern 0101 to pattern 0111.
- •It detects a difference at bit position 1, as a result, it transmits a pattern 0100 on the arbitration lines.
- The pattern that appears on the arbitration lines is the logical-OR of 0100 and 0110, which is 0110.
- This pattern is the same as the device ID of B, and hence B has won the arbitration.

Buses

Buses

- Processor, main memory, and I/O devices are interconnected by means of a bus.
- Bus provides a communication path for the transfer of data.
 - Bus also includes lines to support interrupts and arbitration.
- A bus protocol is the set of rules that govern the behavior of various devices connected to the bus, as to when to place information on the bus, when to assert control signals, etc.

Buses (contd..)


- Bus lines may be grouped into three types:
 - Data
 - Address
 - Control
- Control signals specify:
 - Whether it is a read or a write operation.
 - Required size of the data, when several operand sizes (byte, word, long word) are possible.
 - Timing information to indicate when the processor and I/O devices may place data or receive data from the bus.


Buses (contd..)

- **Master** (Initiator) initiates data transfer by issuing read or write command on the bus.
- processor or a DMA capable device can act as master.
- Slave / Target The device addressed by the master.
- Schemes for timing of data transfers over a bus can be classified into:
 - Synchronous,
 - Asynchronous.

Synchronous bus

- In synchronous bus, all devices derive timing information from a common clock line.
- Equally spaced pulses on this line define equal time intervals or bus cycles
- During a "bus cycle" one data transfer can take place.






- •In case of a Write operation, the master places the data on the bus along with the address and commands at time t_0 .
- The slave strobes the data into its input buffer at time t_2 .

- Once the master places the device address and command on the bus, it takes time for this information to propagate to the devices:
 - This time depends on the physical and electrical characteristics of the bus.
- Also, all the devices have to be given enough time to decode the address and control signals, so that the addressed slave can place data on the bus.
- Width of the pulse t_1 t_0 depends on:
 - Maximum propagation delay between two devices connected to the bus,
 - time taken by all the devices to **decode the address** and **control signals**, so that the addressed slave can respond at time t_1 .


- At the end of the clock cycle, at time t_2 , the master strobes the data on the data lines into its input buffer if it's a Read operation.
 - "Strobe" means to capture the values of the data and store them into a buffer.
- When data are to be loaded into a storage buffer register, the data should be available for a period longer than the setup time of the device.
- Width of the pulse t_2 t_1 should be longer than:
 - Maximum **propagation time** of the bus plus
 - set up time of the input buffer register of the master.



- Signals do not appear on the bus as soon as they are placed on the bus, due to the propagation delay in the interface circuits.
- Signals reach the devices after a propagation delay which depends on the characteristics of the bus.
- Data must remain on the bus for some time after t_2 equal to the hold time of the buffer.

- Data transfer has to be completed within one clock cycle.
 - Clock period t2 must be such that the longest propagation delay on the bus and the slowest device interface must be accommodated.
 - Forces all the devices to operate at the speed of the slowest device.
- Processor just assumes that the data are available at t2 in case of a Read operation, or are read by the device in case of a Write operation.
 - What if the device is actually failed, and never really responded?

- Most buses have control signals to represent a response from the slave.
- Control signals serve two purposes:
 - Inform the master that the slave has recognized the address, and is ready to participate in a data transfer operation.
 - Enable to adjust the duration of the data transfer operation based on the speed of the participating slaves.
- High-frequency bus clock is used:
 - Data transfer spans several clock cycles instead of just one clock cycle as in the earlier case.




Asynchronous bus

- Data transfers on the bus is controlled by a handshake between the master and the slave.
- Common clock in the synchronous bus case is replaced by two timing control lines:
 - Master-ready,
 - Slave-ready.
- Master-ready signal is asserted by the master to indicate to the slave that it is **ready to participate** in a data transfer.
- Slave-ready signal is asserted by the slave in response to the master-ready from the master, and it indicates to the master that the **slave is ready to participate** in a data transfer.

• Data transfer using the handshake protocol:


- Master places the address and command information on the bus.
- Asserts the Master-ready signal to indicate to the slave that the address and command information has been placed on the bus.
- All devices on the bus decode the address.
- Addressed slave performs the required operation, and informs the processor it has done so by asserting the Slave-ready signal.
- Master removes all the signals from the bus, once Slave-ready is asserted.
- If the operation is a Read operation, Master also strobes the data into its input buffer.

Asynchronous bus- Timing diagram for i/p operation



- t_0 Master places the address and command information on the bus.
- t_1 Master asserts the Master-ready signal. Master-ready signal is asserted at t_1 instead of t_0
- t₂ Addressed slave places the data on the bus and asserts the Slave-ready signal.
- t₃ Slave-ready signal arrives at the master.
- t₄ Master removes the address and command information.
- t_5 Slave receives the transition of the Master-ready signal from 1 to 0. It removes the data and the Slave-ready signal from the bus.

Asynchronous bus- Timing diagram for o/p operation



Asynchronous vs. Synchronous bus

Advantages of asynchronous bus:

- Eliminates the need for synchronization between the sender and the receiver.
- Can accommodate varying delays automatically, using the Slave-ready signal.

• Disadvantages of asynchronous bus:

- Data transfer rate with full handshake is limited by two-round trip delays.
- Data transfers using a synchronous bus involves only one round trip delay, and hence a synchronous bus can achieve faster rates.
- However, for synchronous bus, Clock circuitry must be designed carefully to ensure proper synchronization, and delays must be kept within strict bounds

Interface Circuits


Interface circuits

- I/O interface consists of the circuitry required to connect an I/O device to a computer bus.
- Side of the interface which connects to the computer has bus signals for:
 - Address,
 - Data
 - Control
- Side of the interface which connects to the I/O device has:
 - Datapath and associated controls to transfer data between the interface and the I/O device.
 - This side is called as a <u>"port".</u>
- Ports can be classified into two:
 - Parallel port,
 - Serial port.

Interface circuits (contd..)


- Parallel port transfers data in the form of a number of bits, normally 8 or 16 to or from the device.
- Serial port transfers and receives data **one bit** at a time.
- Processor communicates with the bus in the same way, whether it is a parallel port or a serial port.
 - Conversion from the parallel to serial and vice versa takes place inside the interface circuit.

Parallel port




- •Keyboard is connected to a processor using a parallel port.
- •Processor is 32-bits and uses memory-mapped I/O and the **asynchronous** bus protocol.
- •On the processor side of the interface we have:
 - Data lines.
 - Address lines
 - Control or R/W line.
 - Master-ready signal and
 - Slave-ready signal.

Parallel port (contd..)




- •On the keyboard side of the interface:
 - Encoder circuit which generates a code for the key pressed.
 - Debouncing circuit which eliminates the effect of a key bounce (a single key stroke may appear as multiple events to a processor).
 - Data lines contain the code for the key.
 - Valid line changes from 0 to 1 when the key is pressed. This causes the code to be loaded into DATAIN and SIN to be set to 1.

Input Interface Circuit




Parallel port (contd..)



- •Printer is connected to a processor using a parallel port.
- •Processor is 32 bits, uses memory-mapped I/O and asynchronous bus protocol.
- •On the processor side:
 - Data lines.
 - Address lines
 - Control or R/W line.
 - Master-ready signal and
 - Slave-ready signal.


Parallel port (contd..)




•On the printer side:

- Idle signal line which the printer asserts when it is **ready to accept a character**. This causes the **SOUT** flag to be set to 1.
- Processor places a new character into a **DATAOUT** register.
- **Valid** signal, asserted by the interface circuit when it places a new character on the data lines.

Output Interface Circuit





- •Data lines of the processor bus are connected to the DATAOUT register of the interface.
- •The status flag SOUT is connected to the data line D1 using a three-state driver.
- •The three-state driver is turned on, when the control Read-status line is 1.
- •Address decoder selects the output interface using address lines A1 through A31.
- •Address line A0 determines whether the data is to be loaded into the DATAOUT register or status flag is to be read.
- •If the Load-data line is 1, then the Valid line is set to 1.
- •If the Idle line is 1, then the status flag SOUT is set to 1.



Combined I/O interface circuit:

- •Address bits A2 through A31, that is 30 bits are used to select the overall interface.
- •Address bits A1 through A0, that is, 2 bits select one of the three registers, namely, DATAIN, DATAOUT, and the status register.
- •Status register contains the flags SIN and SOUT in bits 0 and 1.
- •Data lines PA0 through PA7 connect the input device to the DATAIN register.
- •DATAOUT register connects the data lines on the processor bus to lines PB0 through PB7 which connect to the output device.
- •Separate input and output data lines for connection to an I/O device.






A general 8-bit parallel interface

- •Data lines to I/O device are bidirectional.
- •Data lines P7 through P0 can be used for both input, and output.
- •In fact, some lines can be used for input & some for output depending on the pattern in the Data Direction Register (DDR).
- •Processor places an 8-bit pattern into a DDR.
- •If a given bit position in the DDR is 1, the corresponding data line acts as an output line, otherwise it acts as an input line.
- •C1 and C2 control the interaction between the interface circuit and the I/O devices.
- •Ready and Accept lines are the handshake control lines on the processor bus side, and are connected to Master-ready & Slave-ready.
- •Input signal My-address is connected to the output of an address decoder.
- •Three register select lines that allow up to 8 registers to be selected.

Serial port

- Serial port is used to connect the processor to I/O devices that require transmission of data one bit at a time.
- Serial port communicates in a bit-serial fashion on the device side and bit parallel fashion on the processor side.
 - Transformation between the parallel and serial formats is achieved with shift registers that have parallel access capability.



Serial port (contd..)

- Serial interfaces require fewer wires, and hence serial transmission is convenient for connecting devices that are **physically distant** from the computer.
- Speed of transmission of the data over a serial interface is known as the "bit rate".
 - Bit rate depends on the nature of the devices connected.
- In order to accommodate devices with a range of speeds, a serial interface must be able to use a range of clock speeds.
- Several standard serial interfaces have been developed:
 - Universal Asynchronous Receiver Transmitter (UART) for low-speed serial devices.
 - RS-232-C for connection to communication links.

Standard I/O interfaces

- I/O device is connected to a computer using an interface circuit.
- Do we have to design a different interface for every combination of an I/O device and a computer?
- A practical approach is to develop standard interfaces and protocols.
- A personal computer has:
 - A motherboard which houses the processor chip, main memory and some I/O interfaces.
 - A few connectors into which additional interfaces can be plugged.
- Processor bus is defined by the signals on the processor chip.
 - Devices which require high-speed connection to the processor are connected directly to this bus.


Standard I/O interfaces (contd..)

- Because of electrical reasons only a few devices can be connected directly to the processor bus.
- Motherboard usually provides another bus that can support more devices.
 - Processor bus and the other bus (called as expansion bus) are interconnected by a circuit called "bridge".
 - Devices connected to the expansion bus experience a small delay in data transfers.
- Design of a processor bus is closely tied to the architecture of the processor.
 - No uniform standard can be defined.
- Expansion bus however can have uniform standard defined.

Standard I/O interfaces (contd..)

- A number of standards have been developed for the expansion bus.
 - Some have evolved by default.
 - For example, IBM's Industry Standard Architecture.
- Three widely used bus standards:
 - PCI (Peripheral Component Interconnect)
 - SCSI (Small Computer System Interface)
 - USB (Universal Serial Bus)

Standard I/O interfaces (contd..)




PCI Bus

- Peripheral Component Interconnect
- Introduced in 1992
- Low-cost bus
- Processor independent
- Plug-and-play capability
- In today's computers, most memory transfers involve a burst of data rather than just one word. The PCI is designed primarily to support this mode of operation.
- The bus supports three independent address spaces: memory, I/O, and configuration.
- we assumed that the master maintains the address information on the bus until data transfer is completed. But, the address is needed only long enough for the slave to be selected. Thus, the address is needed on the bus for one clock cycle only, freeing the address lines to be used for sending data in subsequent clock cycles. The result is a significant cost reduction.
- A master is called an initiator in PCI terminology. The addressed device that responds to read and write commands is called a target.

Data transfer signals on the PCI bus.

Name	F unction
CLK	A 33-MHz or 66-MHz clock.
FRAME#	Sent by the initiator to indicate the duration of a transaction.
AD	32 address/data lines, which may be optionally increased to 64.
C/BE#	4 command/byte-enable lines (8 for a 64-bit bus).
IRD Y#, TRD Y#	Initiator-ready and Target-ready signals.
DEVSEL#	A response from the device indicating that it has recognized its address and is ready for a data transfer transaction.
IDSEL#	Initialization Device Select.



A read operation on the PCI bus

Device Configuration

- When an I/O device is connected to a computer, several actions are needed to configure both the device and the software that communicates with it.
- PCI incorporates in each I/O device interface a small configuration ROM memory that stores information about that device.
- The configuration ROMs of all devices are accessible in the configuration address space. The PCI initialization software reads these ROMs and determines whether the device is a printer, a keyboard, an Ethernet interface, or a disk controller. It can further learn bout various device options and characteristics.
- Devices are assigned addresses during the initialization process.
- This means that during the bus configuration operation, devices cannot be accessed based on their address, as they have not yet been assigned one.
- Hence, the configuration address space uses a different mechanism. Each device has an input signal called Initialization Device Select, IDSEL#
- Electrical characteristics:
 - PCI bus has been defined for operation with either a 5 or 3.3 V power supply

SCSI Bus

- The acronym SCSI stands for Small Computer System Interface.
- It refers to a standard bus defined by the American National Standards Institute (ANSI) under the designation X3.131.
- In the original specifications of the standard, devices such as disks are connected to a computer via a 50-wire cable, which can be up to 25 meters in length and can transfer data at rates up to 5 megabytes/s.
- The SCSI bus standard has undergone many revisions, and its data transfer capability has increased very rapidly, almost doubling every two years.
- SCSI-2 and SCSI-3 have been defined, and each has several options.
- Because of various options SCSI connector may have 50, 68 or 80 pins.

- Devices connected to the SCSI bus are not part of the address space of the processor
- The SCSI bus is connected to the processor bus through a SCSI controller. This controller uses DMA to transfer data packets from the main memory to the device, or vice versa.
- A packet may contain a block of data, commands from the processor to the device, or status information about the device.
- A controller connected to a SCSI bus is one of two types an initiator or a target.
- An initiator has the ability to select a particular target and to send commands specifying the operations to be performed. The disk controller operates as a target. It carries out the commands it receives from the initiator.
- The initiator establishes a logical connection with the intended target.
- Once this connection has been established, it can be suspended and restored as needed to transfer commands and bursts of data.
- While a particular connection is suspended, other device can use the bus to transfer information.
- This ability to overlap data transfer requests is one of the key features of the SCSI bus that leads to its high performance.

- Data transfers on the SCSI bus are always controlled by the target controller.
- To send a command to a target, an initiator requests control of the bus and, after winning arbitration, selects the controller it wants to communicate with and hands control of the bus over to it.
- Then the controller starts a data transfer operation to receive a command from the initiator.

- Assume that processor needs to read block of data from a disk drive and that data are stored in disk sectors that are not contiguous.
- The processor sends a command to the SCSI controller, which causes the following sequence of events to take place:
 - 1. The SCSI controller, acting as an initiator, contends for control of the bus.
 - 2. When the initiator wins the arbitration process, it selects the target controller and hands over control of the bus to it.
 - 3. The target starts an output operation (from initiator to target); in response to this, the initiator sends a command specifying the required read operation.
 - 4. The target, realizing that it first needs to perform a disk seek operation, sends a message to the initiator indicating that it will temporarily suspend the connection between them. Then it releases the bus.
 - 5. The target controller sends a command to the disk drive to move the read head to the first sector involved in the requested read operation. Then, it reads the data stored in that sector and stores them in a data buffer. When it is ready to begin transferring data to the initiator, the target requests control of the bus. After it wins arbitration, it reselects the initiator controller, thus restoring the suspended connection.

- 6. The target transfers the contents of the data buffer to the initiator and then suspends the connection again
- 7. The target controller sends a command to the disk drive to perform another seek operation. Then, it transfers the contents of the second disk sector to the initiator as before. At the end of this transfers, the logical connection between the two controllers is terminated.
- 8. As the initiator controller receives the data, it stores them into the main memory using the DMA approach.
- 9. The SCSI controller sends as interrupt to the processor to inform it that the requested operation has been completed

Operation of SCSI bus from H/W point of view

Category	Name	Function
Data	- DB(0) to - DB(7)	Data lines: Carry one byte of information during the information transfer phase and iden tify device during arbitration, selection and reselection phases
	⁻ DB(P)	Parity bit for the data bus
Phase	- BSY	Busy: Asserted when the bus is notfree
	-SEL	Selection: Asserted during selection and reselection
Information type	– C/D	Control/Data: Asserted during transfer of control information (command, status or message)
	– MSG	Message: indicates that the information being transferred is a message

Table 4. The SCSI bus signals.

Table 4. The SCSI bus signals.(cont.)

Category	Name	Function
Handshake	- REQ	Request: Asserted by a target to request a data transfer cycle
	— A СК	Acknowledge: Asserted by the initiator when it has completed a data transfer operation
Direction of transfer	- I/O	Input/Output: Asserted to indicate an input operation (relative to the initiator)
Other	- ATN	Attention: Asserted by an initiator when it wishes to send a message to a target
	[—] RST	Reset: Causes all device controls to disconnect from the bus and assume their start-upstate

Main Phases involved

- Arbitration
 - A controller requests the bus by asserting BSY and by asserting it's associated data line
 - When BSY becomes active, all controllers that are requesting bus examine data lines
- Selection
 - Controller that won arbitration selects target by asserting SEL and data line of target. After that initiator releases BSY line.
 - Target responds by asserting BSY line
 - Target controller will have control on the bus from then
- Information Transfer
 - Handshaking signals are used between initiator and target
 - At the end target releases BSY line
- Reselection





Figure 42. Arbitration and selection on the SCSI bus.

Device 6 wins arbitration and selects device 2.

USB

- Universal Serial Bus (USB) is an industry standard developed through a collaborative effort of several computer and communication companies, including Compaq, Hewlett-Packard, Intel, Lucent, Microsoft, Nortel Networks, and Philips.
- Speed
 - Low-speed(1.5 Mb/s)
 - Full-speed(12 Mb/s)
 - High-speed(480 Mb/s)
- Port Limitation
- Device Characteristics
- Plug-and-play

Universal Serial Bus tree structure



Universal Serial Bus tree structure


- To accommodate a large number of devices that can be added or removed at any time, the USB has the tree structure as shown in the figure.
- Each node of the tree has a device called a hub, which acts as an intermediate control point between the host and the I/O devices. At the root of the tree, a root hub connects the entire tree to the host computer. The leaves of the tree are the I/O devices being served (for example, keyboard, Internet connection, speaker, or digital TV)
- In normal operation, a hub copies a message that it receives from its upstream connection to all its downstream ports. As a result, a message sent by the host computer is broadcast to all I/O devices, but only the addressed device will respond to that message. However, a message from an I/O device is sent only upstream towards the root of the tree and is not seen by other devices. Hence, the USB enables the host to communicate with the I/O devices, but it does not enable these devices to communicate with each other.

Addressing


- When a USB is connected to a host computer, its root hub is attached to the processor bus, where it appears as a single device. The host software communicates with individual devices attached to the USB by sending packets of information, which the root hub forwards to the appropriate device in the USB tree.
- Each device on the USB, whether it is a hub or an I/O device, is assigned a 7-bit address. This address is local to the USB tree and is not related in any way to the addresses used on the processor bus.
- A hub may have any number of devices or other hubs connected to it, and addresses are assigned arbitrarily. When a device is first connected to a hub, or when it is powered on, it has the address 0. The hardware of the hub to which this device is connected is capable of detecting that the device has been connected, and it records this fact as part of its own status information. Periodically, the host polls each hub to collect status information and learn about new devices that may have been added or disconnected.
- When the host is informed that a new device has been connected, it uses a sequence of commands to send a reset signal on the corresponding hub port, read information from the device about its capabilities, send configuration information to the device, and assign the device a unique USB address. Once this sequence is completed the device begins normal operation and responds only to the new address.

USB Protocols

- All information transferred over the USB is organized in packets, where a packet consists of one or more bytes of information. There are many types of packets that perform a variety of control functions.
- The information transferred on the USB can be divided into two broad categories: control and data.
 - Control packets perform such tasks as addressing a device to initiate data transfer, acknowledging that data have been received correctly, or indicating an error.
 - Data packets carry information that is delivered to a device.
- A packet consists of one or more fields containing different kinds of information. The first field of any packet is called the packet identifier, PID, which identifies the type of that packet.
- They are transmitted twice. The first time they are sent with their true values, and the second time with each bit complemented
- The four PID bits identify one of 16 different packet types. Some control packets, such as ACK (Acknowledge), consist only of the PID byte.



(a) Packet identifier field




(b) Token packet, IN or OUT

Control packets used for controlling data transfer operations are called token packets.



(c) Data packet

Figure 45. USB packet format.



Isochronous Traffic on USB

- One of the key objectives of the USB is to support the transfer of isochronous data.
- Devices that generates or receives isochronous data require a time reference to control the sampling process.
- To provide this reference. Transmission over the USB is divided into frames of equal length.
- A frame is 1ms long for low-and full-speed data.
- The root hub generates a Start of Frame control packet (SOF) precisely once every 1 ms to mark the beginning of a new frame.
- The arrival of an SOF packet at any device constitutes a regular clock signal that the device can use for its own purposes.
- To assist devices that may need longer periods of time, the SOF packet carries an 11-bit frame number.
- Following each SOF packet, the host carries out input and output transfers for isochronous devices.
- This means that each device will have an opportunity for an input or output transfer once every 1 ms.

Electrical Characteristics

- The cables used for USB connections consist of four wires.
- Two are used to carry power, +5V and Ground.
 - Thus, a hub or an I/O device may be powered directly from the bus, or it may have its own external power connection.
- The other two wires are used to carry data.
- Different signaling schemes are used for different speeds of transmission.
 - At low speed, 1s and 0s are transmitted by sending a high voltage state (5V) on one or the other o the two signal wires. For high-speed links, differential transmission is used.