Cache Memory

COAL FALL 2020


Asma Ahmad

Characteristics of Memory Systems

Table 4.1 Key Characteristics of Computer Memory Systems

Location	Performance
Internal (e.g., processor registers, cache, main	Access time
memory)	Cycle time
External (e.g., optical disks, magnetic	Transfer rate
disks, tapes)	Physical Type
Capacity	Semiconductor
Number of words	Magnetic
Number of bytes	Optical
Unit of Transfer	Magneto-optical
Word	Physical Characteristics
Block	Volatile/nonvolatile
Access Method	Erasable/nonerasable
Sequential	Organization
Direct	Memory modules
Random	100 (100 (100 (100 (100 (100 (100 (100
Associative	

Memory Hierarchy



Example of Sequential Access





Example of Direct Access



CACHE MEMORY PRINCIPLES

- Cache memory is designed to combine the memory access time of expensive, high-speed memory combined with the large memory size of less expensive, lower-speed memory.
- The cache contains a copy of portions of main memory.
- When the processor attempts to read a word of memory, a check is made to determine if the word is in the cache.
- If so, the word is delivered to the processor.
- If not, a block of main memory, consisting of some fixed number of words, is read into the cache and then the word is delivered to the processor.
- Because of the phenomenon of locality of reference, when a block of data is fetched into the cache to satisfy a single memory reference, it is likely that there will be future references to that same memory location or to other words in the block





(b) Three-level cache organization


Figure 4.3 Cache and Main Memory

CACHE MEMORY PRINCIPLES

- Cache hit
 - Copy of data is in cache, quick access
- Cache miss
 - Copy of data is not in cache, read data on that address and possibly its neighbors into cache

Average Access Time

- Suppose we have two level memory L1 and L2
- L1 is on 1000 word capacity and L2 is on 10000 word capacity
- If required data is in L1 the processor will read it in 0.01 us
- If data was not in L1, then its in L2. To get the data to processor it has to be moved form L2 to L1 which will take 0.1 us
- How much total time is require to move data from L2 to processor?
 - 0.11 us
- Hit rate of L1 is 95%, that is, 95% of the time data is found in L1. Rest of the 5% of time data is not in L1 and has to be read from L2.
- What is the average access time given the hit rate above?
 - (0.95 * 0.01) + (0.5 * 0.11)= 0.015 us




Average access time

- What will be the average access rate is hit rate of L1 drops to 50%?
 - (0.5 *0.01) + (0.5 *0.11) = 0.06
- Which is much higher when hit rate was 95%
- What will be the average access rate is hit rate of L1 is 100%?
 - (1 *0.01) + (0 * 0.11) = 0.01 (perfect but not possible)
- What will be the average access rate is hit rate of L1 is 0%?
 - (0 *0.01) + (1 * 0.11) = 0.11 (worst case, no use of L1)

Average Access Time

- Question:
- Consider a 3 level memory. It takes 0.001us to read from level 1, 0.01us to read from level 2 and 0.1us from level 3.
- Data is found in L1 80% of time, out the remaining 20% of time 15% it is found in L2 and 5% data is to be read from L3.
- What is the average access time?
 - (0.8 * 0.001) + (0.15 * [0.001+0.01]) + (0.05 * [0.001+0.01+0.1]) = 0.008



Elements of Cache Design

Table 4.2 Elements of Cache Design

	Ca	ch	e	A	dd	resses
--	----	----	---	---	----	--------

Logical Physical

Cache Size

Mapping Function

Direct

Associative

Set associative

Replacement Algorithm

Least recently used (LRU)

First in first out (FIFO)

Least frequently used (LFU)

Random

Write Policy

Write through Write back

Line Size

Number of Caches

Single or two level Unified or split

Cache Structure

- <u>Index</u>: A number to each block/cell of cache
- <u>Tag</u>: Used to keep complete or part of address of data the was brought from main memory
- Data: To keep data brought from RAM
- Value <u>Bit</u>: A single bit use to show if the data is updated after bringing it in from RAM
- Note that tag kept is stored in cache so longer the tag the more space it requires in cache.
- Whereas <u>index</u> is just the cell number, doesn't need any storage.

Index	Tag	Data	Value Bit
0			
1			
2			
N			

Cache Addressing

- Depends on the location where cache is installed as shown in figures
- Logical caches that take Logical address is input
- Physical Caches that takes
 Physical Address is input




Figure 4.7 Logical and Physical Caches

Cache Size

- Small enough so that the overall average cost per bit is close to that of main memory alone
- Large enough so that the overall average access time is close to that of the cache alone
- There are several other motivations for minimizing cache size.
 - The larger the cache, the larger the number of gates involved in addressing the cache. The result is that large caches tend to be slightly slower than small ones—even when built with the same integrated circuit technology and put in the same place on chip and circuit board.
 - The available chip and board area also limits cache size. Because the performance of the cache is very sensitive to the nature of the workload, it is impossible to arrive at a single "optimum" cache size.
- Table 4.3 lists the cache sizes of some current and past processors.

Table 4.3 Cache Sizes of Some Processors

Processor	Туре	Year of Introduction	L1 Cache ^a	L2 Cache	L3 Cache
IBM 360/85	Mainframe	1968	16-32 kB	1=	-
PDP-11/70	Minicomputer	1975	1 kB		
VAX 11/780	Minicomputer	1978	16 kB	-	-
IBM 3033	Mainframe	1978	64 kB	-	-
IBM 3090	Mainframe	1985	128-256 kB		-
Intel 80486	PC	1989	8 kB		=
Pentium	PC	1993	8 kB/8 kB	256-512 kB	-
PowerPC 601	PC	1993	32 kB	-	-
PowerPC 620	PC	1996	32 kB/32 kB	-	-
PowerPC G4	PC/server	1999	32 kB/32 kB	256 kB to 1 MB	2 MB
IBM S/390 G6	Mainframe	1999	256 kB	8 MB	-
Pentium 4	PC/server	2000	8 kB/8 kB	256 kB	-
IBM SP	High-end server/ supercomputer	2000	64 kB/32 kB	8 MB	-
CRAY MTA ^b	Supercomputer	2000	8 kB	2 MB	-
Itanium	PC/server	2001	16 kB/16 kB	96 kB	4 MB
Itanium 2	PC/server	2002	32 kB	256 kB	6 MB
IBM POWER5	High-end server	2003	64 kB	1.9 MB	36 MB
CRAY XD-1	Supercomputer	2004	64 kB/64 kB	1 MB	-
IBM POWER6	PC/server	2007	64 kB/64 kB	4 MB	32 MB
IBM z10	Mainframe	2008	64 kB/128 kB	3 MB	24-48 MB
Intel Core i7 EE 990	Workstation/ server	2011	6 × 32 kB/ 32 kB	1.5 MB	12 MB
IBM zEnterprise 196	Mainframe/ server	2011	24 × 64 kB/ 128 kB	24 × 1.5 MB	24 MB L3 192 MB L4

Notes: a Two values separated by a slash refer to instruction and data caches. Both caches are instruction only; no data caches.

Mapping Function

- Because there are fewer cache lines than main memory blocks, an algorithm is needed for mapping main memory blocks into cache lines.
- Further, a means is needed for determining which main memory block currently occupies a cache line.
- The choice of the mapping function dictates how the cache is organized. Three techniques can be used:
 - Direct
 - Associative
 - Set-associative

Associative Mapping

- Any cell of main memory can be loaded in any cell of Cache
- Addresses of RAM are stored as Tag
- The cache control logic must simultaneously examine every tag for a match
- Pros:
 - Flexibility
- Cons:
 - Larger value of tag
 - Number of bits required for tag= log2(size of RAM)
 - For 1MB RAM tag size is of 20 bits

Associative Mapping

Index	Tag	Data	Value Bit
00			
01			
11			
11			

Main Memory

Address	Word
0000	Α
0001	В
0010	С
0011	D
0100	E
0101	F
0110	G
0111	Н
1000	I
1001	J
1010	K
1011	L
1100	M
1101	N
1110	0
1111	Р

Cache

Read 0000 It's a miss in cache

Cache

Index	Tag	Data	Value Bit
00			
01			
11			
11			

0000 will be brought to cache, on first available slot

Index	Tag	Data	Value Bit
00	0000	А	0
01			
11			
11			

Address	Word
0000	Α
0001	В
0010	С
0011	D
0100	Е
0101	F
0110	G
0111	Н
1000	I
1001	J
1010	K
1011	L
1100	M
1101	N
1110	0
1111	Р

Main Memory

Read 0011, It's a miss

Cache

Index	Tag	Data	Value Bit
00	0000	Α	0
01			
10			
11			

Bring 0011 to cache

Index	Tag	Data	Value Bit
00	0000	А	0
01	0011	D	0
10			
11			

Address	Word
0000	Α
0001	В
0010	С
0011	D
0100	Е
0101	F
0110	G
0111	Н
1000	I
1001	J
1010	K
1011	L
1100	M
1101	N
1110	0
1111	Р

Read 1000, It's a miss

	Index	Tag	Data	Value Bit
Cache		0000	Α	0
Cacrie		0011	D	0
	10			
	11			

Bring 1000 to cache

Index	Tag	Data	Value Bit
00	0000	Α	0
01	0011	D	0
10	1000	Ī	0
11			

Address Word 0000 A 0001 B 0010 C 0011 D 0100 E 0101 F 0110 G 0111 H 1000 I 1001 J 1010 K 1011 L 1100 M 1101 N 1110 O 1111 P

Read 1010, it's a miss

 Index
 Tag
 Data
 Value Bit

 00
 0000
 A
 0

 Cache
 01
 0011
 D
 0

 10
 1000
 I
 0

 11
 0
 I
 0

Bring 1010 to cache

Index	Tag	Data	Value Bit
00	0000	Α	0
01	0011	D	0
10	1000	I	0
11	1010	K	0

Α
В
С
D
E
F
G
Н
I
J
K
L

1100 M

1101 N

1110 O

1111 P

Address Word

Read 1110, It's a miss, there is no space in cache so we replace least recently used element (i.e., 0000)

Index	Tag	Data	Value Bit
00	0000	Α	0
01	0011	D	0
10	1000	Γ	0
11	1010	K	0

Bring 1110 in place of least recently used

Index	Tag	Data	Value Bit
00	1110	0	0
01	0011	D	0
10	1000	1	0
11	1010	K	0

Address	Word
0000	Α
0001	В
0010	С
0011	D
0100	E
0101	F
0110	G
0111	Н
1000	1
1001	J
1010	K
1011	L
1100	М
1101	N
1110	0
1111	Р

Read 0000, It's a miss Cache is full so we replace the least recently used element (i.e 0011),

Index	Tag	Data	Value Bit
00	1110	0	0
01	0011	D	0
10	1000	I	0
11	1010	K	0

Bring 0000 in cache by replacing 0011 Note the now 0000 is on index 1 (Flexible)

Index	Tag	Data	Value Bit
00	1110	0	0
01	0000	Α	0
10	1000	Γ	0
11	1010	K	0

Address	Word
0000	Α
0001	В
0010	С
0011	D
0100	E
0101	F
0110	G
0111	Н
1000	1
1001	J
1010	K
1011	L
1100	M
1101	N
1110	0
1111	Р

Read 0000 It's a hit

	Index	Tag	Data	Value Bit
(Cache 00	1110	0	0
	01	0000	Α	0
	10	1000	Ι	0
	11	1010	K	0

Address	Word
0000	Α
0001	В
0010	С
0011	D
0100	Е
0101	F
0110	G
0111	Н
1000	1
1001	J
1010	K
1011	L
1100	M
1101	N
1110	0
1111	Р

Associative Mapping

- We can see from last example that
 - Tag takes a lot of memory in cache
 - Index in not used at all
- Thus to save the space we can utilizing the index to save portion of address
 - This is done in direct mapping

Direct Mapping

- Main Memory address is divided into 2 fields
 - Index = Main Memory Address % Size of Cache
 - Data is placed in cache at this index
 - Tag = Main Memory Address / Size of Cache
 - As stored in cache along with data
 - Main Memory Address = Tag*Size of Cache + Index
- The drawback is that there is no flexibility, a certain address can only go in one designated slot in cache

Example

- If cache has 4 slots, indexes will be from 0 to 3
- Memory address 21 can only go on index 1 of cache ($\frac{20}{20}$ %4=1)
- Tag will be 21/4 = 5
- From tag and index you can get the address back Tag * 4 + index
- $\bullet = 5*4+1=21$

Example

- What address of ram is mapped on index 0, 1, 2 at this time?
- What will the address 31 go?

Index	Tag	Data	Value Bit
0	2		
1	6		
2	8		
3			
4			
5			

Index	Tag	Data	Value Bit
0			
1			
2			
3			

Cache

Address	Word
0000	Α
0001	В
0010	С
0011	D
0100	E
0101	F
0110	G
0111	Н
1000	1
1001	J
1010	K
1011	L
1100	M
1101	N
1110	0
1111	Р

Read 0000b (0d)
The tag and index of this address is
Tag=00b Index=00b
It's a miss

Index	Tag	Data	Value Bit
00			
01			
10			
11			

Cache

Address	Word
0000	Α
0001	В
0010	С
0011	D
0100	E
0101	F
0110	G
0111	Н
1000	I
1001	J
1010	K
1011	L
1100	M
1101	N
1110	0
1111	P

0000b (0d) will be placed on cache at index 00 and tag 00 will be stored

Index	Tag	Data	Value Bit
00	00	А	0
01			
10			
11			

Address	Word
0000	Α
0001	В
0010	С
0011	D
0100	Е
0101	F
0110	G
0111	Н
1000	1
1001	J
1010	K
1011	L
1100	М
1101	N
1110	0
Main Mem 1111	ory

Read 0100b (4d)
The tag and index of this address is
Tag=01b Index=00b
It's a miss

Index	Tag	Data	Value Bit
00	00	Α	0
01			
10			
11			

Address	Word
0000	Α
0001	В
0010	С
0011	D
0100	Е
0101	F
0110	G
0111	Н
1000	1
1001	J
1010	K
1011	L
1100	М
1101	N
1110	0
1111	Р

0100b (4d) will be placed on cache at index 00 and tag 01 will be stored But index 00 already has some data, we will replace that

Note that even rest of the cache is free 0100 will go at index 00b

Index	Tag	Data	Value Bit
0	01	Е	0
1			
2			
3			

Address	Word
0000	Α
0001	В
0010	С
0011	D
0100	E
0101	F
0110	G
0111	Н
1000	1
1001	J
1010	K
1011	L
1100	M
1101	N
1110	0
1111	Р

Question: See the tag at index 2 of cache. What data is placed over there?

Index	Tag	Data	Value Bit
0	00	А	0
1	10	J	0
2	11	?	0
3			

Address	Word
0000	Α
0001	В
0010	С
0011	D
0100	Е
0101	F
0110	G
0111	Н
1000	1
1001	J
1010	K
1011	L
1100	M
1101	N
1110	0
1111	Р

Question:

See the tag at index 2 of cache. What

data is placed over there?

Answer: O i.e., data of address 1110

Index	Tag	Data	Value Bit
0	00	А	0
1	10	J	0
2	11	?	0
3			

Address	Word
0000	Α
0001	В
0010	С
0011	D
0100	Е
0101	F
0110	G
0111	Н
1000	1
1001	J
1010	K
1011	L
1100	М
1101	N
1110	0
1111	Р

Read 1001 (9d)
The tag and index of this address is
Tag=10b Index=01b
It's a miss

Index	Tag	Data	Value Bit
0	00	Α	0
1			
2			
3			

Address	Word
0000	Α
0001	В
0010	С
0011	D
0100	Е
0101	F
0110	G
0111	Н
1000	1
1001	J
1010	K
1011	L
1100	M
1101	N
1110	0
1111	Р

1001 will be placed on cache at index 01 and tag 10 will be stored

Index	Tag	Data	Value Bit
0	00	Α	0
1	10	J	0
2			
3			

Address	Word
0000	Α
0001	В
0010	С
0011	D
0100	Е
0101	F
0110	G
0111	Н
1000	1
1001	J
1010	K
1011	L
1100	М
1101	N
1110	0
1111	Р

Direct Mapping

- The size of tag will depend of size of cache and size of RAM
 - Number of bits required for tag
 - =Number of bits required for Ram address number of bits of cache index
 - = log 2(Size of ram) log 2(size of cache)
 - =log2(size of Ram/ Size of Cache)

Direct Mapping

- Question:
 - If cache is of 8 words and Ram of 16 words
 - What is the size of tag?
 - Answer log2(16/8)= 1
 - If cache is of 1k Words and Ram is of 1M words
 - What is the size of tag?
 - Answer = log 2(2^20/2^10)= 10