## **IS2111**

#### Computer Networks

Dr. Chamath Keppitiyagama

University of Colombo School of Computing

$$100 = 10^{2}$$

$$log(100) = 2$$

$$100 = 10^2$$

$$log_{10}(100) = 2$$

$$0.01 = \frac{1}{100}$$

$$0.01 = \frac{1}{10^2}$$

$$0.01 = 10^{-2}$$

$$log_{10}(0.01) = -2$$

$$32 = 2^5$$
  
 $log_2(32) = 5$ 

Think ...

Assume that you can count 1 million numbers per second. How long will it take to count from 1 to

 $2^{64}$ ?

$$\begin{array}{rcl} 2 & = & 10^{0.3} \\ \frac{1}{2} & = & 2^{-1} \\ 2^{-1} & = & 10^{-0.3} \\ log_{10}(\frac{1}{2}) & = & -0.3 \end{array}$$

$$\frac{Power_{out}}{Power_{in}} = \frac{1}{2}$$

$$log_{10}(\frac{Power_{out}}{Power_{in}}) = log_{10}(\frac{1}{2})$$

$$= -0.3Bell$$

$$-0.3Bell = -3dB$$

## Bandwidth




Image credit: Wikipedia  $10 log(rac{1}{2}) pprox -3$ 

# Bandwidth and the Bitrate How fast can we send data over a channel?

## Nyquist's Theorem

$$R = 2H \log_2 L$$

- R = data rate (bits/sec)
- ightharpoonup H =bandwidth of the channle (Hz)
- ightharpoonup L = number of signal levels

# Bandwidth and the Bitrate How fast can we send data over a channel?

### Nyquist's Theorem

$$R = 2H \log_2 L$$

- R = data rate (bits/sec)
- ightharpoonup H =bandwidth of the channle (Hz)
- ightharpoonup L = number of signal levels

What is the maximum bitrate possible in a noiseless channel if the bandwidth is 1000Hz?



## Not so fast !!

#### Shannon's Law

$$R = H \log_2(1 + \frac{s}{N})$$

- $\triangleright$  S = signal level
- ► *N* = noise level

## The problem

- A sender transmits data at a rate of 1Mbps one million bits per second.
  - one bit every  $\frac{1}{10^6}$  seconds o one bit every  $1\mu$  seconds
  - ▶ The sender has a clock.
- ▶ The receiver tries to sample the medium at the center of every bit and should sample the line once every  $1\mu s$ .
- The receiver has its own clock.
- Assume that the receivers clock is 1% faster.
  - ▶ If the first sample is taken right at the center of a bit time then the second sample will be  $0.01\mu s$  off from the center.
  - After 50 more samples the sampling would be more than  $0.5\mu s$  off from the center !!

## Asynchronous Transmission



- Don't send long uninterrupted sequence of bits.
- Send one character at a time.
- ▶ At the beginning of each character the receiver gets another chance to synchronize the clock.

#### **Errors**




- ▶ Sender sends a bit every  $100\mu s$ .
- ▶ The receiver is 6% faster and samples the line every  $94\mu s$ .
- Two errors
  - Last sampled bit is incorrectly received.
  - ▶ If the bit 7 is 1 and bit 8 is 0 then bit 8 could be taken as a starting bit.
    - ► Framing Error

## Synchronous Transmission

- Transmit a block of data as a stream of bits without a start or stop bits.
- Keep the clocks synchronized.
  - Use a seperate set of lines between the sender and receiver.
     The sender sends the clock pulse to the receiver over these lines.
    - Works for short distances.
    - Clock pulse is another piece of data. We again have another synchronization problem.
  - 2. Embed the clocking information in the data signal.
    - Manchester encoding.

## Manchester Encoding



- ▶ There is a transition at the middle of each bit period.
- ▶ What is the baud rate?
- ▶ What is the bit rate?



#### Error Detection


















Probability of accepting a wrong bit = 0.2

# Error Detecting Code

$$0 \Rightarrow 00$$

$$1 \Rightarrow 11$$



Probability of wrong decoding = 0.04

1	1	1	0	0	1	0	1	
---	---	---	---	---	---	---	---	--

1	1	1	0	0	1	0	1	1
---	---	---	---	---	---	---	---	---

1	0	1	0	0	1	0	1	
---	---	---	---	---	---	---	---	--

1	0	1	0	0	1	0	1	0
---	---	---	---	---	---	---	---	---