




# Agenda

- Introduction.
- Basic Concepts.
- Frame Formats.
- Error Detections.
- Error Handling.
- CAN protocol Versions.



▶ How it all began ...






### Each type requires specific features:

- Conventional body and powertrain applications use protocols with known real-time properties
  - CAN
- Multimedia applications, calling for protocols that should provide high bandwidth and speed and even wireless interconnection.
  - Bluetooth
  - MOST
  - Firewire



- Safety critical applications, needing protocols that are fault tolerant and reliable. X-by-wire is an emerging market that calls for protocols like
  - TTP/C (Time-Triggered Protocol classified as a SAE type C network)
  - FlexRay
  - TT-CAN (Time Triggered CAN).
- Mechatronic type applications such as smart sensors and actuators, or even complex ECUs with simple communication needs. These applications are addressed by protocols like
  - LIN
  - ▶ TTP/A
  - other OEM (Original Equipment Manufacturer) specific protocols.






- ▶ How it all began ...
  - Discrete Interconnection of different systems (point to point wiring)

Network cable with a length of up to several miles and many connectors was required!! Air Con-Anti-Lighting Engine dition Lock Power Control Brakes Locks Dashboard Airbag Power Seats Trans-Active Power mission Suspen-Win-Control sion dows

▶ How it all began ...




# Agenda

- Introduction.
- Basic Concepts.
- ▶ Frame Formats.
- Error Detections.
- Error Handling.
- CAN protocol Versions.
- Motorola Scalable CAN (MSCAN).




- Multi-Master Concept.
- Number of Nodes is not limited by protocol
- No Node addressing
  - Message ID specifies contents and priority.
- Easy connection/disconnection of nodes.
- Broadcast/Multicast capability.
- CAN Network Speed:
  - Low Speed CAN baud rates from 40 Kbit/s to 125 Kbits/sec
  - High Speed CAN baud rates from 40 Kbit/s to 1 Mbits/sec, depending on cable length






CAN Bus Characteristics - Wired-AND





CAN Bus Characteristics - Wired-AND






CAN Bus Characteristics - Wired-AND

Recessive Vs Dominant

Two logic states possible on the bus:


"1" = recessive

"0" = dominant






Bus Access and Arbitration





- Sophisticated Error Detection/ Handling
- NRZ and Bit Stuffing for Synchronization
- Bus Access via CSMA/CD



CSMA/CD→ Carrier Sense Multiple Access / Collision Detection

# Agenda

- Introduction.
- Basic Concepts.
- Frame Formats.
- Error Detections.
- Error Handling.
- CAN protocol Versions.
- Motorola Scalable CAN (MSCAN).




# Frame Formats "Ref: http://esd.cs.ucr.edu/webres/can20.pdf"

- Data Frame
- Remote Frame
- Error Frame
- Overload Frame
- Inter-Frame Space
- Message vs. Signal




### Frame Formats- Data Frame






### Frame Formats-Remote Frame





### Frame Formats- Remote Frame


Remote Frame Scenario






### Frame Formats- Error Frame

#### Active Error Frame






### Frame Formats- Error Frame






### Frame Formats- Overload Frame

Overload Frame used to delay next CAN message




# Frame Formats-Inter-frame Space

Separates a frame (of whatever type) from a following
 Data or Remote frame



### Frame Formats- Message vs. Signal

- Messages are transmitted between Network Nodes over the bus.
- The data bytes of any message is divided into Signals.
- Signals represent a physical value.
- For example, one data byte could be divided into 3 signals as:
  - 4 bits that represent the vehicle speed => e.g: Named SpeedSig
  - 2 bits that represent the gear position => e.g: Named GearPosSig
  - 2 bits that represent the light status => e.g: Named LightStatSig





# Agenda

- Introduction.
- Basic Concepts.
- ▶ Frame Formats.
- Error Detections.
- Error Handling.
- CAN protocol Versions.
- Motorola Scalable CAN (MSCAN).




### **Error Detection**

- ▶ CRC Error
- ACK Error
- ▶ Form Error
- ▶ Bit Error
- Stuff Error



### Error Detection- CRC Error


Calculated and Received checksum must match





#### Error Detection- CRC Error


Otherwise frame wasn't received correctly (CRC Error)





# Error Detection- Acknowledge

 A frame must be acknowledged by at least one other node, otherwise ACK Error





### Error Detection- Frame Check

- No Dominant Bits allowed in
  - CRC Delimiter
  - ACK Delimiter
  - ▶ End of Frame
  - Inter-frame space

Otherwise Form Error is generated



# Error Detection-Bit Monitoring


- A transmitted bit must be correctly read back from CAN bus, otherwise Bit Error
- Dominant bits may overwrite recessive bits only in the Arbitration field and in the Acknowledge slot.



# Error Detection- Bit Stuffing

 Six consecutive bits with same polarity are not allowed between start of frame and CRC Delimiter

Otherwise Bit Stuffing Error




# Agenda

- Introduction.
- Basic Concepts.
- ▶ Frame Formats.
- Error Detections.
- Error Handling.
- CAN protocol Versions.
- Motorola Scalable CAN (MSCAN).




# Error Handling

- Detected errors are made public to all other nodes via Error Frames.
- The transmission of the erroneous message is aborted and the frame is repeated as soon as possible.



# Error Handling

Each Node is either in Error Active, Error Passive or Bus off state.



faulty nodes withdraw from the bus automatically (Bus off State)



## **Undetected Errors**

- Imagine a vehicle equipped with CAN
  - Running 2000 hr/year
  - At CAN bus speed of 500 Kbps
  - With 25% bus load

=> This will result in I undetected error every 1000 years!!



## Agenda

- Introduction.
- Basic Concepts.
- Frame Formats.
- Error Detections.
- Error Handling.
- CAN protocol Versions.
- Motorola Scalable CAN (MSCAN).



## CAN protocol versions

- Two CAN protocol versions available:
  - V2.0A (Standard) I I bit Message ID's 2048 ID's available.

Start of	ldentifier	Control	Data Field	CRC	ACK	End
Frame	11 bits	Field	(08 Bytes)	Field	Field	of Frame

V2.0B (Extended) - 29 bit Message ID's - more than 536 Million ID's available

Start of	Identifier	Control	Data Field	CRC	ACK	End
Frame	29 bits	Field	(08 Bytes)	Field	Field	of Frame



## CAN protocols versions

- Three types of CAN modules available (all handles 11 bit ID's)
  - 2.0A- Considers 29 bit ID as an error.
  - ▶ 2.0B Passive Ignores 29 bit ID messages
  - 2.0B Active- Handles both 11 and 29 bit ID Messages

	Frame with 11 bit ID	Frame with 29 bit ID
V2.0B Active CAN Module	Tx/Rx OK	Tx/Rx OK
V2.0B Passive CAN Module	Tx/Rx OK	Tolerated
V2.0A CAN Module	Tx/Rx OK	Bus ERROR



#### የማ


# Agenda

- Introduction.
- ▶ Basic Concepts.
- Frame Formats.



- The LIN is a SCI/UART-based serial
- Single-Master / Multi Slave Concept.
- Number of Nodes is limited up to 16 slaves
- No Node addressing
  - Message ID specifies contents and priority.
- Broadcast/Multicast capability.
- LIN Network Speed:
  - LIN baud rates up to 20 Kbit/s







- LIN is a Time Triggered communication protocol designed to support automotive networks in conjunction with Controller Area Network (CAN)
- No collision detection exists in LIN, therefore all messages are initiated by the master with at most one slave replying for a given message identifier.



- The LIN bus is connected between smart sensor or actuators and an Electronic Control Unit (ECU) which is often a gateway with CAN bus.
- Enables cost-effective communication with sensors and actuators when all the features of CAN are not required.
- The main features of this protocol (compared to CAN) are low cost and low speed and used for short distance networks.



- The master is typically a moderately powerful microcontroller, whereas the slaves can be less powerful, cheaper microcontrollers or dedicated ASICs.
- The LIN is a single wire 12V bus connection, in which the communication protocol is based upon ISO 9141 NRZstandard.
- An important feature of LIN is the synchronization mechanism that allows the clock recovery by slave nodes without quartz or ceramics resonator.
- Only the master node will be using the oscillating device. Nodes can be added to the LIN network without requiring hardware or software changes in other slave nodes.




# Agenda

- Introduction.
- ▶ Basic Concepts.
- Frame Formats.




- A frame consists of a header (provided by the master task) and a response (provided by a slave task)
- The slave tasks interested in the data associated with the identifier receives the response, verifies the checksum and uses the data transported






#### ▶ Frame Structure





- Frame Structure
- Structure of a Byte field
  - The LSB of the data is sent first and the MSB last.
  - The start bit is encoded as a bit with value zero (dominant) and the stop bit is encoded as a bit with value one (recessive)





#### Break:

- The break symbol is used to signal the beginning of a new frame
- A break is always generated by the master task and it shall be at least 13 bits of dominant value, including the start bit, followed by a break delimiter

Start bit Break delimit




- Synch Byte:
  - Synch is a byte field with the data value 0x55
  - A slave task shall always be able to detect the break/synch symbol sequence





- Protected Identifier
- Identifier:
  - Six bits are reserved for the identifier (ID), values in the range
     0 to 63 can be used
  - ▶ The identifiers are split in four categories:
  - Values 0 to 59 (0x3b) are used for signal-carrying frames
  - $\triangleright$  60 (0x3c) and 61 (0x3d) are used to carry diagnostic data
  - ▶ 62 (0x3e) is reserved for user-defined extensions
  - ▶ 63 (0x3f) is reserved for future protocol enhancements



- ▶ Parity:
  - ▶ The parity is calculated on the identifier bits
  - ▶ P0 = ID0 ⊕ID1 ⊕ID2 ⊕ID4
  - $\triangleright$  PI = (IDI  $\oplus$ ID3  $\oplus$ ID4  $\oplus$ ID5)



#### Data:

- A frame carries between one and eight bytes of data
- A data byte is transmitted in a byte field
- For data entities longer than one byte, the entity LSB is contained in the byte sent first and the entity MSB in the byte sent last (little-endian)

Data 1 Data 2 Data 3 Data 4 Data 5 Data 6 Data 7 Data 8

#### Checksum:

- The checksum contains the inverted eight bit sum with carry 6 over all data bytes or all data bytes and the protected identifier
- Checksum calculation over the data bytes only is called classic checksum and it is used for communication with LIN 1.3 slaves
- Checksum calculation over the data bytes and the protected identifier byte is called enhanced checksum and it is used for communication with LIN 2.0 slaves
- Identifiers 60 (0x3c) to 63 (0x3f) shall always use classic checksum

