Hes-so

Haute Ecole Spécialisée
de Suisse occidentale
Fachhochschule Westschweiz
University of Applied Sciences
Western Switzerland

# Design of Embedded Hardware and Firmware

# Introduction on "System On Programmable Chip" NIOS II – Avalon Bus

Andres Upegui, René Beuchat Laboratoire de Systèmes Numériques hepia/HES-SO



### **Embedded system on Altera FPGA**

#### Goals:

- To understand the architecture of an embedded system on FPGA
- To be able to identify the components required for building a specific interface
- To have an overview of the construction of a full system based on a standard softcore bus in a FPGA with block modules

### **Embedded system on Altera FPGA**


### **Contents**

- System On FPGA
- NIOS II a softcore processor
- Avalon Bus
- Design of a specific slave programmable interface on Avalon

#### NIOS II -

#### **Embedded system NIOSII/Avalon Architecture**

Note: The same principles are available for Altera, Xilinx, Actel or others FPGA



#### NIOS II

- Softcore Processor from Altera
  - ➤ A processor implemented with Logic Elements (LUT+DFF) in a FPGA
  - A processor synthesized by a compiler and placed & routed on the FPGA
  - A processor described by a HDL langage(VHDL/Verilog/ ...)
- 32 bits Architecture
- 256 instructions available for user implementation
- 3 versions
- Operating systems supported: linux, eCos, embOS, Euros RTOS, oSCAN, uCLinux, ThreadX, VxWorks





# NIOS II Processor : 3 basic configurable architectures

	Nios II / f Fast	Nios II / s Standard	Nios II / e Economy
Pipeline	6 stages	5 stages	None
<b>Branch prediction</b>	Dynamic	Static	None
<b>Instruction Cache</b>	Configurable	Configurable	None
Data Cache	Configurable	None	None
MMU	Yes	No	No
Hard Multiplier	1 cycle	3 cycles	None
Hard divider	Yes	Yes	No
Resources	Env 2500 LEs	< 1400 LEs	< 700 LEs
Max freq	290 MHz	270 MHz	340 MHz




### **NIOS II Processor performance**

<b>Processor Category</b>	Cost- and Power-Sensitive Processors			Real-Time Processors	
Devices	ARM Cortex-M1	V1 ColdFire	Nios II Economy	Nios II Standard	Nios II Fast
Cyclone III	80 at	84 at	30 at	90 at	195 at
(MIPS <sup>(1)</sup> at MHz)	145	90	215	145	175
Cyclone III LS	-	65 at	20 at	70 at	160 at
(MIPS <sup>(1)</sup> at MHz)		70	150	110	140
Cyclone IV GX	-	70 at	30 at	70 at	190 at
(MIPS <sup>(1)</sup> at MHz)		75	175	110	165
Arria II GX		84 at	45 at	115 at	270 at
(MIPS <sup>(1)</sup> at MHz)		90	300	180	240
Stratix III	150 at	104 at	48 at	140 at	340 at
(MIPS <sup>(1)</sup> at MHz)	230	112	340	230	290
Stratix IV	-	135 at	50 at	155 at	340 at
(MIPS <sup>(1)</sup> at MHz)		145	340	240	290
Stratix V	-	135 at	50 at	170 at	320 at
(MIPS <sup>(1)</sup> at MHz)		145	330	270	280



#### **Accelerating computation: Custom user instructions**

 The ALU can be extended by user own instructions, until 256.



#### Instructions can be:

- Combinatorial
- Multi-cycle, synchronized by clk and stall
- Parameterized


They can have access to all the FPGA resources !!!





#### Improving performance: hardware accelerator


- For cycles consuming operations, a hardware accelerator can be included/developed
- A Master unit which has access to Memory and Programmable Interfaces for accelerated operations or with hard real time constrains



et d'architecture de Genève

#### Classic Computer architecture (general and simplified)

In single master, address bus is totem-pole, data bus is tri-state



#### Classic Computer architecture (general and simplified)

- Classical architecture
  - ▶ Processor
  - ➤ Memories
  - ➤ Input/Output (programmable) interface
  - >Address bus
  - ➤ Data Bus (tri-state)
  - ➤ General decoder



#### SoPC architecture: Avalon bus


Multi-Master


. Avalon Bus Module Block Diagram - An Example System

Arbitrage « slave-side »

#### **Concurrent Master-Slave Access**

Synchronous transfers








#### SoPC architecture

- Processor
- Memories
- Input/Output (programmable) interface
- Address bus
- Separated Data Bus In/Out → multiplexers
- Local decoder on the Avalon bus
- Bus transfers size adaptation is done at Avalon bus level
- Master/Slave
- Synchronous bus
- Wait state by configuration or dynamic
- Hold / Set up available





### « slave » signals

Signal Type	Width	Direction	Required	Description
clk	1	In	(No)	Global clk for system module and Avalon bus modules. All transactions synchronous to clk rising edge
nReset	1	In	No	Global Reset of the system
address	132	In	No	Address for Avalon bus modules
chipselect	1	In	Yes	Selection of the Avalon bus module
read	1	In	No	Read request to the slave
readdata	132	Out	No	Read data from the slave module
write	1	In	No	Write request to the slave
writedata	132	In	No	Data from Master to Slave module
irq	1	Out	No	Interrupt request to the master



hepia

#### « slave » signals

- The ChipSelect is generated by the Avalon bus and selects the module
- The Address[n .. 0] is used to access a specific register/memory position in the selected module.
   Only the minimum number of address is necessary.
- The Read and Write signals specified the direction of the transfers. They are provided by a Master and received by the slave modules
- ReadData(..) and WriteData(..) bus transfers the Datas from (read)/ to (write) the Slaves

#### « slave » signals

- The Read and Write signals specified the direction of the transfers.
- They are provided by a Master and received by the slave modules
- The direction is the view of the Master unit
- ReadData(..) and WriteData(..) bus transfers the Datas from (read)/ to (write) the Slaves



#### « slave » signals

- BE (Byte Enable) signals indicate the bytes to transfer.
  - The number of BE activated are always a power of 2
  - They start at a multiple of the size to transfer
- A master address is a byte address
- A slave address is a word address
- The Avalon bus make the translation and performs multiple accesses if required.


# Avalon byte enable

byteenable_n[3:0]	Write action
0000	Write full 32-bits
1100	Write lower 2 bytes
0011	Write upper 2 bytes
1110	Write byte 0 only
1011	Write byte 2 only


Specify bytes to be transferred Active low signals in this representation



#### Master to slave addresses: Master 32 bits, Slave 8 bits




#### Master to slave addresses: Master 32 bits, Slave 16 bits



#### Master to slave addresses: Master 32 bits, Slave 32 bits








Byte Address Word = Quadlet (32 bits)





et d'architecture de Genève

### Master to slave addresses: Master 32 bits, Slave 64 bits



# Avalon « slave » signals

Signal Type	Width	Direction	Required	Description
WaitRequest/ WaitRequest_n	1	Out	No	Assert by the slave when it is not able to answer in this clock cycle to read or write access
ByteEnable/ ByteEnable_n	1, 2, 4, 8,,128	In	No	The bytes to transfer
BeginTransfer	1	In	No	Inserted by Avalon fabric at and only at first clock of each transfer
ReadDataValid/ ReadDataValid_n	1	Out	No	For read transfer with <b>variable latency</b> , means data are valid to master
BurstCount	111	In	No	Number of burst transfers
BeginBurstTransfer	1	In	No	First cycle of a burst transfer, valid for 1 clock cycle




### **Avalon Bus**

### Slave view of transfers


- Transfers are synchronous on the rising edge of the Clk
- Between Clk, the timing relation between signals are NOT relevant

### Avalon slave read, 0 wait, asynchronous peripheral




### Avalon slave read, 1 wait

### Wait cycle specified by design





# Avalon read slave, 2 wait






# Avalon read slave, 1 set up and 1 wait








### Avalon read slave, wait request generated by slave device






# Avalon read slave, burst of 4 from Master A, 2 from master B




### Pipeline of master access

ReadDataValid activated by slave for each data


# Avalon write slave, 0 wait









# **Avalon write** slave, 1 wait








# Avalon write slave, wait request generated by slave






# Avalon write slave, 1 set up, 1 hold, 0 wait





# Avalon write burst transfer of 4, wait request generated by slave



### **Bus avalon**

#### **Master view**

- The master starts a transfer (read or write)
- It provides the Addresses (32 bits on NIOSII)
- It waits on WaitRequest signal to resume the transfer

# **Avalon** master signals (1)


Signal Type	Width	Direction	Required	Description
clk	1	in	yes	Global clock signal for the system module and Avalon bus module. All bus transactions are synchronous to clk.
reset	1	in	no	Global reset signal. Implementation is peripheral- specific.
address	1 - 32	out	yes	Address lines from the Avalon bus module. All Avalon masters are required to drive a byte address on their address output port.
byteenable	0, 2, 4	out	no	Byte-enable signals to enable specific byte lane(s) during transfers to memories of width greater than 8 bits. Implementation is peripheral-specific.
read	1	out	no	Read request signal from master port. Not required if master never performs read transfers. If used, readdata must also be used.
readdata	8, 16, 32	in	no	Data lines from the Avalon bus module for read transfers. Not required if the master never performs read transfers. If used, read must also be used.
write	1	out	no	Write request signal from master port. Not required if the master never performs write transfers. If used, writedata must also be used.



# Avalon master signals (2)


Signal Type	Width	Direction	Required	Description
writedata	8, 16, 32	out	no	Data lines to the Avalon bus module for write transfers. Not required if the master never performs write transfers. If used, write must also be used.
waitrequest	1	in	yes	Forces the master port to wait until the Avalon bus module is ready to proceed with the transfer.
irq	1	in	no	Interrupt request has been flagged by one or more slave ports.
irqnumber	6	in	no	The interrupt priority of the interrupting slave port. Lower value has higher priority.
endofpacket	1	in	no	Signal for streaming transfers. May be used to indicate an end of packet condition from the slave to the master port. Implementation is peripheral-specific.
readdatavalid	1	in	no	Signal for read transfers with latency and is for a master only. Indicates that valid data from a slave port is present on the readdata lines. Required if the master is latency-aware.
flush	1	out	no	Signal for read transfers with latency. Master can clear any pending latent read transfers by asserting flush.

## **Avalon Master Basic fundamental transfers**






## Avalon read master, 0 wait






## Avalon read master, wait generated by slave/Avalon bus






## Avalon write master, 0 wait






# **Avalon write** master, wait generated by slave




## **Avalon read** transfers with latency (ex. 2 cycles)



Wait request here means:


delay address cycle Fixed latency (here 2)






#### **Avalon read**

transfers with latency, and *readdatavalid* generated by slave




### Readdatavalid specify when data are ready






#### **Avalon burst Write**



Address and BurstCount available for the whole transfer Write can be deactivated by the master The number of burstcount needs to be generated



### **Embedded System on FPGA (example)**





MASTER OF SCIENCE IN ENGINEERING

Haute école du paysage, d'ingénierie et d'architecture de Genève

## Conclusion

Some positive points of a softcore architecture
☐ Fast implementation
☐ Modular Architecture
☐ Affordable system complexity
☐ Good documentation
☐ Reuse of existing IP cores
☐ Ease of development of our own programmable interface on internal bus (i.e. Avalon in VHDL, Verilog)
☐ Full system on FPGA, easily adaptable
☐ Operating Systems available
Some negative points
☐ Several complex tools to develop a system: hardware and software specific
☐ Several debugging levels to deal with for hardware and software.



hepia