

**RA6963** 

Dot Matrix
LCD Controller
Specification

Version 1.4 March 27, 2009

RAiO Technology Inc.
©Copyright RAiO Technology Inc. 2009



	Update History						
Version	Date	Description					
1.0	May 29, 2007	Formal Release					
1.1	September 27, 2007	Update Figure 9-4					
1.2	November 15, 2007	Update < Table 8-2 > Max. $f_{OSC}$ to 18MHz. Update < Table 8-4 > Max. $f_{SCP}$ to 9MHz. Update the Chapter 5-4 "Misc Interface" – the description of pin "MDS" and MD[1:0].					
1.3	February 26, 2008	Update the description of pin "X1" in Section 5-4. Update Figure 6-13, 6-14, 9-5 and 9-6.					
1.4	March 27, 2009	Update < Table 6-5 > Command Definition Description. Update Figure 6-10. Update < Table 6-31 > Package Description in Section 6-21. Update < Table 8-2 >					



Chapter	Contents	Pages
1 Overview		5
	n	
	ns	
_	9	
	terface	
	face	
_	e	
	scription	
	efinition	
	ESET/HALT	
	and Oscillation Clock	
	ons with MPU	
	ons with MPO	
•	efinitions	
6-6 Setting Regis	ters	17
	Pointer	
6-6-2 Set Offset R	egister	18
	Pointer	
	/ord	
	me Address	_
•	Home Address	
	a Area	
•	Al Ga	
	)	
• •	ern Select	
	ead/Write	
	Vrite	
	«	
	yt	
	erse	
	Mandan	
6-18 Cursor Auto	Moving	



33
34
35
36
36
36
37
38
39
39
40
40
41
43
43
44
44
45
46
46



## 1. Overview


The RA6963 is a dot matrix LCD Controller which fully compatible with T6963C. It supports various LCD Driver for standard or custom-made LCD module. The RA6963 built-in a 256-word CG(Character Generator) ROM that for ASCII, Japanese or numeric display in text mode. It also supports Graphics mode and mixed display with Text. The supported maximum external display RAM is 64Kbyte and the display Window can be moved freely within the allocated memory range. The RA6963 has an 8-bit parallel data bus that can be directly connected to an 8080 series MPU.

The RA6963 supports a very broad range of LCD formats by allowing selection of different combinations via a set and combination text-and-graphic modes, and includes various attribute functions.

### 2. Features

- Support Display Range:
   Columns → 32, 40, 64, 80
   Rows → 2, 4, 6, 8, 10, 12, 14, 16, 20, 24, 28, 32
- ◆ Support 8080 8-bit MPU Interface
- ◆ Built-in 256-word Font ROM: Basic ASCII Japanese Numeric
- Support Max. 64Kbyte External Display SRAM
- Display Mode : Character \( \cdot \) Graphics and Mixed Mode
- ◆ Font Size : Horizontal → 5, 6, 7, 8 Pixels Vertical → 8 Pixels
- Support Bold Font and Reverse Display
- Support Various LCD Driver
- ◆ Support 1/16 ~1/128 Duty
- ◆ Built-in X'tal Oscillator or Using External Clock
- ◆ Power Supply Range: 3.0~5.5V
- Package: LQFP-67Pin (RoHS Compliance)


## 3. Block Diagram



< Figure 3-1 >



## 4. Package



< Figure 4-1 >

RA6963L2NA: LQFP-67 Pin, RoHS Compliance Package, Font-01 (Refer to Chapter 6-20) RA6963L2NB: LQFP-67 Pin, RoHS Compliance Package, Font-02 (Refer to Chapter 6-20)

# 5. Pin Descriptions

### 5-1 MPU Interface

< Table 5-1 >

Pin Name	I/O	Description							
SD[70]	I/O	Data Bus This is bus for o	Data Bus This is bus for data transfer between MPU and RA6963.						
RD	I	Read Control RD is a data re	Read Control RD is a data read signal. When Low, MPU read data from RA6963.						
WR	I	Write Control WR is a data v	Write Control  WR is a data write signal. When Low, MPU write data into RA6963.						
		Command/Data Select or Register Select This is a Data or Command select signal.							
C/ D		C/D	WR = Low	RD = Low					
C/ D		High	Command Write	Status Read					
		Low	Data Write	Data Read					
CE	I	Chip Enable This s chip enable of RA6963. When MPU communicate with RA6963, this pin must be Low.							



## **5-2 LCD Driver Interface**

## < Table 5-2 >

Pin Name	I/O	Description
FR	0	Frame
LP	0	Latch Latch pulse for column driver. Shift clock pulse for Row Driver
CDATA	0	Synchronous Data Synchronous Data for Row Driver.
HSCP	0	Shift Clock Pulse Shift clock pulse for Column Driver in upper area of LCD.
HOD	0	Data Output Data output for Odd Columns in upper area of LCD.
ED	0	Data Output  SDSEL = High → Data output for even columns in both upper and lower area of LCD.  SDSEL = Low → Data output for columns in both upper and lower area of LCD.
DSPON	0	Display On Display On/Off control signal. When HALT or RST is Low, DSPON output Low (LCD Display Off).

# **5-3 Memory Interface**

### < Table 5-3 >

Pin Name	I/O	Description
A[15:0]	0	Address Output for External Memory
D[7:0]	I/O	Data Bus for External Memory
MCE	0	Memory Chip Enable  MCE = Low → Memory Enable.  MCE = High → Memory Disable.
MRW	0	Memory Read/Write Control  MRW = Low → Memory Write Enable.  MRW = High → Memory Read Enable.
CE0 LOD	0	Memory Chip Enable 0  If DUAL = High → Chip enable pin for display memory in the address range 0000~07FFh.  If DUAL = Low → Serial data output for odd columns in lower area of LCD.
CE1 LSCP	0	Memory Chip Enable 1  If DUAL = High → Chip enable pin for display memory in the address range 0800~0FFFh.  If DUAL = Low → Shift clock output for Column Driver in lower area of LCD.
VDD	Р	Power
GND	Р	Ground



## 5-4 Misc. Interface

< Table 5-4 >

< Table 5-4 >												
Pin Name	I/O		<u> </u>			Descr	iption					
DUAL	I	DUAL	Scan Select  DUAL = Low → Dual-Scan Mode.  DUAL = High → Signal-Scan Mode.									
		LCD	LCD Size Selection One Screen:									
			DUAL	Н	Н	Н	Н	Н	Н	Н	Н	
			MDS	L	L	L	L	Н	Н	Н	Н	
			MD1	Н	Н	L	L	Н	Н	L	L	
			MD0	Н	L	Н	L	Н	L	Н	L	
			Lines	2	4	6	8	10	12	14	16	
MDS	١,		V-Dots	16	32	48	64	80	96	112	128	
MD[1:0]	'	Two	Screens:									-
			DUAL	L	L	L	L	L	L	L	L	
			MDS	L	L	L	L	Н	Н	Н	Н	
			MD1	Н	Н	L	L	Н	Н	L	L	
			MD0	Н	L	Н	L	Н	L	Н	L	
			Lines	4	8	12	16	20	24	28	32	
			V-Dots	32	64	96	128	160	192	224	256	
X1	I	Crystal Oscillator Input A crystal oscillator circuit is built in. The oscillation frequency is adjusted according to the display size. If using an external clock, use the X1 pin as the clock input. (X2 open.) External capacitors 15 to 20pF.										
X2	0	Cryst	al Oscillator	Outp	ut							
		Font	Selection	T							<b>-</b>	
FS[1:0]	۱ ،		FS0	-	H	L		Н		L	_	
1, 1,			FS1	-	Н	Н	-	L		L		
			Font	5	X 8	6 X	8	7 X 8		8 X 8		
		Colur	nns Selectio	n							_	
MD[3:2]	1		MD2		Н	L		Н		L		
			MD3		Н	Н		L		L		
			Columns	] 3	32	40	)	64		80		
		Data	Transfer Mo	de								
SDSEL	I		$\overline{EL} = Low \rightarrow S$		•	•	•					
		SDSE	EL = High → S	Sendir	ng data	by ode	d/even	separt	ion mo	de.		



		Halt Signal
HALT	I	HALT = Low → Stop the Clock.
		HALT = High → Normal Mode.
		Reset Signal
RST	ı	RST = Low → RA6963 will be reset.
		RST = High → Normal mode. RA6963 built-in a Pull-Hi resistor.
TEST[2:1]	1	Test Pins
1631[2.1]	'	These are test pins. No need for connection(NC).
CH1, CH2	0	Check Signals
FONTSEL	I	CGROM Font Select This pin is used to select the character of CGROM. Refer to Chapter 6-20. Please note, this pin is only reserved for die base chip only. Refer to Chapter 7-2. FONTSEL = Low → Select default CGROM Font-01. FONTSEL = High → Select default CGROM Font-02.



## 6. Functions Description

#### 6-1 Functional Definition

- ◆ After power on, it is necessary to reset. The RST is kept Low between 5 clocks up (oscillation clock).
- ◆ When HALT = Low, the oscillation stops. The power supply for the LCD must be turned off, to protect the LCD from DC bias.
- ◆ The HALT function(HALT = Low) includes the RESET function(RST = Low).
- ◆ The column/line counter and display register are cleared by RST. (Other registers are not cleared.) Disable the display using the clear-display register
- ◆ The status must be checked before data or commands are sent. The MSB=0 status check must be done in particular. There is a possibility of erroneous operation due to a hard interrupt.
- ◆ STA0 and STA1 must be checked at the same time. When a command is executed, data transmission errors may occur.
- ◆ The RA6963 can only handle one byte per machine cycle (16 clocks). It is impossible to send more than two data in a machine cycle.
- ◆ When using a command with operand data, it important to send the data first, and then executes the command.
- ◆ The character fonts used by the RA6963 are different from ASCII codes.

#### 6-2 State After RESET/HALT

< Table 6-1 >

Pins	HALT	RESET
SD[7:0]	Floating	Floating
D[7:0]	Floating	Floating
MRW	Hi	Hi
MCE	Hi (Note 1)	Hi (Note 1)
A[15:0]	Hi (Note 2)	Hi (Note 2)
CE0, CE1	Hi (Note 1)	Hi (Note 1)
ED, HOD	Final data	Final data
HSCP	Low	Low
LP	Low	Low
CDATA	Hi	Hi
FR	Hi	Hi
CH1	Low	Test Signal
CH2	Low	Test Signal
DSPON	Low	Low
X2	Hi	OSC Clock

Note 1: In Attribute mode, Hi or Low according to state of graphic pointer

Note 2: In Attribute mode, data to graphic pointer



#### 6-3 Row / Column and Oscillation Clock

The frequency of the crystal oscillator is adjusted by the following formula.

**f**osc : Frequency of oscillation

 $f_{SCP}$ : Frequency of shift clock ( $f_{SCP} = f_{OSC}/2$ )

**f**<sub>R</sub> : Frequency of Frame

M : Number of characters on one line (number of dots on one line =8M)

For all font sizes (e.g. 7 x 8, 7 x 8, 5 x 8) the oscillation frequency remains constant.

N : Number of rows (Duty=1/8N)

$$\frac{8M}{f_{SCP}} \times 8N = \frac{1}{f_R}$$

$$f_{OSC} = f_R x 64 x 2 x M x N$$
  
 $(f_R = 60Hz)$ 

#### < Table 6-2 >

Unit: MHz

_						OTTIL. IVII 12	
N	M	32	40	64	80	Duty	
	Upper	0.492	0.614	0.983	1.229	1/16	
2	Lower	0.983	1.229	1.966	2.458	1/10	
4	Upper	0.983	1.229	1.966	2.458	1/32	
4	Lower	1.966	2.458	3.932	4.915	1/32	
	Upper	1.475	1.843	2.949	3.688	1/48	
6	Lower	2.949	3.685	5.898	7.372	1/40	
	Upper	1.966	2.458	3.932	4.915	1/64	
8	Lower	3.932	4.915	7.864	9.830	1/04	
40	Upper	2.458	3.072	4.915	6.144	1/00	
10	Lower	4.915	6.144	9.830	12.288	1/80	
40	Upper	2.949	3.686	5.898	7.373	1/06	
12	Lower	5.898	7.373	11.776	14.746	1/96	
4.4	Upper	3.440	4.300	6.881	8.602	1/112	
14	Lower	6.881	8.601	13.763	17.203	1/112	
40	Upper	3.932	4.915	7.864	9.830	1/120	
16	Lower	7.864	9.830	15.729	19.660	1/128	

Note 1: Upper  $\rightarrow$  Single-Scan. Lower  $\rightarrow$  Dual-Scan at  $f_R = 60$ Hz



#### 6-4 RAM Interface


The external RAM is used to store display data (text, graphic and external CG data).

With single-scan, text data, graphic data and external CG data can be freely allocated to the memory area (64 KB max).

With dual-scan, LCD-I is allocated to 0000h to 7FFFh (32 KB max), LCD-II is allocated to 8000h to FFFFh (32-KB Max). Text data, graphic data and external CG data can be freely allocated in LCD-I. In LCD-II, the same addresses must be allocated as in LCD-I, except A15. A15 determines selection of LCD-I or LCD-II.

It can be used the address-decoded signals  $\overline{\text{CE0}}$  (0000h to 07FFh),  $\overline{\text{CE1}}$  (0800h to 0FFFh) within 4 KB.  $\overline{\text{CE0}}$  and  $\overline{\text{CE1}}$  allow decoding of addresses in the ranges (0000h to 07FFh) and (0800h to 0FFFh) respectively within a 4-KB memory space.

(Example)



< Figure 6-1 >



#### 6-5 Communications with MPU

#### 6-5-1 Status Read

A status check must be performed before data is read or written.

#### Status Check

The Status of RA6963 can be read from the data lines.

#### < Table 6-3 >

RD	WR	CS	C/D	SD[7:0]
L	Н	L	Н	Status Word

The RA6963 status word format is as follows:

MSB							LSB
SD7	SD6	SD5	SD4	SD3	SD2	SD1	SD0
STA7	STA6	STA5	STA4	STA3	STA2	STA1	STA0

#### < Table 6-4 >

STA0	Check command execution capability	0: Disable
01710	Check command excedition capability	1: Enable
STA1	Check data read/write capability	0: Disable
SIAI	Check data read/write capability	1: Enable
STA2	Check Auto mode data read capability	0: Disable
STAZ	Check Auto mode data read capability	1: Enable
STA3	Chack Auto made data write canability	0: Disable
STAS	Check Auto mode data write capability	1: Enable
STA4	Not used	
STA5	Check controller operation capability	0: Disable
STAS	Check controller operation capability	1: Enable
STA6	Error flog Llood for Coroon conv.commanda	0: No error
STAG	Error flag. Used for Screen copy commands.	1: Error
STA7	Check the blink condition	0: Display off
STAI	Check the billik condition	1: Normal display

Note 1: It is necessary to check STA0 and STA1 at the same time.


There is a possibility of erroneous operation due to a hardware interrupt.

Note 2: For most modes STA0 /STA1 are used as a status check.

Note 3: STA2 and STA3 are valid in Auto mode; STA0 and STA1 are invalid.



#### Status Checking Flow



< Figure 6-2 >

Note 4: When using the MSB=0 command, a Status Read must be performed.

If a status check is not carried out, the RA6963 cannot operate normally, even after a delay time.

The hardware interrupt occurs during the address calculation period (at the end of each line).

If a MSB=0 command is sent to the RA6963 during this period, the RA6963 enters Wait status.


If a status check is not carried out in this state before the next command is sent, there is the possibility that command or data will not be received.



## 6-5-2 Setting Data

When using the RA6963, first set the data, then set the command.

## Procedure for Sending a Command



< Figure 6-3 >

Note: When sending more than two data, the last datum (or last two data) is valid.



## 6-5-3 Command Definitions

### < Table 6-5 >

Command	Code	D1	D2	Function
Registers Setting	00100001	X address	Y address	Set cursor pointer
3	00100010	Data	00h	Set Offset Register
	00100100	Low address	High address	Set Address pointer
Set Control Word	01000000	Low address	High address	Set Text Home Address
	01000001	Columns	00h	Set Text Area
	01000010	Low address	High address	Set Graphic Home Address
	01000011	Columns	00h	Set Graphic Area
Mode Set	1000X000			OR mode
mode oct	1000X001			EXOR mode
	1000X001			AND mode
	1000X1100			Text Attribute mode
	1000X100			Internal CG ROM mode
	10000XXX			External CG RAM mode
Display Mode	100017777			Display off
Display Mode	10010000 1001XX10			Cursor on, blink off
	1001XX10			Cursor on, blink on
	1001XX11			
	100101XX			Text of, graphic off
				Text off, graphic on
Curacu Dattaun Calact	100111XX			Text on, graphic on
Cursor Pattern Select	10100000			1-line cursor
	10100001			2-line cursor
	10100010			3-line cursor
	10100011			4-line cursor
	10100100			5-line cursor
	10100101			6-line cursor
	10100110			7-line cursor
D . D . 1044 14	10100111			8-line cursor
Data Read/Write	11000000	Data		Data Write and Increment ADP
	11000001			Data Read and Increment ADP
	11000010	Data		Data Write and Decrement ADP
	11000011			Data Read and Decrement ADP
	11000100	Data		Data Write and Non-variable ADP
	11000101			Data Read and Non-variable ADP
Data auto Read/Write	10110000			Set Data Auto Write
	10110001			Set Data Auto Read
	10110010			Auto Reset
Screen Peek	11100000			Screen Peek
Screen Copy	11101000			Screen Copy
Bit Set/Reset	11110XXX			Bit Reset
	11111XXX			Bit Set
	1111X000			Bit 0 (LSB)
	1111X001			Bit 1
	1111X010			Bit 2
	1111X011			Bit 3
	1111X100			Bit 4
	1111X101			Bit 5
	1111X110			Bit 6
	1111X111			Bit 7 (MSB)



Screen Reverse	11010000	Data	Data (Don't' care) (Note)	Whole screen reverse Data Bit 0 0 : Normal 1 : Reverse
Blink Time	01010000	Data	Data (Don't' care) (Note)	If Frame = 60Hz Data Bit 2:0 000: 0.066s 001: 0.25s 010: 0.5s (Default) 011: 0.75s 100: 1s 101: 1.25s 110: 1.5s 111: 2s
Cursor Auto Moving	01100000	Data	Data (Don't' care) (Note)	Data Bit 0 0 : Disable.(Default) 1 : Enable.
CGROM Font Select	01110000	Data	Data (Don't' care) (Note)	Data Bit 1:0 00 : Do not care.(Default) 01 : Do not care. 10 : CGROM Font-01. 11 : CGROM Font-02.

Note: In these functions, it must be sent two data before sending the command, but the contents of the second datum (D2) can be any values.

## 6-6 Setting Registers

#### < Table 6-6 >

Code	Hex.	Function	D1	D2
00100001	21h	Set Cursor Pointer	X-Adrs	Y-Adrs
00100010	22h	Set Offset Register	Data	00h
00100100	24h	Set Address Pointer	Low Adrs	High Adrs

### 6-6-1 Set Cursor Pointer

The X-Adrs and Y-Adrs specify the position of the cursor. The cursor position can only be moved by this command. Data read /write from the MPU never changes the cursor pointer. X-Adrs and Y-Adrs are specified as follows.

X-Adrs 00h to 4Fh (lower 7 bits are valid) Y-Adrs 00h to 1Fh (lower 5 bits are valid)

a) Single-ScanX-Adrs 00h to 4Fh

Y-Adrs 00h to 0Fh


b) Dual-Scan X-Adrs 00h to 4Fh

Y-Adrs 00h to 0Fh Upper Screen
Y-Adrs 10h to 1Fh Lower Screen



#### 6-6-2 Set Offset Register

The offset register is used to determine the external character generator RAM area. The RA6963 has a 16-bit address bus as follows:




RA6963 assign External character generator, when character code set 80h to FFh in using Internal character generator. Character code 00h to 80h assign External character generator, when External generator mode.

The senior five bits define the start address in external memory of the CG RAM area. The next eight bits represent the character code of the character. In internal CG ROM mode, character Codes 00h to 7Fh represent the predefined "internal" CG ROM characters, and codes 80h to FFh Represent the user's own "external" characters. In external CG RAM mode, all 256 codes from 00h to FFh can be used to represent the user's own characters. The three least significant bits indicate one of the eight rows of eight dots that define the character's shape.

### The Relationship between Display RAM Address and Offset Register

Offset Register Data 00000 00001 00010	CG RA	080	Address 0 to 07F 0 to 0FF 0 to 17F	Èh Fh	End)
11100 11101 11110 11111		E80 F00	0 to E7F 0 to EFF 0 to F7F 0 to FFF	Fh Fh	
(Example 1) Offset Register Character Code Character Generator RAM Start Address	02h 80h 0001 1	0100	0000	0000	h



< Figure 6-4 >



(Example 2) The relationship between Display RAM data and display characters

	(DAM D-4-)	(Ob t)
	(RAM Data)	(Character)
AD DE % CUI	21h	Α
$AB \gamma DE \zeta GH$	22h	В
:	83h	11h
	24h	D
	25h	E
	86h	14h
	27h	G
Display Character	28h	Н


< Figure 6-5 >

The " $\gamma$ " and " $\zeta$ " are displayed by character generator RAM.

#### 6-6-3 Set Address Pointer

The Set Address Pointer command is used to indicate the start address for writing to (or reading from) External RAM.

### The Flowchart for Set Address Pointer Command



< Figure 6-6 >



#### 6-7 Set Control Word

#### < Table 6-7 >

Code	Hex.	Function	D1	D2
01000000	40h	Set Text Home Address	Low Address	High Address
01000001	41h	Set Text Area	Columns	00h
01000010	42h	Set Graphic Home Address	Low Address	High Address
01000011	43h	Set Graphic Area	Columns	00h

The home address and column size are defined by this command.

#### 6-7-1 Set Text Home Address

The starting address in the external display RAM for text display is defined by this command. The text home address indicates the leftmost and uppermost position.

### The Relationship between Display RAM Address and Display Position

< Table 6-8 >

TH		TH + CL
TH + TA		TH + TA + CL
(TH + TA) + TA		TH + 2TA + CL
(TH + 2TA) + TA		TH + 3TA + CL
:	:	:
:	:	:
:	:	:
:	:	:
TH + (n-1) TA		TH + (n-1) TA + CL

TH: Text home address

TA: Text area number (columns)

CL: Columns are fixed by hardware (pin-programmable).

### (Example)

Text Home Address : 0000h
Text Area : 0020h

MD2=H, MD3=H : 32 Columns

DUAL =H, MDS=L, MD0=L, MD1=H : 4 Lines



<	Та	bl	е	6-	.9	>
---	----	----	---	----	----	---

0000h	0001h	 001Eh	001Fh
0020h	0021h	 003Eh	002Fh
0040h	0041h	 005Eh	005Fh
0060h	0061h	 007Eh	007Fh

## 6-7-2 Set Graphic Home Address

The starting address of the external display RAM used for graphic display is defined by this Command. The graphic home address indicates the leftmost and uppermost position.

### The Relationship between External Display RAM Address and Display Position

< Table 6-10 >

GH		GH + CL
GH + GA		GH + GA + CL
(GH + GA) + GA		GH + 2GA + CL
(GH + 2GA) + GA		GH + 3GA + CL
:	:	:
:	:	:
:	:	:
:	:	:
GH + (n-1) GA		GH + (n-1) GA + CL

GH: Graphic Home Address

GA: Graphic Area Number (columns)

CL: Columns are fixed by hardware (pin-programmable).

### (Example)

Graphic Home Address : 0000h
Graphic Area : 0020h

MD2=H, MD3=H : 32 columns

DUAL =H, MDS=L, MD0=H, MD1=H : 2 lines



< 1	Га	h	le	6-1	1	<b> </b> >

0000h	0001h		001Eh	001Fh
0020h	0021h		003Eh	003Fh
0040h	0041h		005Eh	005Fh
0060h	0061h		007Eh	007Fh
0080h	0081h		009Eh	009Fh
00A0h	00A1h		00BEh	00BFh
00C0h	00C1h		00DEh	00DFh
00E0h	00E1h		00FEh	00FFh
0100h	0101h		011Eh	011Fh
0120h	0121h		013Eh	013Fh
0140h	0141h		015Eh	015Fh
0160h	0161h	*******	017Eh	017Fh
0180h	0181h	*******	019Eh	019Fh
01A0h	01A1h		01BEh	01BFh
01C0h	01C1h		01DEh	01DFh
01E0h	01E1h		01FEh	01FFh

#### 6-7-3 Set Text Area

The display columns are defined by the hardware setting. This command can be used adjust the columns of the display.

### (Example)

LCD Size : 20 columns, 4 lines

Text Home Address : 0000h

Text Area : 0014h

MD2=H, MD3=H : 32 columns

DUAL =H, MDS =L, MD0=L, MD1=H : 4 lines

### < Table 6-12 >

0000	0001	 0013	0014	 001F
0014	0015	 0027	0028	 0033
0028	0029	 003B	003C	 0047
003C	003D	 004F	0050	 005B



#### 6-7-4 Set Graphic Area

The display columns are defined by the hardware setting. This command can be used to adjust the columns of the graphic display.

### (Example)

LCD Size : 20 columns, 2 lines

Graphic Home Address : 0000h
Graphic Area : 0014h
MD2=H, MD3=H : 32 columns

DUAL =H, MDS=L MD0=H, MD1=H : 2 lines

#### < Table 6-13 >

0000	0001	 0013	0014	 001F
0014	0015	 0027	0028	 0033
0028	0029	 003B	003C	 0047
003C	003D	 004F	0050	 005B
0050	0051	 0063	0064	 006F
0064	0065	 0077	0078	 0083
0078	0079	 008B	008C	 0097
008C	008D	 009F	00A0	 00AB
00A0	00A1	 00B3	00B4	 00BF
00B4	00B5	 00C7	00C8	 00D3
00C8	00C9	 00DB	00DC	 00E7
00DC	00DD	 00EF	00F0	 00FD
00F0	00F1	 0103	0104	 011F
0104	0105	 0127	0128	 0123
0128	0129	 013B	013C	 0147
013C	013D	 014F	0150	 015B



If the graphic area setting is set to match the desired number of columns on the LCD, the addressing scheme will be automatically modified so that the start address of each line equals the end address of the previous line +1.



#### 6-8 Mode Set

#### < Table 6-14 >


Function	Operand
OR Mode	_
EXOR Mode	
AND Mode	
Text Attribute Mode	_
Internal Character Generator Mode	
External Character Generator Mode	_
	OR Mode  EXOR Mode  AND Mode  Text Attribute Mode  Internal Character Generator Mode

X: Invalid

The display mode is defined by this command. The display mode does not change until the next command is sent. The logical OR, EXOR, AND of text or graphic display can be displayed.

In internal Character Generator mode, character codes 00h to 7Fh are assigned to the built-in Character generator ROM. The character codes 80h to FFh are automatically assigned to the external character generator RAM.

(Example)



< Figure 6-7 >

Note: Attribute functions can only be applied to text display, since the attribute data is placed in the graphic RAM area.

#### **Attribute Function**

The attribute operations are Reverse display, Character blink, bold and Inhibit. The attribute data is written into the graphic area, which was defined by the Set Control word command. Only text display is possible in Attribute Function mode; graphic display is automatically disabled. However, the Display Mode command must be used to turn both Text and Graphic on that in order to for the Attribute function available.

The attribute data for each character in the text area is written to the same address in the graphic area.

The Attribute function is defined as follows.



Attribute I	RAM	1byte
-------------	-----	-------

X X X	Х	d3	d2	d1	d0
-------	---	----	----	----	----

X: Invalid

< Table 6-15 >


d3	d2	d1	d0	Function	
0	0	0	0	Normal Display	
0	1	0	1	Reverse Display	
0	0	1	1	Inhibit Display	
1	0	0	0	Blink of Normal Display	
1	1	0	1	Blink of Reverse Display	
1	0	1	1	Blink of Inhibit Display	
0	1	1	1	Bold Display	
1	1	1	1	Blink of Bold Display	

## 6-9 Display Mode

< Table 6-16 >

110000107					
Code	Function	Operand			
10010000	Display off	_			
1001XX10	Cursor on, Blink off	_			
1001XX11	Cursor on, Blink on	_			
100101XX	Text on, Graphic off	_			
100110XX	Text off, Graphic on	_			
100111XX	Text on, Graphic on	_			

X: Invalid



Note: It is necessary to turn on "Text Display" and "Graphic Display" in the following cases.

- a) Combination of text /graphic display
- b) Attribute function



#### 6-10 Cursor Pattern Select

< Table 6-17 >

Code	Function	Operand
10100000	1-line cursor	_
10100001	2-line cursor	_
10100010	3-line cursor	_
10100011	4-line cursor	_
10100100	5-line cursor	_
10100101	6-line cursor	_
10100110	7-line cursor	_
10100111	8-line cursor	_

When cursor display is ON, this command selects the cursor pattern in the range 1 line to 8 lines. The cursor address is defined by the Cursor pointer Set command.

#### 6-11 Data Auto Read/Write

< Table 6-18 >

Code	Hex.	Function	Operand
10110000	B0h	Set Data Auto Write	_
10110001	B1h	Set Data Auto Read	
10110010	B2h	Auto Reset	


This command is convenient for sending a full screen of data from the external display RAM. After Setting Auto mode, a Data Write (or Read) command does not need sent between each datum. A Data Auto Write (or Read) command must be sent after a Set Address Pointer command. After this Command, the address pointer is automatically incremented by 1 after each datum. In Auto mode, the RA6963 cannot accept any other commands.

The Auto Reset command must be sent to the RA6963 after all data has been sent, to clear Auto Mode.

Note: A Status Check for Auto Mode

STA2, STA3 should be checked between sending of each datum. Auto Reset should be performed after checking STA3=1 (STA2=1). Refer to the following flowchart.





< Figure 6-8 >



#### 6-12 Data Read/Write


< Table 6-19 >

Code	Hex.	Function	Operand
11000000	C0h	Data Write and Increment ADP	Data
11000001	C1h	Data Read and Increment ADP	_
11000010	C2h	Data Write and Decrement ADP	Data
11000011	C3h	Data Write and Decrement ADP	_
11000100	C4h	Data Write and Non-variable ADP	Data
11000101	C5h	Data Read and Non-variable ADP	_

This command is used for writing data from the MPU to external display RAM, and reading data from external display RAM. Data Write / Data Read should be executed after setting address using Set Address Pointer command, The address pointer can be automatically incremented or decremented using this command.

Note: This command is necessary for each 1-byte datum.

Refer to the following flowchart.



< Figure 6-9 >



#### 6-13 Screen Peek


< Table 6-20 >

Code	Hex.	Function	Operand
11100000	E0h	Screen Peek	_

This command is used to transfer 1 byte of displayed data to the data stack; this byte can be read from the MPU by data access. The logical combination of text and graphic display data on the LCD screen can be read by this command.

The status (STA6) should be checked just after the Screen Peek command. If the address Determined by the Set Address Pointer command is not in the graphic area, this command is ignored and a status flag (STA6) is set.

Refer to the following flowchart.



< Figure 6-10 >

Note: This command is available when hardware column number and software column number are the same. Hardware column number is related to MD2 and MD3 setting. Software column number is related to Set Text Area and Set Graphic Area command.



## 6-14 Screen Copy

< Table 6-21 >

Code	Hex.	Function	Operand
11101000	E8h	Screen Copy	_


This command copies a single raster line of data to the graphic area.

The start point must be set using the Set Address Pointer command.

Note 1: If the attribute function is being used, this command is not available. (With Attribute data is graphic area data.)

Note 2: With Dual-Scan, this command cannot be used (because the RA6963 cannot separate the upper screen data and lower screen data).

Refer to the following flowchart.



< Figure 6-11 >

Note: This command is available when hardware column number is the same. Hardware column number is related to MD2 and MD3 setting. Software column number is related to Set Text Area and Set Graphic Area command.

RAIO TECHNOLOGY INC. 30/46 www.raio.com.tw



### 6-15 Bit Set/Reset


< Table 6-22 >

Code	Function	Operand
11110XXX	Bit Reset	_
11111XXX	Bit Set	_
1111X000	Bit 0 (LSB)	_
1111X001	Bit 1	_
1111X010	Bit 2	_
1111X011	Bit 3	_
1111X100	Bit 4	_
1111X101	Bit 5	_
1111X110	Bit 6	_
1111X111	Bit 7 (MSB)	_

X: Invalid

This command used to set or reset a bit of the byte specified by the address pointer. Only one bit can be set / reset at time.

Refer to following flowchart.



< Figure 6-12 >



#### 6-16 Screen Reverse

#### <Table 6-23>

Code	Hex.	Function	D1	D2
11010000	D0h	Enable/Disable the whole screen reversing	Data	-

#### <Table 6-24>

Screen Reverse Selection (D1)

Bit7	Bit6	Bit5 Bit4 Bit3 B		Bit2	Bit1	Bit0	
Х	Х	Х	Х	Х	Х	Х	0/1

Bit0 = 0: Normally display.

Bit0 = 1: Reverse the whole screen.

This command (D0h) is used to reverse the displayed data of the whole screen. When this function is enabled, the displayed data on the LCD are reversed to show reversing pattern.

## 6-17 Blink Time

#### <Table 6-25>

Code	Hex.	Function	D1	D2
01010000	50h	Adjust the blink time for the blink functions of the RA6963	Data (Bit2~Bit0)	Do not care (Note)

Note: In this function, it must be sent two data before sending the command, but the contents of the second datum (D2) can be any values.

<Table 6-26>

Blink Time Selection (D1)

Bit 2	Bit 1	Bit 0	Blink Time(If f <sub>R</sub> =60Hz)					
0	0	0	0.066 sec.					
0	0	1	0.25 sec.					
0	1	0	0.5 sec.					
0	1	1	0.75 sec.					
1	0	0	1 sec.					
1	0	1	1.25 sec.					
1	1	0	1.5 sec.					
1	1	1	2 sec.					

The blink time of the blink functions are adjusted by this command (50h). For example, if the frequency of the frame equals 60Hz, the blink time can be adjusted from 0.066 second to 2 second by using software selections. The selections are listed in the Table 6-26.



## 6-18 Cursor Auto Moving

#### <Table 6-27>

Code	Hex.	Function	D1	D2
01100000	60h	Enable/Disable the automatic cursor movement	Data (Bit0)	Do not care (Note)

Note: In this function, it must be sent two data before sending the command, but the contents of the second datum (D2) can be any values.

#### <Table 6-28>

Cursor Auto Moving Selection (D1)

Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0					
Х	Х	Х	Х	Х	Х	Х	0/1					

Bit0 = 0: Disable. Bit0 = 1: Enable.

The RA6963 provides a unique function for the automatic cursor movement. After writing (reading) each displayed datum, the cursor pointer is automatically increased/decreased by one in the Cursor Auto-Moving mode.

## 6-19 CGROM Font Select

#### <Table 6-29>

Code	Hex.	Function	D1	D2
01110000	70h	Change the Character	Data	Do not care
01110000	7011	Font Map	(Bit1~Bit0)	(Note)

Note: In this function, it must be sent two data before sending the command, but the contents of the second datum (D2) can be any values.

<Table 6-30>

CGROM Font Selection (D1)

Bit 1	Bit 0	CGROM Font
0	0	Do not care(Default)
0	1	Do not care
1	0	CGROM Font-01.
1	1	CGROM Font-02.

This command (70h) is a convenient function for selecting the Character Font Map. The user can get more built-in characters from CGROM Font-01 or CGROM Font-02, which is determined by software selections. The selections are listed in the Table 6-30.



## 6-20 Character Font Map

## CGROM Font - 01 Α С D Е MSB 0 1 2 3 4 m 5 6 7

< Figure 6-13 >

CGF	CGROM Font – 02															
LSB MSB	0	1	2	3	4	5	6	7	8	9	А	В	С	D	Е	F
0					4				I.							
1					4											
2			B	-						I		K				
3	F		R													
4		語					7									
5							n								E	
6					ŀ										+	
7										Ш						

< Figure 6-14 >

The RA6963 has two part number - RA6963L2NA and RA6963L2NB. The RA6963L2NA is compatible to T6963C(code 0101) and the default font is Figure 6-13 as above. The RA6963L2NB is compatible to T6963C(code 0201) and the default font is Figure 6-14 as above.

Although RA6963 provide a extra internal command for MCU to select both font of above, but you do not need to change the software to select the font that if you chose the right part number.



## 6-21 RA6963 vs. T6963C


### < Table 6-31 >

Item	Description	RAiO RA6963	Toshiba T6963C	Note
1	CGROM Font Select	Yes		RA6963 provides two CGROMs – Font-01 and Font-02
2	Blink Time Selection	Yes		RA6963 provides eight selections for blinking.
3	Cursor Auto Move	Yes		
4	Whole Screen Reverse	Yes		
5	Bold Text and Blink	Yes		RA6963 provides Bold Text feature.
6	Package	LQFP- 67Pin	LQFP- 67Pin	



## 7. Package Dimensions

### 7-1 Die Form



< Figure 7-1 >

#### 7-2 Part Number:

RA6963L2NA: LQFP-67 Pin, RoHS Compliance Package, the default font is Font-01 RA6963L2NB: LQFP-67 Pin, RoHS Compliance Package, the default font is Font-02 (Refer to Chapter 6-20)



## 7-3 XY Coordinate


Pad No.	Pad 名稱	X 座標	Y座標
1	HALT	-1060.5	-964.65
2	RST	-959.5	-964.65
3	MDS	-858.5	-964.65
4	MD0	-757.5	-964.65
5	MD1	-656.5	-964.65
6	MD2	-555.5	-964.65
7	MD3	-454.5	-964.65
8	FS0	-353.5	-964.65
9	FS1	-252.5	-964.65
10	SD0	-151.5	-964.65
11	SD1	-50.5	-964.65
12	SD2	50.5	-964.65
13	SD3	151.5	-964.65
14	SD4	252.5	-964.65
15	SD5	353.5	-964.65
16	SD6	454.5	-964.65
17	SD7	555.5	-964.65
18	WR	656.5	-964.65
19	RD	757.5	-964.65
20	CE	858.5	-964.65
21	C/D	959.5	-964.65
22	D0	1320.4	-704.75
23	D1	1320.4	-603.75
24	D2	1320.4	-502.75
25	D3	1320.4	-401.75
26	D4	1320.4	-300.75
27	VDD	1320.4	-199.75
28	FONTSEL	1320.4	-98.75
29	GND	1320.4	10.25
30	D5	1320.4	115.25
31	D6	1320.4	216.25
32	D7	1320.4	317.25
33	MRW	1320.4	418.25
34	MCE	1320.4	519.25
35	A0	1060.5	964.65

Pad No.	Pad 名稱	X座標	Y座標
36	A1	959.5	964.65
37	A2	858.5	964.65
38	A3	757.5	964.65
39	A4	656.5	964.65
40	A5	555.5	964.65
41	A6	454.5	964.65
42	A7	353.5	964.65
43	A8	252.5	964.65
44	A9	151.5	964.65
45	A10	50.5	964.65
46	A11	-50.5	964.65
47	A12	-151.5	964.65
48	A13	-252.5	964.65
49	A14	-353.5	964.65
50	A15	-454.5	964.65
51	CE0	-555.5	964.65
52	CE1	-656.5	964.65
53	HOD	-757.5	964.65
54	ED	-858.5	964.65
55	HSCP	-959.5	964.65
56	DUAL	-1060.5	964.65
57	LP	-1320.4	591.45
58	CDATA	-1320.4	490.45
59	FR	-1320.4	389.45
60	CH1	-1320.4	288.45
61	CH2	-1320.4	187.45
62	DSPON	-1320.4	86.45
63	VDD	-1320.4	-14.55
64	SDSEL	-1320.4	-115.55
65	GND	-1320.4	-224.55
66	TEST2	-1320.4	-329.55
67	TEST1	-1320.4	-430.55
68	X1	-1320.4	-556.8
69	X2	-1320.4	-692.8




## 7-4 Outline Drawing

LQFP-67Pin



< Figure 7-2 >



< Figure 7-3 >



# 8. Specifications

## 8-1 Absolute Maximum Ratings

### < Table 8-1 >

Ta=25°C

Parameter	Symbol	Rating	Unit
Supply Voltage Range	V <sub>DD</sub> (Note 1)	-0.3 to +7.0	V
Input Voltage Range	V <sub>in</sub> (Note 1)	-0.3 to VDD +0.3	V
Operating Temperature Range	T <sub>op</sub>	-30 to +85	$^{\circ}$
Storage Temperature Range	$T_{stg}$	-55 to +125	$^{\circ}$
Solder Temperature Range	T <sub>sdt</sub> (Note 2)	400	$^{\circ}$ C

Note 1: Gnd = 0V.

Note 2: Solder Time = 8 Minutes.

#### < Table 8-2 >

( V\_DD=+5V / +3.3V±10%,GND=0V,Ta= -20 to +70 $^{\circ}\mathrm{C}$  )

ltem		Symbol	Test Conditions	Min.	Тур.	Max.	Unit	Pin Name
Operating Voltage	$V_{DD}$	$V_{DD}$		3.0		5.5	V	VDD
Innut	"H"	$V_{IH}$		$0.8V_{DD}$		$V_{DD}$	V	I/P
Input	"L"	$V_{IL}$		0		$0.2V_{DD}$	V	I/P
Output	"H"	$V_{OH}$		V <sub>DD</sub> -0.3		$V_{DD}$	V	O/P
Output	"L"	$V_{OL}$		0		0.3.	V	O/P
Output Posistance	"H"	$R_{OH}$	$V_{OUT}=V_{DD}-0.5$			400	Ω	O/P
Output Resistance	"L"	$R_{OL}$	V <sub>OUT</sub> =0.5			400	Ω	O/P
Current Consumption	Operating	I <sub>DD</sub> (1)	$V_{DD}$ =5.0V (Note 2) $f_{OSC}$ =4.0MHz		3.0	5	mA	VDD
Consumption	Halt	$I_{DD}(2)$	V <sub>DD</sub> =5.0V		1	2	μΑ	VDD
Input Pull Up Resistance		RPU		50	100	300	ΚΩ	(Note 1)
Operating Freq	uency	$f_{OSC}$		0.4	6/8		MHz	
Solder Temper	rature	$T_{SDT}$	(Note 3)		260		$^{\circ}\!\mathbb{C}$	


Note 1: Applied TEST[2:1], RST.

Note 2: MDS=L, MD[1:0]=LL, MD[3:2]=HH, FS[1:0]=LL,  $\overline{\text{SDSEL}}$ =L,  $\overline{\text{DUAL}}$ =H, D[7:0]=LHLHLHLH.

Note 3: Solder Time = 20~40 Seconds.



## 8-2 MPU Interface Timing




< Figure 8-1 >

< Table 8-3 >

(  $V_{DD}$ =+5V±5%,GND=0V,Ta= -20 to +70 $^{\circ}$ C )

Item	Symbol	Test Conditions	Min.	Max.	Unit
C/ D Set Up Time	t <sub>CDS</sub>		100		ns
C/ D Hold Time	t <sub>CDH</sub>		10		ns
CE, RD, WR Pulse Width	$t_{CE},t_{RD},t_{WR}$		80		ns
Data Set Up Time	t <sub>DS</sub>		80		ns
Data Hold Time	$t_DH$		40		ns
Access Time	t <sub>ACC</sub>			150	ns
Output Hold Time	t <sub>OH</sub>		10	50	ns

## 8-3 Driver Interface Timing



< Figure 8-2 >




< Table 8-4 >

(  $V_{DD}$ =+5V±5%,GND=0V,Ta= -20 to +70 $^{\circ}$ C )


Item	Symbol	Test Conditions	Min.	Max.	Unit
Operating Frequency	f <sub>SCP</sub>	Ta = -20~70°C		9	MHz
SCP Pulse Width	$t_{CWH}$ , $t_{CWL}$		150		ns
SCP Rise/Fall Time	t <sub>r</sub> ,t <sub>f</sub>			30	ns
LP Setup Time	t <sub>LSU</sub>		150	290	ns
LP Hold Time	t <sub>LHD</sub>		5	40	ns
Data Setup Time	t <sub>DSU</sub>		170		ns
Data Hold Time	t <sub>DHD</sub>		80		ns
FR Delay Time	t <sub>d</sub>		0	90	ns
CDATA Setup Time	t <sub>csu</sub>		450	850	ns
CDATA Hold Time	t <sub>CHD</sub>		450	950	ns

## **8-4 External Memory Interface**



< Figure 8-3 >





< Figure 8-4 >

< Table 8-5 >

(  $V_{DD}$ =+5V±5%,GND=0V,Ta= -20 to +70 $^{\circ}$ C )

Item	Symbol	Test Conditions	Min.	Max.	Unit
Address Delay Time	t <sub>d1</sub>	-		250	ns
MCE Fall Delay Time(Read)	t <sub>d2</sub>	1		180	ns
MCE Rise Delay Time(Read)	t <sub>d3</sub>	1		180	ns
Data Setup Time	t <sub>DS</sub>	1			ns
Data Hold Time	t <sub>DH</sub>	-			ns
MCE Fall Delay Time(Write)	t <sub>d4</sub>			200	ns
MCE Rise Delay Time(Write)	t <sub>d5</sub>	-		200	ns
MRW Fall Delay Time	t <sub>d6</sub>	1		180	ns
MRW Rise Delay Time	t <sub>d7</sub>	-		180	ns
Data Stable Time	t <sub>d8</sub>			450	ns
Data Hold Time	t <sub>d9</sub>			200	ns



# 9. Application


The RA6963 can be directly connected to Z80(Note 1) series MPU. The following applications are use a TMPZ84C00A to connect RA6963.

## 9-1 MPU Memory Address Mapping

Data is transferred to the RA6963 using a memory request signal.

< Table 9-1 >

	Address
DATA (I/O)	XXXXh
Command/Status	XXXX + 1h



< Figure 9-1 >

Note 1: Z80 is a trademark of Zilog Inc.




## 9-2 MPU I/O Addressing

Data is transferred to the RA6963 using an I/O request signal.

< Table 9-2 >

	I/O Address
DATA	XXh
Command / Status	XX + 1h



< Figure 9-2 >


## 9-3 Use PPI LSI

The RA6963 can be connected to a PPI LSI.

The port A connects to the data bus.

The port C connects to the control bus. (C/  $\overline{D}$  ,  $\overline{CE}$  ,  $\overline{WR}$  ,  $\overline{RD}$  )






< Figure 9-3 >

## 9-4 Application Block Diagram


All LCD require two power sources, VDD for logic circuits and VEE for Liquid Crystal (LC) drive. Some graphics LCD modules will run directly of a single VDD supply by generating the VEE voltage on-board; others will require an external DC-DC converter to generate the negative VEE voltage. Refer to individual specifications for details.



< Figure 9-4 >




## 9-5 Application Circuit(1)



< Figure 9-5 >

## 9-6 Application Circuit(2)



< Figure 9-6 >