CAN: Classic CAN



Description:

This example demonstrates transmission and reception on Classic CAN.

Target Device:

Traveo-II CYT2B6x devices

CPU Board:

- CYTVII-B-E-1M-176-CPU Rev. C Board
- CYTVII-B-E-BB Rev.A Board

CAN: Classic CAN



Dependency:


- CYTVII-B-E-1M-176-CPU board should be connected on CYTVII-B-E-BB board.
- Jumper J70 (RX line), J72 (TX line), J71 (if wakeup needed) and J69 (terminal resistor) should be closed on base board.
- CANoe should be installed on the system.

Expectation:

- Connect CANO connector (P6 upper one) on the base board and CANoe or other analyzer if available.
- If you have CANoe, launch CANFD_CFG.cfg in UseAsCANFDMode folder. It is configured simple test for this example.
 - Change the Type in CAN IG tab to CAN DATA (for standard ID) and Extended CAN DATA (for extended ID)
 - Just run and monitor using trace, statistics window.
- Check the transmission and reception behavior based on configuration below:
 - 4 message is sent from periodically. (100ms)
 - 2 standard IDs and 2 extended IDs.
 - All ID filters are configured as the clasical filter only following IDs are accepted by the MCU: STD: 0x010, 0x020 EXT: 0x10010. 0x10020
 - At the receive call back CAN_RxMsgCallback in the main.c, received message is sent back with received ID +1.

CAN: Classic CAN





Legend:

- Red block for power, debug and USB (Mandatory)
- Yellow block for the example specific connections