
## **Enraged Rabbit Project**

## **Carrot Warehouse assembly**





Remove print-in-place supports (use a plier)


## 4 Wheel and buffer assembly



4-b Insert the bowden insert




4-c Assemble the wheel axis



Clic the bottom end of the buffer cross

Clic the 3 other ends of the buffer cross using the latches Latch Latch Latch M5 Nylock nut

- 4-f
- Make sure the 4 ends of the buffer cross are well clicked-in (no gap)
- The wheel just spin easily



PTFE tubing: insert around 30cm of PTFE tube from the sliding arm to the bottom of buffer cross. Push it to the max on both ends.

8 Done!