NOTE: connections needed only to leftmost LED; daisy chain is within the LED Stick DIN DOUT WS2812B R? 220 to 300 Ohm A? Arduino_USB TX1 SW? SW_Push RX0 GND RST RST GND 5٧ D02 , A6 D03 D04 Α5 D05 DO6 Nano D07 Phys A2 D08 A1 HC-SR04 D09 A0 GND D10 REF D11 3٧3 Trig D12 D13 NOTE: Chips & Modules shown top view, notch at top Author: https://github.com/Mark-MDO47/ArduinoClass/tree/master Sheet: / File: 03_SonarRangeDetector.sch Title: 03 Sonar Range Detector Size: USLetter Date: 2023-04-18 Rev: KiCad E.D.A. kicad (5.1.5)-3 ld: 1/1