




FOOF Rubber Band Gun Operation




FOOF Rubber Band Gun State Machine and Factory Settings



FOOF Rubber Band Gun eSpeak and Sound Files



FOOF Rubber Band Gun Debug Tools



FOOF Rubber Band Gun Arduino Setup

- Board "Arduino Nano"
- Processor "ATmega328P (Old Bootloader)"
- Programmer "AVRISP mkll"

