XPLPro

Generated by Doxygen 1.9.6

1 XPLPro	1
2 Hierarchical Index	3
2.1 Class Hierarchy	3
3 Class Index	5
3.1 Class List	5
4 File Index	7
4.1 File List	7
5 Class Documentation	9
5.1 AnalogIn Class Reference	9
5.1.1 Detailed Description	9
5.1.2 Constructor & Destructor Documentation	10
5.1.2.1 AnalogIn() [1/2]	10
5.1.2.2 AnalogIn() [2/2]	10
5.1.3 Member Function Documentation	10
5.1.3.1 calibrate()	10
5.1.3.2 handle()	11
5.1.3.3 raw()	11
5.1.3.4 setRange()	11
5.1.3.5 setScale()	12
5.1.3.6 value()	12
5.2 Button Class Reference	12
5.2.1 Detailed Description	13
5.2.2 Member Enumeration Documentation	14
5.2.2.1 anonymous enum	14
5.2.3 Constructor & Destructor Documentation	14
5.2.3.1 Button() [1/2]	14
5.2.3.2 Button() [2/2]	14
5.2.4 Member Function Documentation	15
5.2.4.1 engaged()	15
5.2.4.2 getCommand()	15
5.2.4.3 handle() [1/2]	15
5.2.4.4 handle() [2/2]	15
5.2.4.5 handleXP() [1/2]	16
5.2.4.6 handleXP() [2/2]	16
5.2.4.7 pressed()	16
5.2.4.8 processCommand()	17
5.2.4.9 released()	17
5.2.4.10 setCommand() [1/2]	17
5.2.4.11 setCommand() [2/2]	17
5.2.5 Member Data Documentation	18

5.2.5.1 _cmdPush	. 18
5.2.5.2 _mux	. 18
5.2.5.3 _pin	. 18
5.2.5.4 _state	. 18
5.2.5.5 _transition	. 18
5.3 DigitalIn_ Class Reference	. 19
5.3.1 Detailed Description	. 19
5.3.2 Constructor & Destructor Documentation	. 19
5.3.2.1 Digitalln_()	. 19
5.3.3 Member Function Documentation	. 19
5.3.3.1 addMux()	. 19
5.3.3.2 getBit()	. 20
5.3.3.3 handle()	. 20
5.3.3.4 setMux()	. 20
5.4 Encoder Class Reference	. 21
5.4.1 Detailed Description	. 22
5.4.2 Constructor & Destructor Documentation	. 22
5.4.2.1 Encoder() [1/2]	. 22
5.4.2.2 Encoder() [2/2]	. 22
5.4.3 Member Function Documentation	. 23
5.4.3.1 down()	. 23
5.4.3.2 engaged()	. 23
5.4.3.3 getCommand()	. 23
5.4.3.4 handle()	. 24
5.4.3.5 handleXP()	. 24
5.4.3.6 pos()	. 24
5.4.3.7 pressed()	. 24
5.4.3.8 processCommand()	. 25
5.4.3.9 released()	. 25
5.4.3.10 setCommand() [1/4]	. 25
5.4.3.11 setCommand() [2/4]	. 25
5.4.3.12 setCommand() [3/4]	. 26
5.4.3.13 setCommand() [4/4]	. 26
5.4.3.14 up()	. 26
5.5 LedShift Class Reference	. 27
5.5.1 Detailed Description	. 27
5.5.2 Constructor & Destructor Documentation	. 27
5.5.2.1 LedShift()	. 27
5.5.3 Member Function Documentation	. 28
5.5.3.1 handle()	. 28
5.5.3.2 set()	. 28
5.5.3.3 set_all()	. 28

5.5.3.4 setAll()	28
5.5.3.5 setPin()	29
5.6 RepeatButton Class Reference	29
5.6.1 Detailed Description	31
5.6.2 Constructor & Destructor Documentation	31
5.6.2.1 RepeatButton() [1/2]	31
5.6.2.2 RepeatButton() [2/2]	31
5.6.3 Member Function Documentation	32
5.6.3.1 handle() [1/2]	32
5.6.3.2 handle() [2/2]	32
5.6.3.3 handleXP() [1/2]	32
5.6.3.4 handleXP() [2/2]	32
5.6.4 Member Data Documentation	33
5.6.4.1 _delay	33
5.6.4.2 _timer	33
5.7 ShiftOut Class Reference	33
5.7.1 Detailed Description	34
5.7.2 Constructor & Destructor Documentation	34
5.7.2.1 ShiftOut()	34
5.7.3 Member Function Documentation	34
5.7.3.1 handle()	34
5.7.3.2 setAll()	34
5.7.3.3 setPin()	35
5.8 Switch Class Reference	35
5.8.1 Detailed Description	36
5.8.2 Constructor & Destructor Documentation	36
5.8.2.1 Switch() [1/2]	36
5.8.2.2 Switch() [2/2]	36
5.8.3 Member Function Documentation	37
5.8.3.1 getCommand()	37
5.8.3.2 handle()	37
5.8.3.3 handleXP()	37
5.8.3.4 off()	38
5.8.3.5 on()	38
5.8.3.6 processCommand()	38
5.8.3.7 setCommand() [1/4]	38
5.8.3.8 setCommand() [2/4]	39
5.8.3.9 setCommand() [3/4]	39
5.8.3.10 setCommand() [4/4]	39
5.8.3.11 value()	40
5.9 Switch2 Class Reference	40
5.9.1 Detailed Description	41

5.9.2 Constructor & Destructor Documentation	41
5.9.2.1 Switch2() [1/2]	41
5.9.2.2 Switch2() [2/2]	42
5.9.3 Member Function Documentation	42
5.9.3.1 getCommand()	42
5.9.3.2 handle()	42
5.9.3.3 handleXP()	42
5.9.3.4 off()	43
5.9.3.5 on1()	43
5.9.3.6 on2()	43
5.9.3.7 processCommand()	43
5.9.3.8 setCommand() [1/4]	43
5.9.3.9 setCommand() [2/4]	44
5.9.3.10 setCommand() [3/4]	44
5.9.3.11 setCommand() [4/4]	45
5.9.3.12 value()	45
5.10 Timer Class Reference	45
5.10.1 Detailed Description	46
5.10.2 Constructor & Destructor Documentation	46
5.10.2.1 Timer()	46
5.10.3 Member Function Documentation	46
5.10.3.1 count()	46
5.10.3.2 elapsed()	47
5.10.3.3 getTime()	47
5.10.3.4 setCycle()	47
5.11 XPLPro Class Reference	48
5.11.1 Detailed Description	49
5.11.2 Constructor & Destructor Documentation	49
5.11.2.1 XPLPro()	49
5.11.3 Member Function Documentation	49
5.11.3.1 begin()	49
5.11.3.2 commandEnd()	50
5.11.3.3 commandStart()	50
5.11.3.4 commandTrigger() [1/2]	51
5.11.3.5 commandTrigger() [2/2]	51
5.11.3.6 connectionStatus()	51
5.11.3.7 datarefReadElement()	52
5.11.3.8 datarefReadFloat()	52
5.11.3.9 datarefReadInt()	52
5.11.3.10 datarefWrite() [1/6]	52
5.11.3.11 datarefWrite() [2/6]	53
5.11.3.12 datarefWrite() [3/6]	53

87

5.11.3.13 datarefWrite() [4/6]	 . 53
5.11.3.14 datarefWrite() [5/6]	 . 54
5.11.3.15 datarefWrite() [6/6]	 . 54
5.11.3.16 registerCommand()	 . 55
5.11.3.17 registerDataRef()	 . 55
5.11.3.18 requestUpdates() [1/2]	 . 55
5.11.3.19 requestUpdates() [2/2]	 . 56
5.11.3.20 sendDebugMessage()	 . 56
5.11.3.21 sendResetRequest()	 . 56
5.11.3.22 sendSpeakMessage()	 . 57
5.11.3.23 setScaling()	 . 57
5.11.3.24 xloop()	 . 57
C File Decompositation	50
6 File Documentation	59
6.1 Direct inputs/main.cpp	
6.2 MUX inputs/main.cpp	
6.4 Button.h	
6.5 DigitalIn.h	
6.6 Encoder.h	
6.7 LedShift.h	
6.8 ShiftOut.h	
6.9 Switch.h	
6.10 Timer.h	
6.11 XPLPro.h	
6.12 AnalogIn.cpp	
6.13 Button.cpp	
6.14 DigitalIn.cpp	
6.15 Encoder.cpp	
6.16 LedShift.cpp	
6.17 ShiftOut.cpp	
6.18 Switch.cpp	
6.19 Timer.cpp	
6.20 XPLPro.cpp	 . 79

Index

Chapter 1

XPLPro

2 XPLPro

Chapter 2

Hierarchical Index

2.1 Class Hierarchy

This inheritance list is sorted roughly, but not completely, alphabetically:

AnalogIn													 									9
Button					 								 									12
RepeatButto	n																					 29
DigitalIn																						
Encoder					 								 									21
LedShift																						
ShiftOut					 								 									33
Switch					 								 									35
Switch2					 								 									40
Timer													 									45
XPLPro													 									48

4 Hierarchical Index

Chapter 3

Class Index

3.1 Class List

Here are the classes, structs, unions and interfaces with brief descriptions:

Analogin		
	Class to encapsulate analog inputs	9
Button		
	Class for a simple pushbutton with debouncing and XPLDirect command handling. Supports start and end of commands so XPlane can show the current Button status	12
DigitalIn		
0 -	Class to encapsulate digital inputs from 74HC4067 and MCP23017 input multiplexers, used by all digital input devices. Scans all expander inputs into internal process data image	19
Encoder		
	Class for rotary encoders with optional push functionality. The number of counts per mechanical notch can be configured for the triggering of up/down events	21
LedShift		
	Class to encapsulate a DM13A LED driver IC	27
RepeatB	utton	
·	Class for a simple pushbutton with debouncing and XPLDirect command handling, supports start and end of commands so XPlane can show the current Button status. When button is held down	
	cyclic new pressed events are generated for auto repeat function	29
ShiftOut		
	Class to encapsulate a DM13A LED driver IC	33
Switch	·	
	Class for a simple on/off switch with debouncing and XPLDirect command handling	35
Switch2		
	Class for an on/off/on switch with debouncing and XPLDirect command handling	40
Timer		
	Priovide a simple software driven timer for general purpose use	45
XPLPro		48

6 Class Index

Chapter 4

File Index

4.1 File List

Here is a list of all documented files with brief descriptions:

Direct inputs/main.cpp	59
MUX inputs/main.cpp	60
AnalogIn.h	60
Button.h	61
DigitalIn.h	62
Encoder.h	63
LedShift.h	64
ShiftOut.h	64
Switch.h	64
Timer.h	66
XPLPro.h	66
The state of the s	68
	70
DigitalIn.cpp	71
and the second s	73
2000	74
	75
	76
	79
XPLPro.cpp	79

8 File Index

Chapter 5

Class Documentation

5.1 Analogin Class Reference

Class to encapsulate analog inputs.

```
#include <AnalogIn.h>
```

Public Member Functions

• AnalogIn (uint8_t pin, Analog_t type)

Setup analog input.

• AnalogIn (uint8_t pin, Analog_t type, float timeConst)

Setup analog input with low pass filter.

• void handle ()

Read analog input, scale value and perform filtering, call once per sample loop.

• float value ()

Return actual value.

• int raw ()

Return raw value.

• void calibrate ()

Perform calibration for bipolar input, current position gets center and min/max ranges are adapted to cover +/- scale. Usage is only sensible for small deviations like for joysticks.

void setRange (uint16_t min, uint16_t max)

Set subrange for mechanically limited potentiometers and limit output value to this range. for bipolar applications the offset is set to the center value of this range.

void setScale (float scale)

Set output scale for max input range. Default scale is 1.0.

5.1.1 Detailed Description

Class to encapsulate analog inputs.

Definition at line 14 of file AnalogIn.h.

5.1.2 Constructor & Destructor Documentation

5.1.2.1 Analogin() [1/2]

Setup analog input.

Parameters

pin	Arduino pin number to use
type	unipolar (0scale) or bipolar (-scalescale) range.

Definition at line 6 of file AnalogIn.cpp.

5.1.2.2 Analogin() [2/2]

Setup analog input with low pass filter.

Parameters

pin	Arduino pin number to use
type	unipolar (01) or bipolar (-11)
timeConst	Filter time constant (t_filter/t_sample)

Definition at line 26 of file AnalogIn.cpp.

5.1.3 Member Function Documentation

5.1.3.1 calibrate()

```
void AnalogIn::calibrate ( )
```

Perform calibration for bipolar input, current position gets center and min/max ranges are adapted to cover +/- scale. Usage is only sensible for small deviations like for joysticks.

Definition at line 45 of file AnalogIn.cpp.

5.1.3.2 handle()

```
void AnalogIn::handle ( )
```

Read analog input, scale value and perform filtering, call once per sample loop.

Definition at line 34 of file AnalogIn.cpp.

5.1.3.3 raw()

```
int AnalogIn::raw ( )
```

Return raw value.

Returns

Read raw analog input and compensate bipolta offset

Definition at line 40 of file AnalogIn.cpp.

5.1.3.4 setRange()

Set subrange for mechanically limited potentiometers and limit output value to this range. for bipolar applications the offset is set to the center value of this range.

Parameters

min	Minimum value in raw digits (maps to Zero)	
max	Maximum value in raw digits (maps to Scale)	

Definition at line 60 of file AnalogIn.cpp.

5.1.3.5 setScale()

Set output scale for max input range. Default scale is 1.0.

Parameters

scale Scale of output value for maximum range

Definition at line 80 of file AnalogIn.cpp.

5.1.3.6 value()

```
float AnalogIn::value ( ) [inline]
```

Return actual value.

Returns

Actual, filtered value as captured with handle()

Definition at line 33 of file AnalogIn.h.

The documentation for this class was generated from the following files:

- · AnalogIn.h
- · AnalogIn.cpp

5.2 Button Class Reference

Class for a simple pushbutton with debouncing and XPLDirect command handling. Supports start and end of commands so XPlane can show the current Button status.

```
#include <Button.h>
```

5.2 Button Class Reference 13

Public Member Functions

• Button (uint8_t mux, uint8_t muxpin)

Constructor, set mux and pin number.

• Button (uint8_t pin)

Constructor, set digital input without mux.

• void handle ()

Handle realtime. Read input and evaluate any transitions.

• void handle (bool input)

Handle realtime. Read input and evaluate any transitions.

• void handleXP ()

Handle realtime and process XPLDirect commands.

void handleXP (bool input)

Handle realtime and process XPLDirect commands.

• bool pressed ()

Evaluate and reset transition if button pressed down.

• bool released ()

Evaluate and reset transition if button released.

• bool engaged ()

Evaluate status of Button.

void setCommand (int cmdPush)

Set XPLDirect command for Button events.

void setCommand (XPString_t *cmdNamePush)

Set XPLDirect command for Button events.

• int getCommand ()

Get XPLDirect command associated with Button.

void processCommand ()

Process all transitions and active transitions to XPLDirect

Protected Types

enum { transNone , transPressed , transReleased }

Protected Attributes

- uint8_t _mux
- uint8_t _pin
- uint8_t _state
- · uint8_t _transition
- · int _cmdPush

5.2.1 Detailed Description

Class for a simple pushbutton with debouncing and XPLDirect command handling. Supports start and end of commands so XPlane can show the current Button status.

Definition at line 8 of file Button.h.

5.2.2 Member Enumeration Documentation

5.2.2.1 anonymous enum

```
anonymous enum [protected]
```

Definition at line 65 of file Button.h.

5.2.3 Constructor & Destructor Documentation

5.2.3.1 Button() [1/2]

Constructor, set mux and pin number.

Parameters

mux	mux number (from DigitalIn initialization order)
muxpin	pin on the mux (0-15)

Definition at line 8 of file Button.cpp.

5.2.3.2 Button() [2/2]

Constructor, set digital input without mux.

Parameters

pin	Arduino pin number

Definition at line 21 of file Button.h.

5.2 Button Class Reference 15

5.2.4 Member Function Documentation

5.2.4.1 engaged()

```
bool Button::engaged ( ) [inline]
```

Evaluate status of **Button**.

Returns

true: Button is currently held down

Definition at line 47 of file Button.h.

5.2.4.2 getCommand()

```
int Button::getCommand ( ) [inline]
```

Get XPLDirect command associated with Button.

Returns

Handle of the command

Definition at line 59 of file Button.h.

5.2.4.3 handle() [1/2]

```
void Button::handle ( ) [inline]
```

Handle realtime. Read input and evaluate any transitions.

Definition at line 24 of file Button.h.

5.2.4.4 handle() [2/2]

```
void Button::handle (
          bool input ) [inline]
```

Handle realtime. Read input and evaluate any transitions.

Parameters

input Additional mask bit. AND connected with physical input.

Definition at line 28 of file Button.h.

5.2.4.5 handleXP() [1/2]

```
void Button::handleXP ( ) [inline]
```

Handle realtime and process XPLDirect commands.

Definition at line 31 of file Button.h.

5.2.4.6 handleXP() [2/2]

```
void Button::handleXP (
          bool input ) [inline]
```

Handle realtime and process XPLDirect commands.

Parameters

input Additional mask bit. AND tied with physical input.

Definition at line 35 of file Button.h.

5.2.4.7 pressed()

```
bool Button::pressed ( ) [inline]
```

Evaluate and reset transition if button pressed down.

Returns

true: Button was pressed. Transition detected.

Definition at line 39 of file Button.h.

5.2 Button Class Reference 17

5.2.4.8 processCommand()

```
void Button::processCommand ( )
```

Process all transitions and active transitions to XPLDirect

Definition at line 50 of file Button.cpp.

5.2.4.9 released()

```
bool Button::released ( ) [inline]
```

Evaluate and reset transition if button released.

Returns

true: Button was released. Transition detected.

Definition at line 43 of file Button.h.

5.2.4.10 setCommand() [1/2]

Set XPLDirect command for Button events.

Parameters

cmdPush | Command handle as returned by XP.registerCommand()

Definition at line 40 of file Button.cpp.

5.2.4.11 setCommand() [2/2]

Set XPLDirect command for Button events.

Parameters

cmdNamePush | Command name to register

Definition at line 45 of file Button.cpp.

5.2.5 Member Data Documentation

5.2.5.1 _cmdPush

```
int Button::_cmdPush [protected]
```

Definition at line 75 of file Button.h.

5.2.5.2 _mux

```
uint8_t Button::_mux [protected]
```

Definition at line 71 of file Button.h.

5.2.5.3 _pin

```
uint8_t Button::_pin [protected]
```

Definition at line 72 of file Button.h.

5.2.5.4 _state

```
uint8_t Button::_state [protected]
```

Definition at line 73 of file Button.h.

5.2.5.5 _transition

```
uint8_t Button::_transition [protected]
```

Definition at line 74 of file Button.h.

The documentation for this class was generated from the following files:

- Button.h
- Button.cpp

5.3 Digitalin_ Class Reference

Class to encapsulate digital inputs from 74HC4067 and MCP23017 input multiplexers, used by all digital input devices. Scans all expander inputs into internal process data image.

```
#include <DigitalIn.h>
```

Public Member Functions

• DigitalIn_()

Class constructor.

void setMux (uint8_t s0, uint8_t s1, uint8_t s2, uint8_t s3)

Set adress pins for 74HC4067 multiplexers. All mux share the same adress pins.

bool addMux (uint8_t pin)

Add one 74HC4067 multiplexer.

bool getBit (uint8_t expander, uint8_t channel)

Get one bit from the mux or a digital input.

• void handle ()

Read all mux inputs into process data input image.

5.3.1 Detailed Description

Class to encapsulate digital inputs from 74HC4067 and MCP23017 input multiplexers, used by all digital input devices. Scans all expander inputs into internal process data image.

Definition at line 24 of file DigitalIn.h.

5.3.2 Constructor & Destructor Documentation

5.3.2.1 Digitalln_()

```
DigitalIn_::DigitalIn_ ( )
```

Class constructor.

Definition at line 6 of file DigitalIn.cpp.

5.3.3 Member Function Documentation

5.3.3.1 addMux()

Add one 74HC4067 multiplexer.

Parameters

```
pin Data pin the multiplexer is connected to
```

Returns

true when successful, false when all expanders have been used up (increase MUX_MAX_NUMBER)

Definition at line 43 of file DigitalIn.cpp.

5.3.3.2 getBit()

Get one bit from the mux or a digital input.

Parameters

expander	Expander (mux or mcp) to read from. Use NOT_USED to access directly ardunio digital input	
channel Channel (0-15) on the mux or Arduino pin when mux = NOT_USED		

Returns

Status of the input (inverted, true = GND, false = +5V)

Definition at line 78 of file DigitalIn.cpp.

5.3.3.3 handle()

```
void DigitalIn_::handle ( )
```

Read all mux inputs into process data input image.

Definition at line 92 of file DigitalIn.cpp.

5.3.3.4 setMux()

Set adress pins for 74HC4067 multiplexers. All mux share the same adress pins.

Parameters

s0	Adress pin s0
s1	Adress pin s1
s2	Adress pin s2
s3	Adress pin s3

Definition at line 20 of file DigitalIn.cpp.

The documentation for this class was generated from the following files:

- · DigitalIn.h
- · DigitalIn.cpp

5.4 Encoder Class Reference

Class for rotary encoders with optional push functionality. The number of counts per mechanical notch can be configured for the triggering of up/down events.

```
#include <Encoder.h>
```

Public Member Functions

Encoder (uint8_t mux, uint8_t pin1, uint8_t pin2, uint8_t pin3, EncPulse_t pulses)

Constructor. Sets connected pins and number of counts per notch.

• Encoder (uint8_t pin1, uint8_t pin2, uint8_t pin3, EncPulse_t pulses)

Constructor. Sets connected pins and number of counts per notch.

void handle ()

Handle realtime. Read input and evaluate any transitions.

void handleXP ()

Handle realtime and process XPLDirect commands.

• int16 t pos ()

Read current Encoder count.

bool up ()

Evaluate Encoder up one notch (positive turn) and consume event.

• bool down ()

Evaluate Encoder up down notch (negative turn) and consume event.

• bool pressed ()

Evaluate and reset transition if Encoder pressed down.

· bool released ()

Evaluate and reset transition if Encoder released.

· bool engaged ()

Evaluate status of Encoder push function.

void setCommand (int cmdUp, int cmdDown, int cmdPush)

Set XPLDirect commands for Encoder events.

• void setCommand (XPString_t *cmdNameUp, XPString_t *cmdNameDown, XPString_t *cmdNamePush)

Set XPLDirect commands for Encoder events.

void setCommand (int cmdUp, int cmdDown)

Set XPLDirect commands for Encoder events without push function.

void setCommand (XPString_t *cmdNameUp, XPString_t *cmdNameDown)

Set XPLDirect commands for Encoder events.

int getCommand (EncCmd_t cmd)

Get XPLDirect command assiciated with the selected event.

void processCommand ()

Check for Encoder events and process XPLDirect commands as appropriate.

5.4.1 Detailed Description

Class for rotary encoders with optional push functionality. The number of counts per mechanical notch can be configured for the triggering of up/down events.

Definition at line 22 of file Encoder.h.

5.4.2 Constructor & Destructor Documentation

5.4.2.1 Encoder() [1/2]

Constructor. Sets connected pins and number of counts per notch.

Parameters

mux	mux number (from DigitalIn initialization order)
pin1 pin for Encoder A track	
pin2	pin for Encoder B track
pin3	pin for encoder push function (NOT_USED if not connected)
pulses Number of counts per mechanical notch	

Definition at line 8 of file Encoder.cpp.

5.4.2.2 Encoder() [2/2]

```
Encoder::Encoder (
          uint8_t pin1,
          uint8_t pin2,
          uint8_t pin3,
          EncPulse_t pulses ) [inline]
```

Constructor. Sets connected pins and number of counts per notch.

Parameters

pin1	pin for Encoder A track
pin2	pin for Encoder B track
pin3	pin for encoder push function (NOT_USED if not connected)
pulses Number of counts per mechanical notch	

Definition at line 38 of file Encoder.h.

5.4.3 Member Function Documentation

5.4.3.1 down()

```
bool Encoder::down ( ) [inline]
```

Evaluate Encoder up down notch (negative turn) and consume event.

Returns

true: up event available and transition reset.

Definition at line 56 of file Encoder.h.

5.4.3.2 engaged()

```
bool Encoder::engaged ( ) [inline]
```

Evaluate status of Encoder push function.

Returns

true: Button is currently held down

Definition at line 68 of file Encoder.h.

5.4.3.3 getCommand()

Get XPLDirect command assiciated with the selected event.

Parameters

cmd Event to read out (encCmdUp, encCmdDown, encCmdPush)

Returns

Handle of the command, -1 = no command

Definition at line 103 of file Encoder.cpp.

5.4.3.4 handle()

```
void Encoder::handle ( )
```

Handle realtime. Read input and evaluate any transitions.

Definition at line 32 of file Encoder.cpp.

5.4.3.5 handleXP()

```
void Encoder::handleXP ( ) [inline]
```

Handle realtime and process XPLDirect commands.

Definition at line 44 of file Encoder.h.

5.4.3.6 pos()

```
int16_t Encoder::pos ( ) [inline]
```

Read current Encoder count.

Returns

Remaining Encoder count.

Definition at line 48 of file Encoder.h.

5.4.3.7 pressed()

```
bool Encoder::pressed ( ) [inline]
```

Evaluate and reset transition if Encoder pressed down.

Returns

true: Button was pressed. Transition detected and reset.

Definition at line 60 of file Encoder.h.

5.4.3.8 processCommand()

```
void Encoder::processCommand ( )
```

Check for Encoder events and process XPLDirect commands as appropriate.

Definition at line 122 of file Encoder.cpp.

5.4.3.9 released()

```
bool Encoder::released ( ) [inline]
```

Evaluate and reset transition if Encoder released.

Returns

true: Button was released. Transition detected and reset.

Definition at line 64 of file Encoder.h.

5.4.3.10 setCommand() [1/4]

Set XPLDirect commands for Encoder events without push function.

Parameters

cmdUp	Command handle for positive turn as returned by XP.registerCommand()
cmdDown	Command handle for negative turn as returned by XP.registerCommand()

Definition at line 89 of file Encoder.cpp.

5.4.3.11 setCommand() [2/4]

Set XPLDirect commands for Encoder events.

Parameters

	cmdUp	Command handle for positive turn as returned by XP.registerCommand()
cmdDown Command handle for negative turn as returned by XI		Command handle for negative turn as returned by XP.registerCommand()
	cmdPush	Command handle for push as returned by XP.registerCommand()

Definition at line 75 of file Encoder.cpp.

5.4.3.12 setCommand() [3/4]

Set XPLDirect commands for Encoder events.

Parameters

cmdNameUp	Command for positive turn
cmdNameDown	Command for negative turn

Definition at line 96 of file Encoder.cpp.

5.4.3.13 setCommand() [4/4]

Set XPLDirect commands for Encoder events.

Parameters

cmdNameUp	Command for positive turn
cmdNameDown	Command for negative turn
cmdNamePush	Command for push

Definition at line 82 of file Encoder.cpp.

5.4.3.14 up()

```
bool Encoder::up ( ) [inline]
```

Evaluate Encoder up one notch (positive turn) and consume event.

Returns

true: up event available and transition reset.

Definition at line 52 of file Encoder.h.

The documentation for this class was generated from the following files:

- · Encoder.h
- · Encoder.cpp

5.5 LedShift Class Reference

Class to encapsulate a DM13A LED driver IC.

```
#include <LedShift.h>
```

Public Member Functions

```
• LedShift (uint8_t pin_DAI, uint8_t pin_DCK, uint8_t pin_LAT, uint8_t pins=16)

Constructor, setup DM13A LED driver and set pins.
```

void setPin (uint8_t pin, led_t mode)

Set one LED to a display mode.

- void set (uint8_t pin, led_t mode)
- void setAll (led_t mode)

Set display mode for all LEDs.

- void set_all (led_t mode)
- void handle ()

Real time handling, call cyclic in loop()

5.5.1 Detailed Description

Class to encapsulate a DM13A LED driver IC.

Definition at line 21 of file LedShift.h.

5.5.2 Constructor & Destructor Documentation

5.5.2.1 LedShift()

Constructor, setup DM13A LED driver and set pins.

Parameters

pin_DAI	DAI pin of DM13A
pin_DCK	DCL pin of DM13A
pin_LAT LAT pin of DM13A	
pins	Number of LED pins for cascaded LED drivers (max 64)

Definition at line 5 of file LedShift.cpp.

5.5.3 Member Function Documentation

5.5.3.1 handle()

```
void LedShift::handle ( )
```

Real time handling, call cyclic in loop()

Definition at line 72 of file LedShift.cpp.

5.5.3.2 set()

```
void LedShift::set (
          uint8_t pin,
          led_t mode ) [inline]
```

Definition at line 35 of file LedShift.h.

5.5.3.3 set_all()

Definition at line 40 of file LedShift.h.

5.5.3.4 setAII()

Set display mode for all LEDs.

Parameters

ſ	mode	LED display mode (ledOff, ledFast, ledMedium, ledSlow, ledOn)	1
---	------	---	---

Definition at line 63 of file LedShift.cpp.

5.5.3.5 setPin()

Set one LED to a display mode.

Parameters

pin	DM13A pin of the LED (0-64)
mode	LED display mode (ledOff, ledFast, ledMedium, ledSlow, ledOn)

Definition at line 51 of file LedShift.cpp.

The documentation for this class was generated from the following files:

- · LedShift.h
- LedShift.cpp

5.6 RepeatButton Class Reference

Class for a simple pushbutton with debouncing and XPLDirect command handling, supports start and end of commands so XPlane can show the current Button status. When button is held down cyclic new pressed events are generated for auto repeat function.

```
#include <Button.h>
```

Public Member Functions

• RepeatButton (uint8_t mux, uint8_t muxpin, uint32_t delay)

Constructor, set mux and pin number.

RepeatButton (uint8_t pin, uint32_t delay)

Constructor, set digital input without mux.

• void handle ()

Handle realtime. Read input and evaluate any transitions.

• void handle (bool input)

Handle realtime. Read input and evaluate any transitions.

• void handleXP ()

Handle realtime and process XPLDirect commands.

void handleXP (bool input)

Handle realtime and process XPLDirect commands.

Public Member Functions inherited from Button

• Button (uint8_t mux, uint8_t muxpin)

Constructor, set mux and pin number.

• Button (uint8_t pin)

Constructor, set digital input without mux.

• void handle ()

Handle realtime. Read input and evaluate any transitions.

· void handle (bool input)

Handle realtime. Read input and evaluate any transitions.

• void handleXP ()

Handle realtime and process XPLDirect commands.

void handleXP (bool input)

Handle realtime and process XPLDirect commands.

• bool pressed ()

Evaluate and reset transition if button pressed down.

• bool released ()

Evaluate and reset transition if button released.

• bool engaged ()

Evaluate status of Button.

void setCommand (int cmdPush)

Set XPLDirect command for Button events.

void setCommand (XPString_t *cmdNamePush)

Set XPLDirect command for Button events.

• int getCommand ()

Get XPLDirect command associated with Button.

void processCommand ()

Process all transitions and active transitions to XPLDirect

Protected Attributes

- · uint32_t _delay
- uint32 t timer

Protected Attributes inherited from Button

- uint8_t _mux
- uint8_t _pin
- uint8_t _state
- uint8_t _transition
- int _cmdPush

Additional Inherited Members

Protected Types inherited from Button

enum { transNone , transPressed , transReleased }

5.6.1 Detailed Description

Class for a simple pushbutton with debouncing and XPLDirect command handling, supports start and end of commands so XPlane can show the current Button status. When button is held down cyclic new pressed events are generated for auto repeat function.

Definition at line 81 of file Button.h.

5.6.2 Constructor & Destructor Documentation

5.6.2.1 RepeatButton() [1/2]

```
RepeatButton::RepeatButton (
uint8_t mux,
uint8_t muxpin,
uint32_t delay )
```

Constructor, set mux and pin number.

Parameters

mux	mux number (from initialization order)
muxpin	pin on the mux (0-15)
delay	Cyclic delay for repeat function

Definition at line 62 of file Button.cpp.

5.6.2.2 RepeatButton() [2/2]

Constructor, set digital input without mux.

Parameters

pin	Arduino pin number
delay	Cyclic delay for repeat function

Definition at line 96 of file Button.h.

5.6.3 Member Function Documentation

5.6.3.1 handle() [1/2]

```
void RepeatButton::handle ( ) [inline]
```

Handle realtime. Read input and evaluate any transitions.

Definition at line 99 of file Button.h.

5.6.3.2 handle() [2/2]

```
void RepeatButton::handle (
          bool input ) [inline]
```

Handle realtime. Read input and evaluate any transitions.

Parameters

input Additional mask bit. AND connected with physical input.

Definition at line 103 of file Button.h.

5.6.3.3 handleXP() [1/2]

```
void RepeatButton::handleXP ( ) [inline]
```

Handle realtime and process XPLDirect commands.

Definition at line 106 of file Button.h.

5.6.3.4 handleXP() [2/2]

```
void RepeatButton::handleXP (
          bool input ) [inline]
```

Handle realtime and process XPLDirect commands.

Parameters

input Additional mask bit. AND tied with physical input.

Definition at line 110 of file Button.h.

5.6.4 Member Data Documentation

5.6.4.1 _delay

```
uint32_t RepeatButton::_delay [protected]
```

Definition at line 113 of file Button.h.

5.6.4.2 _timer

```
uint32_t RepeatButton::_timer [protected]
```

Definition at line 114 of file Button.h.

The documentation for this class was generated from the following files:

- Button.h
- · Button.cpp

5.7 ShiftOut Class Reference

Class to encapsulate a DM13A LED driver IC.

```
#include <ShiftOut.h>
```

Public Member Functions

- ShiftOut (uint8_t pin_DAI, uint8_t pin_DCK, uint8_t pin_LAT, uint8_t pins=16)
 Constructor, setup shift register and set pins.
- void setPin (uint8_t pin, bool state)

Set one outpot to a display mode.

• void setAll (bool state)

Set state for all outputs.

• void handle ()

Real time handling, call cyclic in loop()

5.7.1 Detailed Description

Class to encapsulate a DM13A LED driver IC.

Definition at line 6 of file ShiftOut.h.

5.7.2 Constructor & Destructor Documentation

5.7.2.1 ShiftOut()

Constructor, setup shift register and set pins.

Parameters

pin_DAI	DAI pin (data)
pin_DCK	DCL pin (clock)
pin_LAT	LAT pin (latch)
pins	Number of pins for cascaded shift registers (max 64)

Definition at line 3 of file ShiftOut.cpp.

5.7.3 Member Function Documentation

5.7.3.1 handle()

```
void ShiftOut::handle ( )
```

Real time handling, call cyclic in loop()

Definition at line 63 of file ShiftOut.cpp.

5.7.3.2 setAII()

```
void ShiftOut::setAll (
          bool state )
```

Set state for all outputs.

Parameters

state	State to set (HIGH/LOW)
-------	-------------------------

Definition at line 54 of file ShiftOut.cpp.

5.7.3.3 setPin()

Set one outpot to a display mode.

Parameters

pin	Pin to set (0-64)
state	State to set (HIGH/LOW)

Definition at line 42 of file ShiftOut.cpp.

The documentation for this class was generated from the following files:

- ShiftOut.h
- · ShiftOut.cpp

5.8 Switch Class Reference

Class for a simple on/off switch with debouncing and XPLDirect command handling.

```
#include <Switch.h>
```

Public Member Functions

```
• Switch (uint8_t mux, uint8_t pin)
```

Constructor. Connect the switch to a pin on a mux.

• Switch (uint8_t pin)

Constructor, set digital input without mux.

• void handle ()

Handle realtime. Read input and evaluate any transitions.

void handleXP ()

Handle realtime and process XPLDirect commands.

• bool on ()

Check whether Switch set to on.

• bool off ()

Check whether Switch set to off.

void setCommand (int cmdOn)

Set XPLDirect commands for Switch events (command only for on position)

void setCommand (XPString_t *cmdNameOn)

Set XPLDirect commands for Switch events (command only for on position)

void setCommand (int cmdOn, int cmdOff)

Set XPLDirect commands for Switch events.

void setCommand (XPString_t *cmdNameOn, XPString_t *cmdNameOff)

Set XPLDirect commands for Switch events.

• int getCommand ()

Get XPLDirect command for last transition of Switch.

void processCommand ()

Process all transitions to XPLDirect.

• float value (float onValue, float offValue)

Check Status of Switch and translate to float value.

5.8.1 Detailed Description

Class for a simple on/off switch with debouncing and XPLDirect command handling.

Definition at line 7 of file Switch.h.

5.8.2 Constructor & Destructor Documentation

5.8.2.1 Switch() [1/2]

Constructor. Connect the switch to a pin on a mux.

Parameters

mux	mux number (from DigitalIn initialization order)
pin	pin on the mux (0-15)

Definition at line 7 of file Switch.cpp.

5.8.2.2 Switch() [2/2]

Constructor, set digital input without mux.

5.8 Switch Class Reference 37

Parameters

pin Arduino pin number

Definition at line 17 of file Switch.h.

5.8.3 Member Function Documentation

5.8.3.1 getCommand()

```
int Switch::getCommand ( )
```

Get XPLDirect command for last transition of Switch.

Returns

Handle of the last command

Definition at line 65 of file Switch.cpp.

5.8.3.2 handle()

```
void Switch::handle ( )
```

Handle realtime. Read input and evaluate any transitions.

Definition at line 19 of file Switch.cpp.

5.8.3.3 handleXP()

```
void Switch::handleXP ( ) [inline]
```

Handle realtime and process XPLDirect commands.

Definition at line 23 of file Switch.h.

5.8.3.4 off()

```
bool Switch::off ( ) [inline]
```

Check whether Switch set to off.

Returns

true: Switch is off

Definition at line 31 of file Switch.h.

5.8.3.5 on()

```
bool Switch::on ( ) [inline]
```

Check whether Switch set to on.

Returns

true: Switch is on

Definition at line 27 of file Switch.h.

5.8.3.6 processCommand()

```
void Switch::processCommand ( )
```

Process all transitions to XPLDirect.

Definition at line 81 of file Switch.cpp.

5.8.3.7 setCommand() [1/4]

```
void Switch::setCommand (
            int cmdOn )
```

Set XPLDirect commands for Switch events (command only for on position)

Parameters

cmdOn

Command handle for Switch moved to on as returned by XP.registerCommand()

Definition at line 41 of file Switch.cpp.

5.8.3.8 setCommand() [2/4]

Set XPLDirect commands for Switch events.

Parameters

cmdOn	Command handle for Switch moved to on as returned by XP.registerCommand()
cmdOff	Command handle for Switch moved to off as returned by XP.registerCommand()

Definition at line 53 of file Switch.cpp.

5.8.3.9 setCommand() [3/4]

Set XPLDirect commands for Switch events (command only for on position)

Parameters

cmdNameOn	Command for Switch moved to on
-----------	--------------------------------

Definition at line 47 of file Switch.cpp.

5.8.3.10 setCommand() [4/4]

Set XPLDirect commands for Switch events.

Parameters

cmdNameOn	Command for Switch moved to on
cmdNameOff	Command for Switch moved to off

Definition at line 59 of file Switch.cpp.

5.8.3.11 value()

Check Status of Switch and translate to float value.

Parameters

onValue	Value to return when Switch is set to on
offValue	Value to return when Switch is set to off

Returns

Returned value

Definition at line 62 of file Switch.h.

The documentation for this class was generated from the following files:

- · Switch.h
- · Switch.cpp

5.9 Switch2 Class Reference

Class for an on/off/on switch with debouncing and XPLDirect command handling.

```
#include <Switch.h>
```

Public Member Functions

Switch2 (uint8_t mux, uint8_t pin1, uint8_t pin2)

Constructor. Connect the switch to pins on a mux.

• Switch2 (uint8_t pin1, uint8_t pin2)

Constructor, set digital input pins without mux.

• void handle ()

Handle realtime. Read inputs and evaluate any transitions.

• void handleXP ()

Handle realtime and process XPLDirect commands.

bool off ()

Check whether Switch set to off.

• bool on1 ()

Check whether Switch set to on1.

• bool on2 ()

Check whether Switch set to on2.

void setCommand (int cmdUp, int cmdDown)

Set XPLDirect commands for Switch events in cases only up/down commands are to be used.

void setCommand (XPString_t *cmdNameUp, XPString_t *cmdNameDown)

Set XPLDirect commands for Switch events in cases only up/down commands are to be used.

void setCommand (int cmdOn1, int cmdOff, int cmdOn2)

Set XPLDirect commands for Switch events in cases separate events for on1/off/on2 are to be used.

• void setCommand (XPString_t *cmdNameOn1, XPString_t *cmdNameOff, XPString_t *cmdNameOn2)

Set XPLDirect commands for Switch events in cases separate events for on1/off/on2 are to be used.

• int getCommand ()

Get XPLDirect command for last transition of Switch.

• void processCommand ()

Process all transitions to XPLDirect.

• float value (float on1 Value, float off Value, float on2 Value)

Check Status of Switch and translate to float value.

5.9.1 Detailed Description

Class for an on/off/on switch with debouncing and XPLDirect command handling.

Definition at line 80 of file Switch.h.

5.9.2 Constructor & Destructor Documentation

5.9.2.1 Switch2() [1/2]

Constructor. Connect the switch to pins on a mux.

Parameters

mux	mux number (from DigitalIn initialization order)
pin1	on1 pin on the mux (0-15)
pin2	on2 pin on the mux (0-15)

Definition at line 96 of file Switch.cpp.

5.9.2.2 Switch2() [2/2]

Constructor, set digital input pins without mux.

Parameters

pin1	on1 Arduino pin number
pin2	on2 Arduino pin number

Definition at line 92 of file Switch.h.

5.9.3 Member Function Documentation

5.9.3.1 getCommand()

```
int Switch2::getCommand ( )
```

Get XPLDirect command for last transition of Switch.

Returns

Handle of the last command

Definition at line 167 of file Switch.cpp.

5.9.3.2 handle()

```
void Switch2::handle ( )
```

Handle realtime. Read inputs and evaluate any transitions.

Definition at line 112 of file Switch.cpp.

5.9.3.3 handleXP()

```
void Switch2::handleXP ( ) [inline]
```

Handle realtime and process XPLDirect commands.

Definition at line 98 of file Switch.h.

5.9.3.4 off()

```
bool Switch2::off ( ) [inline]
```

Check whether Switch set to off.

Returns

true: Switch is off

Definition at line 102 of file Switch.h.

5.9.3.5 on1()

```
bool Switch2::on1 ( ) [inline]
```

Check whether Switch set to on1.

Returns

true: Switch is on1

Definition at line 106 of file Switch.h.

5.9.3.6 on2()

```
bool Switch2::on2 ( ) [inline]
```

Check whether Switch set to on2.

Returns

true: Switch is on2

Definition at line 110 of file Switch.h.

5.9.3.7 processCommand()

```
void Switch2::processCommand ( )
```

Process all transitions to XPLDirect.

Definition at line 206 of file Switch.cpp.

5.9.3.8 setCommand() [1/4]

```
void Switch2::setCommand (
    int cmdOn1,
    int cmdOff,
    int cmdOn2)
```

Set XPLDirect commands for Switch events in cases separate events for on1/off/on2 are to be used.

Parameters

cmdOn1	Command handle for Switch moved to on1 position as returned by XP.registerCommand()
cmdOff	Command handle for Switch moved to off position as returned by XP.registerCommand()
cmdOn2	Command handle for Switch moved to on2 position as returned by XP.registerCommand()

Definition at line 153 of file Switch.cpp.

5.9.3.9 setCommand() [2/4]

Set XPLDirect commands for Switch events in cases only up/down commands are to be used.

Parameters

cmdUp	Command handle for Switch moved from on1 to off or from off to on2 as returned by XP.registerCommand()	1
cmdDown	Command handle for Switch moved from on2 to off or from off to on1 as returned by XP.registerCommand()	

Definition at line 139 of file Switch.cpp.

5.9.3.10 setCommand() [3/4]

Set XPLDirect commands for Switch events in cases separate events for on1/off/on2 are to be used.

Parameters

cmdNameOn1	Command for Switch moved to on1 position
cmdNameOff	Command for Switch moved to off position
cmdNameOn2	Command for Switch moved to on2 position

Definition at line 160 of file Switch.cpp.

5.10 Timer Class Reference 45

5.9.3.11 setCommand() [4/4]

Set XPLDirect commands for Switch events in cases only up/down commands are to be used.

Parameters

cmdNameUp	Command for Switch moved from on1 to off or from off to on2 on	
cmdNameDown	Command for Switch moved from on2 to off or from off to on1]

Definition at line 146 of file Switch.cpp.

5.9.3.12 value()

Check Status of Switch and translate to float value.

Parameters

	on1 Value	Value to return when Switch is set to on1
	offValue	Value to return when Switch is set to off
ĺ	on2Value	Value to return when Switch is set to on2

Returns

Returned value

Definition at line 146 of file Switch.h.

The documentation for this class was generated from the following files:

- Switch.h
- · Switch.cpp

5.10 Timer Class Reference

Priovide a simple software driven timer for general purpose use.

```
#include <Timer.h>
```

Public Member Functions

• Timer (float cycle=0)

Setup timer.

• void setCycle (float cycle)

Set or reset cycle time.

• bool elapsed ()

Check if cyclic timer elapsed and reset if so.

• float getTime ()

Get measured time since and reset timer.

• long count ()

Return cycle counter and reset to zero.

5.10.1 Detailed Description

Priovide a simple software driven timer for general purpose use.

Definition at line 6 of file Timer.h.

5.10.2 Constructor & Destructor Documentation

5.10.2.1 Timer()

Setup timer.

Parameters

cycle Cycle time for elapsing timer in ms. 0 means no cycle, just for measurement.

Definition at line 3 of file Timer.cpp.

5.10.3 Member Function Documentation

5.10.3.1 count()

```
long Timer::count ( )
```

Return cycle counter and reset to zero.

5.10 Timer Class Reference 47

Returns

Number of calls to elapsed() since last call of count()

Definition at line 34 of file Timer.cpp.

5.10.3.2 elapsed()

```
bool Timer::elapsed ( )
```

Check if cyclic timer elapsed and reset if so.

Returns

true: timer elapsed and restarted, false: still running

Definition at line 14 of file Timer.cpp.

5.10.3.3 getTime()

```
float Timer::getTime ( )
```

Get measured time since and reset timer.

Returns

Elapsed time in ms

Definition at line 26 of file Timer.cpp.

5.10.3.4 setCycle()

Set or reset cycle time.

Parameters

cycle | Cycle time in ms

Definition at line 9 of file Timer.cpp.

The documentation for this class was generated from the following files:

- Timer.h
- · Timer.cpp

5.11 XPLPro Class Reference

Public Member Functions

• XPLPro (Stream *device)

Constructor.

void begin (const char *devicename, void(*initFunction)(void), void(*stopFunction)(void), void(*inbound←
 Handler)(int))

Register device and set callback functions.

• int connectionStatus ()

Return connection status.

int commandTrigger (int commandHandle)

Trigger a command once.

• int commandTrigger (int commandHandle, int triggerCount)

Trigger a command multiple times.

int commandStart (int commandHandle)

Start a command. All commandStart must be balanced with a commandEnd.

• int commandEnd (int commandHandle)

End a command. All commandStart must be balanced with a commandEnd.

void datarefWrite (int handle, long value)

Write an integer DataRef.

void datarefWrite (int handle, int value)

Write an integer DataRef. Maps to long DataRefs.

void datarefWrite (int handle, long value, int arrayElement)

Write a Integer DataRef to an array element.

void datarefWrite (int handle, int value, int arrayElement)

Write a Integer DataRef to an array element. Maps to long DataRefs.

• void datarefWrite (int handle, float value)

Write a float DataRef.

• void datarefWrite (int handle, float value, int arrayElement)

Write a float DataRef to an array element.

• void requestUpdates (int handle, int rate, float precision)

Request DataRef updates from the plugin.

• void requestUpdates (int handle, int rate, float precision, int element)

Request DataRef updates from the plugin for an array DataRef.

void setScaling (int handle, int inLow, int inHigh, int outLow, int outHigh)

set scaling factor for a DataRef (offload mapping to the plugin)

int registerDataRef (XPString_t *datarefName)

Register a DataRef and obtain a handle.

int registerCommand (XPString t *commandName)

Register a Command and obtain a handle.

float datarefReadFloat ()

Read the received float DataRef.

long datarefReadInt ()

Read the received integer DataRef.

int datarefReadElement ()

Read the received array element.

int sendDebugMessage (const char *msg)

Send a debug message to the plugin.

• int sendSpeakMessage (const char *msg)

Send a speech message to the plugin.

void sendResetRequest (void)

Request a reset from the plugin.

• int xloop ()

Cyclic loop handler, must be called in idle task.

5.11.1 Detailed Description

Definition at line 98 of file XPLPro.h.

5.11.2 Constructor & Destructor Documentation

5.11.2.1 XPLPro()

Constructor.

Parameters

```
device Device to use (should be &Serial)
```

Definition at line 5 of file XPLPro.cpp.

5.11.3 Member Function Documentation

5.11.3.1 begin()

Register device and set callback functions.

Parameters

devicename	Device name
initFunction	Callback for DataRef and Command registration
stopFunction	Callback for XPlane shutdown or plane change
inboundHandler	Callback for incoming DataRefs

Definition at line 11 of file XPLPro.cpp.

5.11.3.2 commandEnd()

End a command. All commandStart must be balanced with a commandEnd.

Parameters

Returns

0: OK, -1: command was not registered

Definition at line 61 of file XPLPro.cpp.

5.11.3.3 commandStart()

Start a command. All commandStart must be balanced with a commandEnd.

Parameters

commandHandle	Handle of the command to start

Returns

0: OK, -1: command was not registered

Definition at line 51 of file XPLPro.cpp.

5.11.3.4 commandTrigger() [1/2]

Trigger a command once.

Parameters

commandHandle of the	command to trigger
----------------------	--------------------

Returns

0: OK, -1: command was not registered

Definition at line 119 of file XPLPro.h.

5.11.3.5 commandTrigger() [2/2]

Trigger a command multiple times.

Parameters

commandHandle	Handle of the command to trigger
triggerCount	Number of times to trigger the command

Returns

0: OK, -1: command was not registered

Definition at line 40 of file XPLPro.cpp.

5.11.3.6 connectionStatus()

```
int XPLPro::connectionStatus ( )
```

Return connection status.

Returns

True if connection to XPlane established

Definition at line 71 of file XPLPro.cpp.

5.11.3.7 datarefReadElement()

```
int XPLPro::datarefReadElement ( ) [inline]
```

Read the received array element.

Returns

Received array element

Definition at line 205 of file XPLPro.h.

5.11.3.8 datarefReadFloat()

```
float XPLPro::datarefReadFloat ( ) [inline]
```

Read the received float DataRef.

Returns

Received value

Definition at line 197 of file XPLPro.h.

5.11.3.9 datarefReadInt()

```
long XPLPro::datarefReadInt ( ) [inline]
```

Read the received integer DataRef.

Returns

Received value

Definition at line 201 of file XPLPro.h.

5.11.3.10 datarefWrite() [1/6]

Write a float DataRef.

Parameters

handle	Handle of the DataRef to write
value	Value to write to the DataRef

Definition at line 130 of file XPLPro.cpp.

5.11.3.11 datarefWrite() [2/6]

```
void XPLPro::datarefWrite (
                int handle,
                float value,
                int arrayElement )
```

Write a float DataRef to an array element.

Parameters

handle	Handle of the DataRef to write
value	Value to write to the DataRef

Definition at line 147 of file XPLPro.cpp.

5.11.3.12 datarefWrite() [3/6]

Write an integer DataRef. Maps to long DataRefs.

Parameters

handle	Handle of the DataRef to write
value	Value to write to the DataRef

Definition at line 90 of file XPLPro.cpp.

5.11.3.13 datarefWrite() [4/6]

```
int value,
int arrayElement )
```

Write a Integer DataRef to an array element. Maps to long DataRefs.

Parameters

handle	Handle of the DataRef to write
value	Value to write to the DataRef
arrayElement	Array element to write to

Definition at line 100 of file XPLPro.cpp.

5.11.3.14 datarefWrite() [5/6]

Write an integer DataRef.

Parameters

handle	Handle of the DataRef to write
value	Value to write to the DataRef

Definition at line 110 of file XPLPro.cpp.

5.11.3.15 datarefWrite() [6/6]

```
void XPLPro::datarefWrite (
                int handle,
                long value,
                int arrayElement )
```

Write a Integer DataRef to an array element.

Parameters

handle	Handle of the DataRef to write
value	Value to write to the DataRef
arrayElement	Array element to write to

Definition at line 120 of file XPLPro.cpp.

5.11.3.16 registerCommand()

Register a Command and obtain a handle.

Parameters

ne of the Command (or abbreviation)	commandName
-------------------------------------	-------------

Returns

Assigned handle for the Command, -1 if Command was not found

Definition at line 462 of file XPLPro.cpp.

5.11.3.17 registerDataRef()

Register a DataRef and obtain a handle.

Parameters

datarefName	Name of the DataRef (or abbreviation)

Returns

Assigned handle for the DataRef, -1 if DataRef was not found

Definition at line 437 of file XPLPro.cpp.

5.11.3.18 requestUpdates() [1/2]

Request DataRef updates from the plugin.

Parameters

handle	Handle of the DataRef to subscribe to
rate	Maximum rate for updates to reduce traffic
Generated by Devygen	
precision	Floating point precision
•	

Definition at line 479 of file XPLPro.cpp.

5.11.3.19 requestUpdates() [2/2]

Request DataRef updates from the plugin for an array DataRef.

Parameters

handle	Handle of the DataRef to subscribe to
rate	Maximum rate for updates to reduce traffic
precision	Floating point precision
arrayElement	Array element to subscribe to

Definition at line 493 of file XPLPro.cpp.

5.11.3.20 sendDebugMessage()

Send a debug message to the plugin.

Parameters

msg	Message to show as debug string

Returns

Definition at line 76 of file XPLPro.cpp.

5.11.3.21 sendResetRequest()

Request a reset from the plugin.

Definition at line 174 of file XPLPro.cpp.

5.11.3.22 sendSpeakMessage()

Send a speech message to the plugin.

Parameters

```
msg Message to speak
```

Returns

Definition at line 82 of file XPLPro.cpp.

5.11.3.23 setScaling()

```
void XPLPro::setScaling (
    int handle,
    int inLow,
    int inHigh,
    int outLow,
    int outHigh )
```

set scaling factor for a DataRef (offload mapping to the plugin)

Definition at line 508 of file XPLPro.cpp.

5.11.3.24 xloop()

Cyclic loop handler, must be called in idle task.

Returns

Connection status

Definition at line 25 of file XPLPro.cpp.

The documentation for this class was generated from the following files:

- XPLPro.h
- XPLPro.cpp

Chapter 6

File Documentation

6.1 Direct inputs/main.cpp

```
00001 #include <Arduino.h>
00002 #include <XPLDevices.h>
00004 // The XPLDirect library is automatically installed by PlatformIO with XPLDevices
00005 // Optional defines for XPLDirect can be set in platformio.ini
00006 \!\!\!// This sample contains all the important defines. Modify or remove as needed
00007
00008 // A simple Pushbutton on Arduino pin 2
00009 Button btnStart(2);
00010
00011 // An Encoder with push functionality. 3\&4 are the encoder pins, 5 the push pin.
00012 // configured for an Encoder with 4 counts per mechanical notch, which is the standard
00013 Encoder encHeading(3, 4, 5, enc4Pulse);
00014
00015 // A simple On/Off switch on pin 6
00016 Switch swStrobe(6);
00017
00018 // A Variable to be connected to a DataRef
00019 long strobe;
00020
00021 // Arduino setup function, called once
00022 void setup() {
      // setup interface
00024
       Serial.begin(XPLDIRECT_BAUDRATE);
00025
        XP.begin("Sample");
00026
00027
        // Register Command for the Button
        btnStart.setCommand(F("sim/starters/engage_starter_1"));
00028
00029
00030
        // Register Commands for Encoder Up/Down/Push function.
        encHeading.setCommand(F("sim/autopilot/heading_up"),
   F("sim/autopilot/heading_down")
00031
00032
00033
                                F("sim/autopilot/heading_sync"));
00034
00035
        // Gegister Commands for Switch On and Off transitions. Commands are sent when Switch is moved
00036
        swStrobe.setCommand(F("sim/lights/strobe_lights_on")
00037
                             F("sim/lights/strobe_lights_off"));
00038
       // Register a DataRef for the strobe light. Read only from XP, 100ms minimum Cycle time, no divider XP.registerDataRef(F("sim/cockpit/electrical/strobe_lights_on"),
00039
00040
                            XPL_READ, 100, 0, &strobe);
00041
00042 }
00043
00044 // Arduino loop function, called cyclic
00045 void loop() {
00046 // Handle XPlane interface
00047
        XP.xloop();
00048
00049
        // handle all devices and automatically process commandsin background
00050
       btnStart.handleXP();
00051
        encHeading.handleXP();
00052
        swStrobe.handleXP();
00053
00054
         // Show the status of the Strobe on the internal LED
00055
       digitalWrite(LED_BUILTIN, (strobe > 0));
00056 }
```

60 File Documentation

6.2 MUX inputs/main.cpp

```
00001 #include <Arduino.h>
00002 #include <XPLDevices.h>
00003
        The XPLDirect library is automatically installed by PlatformIO with XPLDevices
00005 // Optional defines for XPLDirect can be set in platformio.ini
00006 // This sample contains all the important defines. Modify or remove as needed
00007
00008 // This sample shows how to use 74HC4067 Multiplexers for the inputs as commonly used by SimVim
00009
00010 // A simple Pushbutton on MUX0 pin 0
00011 Button btnStart(0, 0);
00013 // An Encoder with push functionality. MUX1 pin 8\&9 are the encoder pins, 10 the push pin.
00014 // configured for an Encoder with 4 counts per mechanical notch, which is the standard
00015 Encoder encHeading(1, 8, 9, 10, enc4Pulse);
00016
00017 // A simple On/Off switch on MUX0, pin 15
00018 Switch swStrobe(0, 15);
00019
00020 // A Variable to be connected to a DataRef
00021 long strobe;
00022
00023 // Arduino setup function, called once
00024 void setup() {
00025
      // setup interface
00026
        Serial.begin(XPLDIRECT_BAUDRATE);
00027
       XP.begin("Sample");
00028
00029
        // Connect MUX adress pins to Pin 22-25 (SimVim Pins)
        DigitalIn.setMux(22, 23, 24, 25);
00031
        // Logical MUX0 on Pin 38
00032
        DigitalIn.addMux(38);
00033
        // Logical MUX1 on Pin 39
00034
        DigitalIn.addMux(39);
00035
00036
        // Register Command for the Button
00037
        btnStart.setCommand(F("sim/starters/engage_starter_1"));
00038
00039
        // Register Commands for Encoder Up/Down/Push function.
        encHeading.setCommand(F("sim/autopilot/heading_up"),
00040
00041
                              F("sim/autopilot/heading_down"),
00042
                              F("sim/autopilot/heading_sync"));
00043
00044
        // Gegister Commands for Switch On and Off transitions. Commands are sent when Switch is moved
        00045
00046
00047
        // Register a DataRef for the strobe light. Read only from XP, 100ms minimum Cycle time, no divider XP.registerDataRef (F("sim/cockpit/electrical/strobe_lights_on"),
00048
00049
00050
                           XPL_READ, 100, 0, &strobe);
00051 }
00052
00053 // Arduino loop function, called cyclic
00054 void loop() {
       // Handle XPlane interface
00056
       XP.xloop();
00057
00058
        \ensuremath{//} handle all devices and automatically process commands
in background
00059
       btnStart.handleXP();
00060
       encHeading.handleXP();
       swStrobe.handleXP();
00062
00063
        // Show the status of the Strobe on the internal LED
00064
       digitalWrite(LED_BUILTIN, (strobe > 0));
00065 }
```

6.3 Analogin.h

```
00001 #ifndef AnalogIn_h
00002 #define AnalogIn_h
00003 #include <Arduino.h>
00004
00005 #define AD_RES 10
00006
00007 enum Analog_t
00008 {
00009 unipolar,
00010 bipolar
00011 };
00012
00014 class AnalogIn
```

6.4 Button.h 61

```
00015 {
00016 public:
00020
        AnalogIn(uint8_t pin, Analog_t type);
00021
00026
        AnalogIn(uint8_t pin, Analog_t type, float timeConst);
00027
00029
        void handle();
00030
00033
        float value() { return _value; };
00034
00037
        int raw();
00038
00041
        void calibrate();
00042
00047
        void setRange(uint16_t min, uint16_t max);
00048
00051
        void setScale(float scale);
00052
00053 private:
00054
        void _calcScales();
        float _value;
float _filterConst;
00055
00056
        float _scale;
float _scalePos;
float _scaleNeg;
uint16_t _offset;
00057
00058
00059
00060
00061
        uint16_t _min;
00062
        uint16_t _max;
00063
        uint8_t _pin;
       Analog_t _type;
00064
00065 };
00066
00067 #endif
```

6.4 Button.h

```
00001 #ifndef Button h
00002 #define Button_h
00003 #include <Arduino.h>
00004 #include <XPLPro.h>
00005
00008 class Button
000009 1
00010 private:
00011
       void _handle(bool input);
00012
00013 public:
00017
       Button(uint8_t mux, uint8_t muxpin);
00018
       Button(uint8_t pin) : Button(NOT_USED, pin){};
00021
00022
00024
       void handle()
                                      { _handle(true); };
00025
00028
       void handle(bool input)
                                     { _handle(input); };
00029
00031
       void handleXP()
                                      { _handle(true); processCommand(); };
00032
00035
       void handleXP(bool input)
                                      { handle(input); processCommand(); };
00036
00039
       bool pressed()
                                       { return _transition == transPressed ? (_transition = transNone,
     true) : false; };
00040
00043
                                       { return transition == transReleased ? ( transition = transNone,
       bool released()
     true) : false; };
00044
00047
                                       { return _state > 0; };
       bool engaged()
00048
00051
       void setCommand(int cmdPush);
00052
00055
       void setCommand(XPString_t *cmdNamePush);
00056
00059
       int getCommand()
                                      { return _cmdPush; };
00060
00062
       void processCommand();
00063
00064 protected:
00065
        enum
00066
00067
          transNone,
00068
         transPressed.
00069
         transReleased
00070
00071
       uint8_t _mux;
```

62 File Documentation

```
uint8_t _pin;
       uint8_t _state;
uint8_t _transition;
00073
00074
00075
       int _cmdPush;
00076 };
00077
00081 class RepeatButton : public Button
00082 {
00083 private:
00084
        void _handle(bool input);
00085
00086 public:
00091
       RepeatButton(uint8_t mux, uint8_t muxpin, uint32_t delay);
00092
00096
       RepeatButton(uint8_t pin, uint32_t delay) : RepeatButton(NOT_USED, pin, delay) {};
00097
00099
       void handle()
                                       { handle(true); };
00100
00103
       void handle(bool input)
                                       { _handle(input); };
00104
00106
       void handleXP()
                                       { _handle(true); processCommand(); };
00107
00110
       void handleXP(bool input)
                                      { _handle(input); processCommand(); };
00111
00112 protected:
00113
      uint32_t _delay;
00114
        uint32_t _timer;
00115 };
00116
00117 #endif
```

6.5 Digitalln.h

```
00001 #ifndef DigitalIn_h
00002 #define DigitalIn_h
00003 #include <Arduino.h>
00004
00006 #ifndef MUX_MAX_NUMBER
00007 #define MUX_MAX_NUMBER 6
00008 #endif
00009
00011 #ifndef MCP_MAX_NUMBER
00012 #define MCP_MAX_NUMBER 0
00013 #endif
00015 // Include i2c lib only when needed
00016 #if MCP_MAX_NUMBER > 0
00017 #include <Adafruit_MCP23X17.h>
00018 #endif
00019
00020 #define NOT_USED 255
00021
00024 class DigitalIn_
00025 {
00026 public:
00028
        DigitalIn_();
00029
00035
        void setMux(uint8_t s0, uint8_t s1, uint8_t s2, uint8_t s3);
00036
00040
       bool addMux(uint8_t pin);
00041
00042 #if MCP_MAX_NUMBER > 0
00046
       bool addMCP(uint8_t adress);
00047 #endif
00048
00053
        bool getBit(uint8_t expander, uint8_t channel);
00054
00056
       void handle();
00057 private:
00058 uint8_t _s0, _s1, _s2, _s3;
00059 #ifdef ARDUINO_ARCH_AVR
00060
        uint8_t _s0port, _s1port, _s2port, _s3port;
00061
       uint8_t _s0mask, _s1mask, _s2mask, _s3mask;
00062 #endif
        uint8_t _numPins;
00063
        uint8_ _ pin[MUX_MAX_NUMBER + MCP_MAX_NUMBER];
00064
00065 int16_t _data[MUX_MAX_NUMBER + MCP_MAX_NUMBER];
00066 #if MCP_MAX_NUMBER > 0
00067 uint8_t _numMCP;
00068 Adafruit_MCP23X17 _mcp[MCP_MAX_NUMBER];
00069 #endif
00070 };
00071
```

6.6 Encoder.h

```
00073 extern DigitalIn_ DigitalIn;
00074
00075 #endif
```

6.6 Encoder.h

```
00001 #ifndef Encoder_h
00002 #define Encoder_h
00003 #include <Arduino.h>
00004 #include <XPLPro.h>
00005
00006 enum EncCmd t
00007 {
80000
       encCmdUp,
00009
        encCmdDown,
00010
       encCmdPush
00011 };
00012
00013 enum EncPulse t
00014 {
00015
        enclPulse = 1,
00016
        enc2Pulse = 2,
00017
       enc4Pulse = 4
00018 };
00019
00022 class Encoder
00023 {
00024 public:
00031
        Encoder(uint8_t mux, uint8_t pin1, uint8_t pin2, uint8_t pin3, EncPulse_t pulses);
00032
        Encoder(uint8_t pin1, uint8_t pin2, uint8_t pin3, EncPulse_t pulses) : Encoder(NOT_USED, pin1, pin2,
00038
     pin3, pulses) {}
00039
00041
        void handle();
00042
00044
        void handleXP()
                          { handle(); processCommand(); };
00045
00048
       int16_t pos()
                          { return count; };
00049
00052
                           { return _count >= _pulses ? (_count -= _pulses, true) : false; };
       bool up()
00053
00056
       bool down()
                           { return _count <= -_pulses ? (_count += _pulses, true) : false; };
00057
                           { return _transition == transPressed ? (_transition = transNone, true) : false;
00060
       bool pressed()
00061
00064
                          { return _transition == transReleased ? (_transition = transNone, true) : false;
        bool released()
     } ;
00065
00068
        bool engaged()
                           { return state > 0; };
00069
00074
        void setCommand(int cmdUp, int cmdDown, int cmdPush);
00075
08000
       void setCommand(XPString_t *cmdNameUp, XPString_t *cmdNameDown, XPString_t *cmdNamePush);
00081
00085
       void setCommand(int cmdUp, int cmdDown);
00086
00090
       void setCommand(XPString t *cmdNameUp, XPString t *cmdNameDown);
00091
00095
       int getCommand(EncCmd_t cmd);
00096
00098
       void processCommand();
00099 private:
00100
       enum
00101
00102
          transNone,
00103
          transPressed,
00104
         transReleased
00105
       };
00106
       uint8_t _mux;
        uint8_t _pin1, _pin2, _pin3;
00108
        int8_t _count;
00109
        uint8_t _pulses;
00110
        uint8_t _state;
00111
        uint8_t _debounce;
uint8_t _transition;
00112
        int _cmdUp;
int _cmdDown;
00113
00114
00115
        int _cmdPush;
00116 };
00117
00118 #endif
```

64 File Documentation

6.7 LedShift.h

```
00001 #ifndef LedShift_h
00002 #define LedShift_h
00003 #include <Arduino.h>
00004
00006 enum led_t
00007 {
00009
         ledOff = 0x00,
         ledFast = 0x01
00011
         ledMedium = 0x02,
00013
        ledSlow = 0x04,
ledOn = 0x08
00015
00018 };
00019
00021 class LedShift
00022 {
00023 public:
00029
         LedShift(uint8_t pin_DAI, uint8_t pin_DCK, uint8_t pin_LAT, uint8_t pins = 16);
00030
00034
         void setPin(uint8_t pin, led_t mode);
00035
         void set(uint8_t pin, led_t mode) { setPin(pin, mode); }; // obsolete
00036
         void setAll(led_t mode);
void set_all(led_t mode) { setAll(mode); }; // obsolete
00039
00040
00041
00043
         void handle();
00044
00045 private:
00046 void _send();

00047 uint8_t _pin_DAI;

00048 uint8_t _pin_DCK;

00049 uint8_t _pin_LAT;

00050 uint8_t _pins;
         led_t _mode[64];
uint8_t _count;
unsigned long _timer;
00051
00052
00053
00054 bool _update;
00055 };
00056
00057 #endif
```

6.8 ShiftOut.h

```
00001 #ifndef ShiftOut_h
00002 #define ShiftOut_h
00003 #include <Arduino.h>
00004
00006 class ShiftOut
00007 {
00008 public:
         ShiftOut(uint8_t pin_DAI, uint8_t pin_DCK, uint8_t pin_LAT, uint8_t pins = 16);
00014
00015
00019
         void setPin(uint8 t pin, bool state);
00020
00023
        void setAll(bool state);
00024
00026
        void handle();
00027
00028 private:
00029 void _send();
00030 uint8_t _pin_DAI;
00031 uint8_t _pin_DCK;
00032
         uint8_t _pin_LAT;
         uint8_t _pins;
uint8_t _state[8];
00033
00034
00035
         bool _update;
00036 };
00037
00038 #endif
```

6.9 Switch.h

```
00001 #ifndef Switch_h
00002 #define Switch_h
00003 #include <Arduino.h>
00004 #include <XPLPro.h>
00005
00005
00007 class Switch
```

6.9 Switch.h 65

```
00008 {
00009 public:
00013
        Switch(uint8_t mux, uint8_t pin);
00014
00017
        Switch(uint8_t pin) : Switch (NOT_USED, pin) {};
00018
00020
        void handle();
00021
00023
        void handleXP() { handle(); processCommand(); };
00024
        bool on()
00027
                        { return _state == switchOn; };
00028
00031
        bool off()
                         { return state == switchOff; };
00032
00035
        void setCommand(int cmdOn);
00036
00039
        void setCommand(XPString_t *cmdNameOn);
00040
00044
        void setCommand(int cmdOn, int cmdOff);
00045
00049
        void setCommand(XPString_t *cmdNameOn, XPString_t *cmdNameOff);
00050
00053
       int getCommand();
00054
00056
       void processCommand();
00057
00062
        float value(float onValue, float offValue) { return on() ? onValue : offValue; };
00063
00064 private:
00065
        enum SwState t
00066
00067
          switchOff,
00068
          switch0n
00069
        uint8_t _mux;
00070
        uint8_t _pin;
uint8_t _debounce;
uint8_t _state;
00071
00072
00073
        bool _transition;
00074
00075
        int _cmdOff;
00076
       int _cmdOn;
00077 };
00078
00080 class Switch2
00081 {
00082 public:
00087
        Switch2(uint8_t mux, uint8_t pin1, uint8_t pin2);
00088
        Switch2(uint8_t pin1, uint8_t pin2) : Switch2(NOT_USED, pin1, pin2) {}
00092
00093
00095
        void handle();
00096
00098
        void handleXP() { handle(); processCommand(); };
00099
                        { return _state == switchOff; };
00102
       bool off()
00103
00106
        bool on1()
                         { return _state == switchOn1; };
00107
00110
        bool on2()
                         { return _state == switchOn2; };
00111
00115
        void setCommand(int cmdUp, int cmdDown);
00116
00120
        void setCommand(XPString_t *cmdNameUp, XPString_t *cmdNameDown);
00121
00126
        void setCommand(int cmdOn1, int cmdOff, int cmdOn2);
00127
00132
        void setCommand(XPString_t *cmdNameOn1, XPString_t *cmdNameOff, XPString_t *cmdNameOn2);
00133
00136
        int getCommand():
00137
00139
        void processCommand();
00140
00146
        float value(float on1Value, float offValue, float on2Value) { return (on1() ? on1Value : on2() ?
     on2Value : offValue); };
00147
00148 private:
00149
        enum SwState_t
00150
00151
          switchOff,
00152
          switchOn1.
00153
          switchOn2
00154
        uint8_t _mux;
00155
00156
        uint8_t _pin1;
00157
        uint8_t _pin2;
        uint8_t _lastState;
uint8_t _debounce;
00158
00159
```

```
00160     uint8_t _state;
00161     bool _transition;
00162     int _cmdOff;
00163     int _cmdOn1;
00164     int _cmdOn2;
00165 };
00166     00167 #endif
```

6.10 Timer.h

```
00001 #ifndef SoftTimer_h
00002 #define SoftTimer_h
00003 #include <Arduino.h>
00004
00006 class Timer
00007 {
      public:
80000
         Timer(float cycle = 0); // ms
00011
00012
00015
         void setCycle(float cycle);
00016
00019
         bool elapsed();
00020
00023
         float getTime(); // ms
00024
00027
         long count();
00028
       private:
00029
         unsigned long _cycleTime;
00030
          unsigned long _lastUpdateTime;
00031
          long _count;
00032 };
00034 #endif
```

6.11 XPLPro.h

```
XPLPro.h - Library for serial interface to Xplane SDK.
           Created by Curiosity Workshop, Michael Gerlicher and Martin Ruskowski, 2020-2023
See readme.txt file for information on updates.
00002 //
00003 //
00004 //
           To report problems, download updates and examples, suggest enhancements or get technical support,
     please visit:
00005 //
             discord: https://discord.gg/gzXetjEST4
00006 //
              patreon: www.patreon.com/curiosityworkshop
00007
00008 #ifndef XPLPro_h
00009 #define XPLPro_h
00010
00011 #include <Arduino.h>
00012
00014 \!\!\!// Parameters which can be overridden by command line defines
00017 // Decimals of precision for floating point datarefs. More increases dataflow (default 4)
00018 #ifndef XPL_FLOATPRECISION
00019 #define XPL_FLOATPRECISION 4
00020 #endif
00021
00022 // Timeout after sending a registration request, how long will we wait for the response.
00023 // This is giant because sometimes xplane says the plane is loaded then does other stuff for a while.
      (default 90000 ms)
00024 #ifndef XPL_RESPONSE_TIMEOUT
00025 #define XPL_RESPONSE_TIMEOUT 90000
00026 #endif
00027
00028 \!\!\!\!// For boards with limited memory that can use PROGMEM to store strings.
00029 // You will need to wrap your dataref names with F() macro ie:
00030 // Xinterface.registerDataref(F("laminar/B738/annunciator/drive2"), XPL_READ, 100, 0, &drive2);
00031 // Disable for boards that have issues compiling: errors with strncmp_PF for instance.
00032 #ifndef XPL_USE_PROGMEM
00033 #ifdef _AVR_ARCH_
00034 // flash strings are default on on AVR architecture
00035 #define XPL_USE_PROGMEM 1
00036 #else
00037 // and off otherwise
00038 #define XPL_USE_PROGMEM 0
00039 #endif
00040 #endif
00042 // Package buffer size for send and receive buffer each.
```

6.11 XPLPro.h 67

```
00043 // If you need a few extra bytes of RAM it could be reduced, but it needs to
00044 // be as long as the longest dataref name + 10. If you are using datarefs
00045 // that transfer strings it needs to be big enough for those too.
                                                                               (default 200)
00046 #ifndef XPLMAX_PACKETSIZE_TRANSMIT
00047 #define XPLMAX_PACKETSIZE_TRANSMIT 200
00048 #endif
00050 #ifndef XPLMAX_PACKETSIZE_RECEIVE
00051 #define XPLMAX_PACKETSIZE_RECEIVE 200
00052 #endif
00053
00055 // All other defines in this header must not be modified
00057
00058 // define whether flash strings will be used
00059 #if XPL_USE_PROGMEM
00060 // use Flash for strings, requires F() macro for strings in all registration calls
00061
        typedef const __FlashStringHelper XPString_t;
00062 #else
00063
        typedef const char XPString_t;
00064 #endif
00065
00066 // Parameters around the interface
00067 #define XPL_BAUDRATE 115200 \, // Baudrate needed to match plugin 00068 #define XPL_RX_TIMEOUT 500 \, // Timeout for reception of one frame
00069 #define XPL_PACKETHEADER '[' // Frame start character 00070 #define XPL_PACKETTRAILER ']' // Frame end character
00071 #define XPL_HANDLE_INVALID -1 // invalid handle
00072
00073 // Items in caps generally come from XPlane. Items in lower case are generally sent from the arduino. 00074 \#define XPLCMD_SENDNAME 'N' // plugin request name from arduino
                                                     // plugin request name from arduino
// Arduino responds with device name as initialized in the
00075 #define XPLRESPONSE_NAME 'n'
      "begin" function
00076 #define XPLCMD_SENDREQUEST 'Q'
                                                     // plugin sends this when it is ready to register bindings
00077 #define XPLREQUEST_REGISTERDATAREF 'b'
                                                     // Register a DataRef
00078 #define XPLREQUEST_REGISTERCOMMAND '\text{m}'
                                                     // Register a command
00079 #define XPLRESPONSE_DATAREF 'D'
                                                     // Plugin responds with handle to dataref or - value if not
      found. dataref handle, dataref name
00080 #define XPLRESPONSE_COMMAND 'C'
                                                     // Plugin responds with handle to command or - value if not
      found. command handle, command name
00081 #define XPLCMD_PRINTDEBUG 'g'
                                                      // Plugin logs string sent from arduino
                                                     // plugin speaks string through xplane speech
// the plugin will call this once xplane is loaded in order
00082 #define XPLCMD_SPEAK 's'
00083 #define XPLREQUEST_REFRESH 'd'
      to get fresh updates from arduino handles that write
00084 #define XPLREQUEST_UPDATES 'r'
                                                     // arduino is asking the plugin to update the specified
      dataref with rate and divider parameters
00085 #define XPLREQUEST_UPDATESARRAY 't'
                                                     // arduino is asking the plugin to update the specified
      array dataref with rate and divider parameters
00086 #define XPLREQUEST_SCALING '\mathrm{u'}
                                                     // arduino requests the plugin apply scaling to the dataref
      values
00087 #define XPLCMD_RESET 'z'
                                                     // Request a reset and reregistration from the plugin
00088 #define XPLCMD_DATAREFUPDATEINT '1'
                                                     // Int DataRef update
                                                     // Float DataRef update
// Int array DataRef update
00089 #define XPLCMD_DATAREFUPDATEFLOAT '2'
00090 #define XPLCMD_DATAREFUPDATEINTARRAY '3'
00091 #define XPLCMD_DATAREFUPDATEFLOATARRAY '4' // Float array DataRaéf Update
00092 #define XPLCMD_DATAREFUPDATESTRING '9'
                                                     // String DataRef update
00093 #define XPLCMD_COMMANDTRIGGER 'k'
                                                      // Trigger command n times
00094 #define XPLCMD_COMMANDSTART 'i'
                                                     // Begin command (Button pressed)
00095 #define XPLCMD_COMMANDEND 'j'
                                                     // End command (Button released)
00096 #define XPL_EXITING 'X'
                                                      // XPlane sends this to the arduino device during normal
      shutdown of XPlane. It may not happen if xplane crashes.
00097
00098 class XPLPro
00099 {
00100 public:
00103
        XPLPro(Stream *device);
00104
00110
        void begin (const char *devicename, void (*initFunction) (void), void (*stopFunction) (void), void
      (*inboundHandler)(int));
00111
00114
        int connectionStatus();
00115
00119
        int commandTrigger(int commandHandle) { return commandTrigger(commandHandle, 1); };
00120
        int commandTrigger(int commandHandle, int triggerCount);
00125
00126
00130
        int commandStart(int commandHandle);
00131
00135
        int commandEnd(int commandHandle);
00136
00140
        void datarefWrite(int handle, long value):
00141
00145
        void datarefWrite(int handle, int value);
00146
00151
        void datarefWrite(int handle, long value, int arrayElement);
00152
00157
        void datarefWrite(int handle, int value, int arrayElement);
00158
```

```
void datarefWrite(int handle, float value);
00163
00167
       void datarefWrite(int handle, float value, int arrayElement);
00168
00173
       void requestUpdates(int handle, int rate, float precision);
00174
00180
       void requestUpdates(int handle, int rate, float precision, int element);
00181
00183
       void setScaling(int handle, int inLow, int inHigh, int outLow, int outHigh);
00184
00188
       int registerDataRef(XPString_t *datarefName);
00189
00193
       int registerCommand(XPString_t *commandName);
00194
00197
       float datarefReadFloat() { return _readValueFloat; }
00198
       long datarefReadInt() { return _readValueLong; }
00201
00202
00205
       int datarefReadElement() { return _readValueElement; }
00206
00210
       int sendDebugMessage(const char *msg);
00211
00215
       int sendSpeakMessage(const char *msg);
00216
00218
       void sendResetRequest(void);
00219
00222
       int xloop();
00223
00224 private:
00225
       void _processSerial();
00226
       void _processPacket();
00227
       void transmitPacket();
00228
       void _sendname();
       00229
00230
00231
       int _parseInt(long *outTarget, char *inBuffer, int parameter);
00232
       int _parseFloat(float *outTarget, char *inBuffer, int parameter);
00234
       int _parseString(char *outBuffer, char *inBuffer, int parameter, int maxSize);
00235
00236
       Stream *_streamPtr;
00237
       const char *_deviceName;
00238
       byte _registerFlag;
00239
       byte _connectionStatus;
00240
00241
       char _sendBuffer[XPLMAX_PACKETSIZE_TRANSMIT];
00242
       char _receiveBuffer[XPLMAX_PACKETSIZE_RECEIVE];
       int _receiveBufferBytesReceived;
00243
00244
       void (*_xplInitFunction) (void); // this function will be called when the plugin is ready to receive
00245
     binding requests
00246
       void (*_xplStopFunction)(void); // this function will be called with the plugin receives message or
     detects xplane flight model inactive
00247
       void (*_xplInboundHandler)(int); // this function will be called when the plugin sends dataref
     values
00248
00249
       int _handleAssignment;
       long _readValueLong;
00250
00251
       float _readValueFloat;
00252
       int _readValueElement;
00253 }:
00254
00255 #ifndef XPLPRO_STANDALONE
00257 extern XPLPro XP;
00258
00259 // include device libraries
00260 #include <DigitalIn.h>
00261 #include <Button.h>
00262 #include <Encoder.h>
00263 #include <Switch.h>
00264 #include <ShiftOut.h>
00265 #include <LedShift.h>
00266 #include <Timer.h>
00267 #include <AnalogIn.h>
00268 #endif
00269
00270 #endif
```

6.12 Analogin.cpp

```
00001 #include "AnalogIn.h"
00002
00003 #define FULL_SCALE ((1 « AD_RES) - 1)
```

6.12 AnalogIn.cpp 69

```
00004 #define HALF_SCALE (1 « (AD_RES - 1))
00006 AnalogIn::AnalogIn(uint8_t pin, Analog_t type)
00007 {
       _pin = pin;
80000
        _filterConst = 1.0;
00009
       _scale = 1.0;
00010
00011
        _{min} = 0;
00012
       _max = FULL_SCALE;
00013
        _type = type;
        pinMode(_pin, INPUT);
00014
00015
        if (_type == bipolar)
00016
       . _offset = HALF_SCALE;
}
00017
00018
00019
       else
00020
       _offset = 0;
00021
00022
00025
00026 AnalogIn::AnalogIn(uint8_t pin, Analog_t type, float timeConst) : AnalogIn(pin, type)
00027 {
00028
        if (timeConst > 0)
       {
          _filterConst = 1.0 / timeConst;
00030
00031
00032 }
00033
00034 void AnalogIn::handle()
00035 {
00036
       int _raw = raw();
00037
        _value = (_filterConst \star _raw \star (_raw >= 0 ? _scalePos : _scaleNeg)) + (1.0 - _filterConst) \star
      _value;
00038 }
00039
00040 int AnalogIn::raw()
00041 {
00042
       return constrain(analogRead(_pin), (int16_t)_min, (int16_t)_max) - _offset;
00043 }
00044
00045 void AnalogIn::calibrate()
00046 {
00047
        if (_type == unipolar)
00048
00049
          return;
00050
00051
        long sum = 0;
        for (int i = 0; i < 64; i++)</pre>
00052
00053
00054
         sum += analogRead(_pin);
00055
00056
       \_offset = (int)(sum / 64);
00057
        _calcScales();
00058 }
00059
00060 void AnalogIn::setRange(uint16_t min, uint16_t max)
00061 {
       _min = min(min, max);
_max = max(min, max);
00062
00063
00064
        if (min == max)
00065
00066
         \underline{\text{min}} = 0;
       _.... - 0;
_max = FULL_SCALE;
}
00067
00068
        if (_type == unipolar)
00069
00070
       _offset = _min;
00071
00072
00073
        else
00074
       _offset = (_max + _min) / 2;
00075
00076
       _calcScales();
00077
00078 }
00079
00080 void AnalogIn::setScale(float scale)
00081 {
       _scale = scale;
00082
        _calcScales();
00083
00084 }
00085
00086 void AnalogIn::_calcScales()
00087 {
        if (_type == unipolar)
00088
00089
```

```
00090    _scalePos = _scale / (float) (_max - _min);
00091    _scaleNeg = 0;
00092 }
00093    else
00094 {
00095    _scalePos = (_offset == _max) ? 0 : _scale / (float) (_max - _offset);
00096    _scaleNeg = (_offset == _min) ? 0 : _scale / (float) (_offset - _min);
00097 }
00098 }
```

6.13 Button.cpp

```
00001 #include "Button.h"
00002
00003 #ifndef DEBOUNCE_DELAY
00004 #define DEBOUNCE_DELAY 20
00005 #endif
00006
00007 // Buttons
00008 Button::Button(uint8_t mux, uint8_t pin)
00009 {
00010
       _pin = pin;
_state = 0;
00011
00012
       _transition = 0;
00013
00014
       \_cmdPush = -1;
00015
       if (mux == NOT_USED) {
00016
         pinMode(_pin, INPUT_PULLUP);
       }
00017
00018 }
00019
00020 // use additional bit for input masking
00021 void Button::_handle(bool input)
00022 {
00023
        if (DigitalIn.getBit(_mux, _pin) && input)
00024
          if (_state == 0)
00025
00026
         {
00027
            _state = DEBOUNCE_DELAY;
00028
            _transition = transPressed;
00029
00030
        else if (_state > 0)
00031
00032
         if (--_state == 0)
00033
00034
         {
00035
            _transition = transReleased;
00036
00037
       }
00038 }
00039
00040 void Button::setCommand(int cmdPush)
00041 {
00042
        _cmdPush = cmdPush;
00043 }
00044
00045 void Button::setCommand(XPString_t *cmdNamePush)
00046 {
00047
        _cmdPush = XP.registerCommand(cmdNamePush);
00048 }
00049
00050 void Button::processCommand()
00051 {
       if (pressed())
00053
       {
00054
         XP.commandStart (_cmdPush);
00055
00056
        if (released())
00057
00058
         XP.commandEnd(_cmdPush);
00059
00060 }
00061
00062 RepeatButton::RepeatButton(uint8_t mux, uint8_t pin, uint32_t delay) : Button(mux, pin)
00063 {
       _delay = delay;
00064
        _timer = 0;
00065
00066 }
00067
00068 void RepeatButton::_handle(bool input)
00069 {
00070
        if (DigitalIn.getBit(_mux, _pin) && input)
00071
```

6.14 DigitalIn.cpp 71

```
00072
          if (_state == 0)
00073
           _state = DEBOUNCE_DELAY;
00074
00075
           _transition = transPressed;
00076
            _timer = millis() + _delay;
00077
00078
         else if (_delay > 0 && (millis() >= _timer))
00079
           _state = DEBOUNCE_DELAY;
08000
00081
            _transition = transPressed;
            _timer += _delay;
00082
00083
00084
00085
        else if (_state > 0)
00086
00087
          if (--_state == 0)
00088
00089
            _transition = transReleased;
00090
00091
       }
00092 }
```

6.14 DigitalIn.cpp

```
00001 #include "DigitalIn.h"
00002
00003 #define MCP_PIN 254
00004
00005 // constructor
00006 DigitalIn_::DigitalIn_()
00007 {
80000
        _numPins = 0;
for (uint8_t expander = 0; expander < MUX_MAX_NUMBER; expander++)</pre>
00010
         _pin[expander] = NOT_USED;
00011
00012
       _s0 = NOT_USED;
00013
       _s1 = NOT_USED;
00014
       _s2 = NOT_USED;
00015
00016
       _s3 = NOT_USED;
00017 }
00018
00019 // configure 74HC4067 adress pins S0-S3
00020 void DigitalIn_::setMux(uint8_t s0, uint8_t s1, uint8_t s2, uint8_t s3)
       _s0 = s0;
00022
       _s1 = s1;
_s2 = s2;
00023
00024
00025
        _s3 = s3;
       pinMode(_s0, OUTPUT);
00026
00027
       pinMode(_s1, OUTPUT);
00028
       pinMode(_s2, OUTPUT);
00029
       pinMode(_s3, OUTPUT);
       #ifdef ARDUINO_ARCH_AVR
00030
       _s0port = digitalPinToPort(_s0);
00031
       _slport = digitalPinToPort(_s1);
00032
       _s2port = digitalPinToPort(_s2);
00033
       _s3port = digitalPinToPort(_s3);
00034
00035
       _s0mask = digitalPinToBitMask(_s0);
00036
       _slmask = digitalPinToBitMask(_s1);
       _s2mask = digitalPinToBitMask(_s2);
00037
00038
        _s3mask = digitalPinToBitMask(_s3);
00039
       #endif
00040 }
00041
00042 // Add a 74HC4067
00043 bool DigitalIn_::addMux(uint8_t pin)
00044 {
00045
        if (_numPins >= MUX_MAX_NUMBER)
00046
       {
         return false;
00048
00049
       _pin[_numPins++] = pin;
00050 pinMode(pin, INPUT);
       return true;
00051
00052 }
00053
00054 #if MCP_MAX_NUMBER > 0
00055 // Add a MCP23017
00056 bool DigitalIn_::addMCP(uint8_t adress)
00057 {
00058
        if ( numMCP >= MCP MAX NUMBER)
00059
```

```
00060
          return false;
00061
00062
        if (!_mcp[_numMCP].begin_I2C(adress, &Wire))
00063
00064
          return false;
00065
00066
        for (int i = 0; i < 16; i++)</pre>
00067
00068
        // TODO: register write iodir = 0xffff, ipol = 0xffff, gppu = 0xffff
         _mcp[_numMCP].pinMode(i, INPUT_PULLUP);
00069
00070
00071
        _numMCP++;
        _pin[_numPins++] = MCP_PIN;
00072
00073
        return true;
00074 }
00075 #endif
00076
00077 // Gets specific channel from expander, number according to initialization order
00078 bool DigitalIn_::getBit(uint8_t expander, uint8_t channel)
00079 {
00080
        if (expander == NOT USED)
00081
        #ifdef ARDUINO ARCH AVR
00082
         return (*portInputRegister(digitalPinToPort(channel)) & digitalPinToBitMask(channel)) ? false:
00083
     true;
00084 #else
00085
          return !digitalRead(channel);
00086
        #endif
00087
00088
       return bitRead(_data[expander], channel);
00089 }
00090
00091 // read all inputs together -> base for board specific optimization by using byte read
00092 void DigitalIn_::handle()
00093 {
        // only if Mux Pins present
00094
00095 #if MCP_MAX_NUMBER > 0
        if (_numPins > _numMCP)
00097 #else
00098
        if (_numPins > 0)
00099 #endif
00100
       {
         for (uint8_t channel = 0; channel < 16; channel++)</pre>
00101
00102
00103 #ifdef ARDUINO_ARCH_AVR
00104
            uint8_t oldSREG = SREG;
00105
            noInterrupts();
            bitRead(channel, 0) ? *portOutputRegister(_s0port) |= _s0mask : *portOutputRegister(_s0port) &=
00106
      ~_s0mask;
00107
           bitRead(channel, 1) ? *portOutputRegister( slport) |= slmask : *portOutputRegister( slport) &=
      ~_slmask;
00108
            bitRead(channel, 2) ? *portOutputRegister(_s2port) |= _s2mask : *portOutputRegister(_s2port) &=
      ~_s2mask;
00109
           bitRead(channel, 3) ? *portOutputRegister(_s3port) |= _s3mask : *portOutputRegister(_s3port) &=
     ~_s3mask;
00110
            SREG = oldSREG;
            delayMicroseconds(1);
00111
00112 #else
00113
            digitalWrite(_s0, bitRead(channel, 0));
00114
            digitalWrite(_s1, bitRead(channel, 1));
00115
            digitalWrite(_s2, bitRead(channel, 2));
00116
            digitalWrite(_s3, bitRead(channel, 3));
00117 #endif
00118
            for (uint8_t expander = 0; expander < _numPins; expander++)</pre>
00119
00120
              if (_pin[expander] != MCP_PIN)
00121
00122 #ifdef ARDUINO_ARCH_AVR
               bitWrite(_data[expander], channel, (*portInputRegister(digitalPinToPort(_pin[expander])) &
00123
      digitalPinToBitMask(_pin[expander])) ? false : true);
00124 #else
00125
                bitWrite(_data[expander], channel, !digitalRead(_pin[expander]));
00126 #endif
00127
              }
            }
00128
00129
        }
00130
00131 #if MCP_MAX_NUMBER > 0
00132
       int mcp = 0;
        for (uint8_t expander = 0; expander < _numPins; expander++)</pre>
00133
00134
00135
          if (_pin[expander] == MCP_PIN)
00136
00137
            _data[expander] = ~_mcp[mcp++].readGPIOAB();
00138
00139
00140 #endif
```

6.15 Encoder.cpp 73

```
00141 }
00142
00143 DigitalIn_ DigitalIn;
```

6.15 Encoder.cpp

```
00001 #include "Encoder.h"
00002
00003 #ifndef DEBOUNCE_DELAY
00004 #define DEBOUNCE_DELAY 20
00005 #endif
00006
00007 // Encoder with button functionality on MUX
00008 Encoder::Encoder(uint8_t mux, uint8_t pin1, uint8_t pin2, uint8_t pin3, EncPulse_t pulses)
00009 {
00010
       _pin1 = pin1;
_pin2 = pin2;
_pin3 = pin3;
00011
00012
00013
        _pulses = pulses;
_count = 0;
00014
00015
        _state = 0;
00016
00017
        _transition = transNone;
        \_cmdUp = -1;
00018
        \_cmdDown = -1;
00019
        _{\text{cmdPush}} = -1;
00020
00021
        if (mux == NOT_USED) {
         pinMode(_pin1, INPUT_PULLUP);
pinMode(_pin2, INPUT_PULLUP);
00022
00023
         if (_pin3 != NOT_USED) {
00024
00025
00026
              pinMode(_pin3, INPUT_PULLUP);
00027
00028
00029 }
00030
00031 // real time handling
00032 void Encoder::handle()
00033 {
00034
       // collect new state
00035
        _state = ((_state & 0x03) « 2) | (DigitalIn.getBit(_mux, _pin2) « 1) | (DigitalIn.getBit(_mux,
      _pin1));
00036
       // evaluate state change
00037
        if (_state == 1 || _state == 7 || _state == 8 || _state == 14)
00038
00039
00040
00041
        if (_state == 2 || _state == 4 || _state == 11 || _state == 13)
00042
00043
          _count--;
00044
00045
        if (_state == 3 || _state == 12)
00046
00047
          _count += 2;
00048
00049
        if (_state == 6 || _state == 9)
00050
        _count -= 2;
00051
00052
00053
00054
        // optional button functionality
00055
        if (_pin3 != NOT_USED)
00056
00057
          if (DigitalIn.getBit(_mux, _pin3))
00058
          {
00059
             if (_debounce == 0)
00060
               debounce = DEBOUNCE DELAY;
00061
00062
              transition = transPressed;
00063
00064
00065
          else if (_debounce > 0)
00066
            if (--_debounce == 0)
00067
00068
              _transition = transReleased;
00069
00070
00071
00072
00073 }
00074
00075 void Encoder::setCommand(int cmdUp, int cmdDown, int cmdPush)
```

```
_cmdUp = cmdUp;
00078
        _cmdDown = cmdDown;
        _cmdPush = cmdPush;
00079
00080 }
00081
00082 void Encoder::setCommand(XPString_t *cmdNameUp, XPString_t *cmdNameDown, XPString_t *cmdNamePush)
00084
        _cmdUp = XP.registerCommand(cmdNameUp);
        _cmdDown = XP.registerCommand(cmdNameDown);
_cmdPush = XP.registerCommand(cmdNamePush);
00085
00086
00087 }
00088
00089 void Encoder::setCommand(int cmdUp, int cmdDown)
00090 {
00091
        _cmdUp = cmdUp;
        _cmdDown = cmdDown;
_cmdPush = -1;
00092
00093
00094 }
00095
00096 void Encoder::setCommand(XPString_t *cmdNameUp, XPString_t *cmdNameDown)
00097 {
00098
        _cmdUp = XP.registerCommand(cmdNameUp);
        __cmdDown = XP.registerCommand(cmdNameDown);
_cmdPush = -1;
00099
00100
00101 }
00102
00103 int Encoder::getCommand(EncCmd_t cmd)
00104 {
00105
        switch (cmd)
00106
00107
        case encCmdUp:
        return _cmdUp;
break;
00108
00109
00110
        case encCmdDown:
        return _cmdDown;
break;
00111
00112
        case encCmdPush:
00113
         return _cmdPush;
00114
00115
          break;
00116
        default:
00117
          return -1;
00118
          break;
00119
00120 }
00121
00122 void Encoder::processCommand()
00123 {
00124
        if (up())
00125
00126
          XP.commandTrigger(_cmdUp);
00127
00128
00129
00130
          XP.commandTrigger(_cmdDown);
00131
00132
         if ( cmdPush >= 0)
00134
           if (pressed())
00135
00136
            XP.commandStart(_cmdPush);
00137
00138
          if (released())
00139
00140
             XP.commandEnd(_cmdPush);
00141
00142
        }
00143 }
```

6.16 LedShift.cpp

```
00001 #include "LedShift.h"
00002
00003 #define BLINK DELAY 150
00004
00005 LedShift::LedShift(uint8_t pin_DAI, uint8_t pin_DCK, uint8_t pin_LAT, uint8_t pins)
00006 {
00007
        _{count} = 0;
80000
        _timer = millis() + BLINK_DELAY;
        _pin_DAI = pin_DAI;
_pin_DCK = pin_DCK;
00009
00010
        _pin_LAT = pin_LAT;
00011
        _pins = min(pins, 64);
for (int pin = 0; pin < _pins; pin++)
00012
```

6.17 ShiftOut.cpp 75

```
00014
00015
         _mode[pin] = ledOff;
00016
00017
        pinMode(_pin_DAI, OUTPUT);
00018
        pinMode(_pin_DCK, OUTPUT);
        pinMode(_pin_LAT, OUTPUT);
00019
        digitalWrite(_pin_DAI, LOW);
00021
        digitalWrite(_pin_DCK, LOW);
00022
        digitalWrite(_pin_LAT, LOW);
_____alW
__send();
00024 }
00025
00026 // send data
00027 void LedShift::_send()
00028 {
00029
        // get bit masks
       uint8_t dataPort = digitalPinToPort(_pin_DAI);
00030
        uint8_t dataMask = digitalPinToBitMask(_pin_DAI);
00031
        uint8_t clockPort = digitalPinToPort(_pin_DCK);
        uint8_t clockMask = digitalPinToBitMask(_pin_DCK);
00033
00034
        uint8_t oldSREG = SREG;
00035
        noInterrupts();
00036
        uint8_t val = \_count | 0x08;
00037
        for (uint8_t pin = _pins; pin-- > 0;)
00038
00039
           (_mode[pin] & val) > 0 ? *portOutputRegister(dataPort) |= dataMask : *portOutputRegister(dataPort)
      &= ~dataMask;
00040
         *portOutputRegister(clockPort) |= clockMask;
00041
          *portOutputRegister(clockPort) &= ~clockMask;
00042
00043
        // latch LAT signal
        clockPort = digitalPinToPort(_pin_LAT);
clockMask = digitalPinToBitMask(_pin_LAT);
00044
00045
00046
        *portOutputRegister(clockPort) |= clockMask;
        *portOutputRegister(clockPort) &= ~clockMask;
00047
00048
        SREG = oldSREG;
00049 }
00051 void LedShift::setPin(uint8_t pin, led_t mode)
00052 {
00053
        if (pin < _pins)</pre>
00054
00055
         if (_mode[pin] != mode)
00056
          {
           _mode[pin] = mode;
00057
            _update = true;
00058
00059
00060
       }
00061 }
00062
00063 void LedShift::setAll(led_t mode)
00064 {
00065
        for (int pin = 0; pin < _pins; pin++)</pre>
00066
         _mode[pin] = mode;
00067
00068
_update = true;
00071
00072 void LedShift::handle()
00073 {
00074
        if (millis() >= timer)
00075
        {
00076
        _timer += BLINK_DELAY;
00077
          _{count} = (_{count} + 1) & 0x07;
         _update = true;
00078
00079
08000
        if (update)
00081
        {
         _send();
00083
          _update = false;
00084
00085 }
```

6.17 ShiftOut.cpp

```
00001 #include "ShiftOut.h"
00002
00003 ShiftOut::ShiftOut(uint8_t pin_DAI, uint8_t pin_DCK, uint8_t pin_LAT, uint8_t pins)
00004 {
00005    _pin_DAI = pin_DAI;
00006    _pin_DCK = pin_DCK;
00007    _pin_LAT = pin_LAT;
```

```
_{pins} = min(pins, 64);
00009
        pinMode(_pin_DAI, OUTPUT);
00010
        pinMode(_pin_DCK, OUTPUT);
00011
        pinMode(_pin_LAT, OUTPUT);
00012
        digitalWrite(_pin_DAI, LOW);
        digitalWrite(_pin_DCK, LOW);
00013
        digitalWrite(_pin_LAT, LOW);
00015
        _send();
00016 }
00017
00018 // send data
00019 void ShiftOut:: send()
00020 {
00021
        // get bit masks
        uint8_t dataPort = digitalPinToPort(_pin_DAI);
uint8_t dataMask = digitalPinToBitMask(_pin_DAI);
uint8_t clockPort = digitalPinToPort(_pin_DCK);
00022
00023
00024
        uint8_t clockMask = digitalPinToBitMask(_pin_DCK);
00025
        uint8_t oldSREG = SREG;
00027
        noInterrupts();
00028
        for (uint8_t pin = _pins; pin-- > 0;)
00029
          00030
      *portOutputRegister(dataPort) &= ~dataMask;
          *portOutputRegister(clockPort) |= clockMask;
00031
00032
          *portOutputRegister(clockPort) &= ~clockMask;
00033
00034
        // latch LAT signal
        clockPort = digitalPinToPort(_pin_LAT);
clockMask = digitalPinToBitMask(_pin_LAT);
00035
00036
00037
        *portOutputRegister(clockPort) |= clockMask;
00038
        *portOutputRegister(clockPort) &= ~clockMask;
00039
        SREG = oldSREG;
00040 }
00041
00042 void ShiftOut::setPin(uint8_t pin, bool state)
00043 {
        if (pin < _pins)</pre>
00045
        {
00046
          if (state != bitRead(_state[pin » 3], pin & 0x07))
00047
            bitWrite(\_state[pin > 3], pin & 0x07, state);
00048
00049
            _update = true;
00050
00051
00052 }
00053
00054 void ShiftOut::setAll(bool state)
00055 {
00056
        for (int pin = 0; pin < _pins; pin++)</pre>
00058
          bitWrite(_state[pin » 3], pin & 0x07, state);
00059
00060
       _update = true;
00061 }
00062
00063 void ShiftOut::handle()
00064 {
00065
        if (_update)
00066
00067
           send():
          _update = false;
00068
00069
00070 }
```

6.18 Switch.cpp

```
00001 #include "Switch.h"
00002
00003 #ifndef DEBOUNCE_DELAY
00004 #define DEBOUNCE_DELAY 20
00005 #endif
00006
00007 Switch::Switch(uint8_t mux, uint8_t pin)
00008 {
         _mux = mux;
00009
         _pin = pin;
00010
        _r=n - p=n;
_state = switchOff;
_cmdOn = -1;
_cmdOff = -1;
00011
00012
00013
         if (mux == NOT_USED) {
00014
          pinMode(_pin, INPUT_PULLUP);
00015
```

6.18 Switch.cpp 77

```
00017 }
00018
00019 void Switch::handle()
00020 {
00021
        if (_debounce > 0)
00022
       _debounce--;
       {
00024
00025
       else
00026
00027
          SwState_t input = switchOff;
00028
          if (DigitalIn.getBit(_mux, _pin))
00029
          {
00030
            input = switchOn;
00031
00032
          if (input != _state)
00033
00034
            _debounce = DEBOUNCE_DELAY;
            _state = input;
00035
            _transition = true;
00036
00037
00038
       }
00039 }
00040
00041 void Switch::setCommand(int cmdOn)
00042 {
00043
        \_cmdOn = cmdOn;
       \_cmdOff = -1;
00044
00045 }
00046
00047 void Switch::setCommand(XPString t *cmdNameOn)
00048 {
00049
       _cmdOn = XP.registerCommand(cmdNameOn);
00052
00053 void Switch::setCommand(int cmdOn, int cmdOff)
00054 {
00055
        _cmdOn = cmdOn;
00056
       _cmdOff = cmdOff;
00057 }
00058
00059 void Switch::setCommand(XPString t *cmdNameOn, XPString t *cmdNameOff)
00060 {
00061
       _cmdOn = XP.registerCommand(cmdNameOn);
00062
       _cmdOff = XP.registerCommand(cmdNameOff);
00063 }
00064
00065 int Switch::getCommand()
00066 {
00067
        switch (_state)
00068
00069
       case switchOff:
        return _cmdOff;
break;
00070
00071
00072
       case switchOn:
00073
        return _cmdOn;
break;
00074
00075
        default:
00076
         return -1;
00077
         break;
00078
00079 }
08000
00081 void Switch::processCommand()
00082 {
00083
        if (_transition)
00084
       {
00085
         int cmd = getCommand();
00086
          if (cmd >= 0)
00087
00088
            XP.commandTrigger(getCommand());
00089
          _transition = false;
00090
       }
00091
00092 }
00093
00094 // Switch 2
00095
00096 Switch2::Switch2(uint8 t mux, uint8 t pin1, uint8 t pin2)
00097 {
00098
        _{mux} = mux;
00099
        _pin1 = pin1;
        _pin2 = pin2;
00100
       _state = switchOff;
_cmdOff = -1;
_cmdOn1 = -1;
00101
00102
00103
```

```
00104
        \_cmdOn2 = -1;
00105
        if (_mux == NOT_USED)
00106
        pinMode(_pin1, INPUT_PULLUP);
pinMode(_pin2, INPUT_PULLUP);
00107
00108
00109
00110 }
00111
00112 void Switch2::handle()
00113 {
00114
        if (_debounce > 0)
00115
       {
         _debounce--;
00116
00117
00118
        else
00119
          SwState_t input = switchOff;
00120
          if (DigitalIn.getBit(_mux, _pin1))
00121
00122
00123
            input = switchOn1;
00124
00125
          else if (DigitalIn.getBit(_mux, _pin2))
00126
           input = switchOn2;
00127
00128
00129
          if (input != _state)
00130
           _debounce = DEBOUNCE_DELAY;
00131
00132
           _lastState = _state;
            _state = input;
00133
00134
            _transition = true;
00135
00136
00137 }
00138
00139 void Switch2::setCommand(int cmdUp, int cmdDown)
00140 {
        _cmdOn1 = cmdUp;
        _cmdOff = cmdDown;
00142
00143
        \_cmdOn2 = -1;
00144 }
00145
00146 void Switch2::setCommand(XPString_t *cmdNameUp, XPString_t *cmdNameDown)
00147 {
00148
       _cmdOn1 = XP.registerCommand(cmdNameUp);
00149
        _cmdOff = XP.registerCommand(cmdNameDown);
00150
       \_cmdOn2 = -1;
00151 }
00152
00153 void Switch2::setCommand(int cmdOn1, int cmdOff, int cmdOn2)
00154 {
00155
        _cmdOn1 = cmdOn1;
       _cmdOff = cmdOff;
00156
       _cmdOn2 = cmdOn2;
00157
00158 }
00159
00160 void Switch2::setCommand(XPString_t *cmdNameOn1, XPString_t *cmdNameOff, XPString_t *cmdNameOn2)
00161 {
00162
       _cmdOn1 = XP.registerCommand(cmdNameOn1);
        _cmdOff = XP.registerCommand(cmdNameOff);
00163
       _cmdOn2 = XP.registerCommand(cmdNameOn2);
00164
00165 }
00166
00167 int Switch2::getCommand()
00168 {
00169
        if (_cmdOn2 == -1)
00170
00171
          if (_state == switchOn1)
00172
         {
00173
            return _cmdOn1;
00174
00175
          if (_state == switchOff && _lastState == switchOn1)
00176
00177
            return _cmdOff;
00178
00179
          if (_state == switchOn2)
00180
          {
00181
           return _cmdOff;
00182
          if (_state == switchOff && _lastState == switchOn2)
00183
00184
00185
            return _cmdOn1;
00186
00187
00188
        else
00189
          if ( state == switchOn1)
00190
```

6.19 Timer.cpp 79

```
00191
          {
00192
            return _cmdOn1;
00193
00194
          if (_state == switchOff)
00195
00196
            return cmdOff:
00197
00198
          if (_state == switchOn2)
00199
00200
            return _cmdOn2;
         }
00201
00202
00203
       return -1;
00204 }
00205
00206 void Switch2::processCommand()
00207 {
00208
        if (_transition)
00210
         XP.commandTrigger(getCommand());
          _transition = false;
00211
       }
00212
00213 }
```

6.19 Timer.cpp

```
00001 #include "Timer.h"
00002
00003 Timer::Timer(float cycle)
00004 {
00005
setCycle(cycle);
80000
00009 void Timer::setCycle(float cycle)
00010 {
       _cycleTime = (unsigned long)(cycle * 1000.0);
00011
00012 }
00013
00014 bool Timer::elapsed()
00015 {
       _count++;
00016
       unsigned long now = micros();
00017
00018
       if (now > _lastUpdateTime + _cycleTime)
00019
       _lastUpdateTime = now;
return true;
00020
00021
00022
00023
       return false;
00024 }
00025
00026 float Timer::getTime()
00027 {
00028 unsigned long now = micros();
00029
       unsigned long cycle = now - _lastUpdateTime;
       _lastUpdateTime = now;
00030
       return (float)cycle * 0.001;
00031
00032 }
00033
00034 long Timer::count()
00035 {
00036
       long ret = _count;
       _count = 0;
00037
       return ret;
00039 }
```

6.20 XPLPro.cpp

```
00001 // XPLPro.cpp
00002 // Created by Curiosity Workshop, Michael Gerlicher, 2023.
00003 #include "XPLPro.h"
00004
00005 XPLPro::XPLPro(Stream *device)
00006 {
00007    _streamPtr = device;
00008    _streamPtr->setTimeout(XPL_RX_TIMEOUT);
00009 }
00010
```

```
00011 void XPLPro::begin(const char *devicename, void (*initFunction)(void), void (*stopFunction)(void),
      void (*inboundHandler)(int))
00012 {
00013 #ifndef XPL STANDALONE
        Serial.begin(XPL_BAUDRATE);
00014
00015 #endif
      _deviceName = (char *)devicename;
00016
00017
        _connectionStatus = 0;
00018
        _receiveBuffer[0] = 0;
00019
        _registerFlag = 0;
        _xplInitFunction = initFunction;
_xplStopFunction = stopFunction;
00020
00021
        _xplInboundHandler = inboundHandler;
00022
00023 }
00024
00025 int XPLPro::xloop(void)
00026 {
00027
        // handle incoming serial data
        _processSerial();
00028
00029
        // when device is registered, perform handle registrations
00030
        if (_registerFlag)
00031
         _xplInitFunction();
00032
        __registerFlag = 0;
}
00033
00034
00035
        // return status of connection
00036
        return _connectionStatus;
00037 }
00038
00039 // TODO: is a return value necessary? These could also be void like for the datarefs
00040 int XPLPro::commandTrigger(int commandHandle, int triggerCount)
00041 {
00042
        if (commandHandle < 0)</pre>
00043
        {
00044
          return XPL_HANDLE_INVALID;
00045
        sprintf(_sendBuffer, "%c%c,%i,%i%c", XPL_PACKETHEADER, XPLCMD_COMMANDTRIGGER, commandHandle,
00046
      triggerCount, XPL_PACKETTRAILER);
00047
       _transmitPacket();
00048
        return 0;
00049 }
00050
00051 int XPLPro::commandStart(int commandHandle)
00052 {
00053
        if (commandHandle < 0)</pre>
00054
00055
          return XPL_HANDLE_INVALID;
00056
        _sendPacketVoid(XPLCMD_COMMANDSTART, commandHandle);
00057
00058
        return 0:
00059 }
00060
00061 int XPLPro::commandEnd(int commandHandle)
00062 {
00063
        if (commandHandle < 0)</pre>
00064
        {
00065
          return XPL_HANDLE_INVALID;
00066
00067
        _sendPacketVoid(XPLCMD_COMMANDEND, commandHandle);
00068
        return 0;
00069 }
00070
00071 int XPLPro::connectionStatus()
00072 {
00073
        return _connectionStatus;
00074 }
00075
00076 int XPLPro::sendDebugMessage(const char *msq)
00077 {
00078
        _sendPacketString(XPLCMD_PRINTDEBUG, msg);
00079
        return 1;
00080 }
00081
00082 int XPLPro::sendSpeakMessage(const char *msg)
00083 {
00084
       _sendPacketString(XPLCMD_SPEAK, msg);
00085
        return 1;
00086 }
00087
00088 // these could be done better:
00089
00090 void XPLPro::datarefWrite(int handle, int value)
00091 {
00092
        if (handle < 0)</pre>
00093
        {
00094
          return;
00095
        }
```

6.20 XPLPro.cpp 81

```
00096
        sprintf(_sendBuffer, "%c%c,%i,%i%c", XPL_PACKETHEADER, XPLCMD_DATAREFUPDATEINT, handle, value,
     XPL_PACKETTRAILER);
00097
       _transmitPacket();
00098 }
00099
00100 void XPLPro::datarefWrite(int handle, int value, int arrayElement)
00101 {
00102
        if (handle < 0)
00103
       {
00104
          return;
       }
00105
        sprintf(_sendBuffer, "%c%c,%i,%i,%i,%i%c", XPL_PACKETHEADER, XPLCMD_DATAREFUPDATEINTARRAY, handle,
00106
     value, arrayElement, XPL_PACKETTRAILER);
00107 _transmitPacket();
00108 }
00109
00110 void XPLPro::datarefWrite(int handle, long value)
00111 {
00112
       if (handle < 0)</pre>
00113
       {
00114
00115
ZPL_PACKETTRAILER);
00117 transmir
       sprintf(_sendBuffer, "%c%c,%i,%ld%c", XPL_PACKETHEADER, XPLCMD_DATAREFUPDATEINT, handle, value,
       _transmitPacket();
00118 }
00119
00120 void XPLPro::datarefWrite(int handle, long value, int arrayElement)
00121 {
00122
        if (handle < 0)
00123
       {
00124
          return;
00125
sprintf(_sendBuffer, "%c%c,%i,%ld,%i%c", XPL_PACKETHEADER, XPLCMD_DATAREFUPDATEINTARRAY, handle,
       _transmitPacket();
00128 }
00130 void XPLPro::datarefWrite(int handle, float value)
00131 {
00132
        if (handle < 0)
00133
       {
         return:
00134
00135
00136
        char tBuf[20]; // todo: rewrite to eliminate this buffer. Write directly to _sendBuffer
00137
        dtostrf(value, 0, XPL_FLOATPRECISION, tBuf);
00138
        sprintf(_sendBuffer, "%c%c,%i,%s%c",
                XPL PACKETHEADER.
00139
                XPLCMD DATAREFUPDATEFLOAT.
00140
00141
                handle,
00142
                tBuf,
00143
                XPL_PACKETTRAILER);
       _transmitPacket();
00144
00145 }
00146
00147 void XPLPro::datarefWrite(int handle, float value, int arrayElement)
00148 {
00149
        if (handle < 0)
00150
       {
00151
          return;
00152
       char tBuf[20]; // todo: rewrite to eliminate this buffer. Write directly to _sendBuffer dtostrf(value, 0, XPL_FLOATPRECISION, tBuf);
00153
00154
00155
        sprintf(_sendBuffer, "%c%c,%i,%s,%i%c",
00156
                XPL_PACKETHEADER,
00157
                XPLCMD_DATAREFUPDATEFLOATARRAY,
00158
                handle,
00159
                tBuf.
00160
                arrayElement,
00161
                XPL_PACKETTRAILER);
       _transmitPacket();
00162
00163 }
00164
00165 void XPLPro:: sendname()
00166 {
00167
       // register device on request only when we have a valid name
00168
        if (_deviceName != NULL)
00169
          _sendPacketString(XPLRESPONSE_NAME, _deviceName);
00170
00171
       }
00172 }
00173
00174 void XPLPro::sendResetRequest()
00175 {
00176
        // request a reset only when we have a valid name
00177
        if (_deviceName != NULL)
00178
```

```
_sendPacketVoid(XPLCMD_RESET, 0);
00180
00181 }
00182
00183 void XPLPro:: processSerial()
00184 {
        // read until package header found or buffer empty
00186
        while (_streamPtr->available() && _receiveBuffer[0] != XPL_PACKETHEADER)
00187
         _receiveBuffer[0] = (char)_streamPtr->read();
00188
00189
       /// return when buffer empty and header not found
if (_receiveBuffer[0] != XPL_PACKETHEADER)
00190
00191
00192
00193
          return;
00194
        // read rest of package until trailer
00195
     _receiveBufferBytesReceived = _streamPtr->readBytesUntil(XPL_PACKETTRAILER, (char *)&_receiveBuffer[1], XPLMAX_PACKETSIZE_RECEIVE - 1);
00196
00197
       // if no further chars available, delete package
00198
        if (_receiveBufferBytesReceived == 0)
00199
         _receiveBuffer[0] = 0;
00200
00201
          return;
00202
00203
       // add package trailer and zero byte to frame
00204
       _receiveBuffer[++_receiveBufferBytesReceived] = XPL_PACKETTRAILER;
00205
        _receiveBuffer[++_receiveBufferBytesReceived] = 0; // old habits die hard.
00206
        // at this point we should have a valid frame
       _processPacket();
00207
00208 }
00209
00210 void XPLPro::_processPacket()
00211 {
00212
        int tHandle;
        // check whether we have a valid frame
00213
        if (_receiveBuffer[0] != XPL_PACKETHEADER)
00214
00215
00216
          return:
00217
        // branch on receiverd command
00218
00219
        switch (_receiveBuffer[1])
00220
00221
        // plane unloaded or XP exiting
00222
       case XPL_EXITING:
        _connectionStatus = false;
00223
        _xplStopFunction(); break;
00224
00225
00226
00227
       // register device
00228
       case XPLCMD_SENDNAME:
00229
         _sendname();
         _connectionStatus = true; // not considered active till you know my name
00230
00231
         _registerFlag = 0;
         break;
00232
00233
00234
       // plugin is ready for registrations.
00235
       case XPLCMD_SENDREQUEST:
         _registerFlag = 1; // use a flag to signal registration so recursion doesn't occur
00236
00237
00238
00239
        // get handle from response to registered dataref
00240
       case XPLRESPONSE_DATAREF:
        _parseInt(&_handleAssignment, _receiveBuffer, 2);
00241
00242
00243
00244
       // get handle from response to registered command
        case XPLRESPONSE_COMMAND:
00245
00246
         parseInt(& handleAssignment, receiveBuffer, 2);
00247
          break;
00248
00249
        // int dataref received
       case XPLCMD_DATAREFUPDATEINT:
00250
         _parseInt(&tHandle, _receiveBuffer, 2);
00251
         _parseInt(&_readValueLong, _receiveBuffer, 3);
00252
         _readValueFloat = 0;
00253
00254
         _readValueElement = 0;
          _xplInboundHandler(tHandle);
00255
          break;
00256
00257
        // int array dataref received
00258
        case XPLCMD_DATAREFUPDATEINTARRAY:
00259
00260
         _parseInt(&tHandle, _receiveBuffer, 2);
00261
          _parseInt(&_readValueLong, _receiveBuffer, 3);
00262
         _parseInt(&_readValueElement, _receiveBuffer, 4);
          _readValueFloat = 0;
00263
00264
          _xplInboundHandler(tHandle);
```

6.20 XPLPro.cpp 83

```
00265
         break;
00266
00267
        // float dataref received
00268
        case XPLCMD_DATAREFUPDATEFLOAT:
         _parseInt(&tHandle, _receiveBuffer, 2);
00269
         _parseFloat(&_readValueFloat, _receiveBuffer, 3);
00270
00271
         _readValueLong = 0;
00272
         _readValueElement = 0;
          _xplInboundHandler(tHandle);
00273
00274
00275
       // float array dataref received
00276
00277
       case XPLCMD_DATAREFUPDATEFLOATARRAY:
00278
         _parseInt(&tHandle, _receiveBuffer, 2);
00279
          _parseFloat(&_readValueFloat, _receiveBuffer, 3);
00280
         _parseInt(&_readValueElement, _receiveBuffer, 4);
00281
         _readValueLong = 0;
          _xplInboundHandler(tHandle);
break;
00282
00283
00284
00285
        // obsolete?
00286
       case XPLREQUEST_REFRESH:
00287
         break;
00288
00289
       default:
00290
         break;
00291
00292
       // empty receive buffer
       _receiveBuffer[0] = 0;
00293
00294 }
00295
00296 void XPLPro::_sendPacketVoid(int command, int handle) // just a command with a handle
00297 {
00298
        // check for valid handle
00299
        if (handle < 0)</pre>
00300
        {
00301
         return;
00302
00303
       sprintf(_sendBuffer, "%c%c,%i%c", XPL_PACKETHEADER, command, handle, XPL_PACKETTRAILER);
00304
       _transmitPacket();
00305 }
00306
00307 void XPLPro:: sendPacketString(int command, const char *str) // for a string
00308 {
00309
       sprintf(_sendBuffer, "%c%c,\"%s\"%c", XPL_PACKETHEADER, command, str, XPL_PACKETTRAILER);
       _transmitPacket();
00310
00311 }
00312
00313 void XPLPro:: transmitPacket(void)
00314 {
00315
        _streamPtr->write(_sendBuffer);
00316
        if (strlen(_sendBuffer) == 64)
00317
       {
00318
          // apparently a bug in arduino with some boards when we transmit exactly 64 bytes. That took a
     while to track down..
00319
         _streamPtr->print(" ");
00320
00321 }
00322
00323 int XPLPro::_parseString(char *outBuffer, char *inBuffer, int parameter, int maxSize)
00324 {
       int cBeg;
00325
00326
        int pos = 0;
00327
        int len;
00328
00329
        for (int i = 1; i < parameter; i++)</pre>
00330
         while (inBuffer[pos] != ',' && inBuffer[pos] != 0)
00331
00332
         {
00333
           pos++;
00334
00335
         pos++;
00336
        }
00337
00338
        while (inBuffer[pos] != '\"' && inBuffer[pos] != 0)
00339
00340
         pos++;
00341
00342
        cBeg = ++pos;
00343
        while (inBuffer[pos] != '\"' && inBuffer[pos] != 0)
00344
00345
00346
         pos++;
00347
00348
        len = pos - cBeg;
00349
        if (len > maxSize)
00350
```

```
00351
         len = maxSize;
00352
00353
        strncpy(outBuffer, (char *)&inBuffer[cBeg], len);
00354
        outBuffer[len] = 0;
        // fprintf(errlog, "_parseString, pos: %i, cBeg: %i, deviceName: %s\n", pos, cBeg, target);
00355
00356
        return 0;
00357 }
00358
00359 int XPLPro::_parseInt(int *outTarget, char *inBuffer, int parameter)
00360 {
00361
        int cBeq;
00362
        int pos = 0;
00363
        // search for the selected parameter
00364
        for (int i = 1; i < parameter; i++)</pre>
00365
00366
          while (inBuffer[pos] != ',' && inBuffer[pos] != 0)
00367
00368
            pos++;
00369
00370
          pos++;
00371
        // parameter starts here
00372
00373
        cBeg = pos;
00374
        \ensuremath{//} search for end of parameter
00375
        while (inBuffer[pos] != ',' && inBuffer[pos] != 0 && inBuffer[pos] != XPL_PACKETTRAILER)
00376
00377
          pos++;
00378
        ^{\prime}// temporarily make parameter null terminated
00379
00380
        char holdChar = inBuffer[pos];
inBuffer[pos] = 0;
00381
00382
        // get integer value from string
00383
        *outTarget = atoi((char *)&inBuffer[cBeg]);
00384
        // restore buffer
00385
        inBuffer[pos] = holdChar;
00386
        return 0;
00387 }
00388
00389 int XPLPro::_parseInt(long *outTarget, char *inBuffer, int parameter)
00390 {
        int cBeg;
00391
        int pos = 0;
for (int i = 1; i < parameter; i++)</pre>
00392
00393
00394
00395
          while (inBuffer[pos] != ',' && inBuffer[pos] != 0)
00396
00397
            pos++;
00398
00399
         pos++;
00400
00401
        cBeg = pos;
00402
        while (inBuffer[pos] != ',' && inBuffer[pos] != 0 && inBuffer[pos] != XPL_PACKETTRAILER)
00403
          pos++;
00404
00405
00406
        char holdChar = inBuffer[pos];
        inBuffer[pos] = 0;
00407
00408
        *outTarget = atoi((char *)&inBuffer[cBeg]);
00409
        inBuffer[pos] = holdChar;
00410
        return 0;
00411 }
00412
00413 int XPLPro::_parseFloat(float *outTarget, char *inBuffer, int parameter)
00414 {
        int cBeg;
00415
00416
        int pos = 0;
00417
        for (int i = 1; i < parameter; i++)</pre>
00418
00419
          while (inBuffer[pos] != ',' && inBuffer[pos] != 0)
00420
         {
00421
            pos++;
00422
00423
          pos++;
00424
00425
        cBeq = pos;
        while (inBuffer[pos] != ',' && inBuffer[pos] != 0 && inBuffer[pos] != XPL_PACKETTRAILER)
00426
00427
00428
00429
00430
        char holdChar = inBuffer[pos];
        inBuffer[pos] = 0;
*outTarget = atof((char *)&inBuffer[cBeg]);
00431
00432
00433
        inBuffer[pos] = holdChar;
00434
        return 0;
00435 }
00436
00437 int XPLPro::registerDataRef(XPString t *datarefName)
```

6.20 XPLPro.cpp 85

```
00438 {
00439
        long int startTime;
00440
00441
        // registration only allowed in callback (TODO: is this limitation really necessary?)
00442
        if (!_registerFlag)
00443
        {
          return XPL_HANDLE_INVALID;
00445
00446 #if XPL_USE_PROGMEM
       sprintf(_sendBuffer, "%c%c,\"%s\"%c", XPL_PACKETHEADER, XPLREQUEST_REGISTERDATAREF, (wchar_t
00447
      *)datarefName, XPL_PACKETTRAILER);
00448 #else
        sprintf(_sendBuffer, "%c%c,\"%s\"%c", XPL_PACKETHEADER, XPLREQUEST_REGISTERDATAREF, (char
00449
      *)datarefName, XPL_PACKETTRAILER);
00450 #endif
00451
       _transmitPacket();
00452
         handleAssignment = XPL HANDLE INVALID;
00453
       startTime = millis(); // for timeout function
00454
00455
00456
       while (millis() - startTime < XPL_RESPONSE_TIMEOUT && _handleAssignment < 0)</pre>
00457
          _processSerial();
00458
00459
        return _handleAssignment;
00460 }
00461
00462 int XPLPro::registerCommand(XPString_t *commandName)
00463 {
00464
        long int startTime = millis(); // for timeout function
00465 #if XPL_USE_PROGMEM
       sprintf(_sendBuffer, "%c%c,\"%S\"%c", XPL_PACKETHEADER, XPLREQUEST_REGISTERCOMMAND, (wchar_t
00466
      *) commandName, XPL_PACKETTRAILER);
00467 #else
00468
       sprintf(_sendBuffer, "%c%c,\"%s\"%c", XPL_PACKETHEADER, XPLREQUEST_REGISTERCOMMAND, (char
      *)commandName, XPL_PACKETTRAILER);
00469 #endif
00470
        _transmitPacket();
        _handleAssignment = XPL_HANDLE_INVALID;
00471
00472
        while (millis() - startTime < XPL_RESPONSE_TIMEOUT && _handleAssignment < 0)</pre>
00473
          _processSerial();
00474
00475
00476
        return _handleAssignment;
00477 }
00478
00479 void XPLPro::requestUpdates(int handle, int rate, float precision)
00480 {
        char tBuf[20]; // todo: rewrite to eliminate this buffer. Write directly to _sendBuffer?
00481
        dtostrf(precision, 0, XPL_FLOATPRECISION, tBuf);
sprintf(_sendBuffer, "%c%c,%i,%i,%s%c",
00482
00483
00484
                 XPL_PACKETHEADER,
00485
                 XPLREQUEST_UPDATES,
00486
                 handle,
00487
                 rate,
00488
                 tBuf.
00489
                 XPL PACKETTRAILER);
        _transmitPacket();
00490
00491 }
00492
00493 void XPLPro::requestUpdates(int handle, int rate, float precision, int element)
00494 {
00495
        char tBuf[20]; // todo: rewrite to eliminate this buffer. Write directly to _sendBuffer?
        dtostrf(precision, 0, XPL_FLOATPRECISION, tBuf);
sprintf(_sendBuffer, "%c%c,%i,%i,%s,%i%c",
00496
00497
00498
                 XPL_PACKETHEADER,
00499
                 XPLREQUEST_UPDATESARRAY,
00500
                 handle,
00501
                 rate.
00502
                 tBuf.
00503
                 element,
00504
                 XPL_PACKETTRAILER);
        _transmitPacket();
00505
00506 }
00507
00508 void XPLPro::setScaling(int handle, int inLow, int inHigh, int outLow, int outHigh)
00509 {
        sprintf(_sendBuffer, "%c%c,%i,%i,%i,%i,%i%c",
00510
00511
                 XPL_PACKETHEADER,
00512
                 XPLREQUEST_SCALING,
00513
                 handle.
00514
                 inLow,
00515
                 inHigh,
00516
                 outLow,
00517
                 outHigh,
00518
                 XPL_PACKETTRAILER);
O0519 _transmitPacket();
O0520 }
```

00521 00522 #ifndef XPL_STANDALONE 00523 XPLPro XP(&Serial); 00524 #endif

Index

_cmdPush	commandEnd
Button, 18	XPLPro, 50
_delay	commandStart
RepeatButton, 33	XPLPro, 50
_mux	commandTrigger
Button, 18	XPLPro, 50, 51
_pin	connectionStatus
Button, 18	XPLPro, 51
_state	count
Button, 18	Timer, 46
_timer	
RepeatButton, 33	datarefReadElement
_transition	XPLPro, 51
Button, 18	datarefReadFloat
	XPLPro, 52
addMux	datarefReadInt
Digitalln_, 19	XPLPro, 52
AnalogIn, 9	datarefWrite
AnalogIn, 10	XPLPro, 52–54
calibrate, 10	DigitalIn.cpp, 71
handle, 11	DigitalIn.h, 62
raw, 11	Digitalln_, 19
setRange, 11	addMux, 19
setScale, 11	Digitalln_, 19
value, 12	getBit, 20
AnalogIn.cpp, 68	handle, 20
AnalogIn.h, 60	setMux, 20
h a min	down
begin	Encoder, 23
XPLPro, 49	
Button, 12	elapsed
_cmdPush, 18	Timer, 47
_mux, 18	Encoder, 21
_pin, 18	down, 23
_state, 18	Encoder, 22
_transition, 18	engaged, 23
Button, 14	getCommand, 23
engaged, 15	handle, 24
getCommand, 15	handleXP, 24
handle, 15	pos, 24
handleXP, 16	pressed, 24
pressed, 16	processCommand, 24
processCommand, 16	released, 25
released, 17	setCommand, 25, 26
setCommand, 17	up, 26
Button.cpp, 70	Encoder.cpp, 73
Button.h, 61	Encoder.h, 63
calibrate	engaged
	Button, 15
AnalogIn, 10	Encoder, 23

88 INDEX

getBit	raw
Digitalln_, 20	AnalogIn, 11
getCommand	registerCommand
Button, 15	XPLPro, 54
Encoder, 23	registerDataRef
Switch, 37	XPLPro, 55
Switch2, 42	released
getTime	Button, 17
Timer, 47	Encoder, 25
	RepeatButton, 29
handle	_delay, 33
AnalogIn, 11	_timer, 33
Button, 15	handle, 32
Digitalln_, 20	handleXP, 32
Encoder, 24	RepeatButton, 31
LedShift, 28	requestUpdates
RepeatButton, 32	XPLPro, 55, 56
ShiftOut, 34	, ,
Switch, 37	sendDebugMessage
Switch2, 42	XPLPro, 56
handleXP	sendResetRequest
Button, 16	XPLPro, 56
Encoder, 24	sendSpeakMessage
RepeatButton, 32	XPLPro, 57
Switch, 37	set
Switch2, 42	LedShift, 28
SWILCHZ, 42	set all
LedShift, 27	LedShift, 28
handle, 28	setAll
LedShift, 27	LedShift, 28
set, 28	
set_all, 28	ShiftOut, 34
	setCommand
setAll, 28	Button, 17
setPin, 29	Encoder, 25, 26
LedShift.cpp, 74	Switch, 38, 39
LedShift.h, 64	Switch2, 43, 44
main.cpp, 59, 60	setCycle
пап.срр, 39, 60	Timer, 47
off	setMux
Switch, 37	DigitalIn_, 20
Switch2, 42	setPin
on	LedShift, 29
Switch, 38	ShiftOut, 35
on1	setRange
Switch2, 43	AnalogIn, 11
_	setScale
on2	AnalogIn, 11
Switch2, 43	setScaling
pos	XPLPro, 57
Encoder, 24	ShiftOut, 33
pressed	handle, 34
•	setAll, 34
Button, 16 Encoder, 24	setPin, 35
Encoder, 24	ShiftOut, 34
processCommand	ShiftOut.cpp, 75
Button, 16	ShiftOut.h, 64
Encoder, 24	Switch, 35
Switch, 38	getCommand, 37
Switch2, 43	handle, 37
	•

INDEX 89

la a radii a VD 0.7	VDI Due 1112 70
handleXP, 37 off, 37	XPLPro.cpp, 79 XPLPro.h, 66
on, 38	XI El 16.11, 00
processCommand, 38	
setCommand, 38, 39	
Switch, 36	
value, 40	
Switch.cpp, 76	
Switch, 64	
Switch2, 40 getCommand, 42	
handle, 42	
handleXP, 42	
off, 42	
on1, 43	
on2, 43	
processCommand, 43 setCommand, 43, 44	
Switch2, 41	
value, 45	
Timer, 45	
count, 46 elapsed, 47	
getTime, 47	
setCycle, 47	
Timer, 46	
Timer.cpp, 79	
Timer.h, 66	
up =	
Encoder, 26	
value	
AnalogIn, 12	
Switch, 40	
Switch2, 45	
xloop	
XPLPro, 57	
XPLPro, 48	
begin, 49 commandEnd, 50	
commandStart, 50	
commandTrigger, 50, 51	
connectionStatus, 51	
datarefReadElement, 51	
datarefReadFloat, 52	
datarefReadInt, 52 datarefWrite, 52–54	
registerCommand, 54	
registerDataRef, 55	
requestUpdates, 55, 56	
sendDebugMessage, 56	
sendResetRequest, 56	
sendSpeakMessage, 57	
setScaling, 57 xloop, 57	
XPLPro, 49	