# Module Interface Specification for Truss Tool

Maryam Valian

March 30, 2023

# 1 Revision History

Date	Version	Notes
16/03/2023	1.0	Initial Draft
17/03/2023	1.1	Update Control module
19/03/2023	1.2	Update formulas
20/03/2023	1.3	Update other modules
23/03/2023	1.4	Update based on first Reviewer Feedback
30/03/2023	1.5	Update based on second Reviewer Feedback

# 2 Symbols, Abbreviations and Acronyms

See SRS Documentation at here.

# Contents

1	Rev	ision History											
2	Syn	abols, Abbreviations and Acronyms											
3	Introduction												
4	Not	ation											
5	Mo	dule Decomposition											
3	MIS	MIS of Control module											
	6.1	Module	•										
	6.2	Uses											
	6.3	Syntax											
		6.3.1 Exported Constants											
		6.3.2 Exported Access Programs											
	6.4	Semantics											
		6.4.1 State Variables											
		6.4.2 Environment Variables											
		6.4.3 Assumptions											
		6.4.4 Access Routine Semantics											
		6.4.5 Local Functions											
7	MIS	of Input Module											
	7.1	Module											
	7.2	Uses											
	7.3	Syntax											
		7.3.1 Exported Constants											
		7.3.2 Exported Access Programs											
	7.4	Semantics											
		7.4.1 State Variables											
		7.4.2 Environment Variables	•										
		7.4.3 Assumptions											
		7.4.4 Access Routine Semantics	•										
	MIS	S of Specification Parameters											
	8.1	Module	•										
	8.2	Uses											
	8.3	Syntax											
		8.3.1 Exported Constants											
		8.3.2 Exported Access Programs											
	8 4	Semantics											

		8.4.1 State Variables	8
		8.4.2 Environment Variables	8
	8.5	MIS of Support Reaction Module	8
	8.6	Module	8
	8.7	Uses	8
	8.8		8
		·	8
		•	9
	8.9		9
			9
			9
			9
		•	9
9	MIS	of Internal Forces Module	9
	9.1	Module	9
	9.2	Uses	0
	9.3	Syntax	0
		9.3.1 Exported Constants	0
		9.3.2 Exported Access Programs	0
	9.4	Semantics	0
		9.4.1 State Variables	0
		9.4.2 Environment Variables	
		9.4.3 Assumptions	
		9.4.4 Access Routine Semantics	
	9.5	MIS of Output Verification Module	
	9.6	Module	
	9.7	Uses	
	9.8	Syntax	
	0.0	9.8.1 Exported Constants	
		9.8.2 Exported Access Programs	
	9.9	Semantics	
	0.0	9.9.1 State Variables	
		9.9.2 Environment Variables	
		9.9.3 Assumptions	
		9.9.4 Access Routine Semantics	
		9.9.5 Assumptions	
	0.10	MIS of Output Module	
		Module	
		Uses	
		Syntax	
	5.10	9.13.1 Exported Constants	
		9.13.1 Exported Constants	
		7 To 7 TO A DOUBELL ALLESS LITURIALIS	_/

9.14 Se	ics
9.1	State Variables
9.1	Environment Variables
9.1	Assumptions
9.15 .	
9.1	Access Routine Semantics
10.4	
$10   \mathrm{Appen}$	14

# 3 Introduction

The following document details the Module Interface Specifications for Truss Tool is software designed for engineers and students to analyze a truss.

Complementary documents include the System Requirement Specifications and Module Guide. The full documentation and implementation can be found at Truss Tool repository.

# 4 Notation

The structure of the MIS for modules comes from Hoffman and Strooper (1995), with the addition that template modules have been adapted from Ghezzi et al. (2003). The mathematical notation comes from Chapter 3 of Hoffman and Strooper (1995). For instance, the symbol := is used for a multiple assignment statement and conditional rules follow the form  $(c_1 \Rightarrow r_1|c_2 \Rightarrow r_2|...|c_n \Rightarrow r_n)$ . Capital letters are used to indicate sequenced data type.

The following table summarizes the primitive data types used by Truss Tool.

Data Type	Notation	Description
character	char	a single symbol or digit
integer	$\mathbb{Z}$	a number without a fractional component in $(-\infty, \infty)$
natural number	N	a number without a fractional component in $[1, \infty)$
real	$\mathbb{R}$	any number in $(-\infty, \infty)$

The specification of Truss Tool uses some derived data types: sequences, strings, and tuples. Sequences are lists filled with elements of the same data type. Strings are sequences of characters. Tuples contain a list of values, potentially of different types. In addition, Truss Tool uses functions, which are defined by the data types of their inputs and outputs. Local functions are described by giving their type signature followed by their specification.

# 5 Module Decomposition

The following table is taken directly from the Module Guide document for this project.

Level 1	Level 2
Hardware-Hiding Module	
	Input parameters module
	Input verification module
	Specification parameters module
Behaviour-Hiding Module	Output format module
	Output verification module
	Support reactions module.
	Force decomposing module
	Internal force module
	Control module
	Sequence data structure module
Software Decision Module	linear equation solver module

Table 1: Module Hierarchy

#### MIS of Control module 6

#### 6.1Module

Main

#### 6.2 Uses

Input Module, Reaction Module, Internal Forces Module, Output Verification Module

#### 6.3 Syntax

#### 6.3.1**Exported Constants**

Not applicable.

#### 6.3.2**Exported Access Programs**

Name	In	Out	Exceptions
Main	-	-	-

#### **Semantics** 6.4

#### 6.4.1 State Variables

# from R1 and R2:

 $n:\mathbb{N}$ 

 $m: \mathbb{N}$ 

 $J_n:\mathbb{R}$ 

 $M_m: \mathbb{N}$ 

 $F_m: \mathbb{R}$ 

 $sp: \mathbb{N}$ 

 $sr: \mathbb{N}$ 

# from R3:

 $px: \mathbb{R}$ 

 $py: \mathbb{R}$ 

 $ry: \mathbb{R}$ 

# from R4:

 $I_m:\mathbb{R}$ 

for dor't have state voir.
I have state voir.
I have state voir. put your input in I put your input in I trust module. You don't trust module. State info.

It it does, then you should now those oning e, an output file

#### 6.4.2**Environment Variables**

This module has external interaction with an input file, an output file.

#### 6.4.3 Assumptions

The path and the name of the given input file are correct.

#### **Access Routine Semantics** 6.4.4

Main():

• transition: Modifies the state of the Input module and the environment variables for the Output modules by following these steps:

Get (filename: String) from user which indicates input file. LoadParams(filename). #Find Support reactions  $(P_x, P_y, R_y)$ 

$$P_x = -\sum F_x$$

$$A = \begin{bmatrix} 1 & 1 \\ J_x(sp) & J_x(sr) \end{bmatrix}$$

$$B = \begin{bmatrix} -\sum F_y(i) \\ -\sum (J_x(i) * F_y(i)) \end{bmatrix}$$

an with this (Solve is not defined thywhere), #Find Internal Forces  $I_m$  unto find J such that  $\theta = Decomp(n, m, J, M)$ 

 $\#Compute\ a_{ij}, b_j\ elements\ of\ A, B\ from\ equilibrium\ equations:$  $a_{ij} = I_m * \cos \theta_m, b_j = \sum_x All \text{ forces and reactions at } j$ 

 $a_{ij} = I_m * \sin \theta_m, b_j = \sum_{n} All \text{ forces and reactions at } j$ 

$$I = Solve(A, B)$$
# Output  $P_x, P_y, R_y, I$ 

verify-Output $(P_x, P_y, R_y, I)$ output(file-name, $P_x$ ,  $P_y$ ,  $R_y$ , I)

- output: output file
- exception: Input file not found

John Var July Show Vacable program one program one about and appender and appender and

#### **Local Functions** 6.4.5

None.

# MIS of Input Module

#### Module 7.1

#### 7.2 Uses

#### **Syntax** 7.3

7 MIS of	'Input	Mo	dule
'.1 Module	)		to 80 ll
nputs			add comments soldle
7.2 Uses			John Jages of your
nput Verification	n Module		fe of he follows
7.3 Syntax			What we wanted
	In	Out	Exceptions
Name	In string	Out -	Exceptions Input File Error
Name load_params			
Name load_params verify_params			Input File Error
Name load_params verify_params n		-	Input File Error
Name load_params verify_params $n$ $m$ $J_n$		- - N	Input File Error
Name load_params verify_params $n$ $m$ $J_n$		- - N N	Input File Error
Name load_params verify_params n m		- - N N R	Input File Error
Name load_params verify_params $n$ $m$ $J_n$ $M_m$		- - N N R	Input File Error

#### **Exported Constants** 7.3.1

Not applicable.

#### **Exported Access Programs** 7.3.2

Name	In	Out	Exceptions
Inputs	input plain text file	Parameters	FileError

#### **Semantics** 7.4

#### State Variables

# from R1 and R2:

 $n: \mathbb{N}$  $m:\mathbb{N}$  J<sub>n</sub>  $\mathbb{R}$  des this note sense? What II  $\mathbb{J}_n$ ? It low the first  $\mathbb{R}$  with the  $\mathbb{R}$   $\mathbb{R}$   $\mathbb{R}$   $\mathbb{R}$   $\mathbb{R}$   $\mathbb{R}$   $\mathbb{R}$ 

#### 7.4.2 Environment Variables

InputFile: sequence of strings in the text file.

## 7.4.3 Assumptions

 $sr: \mathbb{N}$ 

- Load parameters will be called before the values of any state variables will be accessed.
- The file contains the string equivalents of the numeric values for each input parameter. The order is important.

#### 7.4.4 Access Routine Semantics

Load-Parameter():

- transition: Modifies the state variables from the input file:
  - Read sequentially from file and loads state variables from R1 and R2.
  - verify-input()
- output: None
- exception: file-Error, input-type-mismatch-Error

Verify-Input():

- transition: Modifies the state variables from the input file:
  - $-\,$  Read constants from specification module.
  - Check constraints given in Table 2.
- output: None
- exception: Bad-parameters-Error

Table 2: Constraint check table

. 7	Constraint	Error
who is J r.J.?	$n_{min} \le n \le n_{max}$	BadInputSize
(150)	$m_{min} \le m \le m_{max}$	${\bf BadInputSize}$
1 Col 13	m < n	BadInputSize
Cer	$ J  \neq n$	In consistent Input
	$ M  \neq m$	In consistent Input
Jilk 7	$ F  \neq n$	In consistent Input
	$J_{min} \le J_j \le J_{max}$	BadInputSize
1500	$F_{min} \leq F_j \leq F_{max}$	BadInputSize
) B	$M_{j,0} = M_{j,1}$	BadMember
segue	Sp > n, Sp < 0	Badsupport
112 00	Sr > n, Sr < 0	BadSupport
Jisa Segverre? Jisa Segverre?	Sp = Sr = 0	NoSupportDefined
We XI w		

# MIS of Specification Parameters

#### Module 8.1

Specification

#### 8.2 Uses

None.

#### 8.3 **Syntax**

#### **Exported Constants** 8.3.1

what we id )? # From Table.2 SRS:  $n_{min} := 3$  $n_{max} := 20$  $m_{min} := 3$  $m_{max} := 30$  $J_{max}(i,j) := 200$  $J_{min}(i,j) := 0$  $F_{max} := 35000$ 

 $F_{min} := -35000$ 

# 8.3.2 Exported Access Programs

# 8.4 Semantics

## 8.4.1 State Variables

None.

## 8.4.2 Environment Variables

None.

# 8.5 MIS of Support Reaction Module

## 8.6 Module

React

# 8.7 Uses

Sequence data structure module. linear equation solver module.

# 8.8 Syntax

Name	In	Out	Exceptions
React	param	s reacts	ReactionFailed Error
n	$\mathbb{N}$	-	
$F_{j}$	$\mathbb{R}$	-	
$J_{j}$	$\mathbb{R}$	-	
Sp	$\mathbb{N}$	-	
Sr	$\mathbb{N}$	-	
$P_x$	-	$\mathbb{R}$	
$P_y$	-	$\mathbb{R}$	
$R_y$	-	$\mathbb{R}$	

## 8.8.1 Exported Constants

None.

## 8.8.2 Exported Access Programs

Name	In		Out	Exceptions
React	(J, F) $array of real, sp, sr$ $Integer)$	:	$(P_x, P_y, R_y : Real)$	ReactFailed

## 8.9 Semantics

### 8.9.1 State Variables

None.

#### 8.9.2 Environment Variables

None.

## 8.9.3 Assumptions

None.

#### 8.9.4 Access Routine Semantics

• Output:

$$Out := P_x = -\sum F_x$$

$$A = \begin{bmatrix} 1 & 1 \\ J_x(sp) & J_x(sr) \end{bmatrix}$$

$$-\sum F_y(i)$$

$$B = \begin{bmatrix} -\sum F_y(i) \\ -\sum (J_x(i) * F_y(i)) \end{bmatrix}$$

$$Out := (P_y, R_y) = Solve(A, B)$$

# 9 MIS of Internal Forces Module

## 9.1 Module

Internal

#### 9.2 Uses

Force decomposing module Sequence data structure module linear equation solver module

# 9.3 Syntax

## 9.3.1 Exported Constants

None.

#### 9.3.2 Exported Access Programs

Name	In	Out	Exceptions
Decomp	$\theta(M_m): \mathbb{R}^2 \to \mathbb{R}$	$\Theta_m$	decompFailed
Internal	$I_m(F_j,\theta_m): \mathbb{R} * \mathbb{R}^2 \to$	$I_m$	Internal Failed
	$\mathbb R$		

Exception decompFailed will show to the user if a correct member is not defined by the user so the angle between the member and the x-axis cannot be calculated. Exception InternalFailed will show to the user if the equations cannot be solved.

## 9.4 Semantics

#### 9.4.1 State Variables

None.

#### 9.4.2 Environment Variables

None.

#### 9.4.3 Assumptions

None.

#### 9.4.4 Access Routine Semantics

• Output: Out := I where:

$$a_{ij} = I_m * \cos \theta_m, b_j = \sum_x All \text{ forces and reactions at } j$$

There are to many whole here.

to this blocomport Theral? Therefurations actions at j One of these functions (& not defined in the spec.

$$a_{ij} = I_m * \sin \theta_m, b_j = \sum_y All \text{ forces and reactions at } j$$
 
$$I = Solve(A, B)$$

# 9.5 MIS of Output Verification Module

## 9.6 Module

verify-out

## 9.7 Uses

None.

# 9.8 Syntax

## 9.8.1 Exported Constants

None.

## 9.8.2 Exported Access Programs

Name	In			Out	Exceptions
Verify-0ut	$check(I_m, J_j)$	:	$\mathbb{R}$ *	Valid/NotValid	verifyFailed
	$\mathbb{R} \to Boolean$				

# 9.9 Semantics

## 9.9.1 State Variables

None.

#### 9.9.2 Environment Variables

None.

## 9.9.3 Assumptions

None.

## 9.9.4 Access Routine Semantics

• Exception: Exep:= $(\sum (I_m(n) + F_m(n), P_x(n), P_y(n), R_y(n)) \neq 0) \Rightarrow VerifyFailed$ 

## 9.9.5 Assumptions

None.

# 9.10 MIS of Output Module

# 9.11 Module

Output

# 9.12 Uses

None.

# 9.13 Syntax

## 9.13.1 Exported Constants

output file name.

## 9.13.2 Exported Access Programs

None.

## 9.14 Semantics

#### 9.14.1 State Variables

None.

## 9.14.2 Environment Variables

output file

#### 9.14.3 Assumptions

None.

#### 9.15

Assumptions None.

#### 9.15.1 Access Routine Semantics

• transition: Write to file the following: the input parameters from Param, and the calculated values  $I_m, P_x, P_y, R_y$ .

# References

Carlo Ghezzi, Mehdi Jazayeri, and Dino Mandrioli. Fundamentals of Software Engineering. Prentice Hall, Upper Saddle River, NJ, USA, 2nd edition, 2003.

Daniel M. Hoffman and Paul A. Strooper. Software Design, Automated Testing, and Main-

there is some confusion on how to
there is some confusion on how to
write a mathematical spec. Focus on the
write a mathematic

# 10 Appendix

Not applicable.