### **Overview**

This example implements the host and the device, where the KHCI works as a host and the EHCI works as a device. The host supports the keyboard device and device works as a mouse when connecting to the PC.

### **System Requirement**

### Hardware requirements

- · Mini/micro USB cable
- USB A to micro AB cable
- Hardware (Tower module/base board, and so on) for a specific device
- Personal Computer(PC)

#### **Software requirements**

 The project path is: <SDK Install>/boards/<board>/usb examples/usb keyboard2mouse/<rtos>/<toolchain>.

Note

The <rtos> is Bare Metal or FreeRTOS OS.

## **Getting Started**

#### **Hardware Settings**

• The Jumper settings: J13 1-2, J9 7-8, Remove all jumpers from J23.

Note

First, set the hardware jumpers (Tower system/base module) to default settings.

#### Prepare the example

- 1. Download the program to the target board.
- 2. Power off the target board and power on again.
- 3. Connect devices to the board and connect a USB cable between the PC and the USB device port of the board.

Note

For detailed instructions, see the appropriate board User's Guide.

# Run the example

- 1. Connect the board UART to the PC and open the COM port in a terminal tool.
- 2. Plug in a hub or a keyboard device to the KHCI port. The attached information prints out in the terminal.
- 3. Plug in the device EHCI port into the PC. An HID-compliant mouse is enumerated in the Device Manager.
- 4. Press <w, s, a, d> in the keyboard, which causes the mouse to move.
  - Press 'w', the mouse move up.
  - Press 's', the mouse move down.
  - Press 'a', the mouse move left.
  - Press 'd', the mouse move right.