DMX-Control

Manual


Introduction:

DMX-Control was made because I could not find a logic reason to spend my money on a DMX to USB converter just to control a single Laser when I had an Arduino lying around.

So I searched the internet for such projects and I found one base on the IC 'SN 75176' and decided to build it

Worked fine but there was no possibility to control it without the terminal so I wrote this Application (in VB.NET).

Controls:



- 1 Sliders: Move to adjust the DMX-Value of the corresponding Channel
- 2 Channel Selection: Here you can set which slider controls which DMX-Channel
- 3 Port Selection: Here you can select the Port to which your Arduino is connected
- 4 Buttons:
 - a) Offline: Activated by default, deactivate to connect to Arduino. As long as this button is activated nothing will be sent to your Arduino thus nothing will change on DMX-Line
 - b) Reset All: Will set all DMX-Channels to 0
 - c) Blackout: Will set all DMX-Channels to 0 and return to previous Values when deactivated (Warning! Does not restore Scenes. This is hopefully being fixed in the future...)
- 5 Channel Sets: Here you can choose between 3 channel sets so you can effectively control 30 different channels. Slider Values will be stored when you switch sets
- 6 Save Button: Saves your Scenes and Programs to 'My Documents/DMX-Control.txt' (Warning! Does not store Slider Channels and Program Speed)
- 7 Load Button: Loads your Scenes and Programs from 'My Documents/DMX-Control.txt' (Warning! Does not load Slider Channels and Program Speed)

- 8 Program Menu: Here you can play and record up to 9 different programs and set the speed at which they are played
- 9 Scene Selection: Here you can set up to 18 different scenes (Warning! Does not work yet with scenes despite claimed to do so in help)

Setting Prorams:

To record a program you have to follow these simple steps:

- 1. Click the 'Record' button
- 2. Click the button of the program you want to record (1-9)
- 3. Set the sliders to match the setting you want as first scene in the program
- 4. Click the 'Save Position' button (If the program was empty the number should now turn red signalizing it is not empty anymore)
- 5. Repeat for the next scenes in program (up to 255 per program. Don't forget to click 'Save Position' for every new setting!)
- 6. When you are finished with your setting click 'Record' again
- 7. You can now set the speed for the program (time waited between changing of scenes)
- 8 Finished

Your program can now be played by clicking on the corresponding button. Click again to stop playback.

Setting Scenes:

To set a scene, do the following:

- 1. Set the sliders to the matching positions for your scene
- 2. Click 'Record' in 'Program Menu'
- 3. Click the scene you want to store your setting to
- 4. Finished

You can now activate your scene by clicking on the corresponding button.

If you find a bug please report it at DMX-Control Issues

If you think there is something missing in this manual or if you think there's a feature that just needs to be added to this program you can also report them at the link above with 'Request' (for manual edits) or 'Idea' (for feature ideas) Label