# CPU Pipelining

CS/COE 1541 (Fall 2020) Wonsun Ahn




# Clocking Review


Stuff you learned in CS 447



## Logic components


Do you remember what all these do?





#### Uses of a Decoder

- Decodes an instruction to a bunch of control signals.
  - E.g. a binary decoder:



#### **Truth Table for Decoder**


Α	В	Q0	Q1	Q2	Q3
0	0	1	0	0	0
0	1	0	1	0	0
1	0	0	0	1	0
1	1	0	0	0	1

You can come up with any truth table and make a decoder for it!




## Uses of a Multiplexer

No problem in fanning out one signal to two points




- Cannot connect two signals to one point
  - Must use a multiplexer to select between the two





## The clock signal

• The clock is a signal that alternates regularly between 0 and 1:



- Bits are latched on to registers and flip-flops on rising edges
- In between rising edges, bits propagate through the logic circuit
  - o Composed of ALUs, muxes, decoders, etc.
  - o Propagation delay: amount of time it takes from input to output



#### Critical Path

- Critical path: path in a circuit that has longest propagation delay
   Determines the overall clock speed.
  - A D Q D Q OUT Select
  - The ALU and the multiplexer both have a 5 ns delay
- How fast can we clock this circuit?
  - $\circ$  Is it 1 / 5 ns (5 × 10<sup>-9</sup>s) = 200 MHz?
  - $\circ$  Or is it 1 / 10 ns (10 × 10<sup>-9</sup>s) = 100 MHz?  $\checkmark$



## MIPS Review

Stuff you learned in CS 447



#### The MIPS ISA - Registers


- MIPS has 32 32-bit registers, with the following usage conventions
  - o But really, all are general purpose registers (nothing special about them)

Name	Register number	Usage
\$zero	0	the constant value 0 (can't be written)
\$at	1	assembler temporary
\$v0-\$v1	2-3	values for results and expression evaluation
\$a0-\$a3	4-7	function arguments
\$t0-\$t7	8-15	unsaved temporaries
\$s0-\$s7	16-23	saved temporaries (like program variables)
\$t8-\$t9	24-25	more unsaved temporaries
\$k0-\$k1	26-27	reserved for OS kernel
\$gp	28	global pointer
\$sp	29	stack pointer
\$fp	30	frame pointer
\$ra	31	return address



#### The MIPS ISA - Memory

- MIPS is a RISC (reduced instruction set computer) architecture
- It is also a *load-store* architecture
  - All memory accesses performed by load and store instructions
- Memory is a giant array of 2<sup>32</sup> bytes




#### The MIPS ISA - Memory

• Loads move data *from* memory *into* the registers.

This is the address, and it means "the value of \$s4 + 8."

• Stores move data *from* the registers *into* memory.

\$t0 is the SOURCE!





#### The MIPS ISA – Flow control

• Jump and branch instructions change the flow of execution.

- **j** : jumps *unconditionally*
- jumps to \_top

```
li $s0, 10
—loop:

# ....
addi $s0, $s0, -1
bne $s0, $zero, _loop
jr $ra
```

```
bne : jumps conditionally
If $s0 != $zero, jumps to _loop
If $s0 == $zero, continues to jr $ra
```




#### Phases of instruction execution

- In most architectures, there are five phases:
  - **1. IF** (Instruction Fetch) get next instruction from memory
  - 2. ID (Instruction Decode) figure out what instruction it is
  - **3. EX** (Execute ALU) do any arithmetic
  - **4. MEM** (Memory) read or write data from/to memory
  - **5. WB** (Register Writeback) write any results to the registers
- Sometimes these phases are chopped into smaller stages



## A simple single-cycle implementation



• An instruction goes through IF/ID/EX/MEM/WB in one cycle



## "Minimal MIPS"



#### It's a "subset" of MIPS


- For pedagogical (teaching) purposes
- Contains only a minimal number of instructions:
  - o lw, sw, add, sub, and, or, slt, beq, and j
  - Other instructions are mostly variations on these
- Let's review the Minimal MIPS CPU focusing on the control signals
  - o Again, these control signals are decoded from the instruction



## The Minimal MIPS single-cycle CPU

University of **Pittsburgh** 

• A more detailed view of the 5-phase implementation




#### Control signals


- Registers
  - RegDataSrc: controls source of a register write (ALU / memory)
  - RegWrite: enables a write to the register file
  - o src1, src2, dst: the register number for each respective operand
- ALU
  - ALUSrc: whether second operand of ALU is a register / immediate
  - ALUOp: controls what the ALU will do (add, sub, and, or etc)
- Memory
  - MemWrite: enables a write to data memory
- PC
  - PCSrc: controls source of next PC (PC + 4 / PC + 4 + imm)
- → All these signals are decoded from the instruction!




#### How an add/sub/and/or/slt work



#### How an **Iw** works




#### How an **sw** works



#### What about **beq**?


- Compares numbers by subtracting and see if result is 0
  - If result is 0, we set PCSrc to use the branch target.
  - Otherwise, we set PCSrc to PC + 4.





## How a **beq** works


Pittsburgh



## What about j?


• We have to add another input to the PCSrc mux.

j top





## A Single-cycle Implementation is not Optimal



- Why? Since the *longest* critical path must be chosen for cycle time
  - And there is a wide variation among different instructions




## A Single-cycle Implementation is not Optimal

- In our CPU, the **lw** instruction has the longest critical path
  - Must go through all 5 stages: IF/ID/EX/MEM/WB
  - Whereas add goes through just 4 stages: IF/ID/EX/WB
- If each phase takes 1 ns each, cycle time must be 5 ns:
  - Because it needs to be able to handle lw, which takes 5 ns
  - o **add** also takes 5 ns when it could have been done in 4 ns
- Q) If **Iw** is 1% and **add** is 99% of instruction mix, what is the average instruction execution time?
- A) Still 5 ns! Even if add is 99% of instructions!



## A Multi-cycle Implementation

• It takes one cycle for each phase through the use of internal latches





## A Multi-cycle Implementation is Faster!

- Now each instruction takes different number of cycles to complete
  - Iw takes 5 cycles: IF/ID/EX/MEM/WB
  - o add takes 4 cycles: IF/ID/EX/WB
- If each phase takes 1 ns each as before:
  - Iw takes 5 ns and add takes 4 ns
- Q) If **lw** is 1% and **add** is 99% of instruction mix, what is the average instruction execution time?
- A) 0.01 \* 5 ns + 0.99 \* 4 ns = 4.01 ns (25% faster than single cycle)
- \* Caveat: there is some delay due to the added latches but net win



#### And we can do even better!

- Did you notice?
  - When an instruction is on a particular phase (e.g. IF) ...
  - o ... other phases (ID/EX/MEM/WB) are not doing any work!
- Our CPU is getting chronically underutilized!
  - If CPU is a factory, 80% (4/5) of the workers are idling!
- Car factories create an assembly line to solve this problem
  - No need to wait until a car is finished before starting on next one
  - Our CPU is going to use a *pipeline* (similar concept)



# Pipelining Basics



## Improving Washer / Dryer / Closet Utilization


If washer works on next load immediately after passing on to dryer
 → Washer gets higher utilization → Improves overall throughput!





## Multi-cycle instruction execution


• Let's watch how an instruction flows through the datapath.





## Pipelined instruction execution


• Pipelining is just an extension of that idea!





## Pipelining Timeline

• This type of parallelism is called *pipelined parallelism*.





## A Pipelined Implementation is even Faster!

- Again each instruction takes different number of cycles to complete
  - Iw takes 5 cycles: IF/ID/EX/MEM/WB
  - o add takes 4 cycles: IF/ID/EX/WB
- If each stage takes 1 ns each:
  - Iw takes 5 ns and add takes 4 ns
- Q) The average instruction execution time (given 100 instructions)?
- A) (99 ns + 5 ns) / 100 = 1.04 ns
  - Assuming last instruction is a **lw** (a 5-cycle instruction)
  - A ~5X speed up from single cycle!



## Pipelined vs. Multi-cycle vs. Single-cycle

What happened to the three components of performance?

$$\frac{\text{instructions}}{\text{program}}$$
 X  $\frac{\text{cycles}}{\text{instructions}}$  X  $\frac{\text{seconds}}{\text{cycle}}$ 

Architecture	Instructions	СРІ	Cycle Time (1/F)
Single-cycle	Same	1	5 ns
Multi-cycle	Same	4~5	1 ns
Pipelined	Same	1	1 ns

- Compared to single-cycle, pipelining improves clock cycle time
  - Or in other words CPU clock frequency
  - o The deeper the pipeline, the higher the frequency will be
- \* Caveat: latch delay and unbalanced stages can increase cycle time
- \* Caveat: pipeline hazards and memory delay can increase CPI



# Pipeline Hazards



#### Pipeline Hazards

- For pipelined CPUs, we said CPI is practically 1
  - But that depends entirely on having the pipeline filled
  - o In real life, there are *hazards* that prevent 100% utilization


#### • Pipeline Hazard

- When the next instruction cannot execute in the following cycle
- Hazards introduce "holes" into the pipeline timeline
- Architects have some tricks up their sleeves to avoid hazards
- But first let's briefly talk about the three types of hazards: Structural hazard, Data hazard, Control Hazard



#### Structural hazards


Two instructions need to use the same hardware at the same time.





#### Structural hazards


Two instructions need to use the same hardware at the same time.






#### Data hazards

• An instruction depends on the output of a previous one.




• sub must wait until add's WB phase is over before doing its ID phase



#### Control hazards

You don't know the outcome of a conditional branch.



• add must wait until beq's EX phase is over before its IF phase

