

Version No: Issue Date: Portfolio:	2.0 25/05/2022 Discrete Water Quality	Horizons Regional Council	Section No: Appendix No: Page:	15.7 XX 1 of 13
horizons regional council		Hydrology Operations Manual		

Version 1.0 24/05/2021

Invertebrate Monitoring Run Guide

WAIKAWA

STATE OF ENVIRONMENT (Annual Sampling)

Job Hazard & Task Analysis

Hazard Identification – tick all that apply, write additional hazards identified:

The yellow highlighted hazards are known hazards at the time of compiling this document. This **does not negate** the need to assess for and potentially eliminate or isolate any hazards at each sample location at every visit

Hazard	Yes	Hazard	Yes	Hazard	Yes
Confined space	<input type="checkbox"/>	Suspended loads	<input type="checkbox"/>	Noise – plant and equipment	<input type="checkbox"/>
Difficult entry/exit	<input checked="" type="checkbox"/>	Falling objects	<input type="checkbox"/>	Communication – means of	<input checked="" type="checkbox"/>
Oxygen deficiency/excess	<input type="checkbox"/>	Working near cranes and crane runways	<input type="checkbox"/>	Remote area	<input checked="" type="checkbox"/>
Poisonous fumes/gas	<input type="checkbox"/>	Live rails-gantry cranes	<input type="checkbox"/>	Temperature extremes	<input checked="" type="checkbox"/>
Explosive gas	<input type="checkbox"/>	Trip hazards	<input checked="" type="checkbox"/>	Reduced visibility	<input checked="" type="checkbox"/>
Flammable materials	<input type="checkbox"/>	Slippery surfaces	<input checked="" type="checkbox"/>	Unauthorized persons	<input type="checkbox"/>
Combustible materials	<input type="checkbox"/>	Manual handling	<input type="checkbox"/>	High pressure water	<input type="checkbox"/>
Hazardous substances	<input type="checkbox"/>	Sharp materials	<input type="checkbox"/>	Vacuum	<input type="checkbox"/>
Drowning	<input checked="" type="checkbox"/>	Line of fire	<input type="checkbox"/>	Air emissions – dust, fumes	<input type="checkbox"/>
Engulfment	<input checked="" type="checkbox"/>	Pressurized fluids	<input type="checkbox"/>	General waste	<input type="checkbox"/>
UV Radiation	<input checked="" type="checkbox"/>	Pressurized air/gas	<input type="checkbox"/>	Hazardous waste	<input type="checkbox"/>
Electrical – low /high voltage	<input checked="" type="checkbox"/>	Traffic / vehicle movements	<input checked="" type="checkbox"/>	Hydrocarbon / chemical spill	<input type="checkbox"/>
Multiple electrical feeds	<input type="checkbox"/>	Machinery – mobile plant	<input type="checkbox"/>	Soil disturbance/erosion	<input type="checkbox"/>
Working at height	<input type="checkbox"/>	Moving parts	<input type="checkbox"/>	Habitat disruption	<input type="checkbox"/>
Ladders	<input type="checkbox"/>	Chemical reaction (Pyrophoric iron)	<input type="checkbox"/>	Lighting	<input type="checkbox"/>
Elevated work platforms	<input type="checkbox"/>	Transport of hazardous substances	<input type="checkbox"/>	Weather extremes	<input checked="" type="checkbox"/>
Potential for difficult rescue	<input checked="" type="checkbox"/>	Stock/Farm Animals	<input checked="" type="checkbox"/>		

Required PPE & Safety Equipment– tick all that apply, write additional PPE required:

The yellow highlighted PPE are known required PPE at the time of compiling this document. This **does not negate** the need to assess for the appropriate required PPE measures at each sample location per visit.

SAMPLING GLOVES	EAR PROTECTION	HARD HAT	SAFETY GLASSES / GOGGLES	WORK BOOTS / WADERS	PROTECTIVE GLOVES	PERSONAL FLOATATION DEVICE (PFD)
						
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>
HI VIZ	SAFETY HARNESS	SUN BLOCK & HAND SANITISER	VHF RADIO	THROW BAG	PERSONAL LOCATOR BEACON	
						
<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	

Known Hazard	Significant		Can it be Eliminated		Can it be Isolated		Method of control
	Yes	No	Yes	No	Yes	No	
Drowning	✓			✓		✓	Staff should use a sample pole if access into the river/stream is unsafe. PFD's must be worn by staff. Always carry a throw bag when working around water and have a personal locator beacon on hand. It is always preferable to have someone else with you at all times when working around water [HMP 18]
UV Radiation	✓			✓	✓		Horizons provide sunscreen and hats. Staff are encouraged to make use of these. [HMP 17]
Engulfment	✓			✓		✓	Rivers/stream are prone to flash flooding creating the potential for engulfment. Staff must be alert and aware at all times of how the waterways are behaving around them, especially in areas where water is dammed or has structures such as intakes and aqueducts. PFD's must be worn by staff and staff must be trained for working around water. Vehicles must be driven a sensible distance from any river or pond edges. Always carry a throw bag when working around water and have a personal locator beacon on hand. It is always preferable to have someone else with you at all times when working around water [HMP18]
Difficult Entry/Exit	✓			✓	✓		Entry and exit into waterways poses many risks and should be treated with caution. Sampling must be done from stable level ground. Staff should use a sample pole if access into the river/stream is unsafe. PFD's must be worn by staff and staff must be trained for working around water. [HMP18]
Electrical-Low/High Voltage	✓			✓	✓		Many of the rural sampling sites require traversing across farm paddocks equipped with electric fences that contain stock. If unknown, treat every farm fence as electric and avoid direct contact. Contact the landowner for advise on whether or not the fence is live and discuss alternative routes or options for avoiding the fence if possible.
Potential for Difficult Rescue	✓			✓		✓	Sampling must always be done from stable level ground. Staff should use a sample pole if access into the river/stream is unsafe. PFD's must be worn by staff and staff must be trained for working around water. Vehicles must be driven a sensible distance from any river or pond edges. Always carry a throw bag when working around water and have a personal locator beacon on hand. It is always preferable to have someone else with you at all times when working around water [HMP18]
Trip Hazards	✓			✓	✓		Prior to sampling, staff must check area is clear of items that pose a risk. Trip Hazards should only be moved if safe to do so. Sampling only to commence if the sampler is

Known Hazard	Significant		Can it be Eliminated		Can it be Isolated		Method of control
	Yes	No	Yes	No	Yes	No	
							satisfied that any slip, trip or fall hazards are isolated.
Slippery Surfaces	✓			✓	✓		Sampling must be done from stable level. Vehicles must be driven a sensible distance from any river or pond edges. [HMP 18]. Staff driving four wheel drive vehicles must have adequate training [HMP 9]
Traffic Vehicle Movements	✓			✓		✓	The designated driver of a vehicle is responsible for ensuring the safety and operational requirements and recommendations are met. All staff working within the road reserve must wear high visibility clothing to AS/NZS 1906.4:2010. This clothing must be fluorescent red orange in colour unless the individual is the site STMS then the garment must be fluorescent lime yellow. [HMP 9] [HMP 16] [HMP 20].
Stock/Farm Animals	✓			✓	✓		Although generally docile, farm animals can still be hazardous. The risk should be isolated by finding alternative access routes to the sample location or contacting the owner for assistance. [HMP26]
Communications-Means of	✓			✓		✓	Cell phone coverage is not available at all sites. Staff must be capable of communicating via VHF radio in an equipped vehicle. [HMP 24]
Remote Area	✓			✓		✓	Most council vehicles are fitted with the E-Road vehicle locator system. Many vehicles are also fitted with a radio operating on the Horizons digital radio network providing communication and tracking coverages across a majority of the region. [HMP 24]
Temperature/Weather Extremes	✓			✓		✓	During the duration of a sampling run varying types and degrees of weather may be experienced. All sampling staff are to have access within their HRC vehicle to additional and appropriate clothing. Staff must have access to suitable PPE and spare clothing within their vehicle. [HMP 18]
Reduced Visibility	✓			✓		✓	If you find you are driving in limited visibility slow your driving speed and turn your fog lights on and watch out for vehicles that aren't using their lights. When working in limited visibility if you cease to able to make out your surrounding environment stop work immediately. If working at night it is advisable to traverse the property in daylight first to map out an action plan outlining walking tracks, vehicle tracks, fence lines, stock positions, ponds, waterways, houses, and sheds as well as other significant items of interest. [HMP12]

Site Information

Hilltop Site Name	Easting/Long (NZTM)	Northing/Lat (NZTM)
Waikawa at North Manakau Road	1788683	5491286
Manakau at SH1	1786684	5489409
Waikawa at Huritini	1783762	5493196



Equipment Required

Equipment	
	<ul style="list-style-type: none">• Camera and GPS• Kick net• Invertebrate Pottles and Propan-2-ol• White plastic tray• Metal ruler• Gravelometer• Sampling Worksheet and Pencil• Bathoscope / Viewer• Scrubbing brush, tooth brush, washer bottle, yellow sample bottle lid and ice cream container• Pottles (Approx 10), chilly bins and ice-packs• Personal Locator Beacon• 4WD Vehicle equipped with VHF Radio• Throw Bag

SITE LOCATION MAP – Waikawa at North Manakau Road



POSSIBLE SITE HAZARDS (this does not negate undertaking a hazard review prior to sampling on the day):

Drowning	UV Radiation	Slippery surfaces	Trip hazards
Difficult entry/exit	Potential for difficult rescue	Weather/Temperature Extremes	Traffic / Vehicle Movements
Electrical- Low/High Voltage	Machinery- Mobile Plant	Stock/Farm Animals	

REQUIRED PPE (in accordance with above hazards – this does not negate undertaking a hazard review prior to sampling on the day and/or using additional PPE if deemed necessary):


WORK BOOTS / WADERS	PFD	SUNSCREEN & HAND SANITISER	PERSONAL LOCATOR BEACON	THROW BAG	VHF RADIO	HI-VIS	
---------------------	-----	----------------------------	-------------------------	-----------	-----------	--------	--

DIRECTIONS:

- From the Palmerston North office head out along State Highway 57, go through Shannon and continue on towards Levin. Head past Levin and take the turn off to Wellington.
- Head through Ohau and continue on. You will cross the Waikawa stream, over the railway lines and it is the next turn on the left, just before the Manakau township
- Follow North-Manakau Road until you reach a bridge, directly after the bridge there is a gate to the right. Pull over to the right side of the road, open the gate and drive through.
- Once through the gate follow the grass track to the left and park next to the green Hydro Shed. From here follow the path down to the Waikawa River and sample here.



SITE LOCATION MAP – Manakau at SH1



POSSIBLE SITE HAZARDS (this does not negate undertaking a hazard review prior to sampling on the day):

Drowning	UV Radiation	Slippery surfaces	Trip hazards
Difficult entry/exit	Potential for difficult rescue	Weather/Temperature Extremes	Traffic / Vehicle Movements
Electrical- Low/High Voltage	Machinery- Mobile Plant		


REQUIRED PPE (in accordance with above hazards – this does not negate undertaking a hazard review prior to sampling on the day and/or using additional PPE if deemed necessary):

WORK BOOTS / WADERS	PFD	SUNSCREEN & HAND SANITISER	PERSONAL LOCATOR BEACON	THROW BAG	VHF RADIO	HI-VIS	SAMPLE POLE


DIRECTIONS:

- From the Waikawa at North Mnakau road, head back to SH1
- Once you get to the intersection with SH1 turn left towards Wellington and continue for approximately 2.4 km until you reach Quarter Acre Café (this is well sign posted).
- Continue around the bend on SH1 for approximately 100m until you reach The Greenery garden centre on the right. Turn down this driveway until you reach a bridge going over the Manakau Stream. Immediately on your right there will be a gate going into a paddock. If the ground is not too wet drive in here and follow the track until you reach a green hydro box. If the ground is wet, park up in the opposite paddock and walk down.
- Take water quality samples and a SmarTroll reading at the Hydro box.
- From the Hydro Box head back to the gate. Follow the gravel path in the opposite paddock towards SH1. Once near the bridge go underneath it to the river.





SITE LOCATION MAP – Waikawa at Huritini



POSSIBLE SITE HAZARDS (this does not negate undertaking a hazard review prior to sampling on the day):


Drowning	UV Radiation	Slippery surfaces	Trip hazards
Difficult entry/exit	Potential for difficult rescue	Weather/Temperature Extremes	Traffic / Vehicle Movements
Stock/Farm Animals	Reduced Visibility		

REQUIRED PPE (in accordance with above hazards – this does not negate undertaking a hazard review prior to sampling on the day and/or using additional PPE if deemed necessary):


WORK BOOTS / WADERS	PFD	SUNSCREEN & HAND SANITISER	PERSONAL LOCATOR BEACON	THROW BAG	VHF RADIO	HI-VIS	SAMPLE POLE

DIRECTIONS:

- Head north, back towards Levin, just out of the Manakau township turn left onto Waikawa Beach rd
- Continue along Waikawa Beach Road until you reach the mailbox for 385 Waikawa Road. Park on the left near their mail box just on the front grass off the road, clear of the drive way.
- Cross the road, climb the fence and, walk across the paddock and down the bank to the river.
- Sample here from a run.
- Can be very soft near the bank, when you first get in the stream, the banks are quite slumped.



HEADING BACK TO THE PALMERSTON NORTH OFFICE



DIRECTIONS:

- From the Waikawa at Huritini site head back the way you came down Waikawa Beach Road (towards SH1).
- Turn left onto SH1 heading towards Levin.
- Just after you go through Ohau turn right onto SH57 towards Palmerston North. Stay on SH57 for about 50 mins.
- After driving into Palmerston North over the Fitzherbert Bridge stay on Fitzherbert Rd for about 600m, then at the first set of lights turn right onto Te Awe Awe St.
- Follow Te Awe Awe St for about 900m then turn left onto Victoria Ave.
- Drive along Victoria Ave until you reach the Palmerston North office on your right.