
Problem 1

Result

Total sum for +0.5 - +100.00 = 605



numppterms.m

```
function [mpp] = numppterms(num)
    mpp = 0;
    rem = num;
    while (rem \sim= 0 && mpp < 10)
        for i = -1:10
             if 2^i >= abs(rem)
                 mpp = mpp + 1;
                 if (2^i - abs(rem) < abs(rem) - 2^{(i-1)})
                     rem = abs(rem) - 2^i;
                 else
                     rem = abs(rem) - 2^{(i-1)};
                 end
             break;
             end
        end
    end
end
```

Problem 2

Matlab output for unscaled coefficients

```
Scale 1.000000 Using coefficients [ 17 -90 241 902 241 -90 17] coef #1 17, 2 partial products coef #2 -90, 4 partial products coef #3 241, 3 partial products coef #4 902, 4 partial products coef #5 241, 3 partial products coef #6 -90, 4 partial products coef #7 17, 2 partial products In total, need 22 partial products
```

Matlab output for scaled coefficients

```
Scale 0.532000 Using coefficients [ 9 -48 128 480 128 -48 9]
coef #1 9, 2 partial products
coef #2 -48, 2 partial products
coef #3 128, 1 partial products
coef #4 480, 2 partial products
coef #5 128, 1 partial products
coef #6 -48, 2 partial products
coef #7 9, 2 partial products
In total, need 12 partial products
```


Matlab code

```
clear;
addpath('../part1/') %add numppterms
%fir
%coef = [17 -90 241 902 241 -90 17]
%pps
       2 4 3
                          3 4
                                    2
                       4
%
       +16 -64 +256 +1024 +256 -64 +16
%
        +1 -32 -16 -128 -16 -32 +1
%
            +4 -1
                       +4 -1 +4
%
            +2
                       -2
                               +2
%original coefficients
coef = [17 -90 241 902 241 -90 17];
%scaling factor
%scale = 1;
scale = 0.532; %12 pps, coef r will be [9 -48 128 480 128 -48 9]
%rounded coedficients
coef r = round( coef * scale );
fprintf("Scale %f Using coefficients [", scale);
fprintf(" %d", coef_r);
fprintf("]\n");
%total number of partial products for FIR
total = 0;
```

```
%calculation
for fircoef = 1:7
    total = total + numppterms(coef_r(fircoef));
    fprintf("coef #%d %d, %d partial products\n", fircoef, coef_r(fircoef),
numppterms(coef_r(fircoef)));
end


fprintf("In total, need %d partial products\n", total);
```

Bogus plot



Dot diagram

[] -4:2 adder, [] -3:2 adder, [] - half adder, "." - signal, " \sim " - inverted signal, "s" - sign extend, ark - right-to-left signal copy to reduce number of adders due to same inputs.




Problem 3


Part 1

Clock period	Total cell area
4ns	162.792004
1ns	162.792004
20ns	162.792004


Top-level diagram:



"cos/sin module" diagram:




"comb" module diagram (applies exception for result):



Energy diff / Energy_data0 = 10*log(0.000002/4096.020943) = -83.11dB

Difff.m output:

```
max(data0-data1) = +0.000031 +0.000031i = +3.05034e-05 +3.05034e-05i
min(data0-data1) = -0.000031 -0.000031i = -3.05034e-05 -3.05034e-05i
max(data0/data1) = -Inf -Infi
min(data0/data1) = +Inf +Infi
approx separated mean(data0/data1) = +0.999508+ +0.999508i
Energy_data0 = 4096.020943
Energy_diff = 0.000002
Energy_data0/Energy_diff = 1653952521.828711 = 92.185230dB
```



Code:

```
/*
Top level for complex number generator
*/
//cos function lookup table
//full precision for angle [0 .. 360) degrees
`timescale 1ns/10ps
module cos(
```

```
input cos en,
    input [11:0] angle,
    output reg [15:0] result
);
reg except;
reg [14:0] cos mem [4095:0];
reg [11:0] angle mem;
initial begin
    result = 16'b0000_0000_0000_0000;
    //load values to memory
    cos mem[12'b00000000000] = 15'b000000000000000;
    cos mem[12'b000000000001] = 15'b0000000000000000;
    cos mem[12'b000000000010] = 15'b0000000000000000;
    cos_mem[12'b000000000011] = 15'b0000000000000000;
    cos mem[12'b00000000100] = 15'b000000000000000;
    cos mem[12'b000000000101] = 15'b0000000000000000;
    cos_mem[12'b000000000110] = 15'b01111111111111;
    cos mem[12'b000000000111] = 15'b011111111111111;
    cos_mem[12'b000000001000] = 15'b01111111111111;
    cos mem[12'b000000001001] = 15'b011111111111110;
    cos mem[12'b000000001010] = 15'b011111111111111;
    cos mem[12'b000000001011] = 15'b011111111111110;
    cos mem[12'b000000001100] = 15'b01111111111111111;
    cos mem[12'b000000001101] = 15'b01111111111111111;
    cos mem[12'b000000001110] = 15'b011111111111100;
    //<Many lines removed>
    cos mem[12'b111111110001] = 15'b011111111111100;
    cos mem[12'b111111110010] = 15'b011111111111100;
    cos mem[12'b111111110011] = 15'b01111111111111111;
    cos_mem[12'b111111110100] = 15'b01111111111111111;
    cos mem[12'b111111110101] = 15'b011111111111110;
    cos mem[12'b111111110110] = 15'b011111111111110;
    cos_mem[12'b111111110111] = 15'b011111111111110;
    cos mem[12'b111111111000] = 15'b011111111111111;
    cos_mem[12'b111111111001] = 15'b01111111111111;
    cos mem[12'b111111111010] = 15'b01111111111111;
    cos mem[12'b111111111011] = 15'b00000000000000000;
    cos mem[12'b11111111100] = 15'b0000000000000000;
    cos_mem[12'b11111111101] = 15'b0000000000000000;
    cos mem[12'b11111111110] = 15'b00000000000000000;
    end
always @(angle or cos en) begin
    //cos/sin selection
    if (\cos en == 1'b1)
```

```
//compute cos(angle)
       angle mem = angle;
   else
       //compute sin(angle) = cos (pi/2 - angle)
       angle_mem = 12'b0100_0000_0000 - angle;
   //exception (when need to return == +1.0)
   except = (angle_mem == 12'b0000_0000_0000);
   except = except |  (angle mem == 12'b0000 0000 0001);
   except = except || (angle_mem == 12'b0000 0000 0010);
   except = except || (angle_mem == 12'b0000_0000_0011);
   except = except || (angle_mem == 12'b0000_0000_0100);
   except = except |  (angle mem == 12'b0000 0000 0101);
   except = except || (angle_mem == 12'b1111_1111_1011);
   except = except || (angle_mem == 12'b1111_1111_1100);
   except = except || (angle mem == 12'b1111 1111 1101);
   //output
   result = {cos_mem[angle_mem][14], cos_mem[angle_mem][14] | except,
cos mem[angle mem][13:0]};
end
endmodule
module compl(
   input [11:0] angle,
   input start,
   input clk,
   input reset,
   output reg [15:0] r,
   output reg [15:0] i
);
parameter IDLE = 2'b00;
parameter COS = 2'b01;
parameter SIN = 2'b10;
reg [1:0] mode, mode c;
reg [11:0] angle_mem, angle_r;
reg [15:0] r_c, i_c;
wire [15:0] cos_val;
reg cos_en, start_r;
initial begin
   mode = IDLE;
   mode_c = IDLE;
   angle mem = 12'b0000 0000 0000;
```

```
angle r = 12'b0000 0000 0000;
    r_c = 16'b0000_0000_0000_0000;
    i_c = 16'b0000_0000_0000_0000;
    cos_en = 1'b0;
//
      start_r = 1'b0;
end
cos cos_mem (.angle (angle_r), .cos_en(cos_en), .result(cos_val));
//State Machine
always @(angle_r or start_r or mode) begin
    mode c = mode;
    case(mode)
        IDLE: begin
            if (start_r == 1'b1) begin
                 mode_c = COS;
                 cos en = mode c[0];
                 angle_mem = angle_r;
            end
        end
        COS: begin
            r_c = cos_val;
            mode c = SIN;
            cos_en = mode_c[0];
        end
        SIN: begin
            i_c = cos_val;
            mode_c = IDLE;
        default: begin
            mode c = IDLE;
        end
    endcase
end
//output FFlop
always @(posedge clk or posedge reset) begin
    if (reset == 1'b1) begin
        r <= #1 16'b0000_0000_0000_0000;
        i <= #1 16'b0000 0000 0000 0000;
        mode <= #1 IDLE;</pre>
        angle_r <= #1 12'b0000_0000_0000;</pre>
        start_r <= #1 1'b0;
    end else begin
        r <= #1 r_c;
        i <= #1 i c;
        mode <= #1 mode c;</pre>
        angle_r <= #1 angle;</pre>
        start_r <= #1 start;</pre>
    end
```

```
end endmodule
```

Testbench:

```
`timescale 1ns/10ps
module tbench();
    reg [11:0] angle;
    integer file;
    wire [15:0] comp r;
    wire [15:0] comp_i;
    reg clk, start, rst;
    integer count = 0;
    compl C1 (
        .angle (angle),
        .start (start),
        .clk (clk),
        .reset (rst),
        .r (comp_r),
        .i (comp_i)
    );
    initial begin
        $recordfile("mult test");
        $recordvars(tbench);
        file = $fopen("complex_result.m", "w");
        $fwrite(file, "output = [\n");
        angle = 12'b0000_0000_0000;
        clk = 1'b0;
        start = 1'b0;
        rst = 1'b1;
        #25;
        angle = 12'b0000_0000_0000;
        rst = 1'b0;
        start = 1'b1;
        count = 3;
    end
    //clock
    always begin
        #10;
        clk = \sim clk;
    end
    //tests
    always @(posedge clk) begin
        #2;
        if (rst == 1'b0) begin
```

```
start = 1'b0;
            if (count != 0) begin
                count = count - 1;
            end else begin
                //write result to file
                $fwrite(file, "%d %d %d;\n", angle, comp_r, comp_i);
                //update angle or exit
                if (angle == 12'b11111111111) begin
                    $fwrite(file, "];\n");
                    $fclose(file);
                    $finish;
                end else begin
                    angle = angle + 1;
                    start = 1'b1;
                    count = 3;
                end
            end
        end
    end
endmodule
```

Area results:

Clk 1ns:

```
***********
Report : area
Design : compl
Version: J-2014.09-SP2
     : Mon Mar 12 22:31:13 2018
************
Information: Updating design information... (UID-85)
Library(s) Used:
   NangateOpenCellLibrary (File:
/software/Synopsys/DesignCompiler/EEC281/lib/nangate45/NangateOpenCellLibrary
.db)
Number of ports:
                                       47
Number of nets:
                                      133
Number of cells:
                                       76
Number of combinational cells:
                                       56
Number of sequential cells:
                                       20
Number of macros/black boxes:
                                        0
Number of buf/inv:
                                        8
Number of references:
                                       14
Combinational area:
                                 64.372000
Buf/Inv area:
                                  4.256000
```

Noncombinational area: 98.420003 Macro/Black Box area: 0.000000

Net Interconnect area: undefined (Wire load has zero net area)

Total cell area: 162.792004

Total area: undefined

1

Clk 4ns:

Report : area
Design : compl

Version: J-2014.09-SP2

Date : Mon Mar 12 22:35:20 2018

Information: Updating design information... (UID-85)

Library(s) Used:

NangateOpenCellLibrary (File:

/software/Synopsys/DesignCompiler/EEC281/lib/nangate45/NangateOpenCellLibrary
.db)

Number of ports: 47 Number of nets: 133 Number of cells: 76 Number of combinational cells: 56 Number of sequential cells: 20 Number of macros/black boxes: 0 Number of buf/inv: 8 Number of references: 14

Combinational area: 64.372000
Buf/Inv area: 4.256000
Noncombinational area: 98.420003
Macro/Black Box area: 0.000000

Net Interconnect area: undefined (Wire load has zero net area)

Total cell area: 162.792004

Total area: undefined

1

Clk 20ns:

Report : area Design : compl

Version: J-2014.09-SP2

Date : Mon Mar 12 22:34:04 2018

Information: Updating design information... (UID-85)

Library(s) Used:

NangateOpenCellLibrary (File:

/software/Synopsys/DesignCompiler/EEC281/lib/nangate45/NangateOpenCellLibrary
.db)

Number of ports: 47 Number of nets: 133 Number of cells: 76 Number of combinational cells: 56 Number of sequential cells: 20 Number of macros/black boxes: 0 Number of buf/inv: 8 Number of references: 14

Combinational area: 64.372000
Buf/Inv area: 4.256000
Noncombinational area: 98.420003
Macro/Black Box area: 0.000000

Net Interconnect area: undefined (Wire load has zero net area)

Total cell area: 162.792004

Total area: undefined

1


Part 2

Clock period	Total cell area
4ns	219.450003
1ns	219.450003
20ns	219.450003

Top-level design is the same as in part 1.

[&]quot;cos/sin module" diagram:

Maxim Shepovalov HW3 EEC281




"Comb" module is the same as in part 1.

Energy_diff / Energy_data0 = $10*\log(0.000002/4096.020943) = -83.113dB$

Difff.m output:

```
max(data0-data1) = +0.000031 +0.000031i = +3.05034e-05 +3.05034e-05i
min(data0-data1) = -0.000031 -0.000031i = -3.05034e-05 -3.05034e-05i
max(data0/data1) = -Inf -Infi
min(data0/data1) = +Inf +Infi
approx separated mean(data0/data1) = +0.999508+ +0.999508i
Energy_data0 = 4096.020943
Energy_diff = 0.000002
Energy_data0/Energy_diff = 1653952521.828711 = 92.185230dB
```



Code:

```
Top level for complex number generator
//cos function lookup table
//full precision and [0 .. 45) degrees
`timescale 1ns/10ps
module cos(
    input cos en,
    input [11:0] angle, //full angle
    output reg [15:0] result
);
reg except;
reg [14:0] cos_mem [512:0];
reg [14:0] sin_mem [512:0];
reg [9:0] angle_mem; //memory address
//logic variables
reg select_cos_mem;
reg select_positive;
```

```
reg [11:0] angle output, angle mem full;
reg [14:0] mem_val;
initial begin
   //defaults
   result = 16'b0000 0000 0000 0000;
   mem val = 15'b000 0000 0000 0000;
   angle output = 12'b0000 0000 0000;
   angle mem full = 12'b0000 0000 0000;
   select cos mem = 1'b0;
   select_positive = 1'b1;
   //load values to memory;
   cos mem[10'b000000000] = 15'b00000000000000; sin mem[10'b0000000000] =
15'b0000000000000000;
   cos mem[10'b000000001] = 15'b00000000000000; sin mem[10'b0000000001] =
15'b00000000011001;
   cos mem[10'b0000000010] = 15'b00000000000000; sin mem[10'b0000000010] =
15'b00000000110010;
   cos mem[10'b0000000011] = 15'b00000000000000; sin mem[10'b0000000011] =
15'b000000001001011;
   cos mem[10'b0000000100] = 15'b00000000000000; sin mem[10'b0000000100] =
15'b000000001100101;
   cos mem[10'b0000000101] = 15'b00000000000000; sin mem[10'b0000000101] =
15'b000000001111110;
   cos mem[10'b0000000110] = 15'b01111111111111111; sin mem[10'b0000000110] =
15'b000000010010111;
   cos mem[10'b0000000111] = 15'b01111111111111111; sin mem[10'b0000000111] =
15'b000000010110000;
   15'b000000011001001;
   cos mem[10'b0000001001] = 15'b011111111111110; sin mem[10'b0000001001] =
15'b000000011100010;
   cos mem[10'b0000001010] = 15'b011111111111110; sin mem[10'b0000001010] =
15'b000000011111011;
   cos mem[10'b0000001011] = 15'b0111111111111110; sin mem[10'b0000001011] =
15'b000000100010100;
   15'b000000100101110;
   cos mem[10'b0000001101] = 15'b0111111111111111111 ; sin mem[10'b0000001101] =
15'b000000101000111;
   cos mem[10'b0000001110] = 15'b011111111111100; sin mem[10'b0000001110] =
15'b000000101100000;
   //<Many lines removed>
   cos mem[10'b0111110010] = 15'b010111000110111; sin mem[10'b0111110010] =
15'b010110001000110;
   cos mem[10'b0111110011] = 15'b010111000100110; sin mem[10'b0111110011] =
15'b010110001011000;
```

```
cos mem[10'b0111110100] = 15'b010111000010101; sin mem[10'b0111110100] =
15'b010110001101010;
    cos mem[10'b0111110101] = 15'b010111000000011; sin_mem[10'b0111110101] =
15'b010110001111100:
    cos mem[10'b0111110110] = 15'b010110111110010; sin mem[10'b0111110110] =
15'b010110010001110;
    cos mem[10'b0111110111] = 15'b010110111100000; sin mem[10'b0111110111] =
15'b010110010100000;
    cos mem[10'b0111111000] = 15'b010110111001111; sin mem[10'b0111111000] =
15'b010110010110010;
    cos_mem[10'b0111111001] = 15'b010110110111101; sin_mem[10'b0111111001] =
15'b010110011000100:
    cos mem[10'b0111111010] = 15'b010110110101011; sin mem[10'b0111111010] =
15'b010110011010110;
    cos mem[10'b0111111011] = 15'b010110110011010; sin mem[10'b0111111011] =
15'b010110011101000;
    cos mem[10'b0111111100] = 15'b010110110001000; sin mem[10'b0111111100] =
15'b010110011111010;
    cos mem[10'b0111111101] = 15'b010110101110110; sin mem[10'b0111111101] =
15'b010110100001100;
    cos mem[10'b0111111110] = 15'b010110101100101; sin mem[10'b01111111110] =
15'b010110100011110;
    cos mem[10'b0111111111] = 15'b0101101010101011; sin mem[10'b0111111111] =
15'b010110100101111;
    cos mem[10'b1000000000] = 15'b010110101000001; sin mem[10'b1000000000] =
15'b010110101000001;
end
always @(angle or cos en) begin
    //cos/sin selection for output
    if (\cos en == 1'b1)
        //compute cos(angle)
        angle output = angle;
    else
        //compute sin(angle) = cos (pi/2 - angle)
        angle output = 11'b100 0000 0000 - angle;
    //choose cos/sin mem bank
    case (angle_output[11:9])
        3'b000: begin //0 - 45
            angle mem full = angle output;
            select cos mem = 1'b1;
            select positive = 1'b1;
        end
        3'b001: begin //45 - 90
            angle mem full = 12'h400 - angle output;
            select cos mem = 1'b0;
            select positive = 1'b1;
        end
        3'b010: begin //90 - 135
```

```
angle mem full = angle output[9:0] - 12'h400;
        select cos mem = 1'b0;
        select positive = 1'b0;
    end
    3'b011: begin //135 - 180
        angle mem full = 12'h800 - angle_output;
        select cos mem = 1'b1;
        select_positive = 1'b0;
    end
    3'b100: begin //180 - 225
        angle_mem_full = angle_output - 12'h800;
        select cos mem = 1'b1;
        select positive = 1'b0;
    3'b101: begin //225 - 270
        angle_mem_full = 12'hC00 - angle_output;
        select cos mem = 1'b0;
        select positive = 1'b0;
    end
    3'b110: begin //270 - 315
        angle mem full = angle output - 12'hC00;
        select cos mem = 1'b0;
        select positive = 1'b1;
    end
    3'b111: begin //315 - 360
        angle mem full = 13'h1000 - angle output;
        select cos mem = 1'b1;
        select_positive = 1'b1;
    end
endcase
//exception (when need to return +1.0)
angle_mem = angle_mem_full[9:0];
except = (angle_mem == 10'b00_0000_0000);
except = except || (angle_mem == 10'b00_0000_0001);
except = except || (angle_mem == 10'b00_0000_0010);
except = except || (angle_mem == 10'b00_0000_0011);
except = except || (angle_mem == 10'b00_0000_0100);
except = except || (angle_mem == 10'b00_0000_0101);
//except only work for cos bank near angle 0
except = except & select cos mem;
//read memory
if (select_cos_mem == 1'b1) begin
    mem_val = cos_mem[angle_mem];
end else begin
    mem val = sin mem[angle mem];
end
//make output
```

```
if (select positive == 1'b1) begin
        result = {mem_val[14], mem_val[14] | except, mem_val[13:0]};
    end else begin
        result = -{mem_val[14], mem_val[14] | except, mem_val[13:0]};
    end
end
endmodule
module compl(
    input [11:0] angle,
    input start,
    input clk,
    input reset,
    output reg [15:0] r,
    output reg [15:0] i
);
parameter IDLE = 2'b00;
parameter COS = 2'b01;
parameter SIN = 2'b10;
reg [1:0] mode, mode c;
reg [11:0] angle_mem, angle_r;
reg [15:0] r_c, i_c;
wire [15:0] cos_val;
reg cos_en, start_r;
initial begin
    mode = IDLE;
    mode c = IDLE;
    angle mem = 12'b0000 0000 0000;
//
      angle_r = 12'b0000_0000_0000;
    r c = 16'b0000 0000 0000 0000;
    i c = 16'b0000 0000 0000 0000;
    cos en = 1'b0;
//
      start r = 1'b0;
end
cos cos_mem (.angle (angle_r), .cos_en(cos_en), .result(cos_val));
//State Machine
always @(angle_r or start_r or mode) begin
    mode c = mode;
    case(mode)
        IDLE: begin
            if (start_r == 1'b1) begin
                mode_c = COS;
                cos_en = mode_c[0];
```

```
angle_mem = angle_r;
             end
        end
        COS: begin
             r_c = cos_val;
             mode c = SIN;
             cos_en = mode_c[0];
        end
        SIN: begin
             i_c = cos_val;
             mode_c = IDLE;
        end
        default: begin
             mode_c = IDLE;
        end
    endcase
end
//output FFlop
always @(posedge clk or posedge reset) begin
    if (reset == 1'b1) begin
        r <= #1 16'b0000_0000_0000_0000;
        i <= #1 16'b0000 0000 0000 0000;
        mode <= #1 IDLE;</pre>
        angle_r <= #1 12'b0000_0000_0000;
        start_r <= #1 1'b0;
    end else begin
        r <= #1 r_c;
        i <= #1 i c;
        mode <= #1 mode c;</pre>
        angle r <= #1 angle;</pre>
        start_r <= #1 start;</pre>
    end
end
endmodule
```

Testbench:

```
`timescale 1ns/10ps
module tbench();

reg [11:0] angle;
integer file;
wire [15:0] comp_r;
wire [15:0] comp_i;
reg clk, start, rst;
integer count = 0;

compl C1 (
    .angle (angle),
```

```
.start (start),
    .clk (clk),
    .reset (rst),
    .r (comp_r),
    .i (comp_i)
);
initial begin
    $recordfile("mult_test");
    $recordvars(tbench);
    file = $fopen("complex_result.m", "w");
    $fwrite(file, "output = [\n");
    angle = 12'b0000 0000 0000;
    clk = 1'b0;
    start = 1'b0;
    rst = 1'b1;
    #25;
    angle = 12'b0000 0000 0000;
    rst = 1'b0;
    start = 1'b1;
    count = 3;
end
//clock
always begin
    #10;
    clk = \sim clk;
end
//tests
always @(posedge clk) begin
    #2;
    if (rst == 1'b0) begin
        start = 1'b0;
        if (count != 0) begin
            count = count - 1;
        end else begin
            //write result to file
            $fwrite(file, "%d %d %d;\n", angle, comp_r, comp_i);
            //update angle or exit
            if (angle == 12'b11111111111) begin
                $fwrite(file, "];\n");
                $fclose(file);
                $finish;
            end else begin
                angle = angle + 1;
                start = 1'b1;
                count = 3;
            end
        end
```

end	
end	
endmodule	

Area results:

```
Clock 1ns:
***********
Report : area
Design : compl
Version: J-2014.09-SP2
Date : Mon Mar 12 22:46:21 2018
************
Information: Updating design information... (UID-85)
Library(s) Used:
   NangateOpenCellLibrary (File:
/software/Synopsys/DesignCompiler/EEC281/lib/nangate45/NangateOpenCellLibrary
.db)
Number of ports:
                                        47
Number of nets:
                                       166
Number of cells:
                                       110
Number of combinational cells:
                                        86
Number of sequential cells:
                                        24
Number of macros/black boxes:
                                        0
Number of buf/inv:
                                        12
Number of references:
                                        16
Combinational area:
                                105.070000
Buf/Inv area:
                                  6.384000
Noncombinational area:
                                114.380004
Macro/Black Box area:
                                  0.000000
Net Interconnect area: undefined (Wire load has zero net area)
Total cell area:
                                219.450003
Total area:
                          undefined
1
```

Clock 4ns:

```
Information: Updating design information... (UID-85)
Library(s) Used:
    NangateOpenCellLibrary (File:
/software/Synopsys/DesignCompiler/EEC281/lib/nangate45/Nangate0penCellLibrary
.db)
Number of ports:
                                                47
Number of nets:
                                               166
Number of cells:
                                               110
Number of combinational cells:
                                                86
Number of sequential cells:
                                                24
Number of macros/black boxes:
                                                 0
Number of buf/inv:
                                                12
Number of references:
                                                16
Combinational area:
                                       105.070000
Buf/Inv area:
                                          6.384000
Noncombinational area: 114.380004
Macro/Black Box area: 0.000000
Net Interconnect area: undefined (Wire load has zero net area)
Total cell area:
                                       219.450003
                               undefined
Total area:
Clock 20ns:
```

```
************
Report : area
Design : compl
Version: J-2014.09-SP2
Date : Mon Mar 12 22:48:52 2018
************
Information: Updating design information... (UID-85)
Library(s) Used:
   NangateOpenCellLibrary (File:
/software/Synopsys/DesignCompiler/EEC281/lib/nangate45/NangateOpenCellLibrary
.db)
Number of ports:
                                       47
Number of nets:
                                      166
Number of cells:
                                      110
Number of combinational cells:
                                       86
Number of sequential cells:
                                       24
Number of macros/black boxes:
                                        0
Number of buf/inv:
                                       12
Number of references:
                                       16
```

Combinational area: 105.070000
Buf/Inv area: 6.384000
Noncombinational area: 114.380004
Macro/Black Box area: 0.000000

Net Interconnect area: undefined (Wire load has zero net area)

Total cell area: 219.450003

Total area: undefined


1

Part 3

Clock period	Total cell area
4ns	342.342004
1ns	342.342004
20ns	342.342004


Top –level diagram is the same as in part 1 and 2.

Cos/sin module:



Memory address module:


Maxim Shepovalov HW3 EEC281



Energy_diff / Energy_data0 = 10*log(0.002413/4096.016469) = -62.298dB

Difff.m output:

```
max(data0-data1) = +0.001554 +0.001554i = +0.00155412 +0.00155412i
min(data0-data1) = -0.001554 -0.001554i = -0.00155412 -0.00155412i
max(data0/data1) = -Inf -Infi
min(data0/data1) = +Inf +Infi
approx separated mean(data0/data1) = +0.997796+ +0.997796i
Energy_data0 = 4096.016469
Energy_diff = 0.002413
Energy_data0/Energy_diff = 1697518.136491 = 62.298144dB
```



Code:

```
Top level for complex number generator
*/
//cos function lookup table
//full precision and [0 .. 45) degrees
`timescale 1ns/10ps
module addr_selector(
    input [11:0] angle,
    input angle shift,
    input cos_en,
    output reg [8:0] mem_address,
    output reg do_except,
    output reg select_cos_mem,
    output reg select_positive
);
//logic variables
reg [11:0] angle_output, angle_mem_full;
always @(angle or cos_en) begin
    //cos/sin selection for output
```

```
if (\cos en == 1'b1)
    //compute cos(angle)
    angle_output = angle + angle[0]*angle_shift;
else
    //compute sin(angle) = cos (pi/2 - angle)
    angle output = 11'b100 0000_0000 - angle - angle[0]*angle_shift;
//choose cos/sin mem bank
case (angle output[11:9])
    3'b000: begin //0 - 45
        angle_mem_full = angle_output;
        select cos mem = 1'b1;
        select positive = 1'b1;
    end
    3'b001: begin //45 - 90
        angle_mem_full = 12'h400 - angle_output;
        select cos mem = 1'b0;
        select positive = 1'b1;
    end
    3'b010: begin //90 - 135
        angle mem full = angle output[9:0] - 12'h400;
        select cos mem = 1'b0;
        select positive = 1'b0;
    end
    3'b011: begin //135 - 180
        angle mem full = 12'h800 - angle output;
        select_cos_mem = 1'b1;
        select_positive = 1'b0;
    end
    3'b100: begin //180 - 225
        angle mem full = angle output - 12'h800;
        select cos mem = 1'b1;
        select_positive = 1'b0;
    end
    3'b101: begin //225 - 270
        angle mem full = 12'hC00 - angle output;
        select cos mem = 1'b0;
        select positive = 1'b0;
    end
    3'b110: begin //270 - 315
        angle mem full = angle output - 12'hC00;
        select cos mem = 1'b0;
        select_positive = 1'b1;
    end
    3'b111: begin //315 - 360
        angle_mem_full = 13'h1000 - angle_output;
        select cos mem = 1'b1;
        select positive = 1'b1;
    end
endcase
```

```
//exception (when need to return +1.0)
   mem address = angle mem full[9:1];
   do_except = (mem_address == 10'b00 0000 0000);
   do_except = do_except || (mem_address == 10'b00_0000_0001);
   do_except = do_except || (mem_address == 10'b00 0000 0010);
   //except only work for cos bank near angle 0
   do_except = do_except & select_cos_mem;
end
endmodule
module cos(
   input cos_en,
   input [11:0] angle,
   output reg [15:0] result
);
reg [15:0] result0, result1;
reg [16:0] result2x;
reg [14:0] cos mem [256:0];
reg [14:0] sin mem [256:0];
reg [14:0] mem val0, mem val1;
wire [8:0] mem adr0, mem adr1;
wire select_cos_mem0, select_cos_mem1, select_positive0, select_positive1,
except0, except1;
initial begin
   //defaults
   result = 16'b0000 0000 0000 0000;
   mem_val0 = 15'b000_0000_0000_0000;
   mem val1 = 15'b000 0000 0000 0000;
   //load values to memory;
   cos mem[9'b000000000] = 15'b00000000000000; sin mem[9'b000000000] =
15'b0000000000000000;
   cos mem[9'b000000001] = 15'b00000000000000; sin mem[9'b000000001] =
15'b00000000110010;
   cos mem[9'b000000010] = 15'b00000000000000; sin mem[9'b000000010] =
15'b000000001100101;
   cos_mem[9'b000000011] = 15'b01111111111111; sin_mem[9'b000000011] =
15'b000000010010111:
   15'b000000011001001;
   cos mem[9'b000000101] = 15'b011111111111110; sin mem[9'b000000101] =
15'b000000011111011;
   cos mem[9'b000000110] = 15'b01111111111111111 ; sin_mem[9'b000000110] =
15'b000000100101110;
```

```
cos mem[9'b000000111] = 15'b011111111111100; sin mem[9'b000000111] =
15'b000000101100000;
    15'b000000110010010;
    cos_mem[9'b000001001] = 15'b0111111111111010; sin_mem[9'b000001001] =
15'b000000111000100;
    cos mem[9'b000001010] = 15'b0111111111111000; sin_mem[9'b000001010] =
15'b000000111110111;
    cos mem[9'b000001011] = 15'b011111111111111111; sin mem[9'b000001011] =
15'b000001000101001:
    cos mem[9'b000001100] = 15'b0111111111110101; sin mem[9'b000001100] =
15'b000001001011011:
    cos mem[9'b000001101] = 15'b0111111111110011; sin mem[9'b000001101] =
15'b000001010001101;
    cos mem[9'b000001110] = 15'b0111111111110001; sin mem[9'b000001110] =
15'b000001011000000;
   //<Many lines removed>
   cos_mem[9'b011110010] = 15'b010111100101000; sin_mem[9'b011110010] =
15'b010101101000101:
    cos mem[9'b011110011] = 15'b010111100000110; sin mem[9'b011110011] =
15'b010101101101010;
    cos mem[9'b011110100] = 15'b010111011100100; sin mem[9'b011110100] =
15'b010101110001111;
    cos mem[9'b011110101] = 15'b010111011000010; sin mem[9'b011110101] =
15'b010101110110100;
    cos mem[9'b011110110] = 15'b010111010011111; sin mem[9'b011110110] =
15'b010101111011000;
    cos mem[9'b011110111] = 15'b010111001111101; sin mem[9'b011110111] =
15'b010101111111101;
    cos mem[9'b011111000] = 15'b010111001011010; sin mem[9'b011111000] =
15'b010110000100001;
    cos_mem[9'b011111001] = 15'b010111000110111; sin_mem[9'b011111001] =
15'b010110001000110;
    cos mem[9'b011111010] = 15'b010111000010101; sin mem[9'b011111010] =
15'b010110001101010;
    cos mem[9'b011111011] = 15'b010110111110010; sin mem[9'b011111011] =
15'b010110010001110;
    cos mem[9'b011111100] = 15'b010110111001111; sin mem[9'b011111100] =
15'b010110010110010;
    cos mem[9'b011111101] = 15'b010110110101011; sin mem[9'b011111101] =
15'b010110011010110;
    cos mem[9'b011111110] = 15'b010110110001000; sin mem[9'b011111110] =
15'b010110011111010;
    cos mem[9'b011111111] = 15'b010110101100101; sin mem[9'b011111111] =
15'b010110100011110;
    cos mem[9'b100000000] = 15'b010110101000001; sin mem[9'b100000000] =
15'b010110101000001;
end
```

```
//address calculation for bottom value
addr selector ADS0 (
    .angle (angle),
    .angle_shift (1'b0),
    .cos en (cos en),
    .mem address (mem adr0),
    .do_except (except0),
    .select cos mem (select cos mem0),
    .select_positive (select_positive0)
);
//address calculation for upper value
addr selector ADS1 (
    .angle (angle),
    .angle_shift (1'b1),
    .cos en (cos en),
    .mem address (mem adr1),
    .do_except (except1),
    .select_cos_mem (select_cos_mem1),
    .select_positive (select_positive1)
);
//calculate upper value
always @(mem adr1 or mem adr1 or select cos mem1 or select positive1) begin
    //read memory
    if (select cos mem1 == 1'b1) begin
        mem_val1 = cos_mem[mem_adr1];
    end else begin
        mem val1 = sin mem[mem adr1];
    end
    if (select_positive1 == 1'b1) begin
        result1 = {mem_val1[14], mem_val1[14] | except1, mem_val1[13:0]};
    end else begin
        result1 = -{mem val1[14], mem val1[14] | except1, mem val1[13:0]};
    end
end
//calculate bottom value
always @(mem adr0 or mem adr0 or select cos mem0 or select positive0) begin
    //read memory
    if (select cos mem0 == 1'b1) begin
        mem_val0 = cos_mem[mem_adr0];
    end else begin
        mem val0 = sin mem[mem adr0];
    end
    if (select positive0 == 1'b1) begin
        result0 = \{\text{mem val0}[14], \text{ mem val0}[14] \mid \text{ except0}, \text{ mem val0}[13:0]\};
    end else begin
        result0 = -{mem_val0[14], mem_val0[14] | except0, mem_val0[13:0]};
```

```
end
end
//write output
always @(result1 or result0) begin
    result2x = {result1[15], result1} + {result0[15], result0};
    result = result2x[16:1]; //devide by 2
end
endmodule
module compl(
    input [11:0] angle,
    input start,
    input clk,
    input reset,
    output reg [15:0] r,
    output reg [15:0] i
);
parameter IDLE = 2'b00;
parameter COS = 2'b01;
parameter SIN = 2'b10;
reg [1:0] mode, mode_c;
reg [11:0] angle_mem, angle_r;
reg [15:0] r_c, i_c;
wire [15:0] cos_val;
reg cos_en, start_r;
initial begin
    mode = IDLE;
    mode c = IDLE;
    angle_mem = 12'b0000_0000_0000;
//
      angle r = 12'b0000 0000 0000;
    r c = 16'b0000 0000 0000 0000;
    i_c = 16'b0000_0000_0000_0000;
    cos en = 1'b0;
//
      start r = 1'b0;
end
cos cos_mem (.angle (angle_r), .cos_en(cos_en), .result(cos_val));
//State Machine
always @(angle_r or start_r or mode) begin
    mode_c = mode;
    case(mode)
        IDLE: begin
            if (start_r == 1'b1) begin
                mode c = COS;
```

```
cos_en = mode_c[0];
                 angle_mem = angle_r;
            end
        end
        COS: begin
             r c = cos val;
            mode c = SIN;
             cos_en = mode_c[0];
        end
        SIN: begin
             i_c = cos_val;
            mode_c = IDLE;
        end
        default: begin
            mode_c = IDLE;
        end
    endcase
end
//output FFlop
always @(posedge clk or posedge reset) begin
    if (reset == 1'b1) begin
        r <= #1 16'b0000 0000 0000 0000;
        i <= #1 16'b0000 0000 0000 0000;
        mode <= #1 IDLE;</pre>
        angle_r <= #1 12'b0000_0000_0000;
        start_r <= #1 1'b0;
    end else begin
        r <= #1 r c;
        i <= #1 i c;
        mode <= #1 mode c;</pre>
        angle r <= #1 angle;</pre>
        start_r <= #1 start;</pre>
    end
end
endmodule
```

Testbench:

```
`timescale 1ns/10ps
module tbench();

reg [11:0] angle;
  integer file;
  wire [15:0] comp_r;
  wire [15:0] comp_i;
  reg clk, start, rst;
  integer count = 0;

compl C1 (
```

```
.angle (angle),
    .start (start),
    .clk (clk),
    .reset (rst),
    .r (comp_r),
    .i (comp i)
);
initial begin
    $recordfile("mult_test");
    $recordvars(tbench);
    file = $fopen("complex_result.m", "w");
    $fwrite(file, "output = [\n");
    angle = 12'b0000_0000_0000;
    clk = 1'b0;
    start = 1'b0;
    rst = 1'b1;
    #25;
    angle = 12'b0000_0000_0000;
    rst = 1'b0;
    start = 1'b1;
    count = 3;
end
//clock
always begin
    #10;
    clk = \sim clk;
end
//tests
always @(posedge clk) begin
    #2;
    if (rst == 1'b0) begin
        start = 1'b0;
        if (count != 0) begin
            count = count - 1;
        end else begin
            //write result to file
            $fwrite(file, "%d %d %d;\n", angle, comp_r, comp_i);
            //update angle or exit
            if (angle == 12'b1111111111) begin
                $fwrite(file, "];\n");
                $fclose(file);
                $finish;
            end else begin
                angle = angle + 1;
                start = 1'b1;
                count = 3;
            end
```

end end end endmodule

Area results:

Clock 1ns:

```
************
Report : area
Design : compl
Version: J-2014.09-SP2
Date : Mon Mar 12 22:51:18 2018
***********
Information: Updating design information... (UID-85)
Library(s) Used:
   NangateOpenCellLibrary (File:
/software/Synopsys/DesignCompiler/EEC281/lib/nangate45/Nangate0penCellLibrary
.db)
Number of ports:
                                        47
Number of nets:
                                       249
Number of cells:
                                       195
Number of combinational cells:
                                       167
Number of sequential cells:
                                        28
Number of macros/black boxes:
                                         0
Number of buf/inv:
                                        23
Number of references:
                                        17
Combinational area:
                                212.001999
Buf/Inv area:
                                 12.502000
Noncombinational area:
                                130.340004
Macro/Black Box area:
                                  0.000000
Net Interconnect area: undefined (Wire load has zero net area)
Total cell area:
                                342.342004
                          undefined
Total area:
1
```

Clock 4ns:

************ Report : area Design : compl Version: J-2014.09-SP2 : Mon Mar 12 22:53:01 2018 ************

```
Information: Updating design information... (UID-85)
Library(s) Used:
    NangateOpenCellLibrary (File:
/software/Synopsys/DesignCompiler/EEC281/lib/nangate45/NangateOpenCellLibrary
.db)
Number of ports:
                                           47
Number of nets:
                                          249
Number of cells:
                                          195
Number of combinational cells:
                                          167
Number of sequential cells:
                                           28
Number of macros/black boxes:
                                            0
Number of buf/inv:
                                           23
Number of references:
                                           17
Combinational area:
                                   212,001999
Buf/Inv area:
                                    12,502000
Noncombinational area:
                                   130.340004
Macro/Black Box area:
                                     0.000000
Net Interconnect area: undefined (Wire load has zero net area)
Total cell area:
                                   342.342004
Total area:
                            undefined
1
Clock 20ns:
```

```
***********
Report : area
Design : compl
Version: J-2014.09-SP2
Date : Mon Mar 12 22:54:08 2018
***********
Information: Updating design information... (UID-85)
Library(s) Used:
   NangateOpenCellLibrary (File:
/software/Synopsys/DesignCompiler/EEC281/lib/nangate45/NangateOpenCellLibrary
.db)
Number of ports:
                                      47
Number of nets:
                                      249
Number of cells:
                                      195
Number of combinational cells:
                                      167
Number of sequential cells:
                                       28
Number of macros/black boxes:
                                       0
Number of buf/inv:
                                       23
```

Maxim Shepovalov HW3 EEC281

Number of references: 17

Combinational area: 212.001999
Buf/Inv area: 12.502000
Noncombinational area: 130.340004
Macro/Black Box area: 0.000000

Net Interconnect area: undefined (Wire load has zero net area)

Total cell area: 342.342004

Total area: undefined

1