ASA Delivery System

ROS Development Kit

for Keenon W3Pro

- 1. Asa\_charge
  - 1.1: Asa\_charge\_state
  - 1.2: Asa charge task
- 2. Asa delivery
  - 2.1: Asa cancel
  - 2.2: Asa Enter lift
  - 2.3: Asa Exit lift
  - 2.4: Asa\_move\_base
  - 2.5: Asa\_pose
  - 2.6: Asa\_sys
- 3. Asa lunach
  - Asa luanch
- 4. Asa\_status
  - Asa\_status
- 5. Asa switch floor
  - Asa switch
- 6. How to implement the package

# 1. Asa charge

### - 1.1: Asa\_charge\_state

A programme created to check the charging status of Keenon W3 Pro.

When called, the programme will subscribe to rostopic "/charge\_state\_fromSTM32" developed by Keenon Robot.

Return True or False to the server for further action

#### **Code Explain:**

```
def charge_status(self):
    global sub

sub = rospy.Subscriber("/charge_state_fromSTM32", ChargeFB, self.charge_callback)

while True:
    if self.status != None:
        counter = self.charge_now()

    if not counter:
        sub.unregister()
        return False
    else:
        return True
```

Create a function for subscribing rostopic "/charge\_state\_fromSTM32" and get the data through the callback

```
def charge_callback(self, data):
    self.data = data
    self.status = data.state
```

from the callback function, the programme still store the state status from charge\_state

```
# Define timeout for checking the current state
def charge_now(self):
    timelimit = 40

    start = time.time()

    while True:
        time.sleep(0.1)
        remaining = timelimit + start - time.time()

        print(remaining)

        if self.status == 53:
            sub.unregister()
            return True

    elif remaining <= 0:
        return False</pre>
```

the programme will loop until timeout (default setting: 40s) and return to boolean

# - 1.2: Asa\_charge\_task

A programme created for executing charging instructions while called by the server.

When called, the programme will create an actionlib client and send the requested data to the action server "charge\_task" for executing instructions "go\_to\_charge\_pile" and "leave\_chrage\_pile".

Return True / False boolean to the server according to the result of the function.

#### **Code Explain:**

```
if __name__ == "__main__":
    # create node asa_charge_task
    rospy.init_node("asa_charge_task")

#create service goCharge for external call
    rospy.Service('/asa_charge_task/goCharge', AsaChargeTask, charge_task)

    rospy.Service('/asa_charge_task/leftCharge', AsaLeftCharge, left_charge)
    rospy.spin()
```

Create a node and create service "goCharge" and "leftCharge" for external call

```
def chargeStatus():
    checkChargeState = charge_state()
    status = checkChargeState.charge_status()
    return status
```

Create a function for calling asa\_charge\_state to get the data from topic "/charge\_state\_fromSTM32"

```
def charge_task(req):
    # create action client to passing the type to the action
    # keenon_charge to the constructor.

client = actionlib.SimpleActionClient('charge_task', ChargeTaskAction)

# Waits until the action server has started up and started
    # listening for goals.

client.wait_for_server()

# Create a goal to send to the action server.

goal = ChargeTaskGoal()

goal.goal_type = 1

# Create the goal to the action server.

client.send_goal(goal)

# Check the charge status of the robot

status = chargeStatus()

if not status:
    cancelCharge()
    return False
else:
    return True
```

Create function "charge\_task" as the callback of service "goCharge" with a actionlib client for sending instruction to the robot

Inorder to cancel the charge task, the programme import GoalID from actionlib\_msg and publish it to rostopic "charge\_task"

```
def left_charge(req):
    client = actionlib.SimpleActionClient('charge_task', ChargeTaskAction)
    client.wait_for_server()
    goal = ChargeTaskGoal()
    goal.goal_type = 3
    client.send_goal(goal)
    wait = client.wait_for_result()
    if not wait:
        return False
    else:
        return True
```

Create function "left\_charge" as the callback of service "leftCharge" which has the same structure of function "charge\_task"

# 2. Asa delivery

#### - 2.1: Asa\_cancel

A programme created for cancel the action of actionlib server "move\_base\_action"

This function will be called when the move\_base's mission is failed in following situation:

- 1. The Goal Location is blocked
- 2. Run out of mission timeout

#### **Code Explain:**

```
class cancelGoal:
    def sendCancel(self):
        self.cancel = rospy.Publisher("/move_base/cancel", GoalID, queue_size=1)
        cancelMsg = GoalID()

    counter = self.cancel.publish@cancelMsg)

    if not counter:
        rospy.logerr("Error: Can't cancel goal.")
        return False

    else:
        rospy.loginfo("Success: Move Base Goal is now canceled.")
        return True
```

Create function "sendCancel" for canceling the goal while the robot cannot arrive the goal position

In order to cancel the move base goal, the program imports GoadID from actionlib\_msg, and publishes it to the topic "/move\_base/cancel" to clear the move\_base\_action instruction.

#### - 2.2: Asa\_Enter\_lift

A programme created for instructing the robot to go into the lift's waiting zone.

The programme will check the pose of the robot while the robot successfully arrives at the target zone or fails.

If the robot fails to enter the target waiting zone, the robot will call out the function "asa\_exit\_lift" automatically and wait for return.

This Function have two return - ifInLift and isInGoal

#### **Code Explain:**

```
# Lift schedule
def enter lift schedule(floor):
    isInGoal = False
    isInLift = True
    # create pos check instant
    tracking = pos check()
    inGoal = asa move base.asa move base(floor, "goal", 25)
    if not inGoal:
        isInGoal = False
    elif inGoal:
        isInGoal = True
        isInLift = tracking.pose check(floor)
    if isInGoal == False:
        exitLift , isInLift = asa_exit_lift.quit_lift(floor)
    # return counter to the server
    return isInGoal, isInLift
```

Create function "enter\_lift\_schedule" and send the goal's data to "asa\_move\_base" While the execution of entering goal position fail or over time limit, call "asa\_exit\_lift"

# - 2.3: Asa\_Exit\_lift

A programme created for instructing the robot to exit the lift area.

The programme subscribes to "asa\_pose" and will check the pose of the robot while the robot successfully exits the lift or fails.

This Function have two return - ifInLift and isInGoal

#### **Code Explain:**

```
def quit_lift(floor):
    exitLift = asa_move_base.asa_move_base(floor, "waiting_zone", 25)
    isInLift = check_pose(floor)
    Goalcancel()
    return exitLift, isInLift
```

Create function "quit\_lift" and send the goal's data to "asa\_move\_base"

```
# Lift - from inside go to waiting zone
def check_pose(floor):
    tracking = pos_check()
    inLift = tracking.pose_check(floor)
    return inLift

def Goalcancel():
    nullGoal = cancelGoal()
    nullGoal.sendCancel()
```

Subscribe to "Asa\_cancel", cancel move\_base\_goal while over time limit

### - 2.4: Asa\_move\_base

A programme created for executing the moving instruction from the server. Providing a point to point moving service.

# **Code Explain:**

```
# asa move base
def asa move base(floor, value, timeout):
    # action client
    client = actionlib.SimpleActionClient('move base', MoveBaseAction)
    client.wait_for_server()
   # loading the data of building
    building description = load building desc()
    # load the goal's pose from the database
    pose = get pose data(floor, value, building description)
    # send goal to move base
    goal = move(pose)
    client.send goal(goal)
   wait = client.wait for result(timeout=rospy.Duration(timeout))
    if wait == True:
        resultCheck = client.get result()
        if resultCheck.ret status == 1:
            return True
        else:
            return False
    else:
        return False
```

Create function "asa\_move\_base" as the server and create a actionlib client subscribe to 'move\_base'

Send the goal to move base and wait for the result

```
def load_building_desc( ):
    # TODO - replace map folder with DB
    map_folder = os.path.abspath('/asa_delivery_sys/src/asa_delivery_sys/asa_delivery/scripts/testing.yaml')
    with open(map_folder) as f:
        yaml_desc = yaml.safe_load(f)
    return yaml_desc
```

Create function "load\_building\_desc" to load the data from the database by the target pose data from the server input.

Create function "get\_pose\_data" to record the data needed passing to the move\_base and store to a list.

```
def move(pose):
    # Create a new goal with MoveBaseGoal constructor
    goal = MoveBaseGoal()
    goal.target pose.header.frame id = "map"
    goal.target pose.header.stamp = rospy.Time.now()
    # X,Y,Z coor data
    goal.target pose.pose.position.x = pose[0][0]
    goal.target pose.pose.position.y = pose[0][1]
    goal.target_pose.pose.position.z = 0.0
    # X,Y,Z,W orientation
    goal.target pose.pose.orientation.x = 0.0
    goal.target_pose.pose.orientation.y = 0.0
    goal.target pose.pose.orientation.z = pose[0][2]
    goal.target pose.pose.orientation.w = pose[0][3]
    print(goal)
    return(goal)
```

Create a function "move" to make the data from recorded link to the 'MoveBaseGoal' type message and return

### 2.5: Asa\_pose

A programme created for checking the current position of the robot. Helps the server determine whether the robot successfully executes the move\_base action or not.

If the robot is in the specified position. return True. Else, return False.

### **Code Explain:**

```
# Function - Subscribing to AMCL_POSE
def PoseSub(self):

# rospy.init_node('pose_sub', anonymous=False)

# Keep tracking /localization/robot_pose and callback the data
global sub
sub = rospy.Subscriber('/localization/robot_pose', PoseWithCovarianceStamped, self.PoseCallBack)
# rospy.spin()
```

Create function 'posesub' that subscribe to the rostopic '/localization/robot pose'

```
# Function - get pose data
def PoseCallBack(self, msg):
    self.msg = msg

# Position Information from Subscribing -
    x = msg.pose.pose.position.x
    y = msg.pose.pose.position.y

self.x_pos = x
    self.y_pos = y

sub.unregister()
```

The callback of the subscription, helps update the current X,Y position on the map frame.

Create a function 'pose\_check' for checking if the robot enters the target zone or not.

#### - 2.6: Asa\_sys

A programme as the server creates ros service of each function and called by the external end user.

# **Code Explain:**

```
if __name__ == "__main__":
    # create node asa_move_base"
    rospy.init_node("asa_move_base")

# create service lift_enter for external call
    rospy.Service('/asa_move_base/lift_enter', AsaEnterLift, enter_Lift)

# create service lift_exit for external call
    rospy.Service('/asa_move_base/lift_exit', AsaExitLift, exit_Lift)

# create service move_to_pose for external call
    rospy.Service('/asa_move_base/move_to_pose', AsaMoveBase, move_base)

rospy.loginfo("Lift Control Server started.")

rospy.spin()
```

#### Create node "asa\_move\_base" and service

```
'/asa_move_base/lift_enter','/asa_move_base/lift_exit','/asa_move_base/move to pose'
```

```
# receive call and send to enter_lift function
def enter_Lift(req):
    print(req)
    enterGoal, enterLift = asa_enter_lift.enter_lift_schedule(req.floor)
    print(enterGoal, enterLift)
    return enterLift, enterGoal
```

With the user's input, call programme 'asa\_enter\_lift'

```
# receive call and send to exit lidt function
def exit_Lift(req):
    exitL, InL = asa_exit_lift.quit_lift(req.floor)
    return InL, exitL
```

With the user's input, call programme 'asa exit lift'

```
# receive string input and send to asa_move_base server
def move_base(req):
    success = asa_move_base.asa_move_srv(req.floor, req.goal)
    return success
```

With the user's input, call programme 'asa\_move\_base'

# 2.7: Asa\_curr\_pos

A programme used to check whether the robot arrived to the certain location or not. If yes the programme will return True and False if it is not.

# **Code Explain:**

Subscribe to topic "/localization/robot\_pose" and get the data of the robot's current position. When call by the user, the programme will compare the data input by the user and return a boolean return to the user

# 3. Asa\_lunach

# - Asa\_luanch

A lunch directory to run the python code inside the package among the workspace "Asa\_delivery\_sys"

Called by common\_robot.launch developed by keenon while the robot booted.

# 4. Asa status

#### - Asa\_status

This package was created to keep posting the feedback from the subscribed topic.

### Code Explain:

```
def __init__(self):
    self.publisher = rospy.Publisher('/asa_status_report', String, queue_size=10)
    self._battery = None
    self._ub_status = None
    self._ch_status = None
```

Create a topic for the server listening.

```
def talker(self):
    rospy.init_node('asa_status')
    rospy.Subscriber('/battery_state', BatteryState, self.battery_callback)
    rospy.Subscriber('/urgency_button_status', Bool, self.ub_callback)
    rospy.Subscriber('/charge_state_fromSTM32', ChargeFB, self.ch_callback)
    rospy.spin()
```

Create a function to subscribe to the topic that will publish the robot status data.

```
def battery_callback(self, data):
    self._battery = data.percentage
    self.publish_msg()

def ub_callback(self, data):
    self._ub_status = data.data
    self.publish_msg()

def ch_callback(self, data):
    self._ch_status = data.state
    self.publish_msg()
```

Call function "pulish\_msg" after ros topic subscribed pulish data to the callback

```
def publish_msg(self):
    msg = {
        "battery_percentage": self._battery,
        "urgency_button_status": self._ub_status,
        "charge_state": self._ch_status
}

msg = json.dumps(msg)

if (self._battery != None and self._ub_status != None and self._ch_status != None):
        rospy.loginfo[msg]
        self.publisher.publish(msg)
```

publish receive data from the callback to the topic created

# 5. Asa switch floor

#### Asa\_switch

A package created for switching the map of the robot for multiple floor mission.

### **Code Explain:**

```
if __name__ == "__main__":
    # create node asa_switch_map
    rospy.init_node("asa_switch_map")

#create service goCharge for external call
    rospy.Service('/asa_switch_map/switchFloor', AsaSwitchFloor, switch_map)
    rospy.spin()
```

Created function "switch\_map" which subscribes to service '/switch\_dest\_floor\_map' developed by keenon.

Created function "get\_pose\_tag" that stored the location data of target floor from database.

```
def switch_map(req):
    # create service proxy to call the keenon switch map

switch_map_service = rospy.ServiceProxy('/switch_dest_floor_map', SwitchMap)

# get the pose tag from the yaml file

pose_tag_current = get_pose_tag(req.currentFloor)

pose_tag_next = get_pose_tag(req.nextFloor)

# call the keenon switch map service with the floor and pose tags

result = switch_map_service(req.nextFloor, pose_tag_current, pose_tag_next)

return result.result
```

Execute switching floor and localize the robot on the new floor map.

# 6. How to implement the package

# Step 1: Create a workspace directory

- Open Terminal
- From the location you want, type " mkdir 'your workspace name' "
- enter the directory you create by typing "cd 'your\_workspace\_name' "
- create a file call src by typing " mkdir src "
- typing "catkin\_make" to build the wordspace

# Step 2: Download the package

- Download the repository's zip file from github
   url: <a href="https://github.com/ASARobotics/keenon robot ROS system">https://github.com/ASARobotics/keenon robot ROS system</a>
- Unzip file and enter directory "backup\_code"
- Unzip file "Keenon.zip"
- from the directory, copy directory "asa\_delivery\_sys" to the src directory you have created in the workspace
- back to the top of your workspace and type in "catkin make"

# Step 3: Move the required file to the Ros Directory

- Move all the file in the devel directory to the Keenon Ros Directory
  - the location should be: /opt/ros/indigo/
- From this content with matching the name of different directory
- For the "share" directory, copy directory "asa\_delivery\_sys" from the src file first, then copy the cmake directory from each package within the "devel/share" from your workspace, and delete the "cmake.txt" file

# Step 4: Change the Launch File

- Enter directory "/opt/ros/indigo/share/robot settings/launch"
- backup the launch file "robot\_common.launch" by typing "cp robot common.launch robot common.launch.bak"
- Edit the launch file by typing "nano robot\_common.launch"
- implement the following code": <include file="/opt/ros/indigo/share/asa\_delivery\_sys/asa\_launch/launch/asa\_sys.launc h">
- </include> "
- Reboot the robot