
## 1 5&6

## Chapter 1: A Tour of Computer System 1.5 Caches Matter

- An important lesson from this simple example is that a system spends a lot of time moving information from one place to another.
  - The machine instructions in the hello program are originally stored on disk.
  - When the program is loaded, they are copied to main memory.
  - As the processor runs the program, instructions are copied from main memory into the processor.
  - Similarly, the data string 'hello,world\n', originally on disk, is copied to main memory and then copied from main memory to the display device.
- Some truths about processor-memory gap:
  - Larger storage devices are slower than smaller storage devices.
  - Faster devices are more expensive to build than their slower counterparts.
  - a typical register file stores only a few hundred bytes of information, as opposed to billions of bytes in the main memory.
  - Processor can read data from the register file almost 100 times faster than from memory.



- To deal with the processor—memory gap, system designers include smaller, faster storage devices called cache memories.
  - L1 cache (SRAM static random access memory: 静态随机存取存储器) holds tens of thousands of bytes and can be accessed nearly as fast as the register file.
  - L2 cache (SRAM static random access memory: 静态随机存取存储器) hundreds of thousands to millions of bytes is connected to the processor by a special bus. 5 times slower than L1 cache but 5-10 times faster than main memory.

## 1.6 Storage Devices Form a Hierarchy

- The main idea of a memory hierarchy is that storage at one level serves as a cache for storage at the next lower level.
  - the register file is a cache for the L1 cache.
  - Caches L1 and L2 are caches for L2 and L3.
  - The L3 cache is a cache for the main memory, which is a cache for the disk.
  - On some networked systems with distributed file systems, the local disk serves as a cache for data stored on the disks of other systems.

