

METHOD STATEMENT

Process: BACK OF HOUSE FLOOR TREATMENT

Site: APPLE R118 - NEW STREET, BIRMINGHAM

<u>Operations Director</u>: Thomas Campton <u>Site Supervisor</u>: Adam Cullen

Originator: D.Campton Position: Director Date: 26th October 2017

H & S Representative

This method statement is critical to the health and safety of the activity it relates to. It is to be strictly adhered to. Any deviation must first be authorised by the Site Supervisor.

Specified Works: Floor Treatment Back Office Areas

Access: As specified 20th and 21st November 2017

From 19:30 to 06:00 – 2 nights

Working Environment and Restrictions: Health & Safety, Security & Fire Regulations In

accordance with our policies and site requirements

Protection of Others: Work to be undertaken outside trading hours

Hazard Warning Signage placed strategically& areas cordoned off.

Emergency Procedures : Normal site emergency procedures

Personal Protective Equipment Appropriate footwear. PPE issued - Gloves ,Safety Glasses.,

Ear plugs, Masks, to be used where appropriate & as instructed.

Plant and Equipment: Rotary Floor Machines, Wet Vacuums, sundry items

Materials Handling/Storage and Safety Information: No special procedures required

Disposal in accordance with MSDS

Stages: (to be undertaken in correct sequence)

BACK OF HOUSE AREAS – Strip and Seal

- 1. Make contact with Security and Site contact
- 2. Check in using Service Channel GPS
- 3. Cordon off area where work to be carried out & position Warning Signage
- 4. Sweep / Pre Vacuum all areas.
- 5. Apply diluted solution of Turbo Strip using mops
- 6. Agitate using Floor Machine & pad.
- 7. Use doodle bugs to agitate in corners & edges
- 8 .Recover Slurry using Wet Vacuums.
- 9. Rinse thoroughly & allow to dry
- 10. Apply 2 coats of Secura Floor Sealant at right angles for even coverage- ensuring surface & Applicator free of dust & particles
- 11. Remove all products & equipment from site
- 12 . Sign out of Work Order & site

N.B. No Foot or wheeled access for 4.6 hours to enable dressing to dry & harden, time will depend on ambient temperature.



