#### **Computer Systems**

Dr. Vasilios Kelefouras

Email: v.kelefouras@plymouth.ac.uk

Website:

https://www.plymouth.ac.uk/staff/vasilioskelefouras

School of Computing (University of Plymouth)

#### Modern CPU Hardware Architectures

#### **Outline**

- Superscalar processors
- Superpipelining processors
- In order and out of order processors
- RISC, CISC processors
- Moore's Law and hardware architecture trends

#### Superscalar Processors

- You have been taught about CPU pipelining but performance is never enough
- Any other options?
- Why not make the pipeline deeper and deeper?
  - By adding more pipeline stages the clock cycle is reduced
  - But beyond some point, adding more pipe stages doesn't help, because control/data hazards increase, and become costlier

#### Superscalar Processors

- A superscalar processor can execute more than one instruction during a clock cycle by simultaneously dispatching multiple instructions to different execution units on the processor
- Duplicates the pipeline to accommodate Instruction Level Parallelism (ILP)
  - Note that duplicating HW in just one pipe stage doesn't help, e.g., when having 2 ALUs, the bottleneck moves to other stages
- It therefore achieves more throughput (the number of instructions that can be executed in a unit of time) that would otherwise be impossible at a given clock rate
- Superscalar machines issue a variable number of instructions each clock cycle, up to some maximum
  - instructions must be independent no data or control dependencies

# Pipeline vs 2 way Superscalar (pipelined)

5								
	1	2	3	4	5	6	7	8
Instruction 1	IF	ID	EX	MEM	WB			
Instruction2		IF	ID	EX	MEM	WB		
Instruction3			IF	ID	EX	MEM	WB	
Instruction4				IF	ID	EX	MEM	WB
Instruction 1	IF	ID	EX	MEM	WB			
Instruction2	IF	ID	EX	MEM	WB			
Instruction3		IF	ID	EX	MEM	WB		
Instruction4		IF	ID	EX	MEM	WB		

Careful: If the instructions are interdependent, then superscalar does not improve performance at all

# Superscalar Hardware Support

- Extra hardware to simultaneously fetch multiple instructions is needed
- Hardware logic to determine data dependencies is needed, involving the registers' values
- Extra hardware (functional units) to execute multiple instructions in parallel
- Extra hardware (functional units) to issue multiple instructions in parallel
- More extra hardware for more complicated notions (out of the scope of this module)


## Superscalar vs Superpipelining (1)

- Superpipelining: Vaguely defined as deep pipelining, i.e., lots of stages
- Superscalar issue complexity: limits super-pipelining
- How to compare them?
  - e.g., 2-way Superscalar vs. two stages

IF	ID	EX	MEM	WB	
IF	ID	EX	MEM	WB	
	IF	ID	EX	MEM	WB
	IF	ID	EX	MEM	WB

IF1	IF2	ID1	ID2	EX1	EX2	M1	M2	WB1	WB2			
	IF1	IF2	ID1	ID2	EX1	EX2	M1	M2	WB1	WB2		
		IF1	IF2	ID1	ID2	EX1	EX2	M1	M2	WB1	WB2	
			IF1	IF2	ID1	ID2	EX1	EX2	M1	M2	WB1	WB2

# Superscalar vs Superpipelining (2)



#### Superscalar Problem

- what if two successive instructions can't be executed in parallel?
  - Superscalar operation is double impacted by a stall
- Superscalar depends upon:
  - Instruction level parallelism (ILP)
  - Compiler based optimization
- Limited by
  - Data dependencies
  - Control dependencies

#### Is superscalar good enough?

- A superscalar processor can fetch, decode, execute more than one instructions in parallel
- □ But...
  - Can execute only independent instructions in parallel
    - Whereas adjacent instructions are often dependent
  - So the utilization of the second pipe is often low
- Solution: out-of-order execution
  - Execute independent instructions in a different, more efficient order
  - A specific HW mechanism examines a sliding window of consecutive instructions (instruction window – it is a small memory)
  - Ready instructions get picked up from window and executed out of order
  - Instructions enter (dispatched) and leave (committed) the instruction window in program order, and an instruction can only leave the window when it is the oldest instruction in the window and it has been completed

## Out of Order Processors (1)

- The pipelines we have studied so far are statically scheduled and inorder, i.e., instructions are executed in program's order
- If a hazard causes stall cycles, then all instructions up to the offending instruction are stalled
  - Forwarding, branch prediction, and other techniques can reduce the number of stall cycles, but sometimes a stall is unavoidable
- Consider the following assembly code in a superscalar processor
  - The first instruction stalls the second pipe
- What about changing the order of the instructions?
  - No stall exists now
  - Careful: data dependencies must be preserved

IMUL R3  $\leftarrow$  R1, R2 ADD R3  $\leftarrow$  R3, R1

IMUL R5  $\leftarrow$  R6, R8

ADD R7  $\leftarrow$  R6, R8

IMUL R3 
$$\leftarrow$$
 R1, R2  
IMUL R5  $\leftarrow$  R6, R8

ADD R7  $\leftarrow$  R3, R5

ADD R3  $\leftarrow$  R3, R1

## Data flow analysis

S1: r1 = r0/7 //division needs many cycles

52: r8 = r1 + r2


S3: r5 = r5 + 1

54: r6 = r6 - r3

\$5: r4=r5+r6

\$6: r7=r8\*r4

#### Data Flow Graph



In order execution:

1	2	3	4	5	6

In order execution 2-way superscalar:

1<sup>st</sup> pipe: 1 2 4 5 6 2<sup>nd</sup> pipe: 3

Out of order execution 2-way superscalar:

1<sup>st</sup> pipe: 1 2 6 2<sup>nd</sup> pipe: 3 4 5

Time

#### Out of Order Execution (1)


- Idea: Move the dependent instructions out of the way of independent ones
  - Rest areas for dependent instructions: Reservation station
- Instruction window: It is a memory that holds the instructions that have been fetched and decoded and are waiting to be executed
  - Note: Often, the instruction window doesn't actually exist as a single buffer, but is distributed among reservation stations and reorder buffer

# Out of Order Execution (2)

- 15
- Fetch, decode & dispatch instructions in order
  - Multiple instructions are fetched/decoded/dispatched in parallel
  - Instructions are put in the instruction window reservation stations (RS)
- Execute instructions (out of order) that are ready in Stations
   the reservation stations speculative execution
  - Instruction operands must be ready
  - Available execution resources
- After execution:
  - Broadcast result on bypass network
  - Signal all dependent instructions that their data are ready
  - Commit instructions (leave the instr. window) in-order
  - □ All execution within the instruction window is speculative (i.e., side-effects are not applied outside the CPU) until it is committed


Fetch Decode Dispatch Stations i Execute **FPU FPU ALU ALU** Reorder Buffer Commit Store Buffer

- Advantages: Better performance!
  - Exploit Instruction Level Parallelism (ILP)
  - Hide latencies (e.g., L1 data cache miss, divide)
- Disadvantages: HW is much more complex than that of in-order processors
  - More expensive, larger chip area, higher power consumption
- Can compilers do this work instead?
  - In a very limited way
  - Compilers lack runtime information
    - Conditional branch direction
    - Data values, which may affect calculation time and control
    - Cache miss / hit



#### Out of Order Processors – the Pipeline (1)


- Dispatch: new instructions are added to the instruction window reservation stations (RS)
- Reservation stations (RS)
  - Instructions wait for their inputs
  - Instructions wait for their functional units
  - If instruction operands are ready they are sent to the FU
  - Otherwise, check on bypass network and wait for operands
- Functional units (FU)
  - ALUs, AGUs, FPUs



## Out of Order Processors – the Pipeline (2)

#### Bypass network


- Broadcast computed values back to reservation stations
- ReOrder buffer (ROB)
  - It allows instructions to be committed in-order
  - De-speculates execution, mostly by Committing instructions in-order
  - flushes the speculative instructions when a misprediction is discovered



## Out of Order Processors – the Pipeline (3)

#### Commit

- All execution within the instruction window is speculative (i.e., side-effects are not applied outside the CPU) until it is committed
- Instructions can write to memory only once it is certain they should have been executed
- Instructions must not affect machine state while they are speculative
- Instructions enter and leave the instruction window in program order, and an instruction can only leave the window when it is the oldest instruction in the window and it has been completed




The instruction window is instantiated as RS & ROB


## Out of Order Processors – the Pipeline (4)

#### **Store Buffer:**

- Stores are not executed Out of Order (OoO)
  - Stores are never performed speculatively
  - There is no transparent way to undo them
- Stores are also never re-ordered among themselves
  - The Store Buffer dispatches a store only when
    - The store has both its address and its data ready and
    - There are no older stores awaiting dispatch




# A Superscalar Processor



## Out of Order Processors - Summary

- Advantages
  - Help exploit Instruction Level Parallelism (ILP)
  - Help hide latencies (e.g., cache miss, divide)
  - Superior/complementary to instuction Scheduler in the compiler
    - Dynamic instruction window
- Complex micro-architecture hardware
  - Complex instruction logic
  - Requires reordering mechanism (retire/commit)
  - Misprediction/speculation recovery
- Speculative Execution
  - Advantage: larger scheduling window ⇒ reveals more ILP
  - ssues:
    - Complex logic needed to recover from mis-prediction
    - Runtime cost incurred when recovering from a mis-prediction

# Comparison of different processors (Brainiacs vs Speed-Demons) (1)




(<a href="http://www.lighterra.com/papers/modernmicroprocessors/">http://www.lighterra.com/papers/modernmicroprocessors/</a>)

# Comparison of different processors (Brainiacs vs Speed-Demons) (2)

- "Brainiac designs"
  - Extra HW in order to achieve more Instruction Level Parallelism (ILP) out of the code
  - Millions of extra transistors
  - More design effort
  - Consume more power
- "Speed-Demons"
  - Run at higher clock speeds because they are simpler
  - Simple HW design
  - Less Chip area
  - Less power consumption

Which would you rather have: 4 powerful brainiac cores, or 8 simpler in-order cores? they use the same chip area



# What is ISA (Instruction Set Architecture)

- It provides commands to the processor, to tell it what to do, e.g., add, load, store
- ISA is analogous to a human language
- Allows communication
  - Human language: person to person
  - □ ISA: software to hardware
- Need to speak the same language/ISA
- Many common aspects
  - Part of speech: verbs, nouns, adjectives, adverbs, etc.
  - Common operations: calculation, control/branch, memory
- Different computer processors may use almost the same instruction set

# RISC vs CISC (1)

- Complex instruction set computer (CISC): complex instructions can execute several low-level operations (such as a load from memory, an arithmetic operation, and a memory store)
  - CISC puts emphasis on HW
  - CISC was developed to make compiler development simpler
  - CISC is typically used for general purpose computers
- Reduced instruction set computer (RISC): simple and 1 cycle instructions
  - RISC puts emphasis on SW
  - RISC was developed to make HW simpler
  - RISC is typically used for smart phones, tablets and other embedded devices

# RISC vs CISC architecture comparison

#### CISC

- Instructions take varying amount of cycle time (multiple cycles)
- Instructions provide complex operations
- 3. Many different instructions
- 4. Less registers
- 5. Pipeline is difficult
- 6. Different length instructions
- The Opcode has no fixed position and size

#### **RISC**

- 1. 1 cycle instruction
- 2. Simple operations
- 3. Few different instructions
- 4. More registers
- 5. Pipeline is easy
- All instructions have the same length(4 bytes)
- 7. The Opcode has a fixed position and size within the instruction

30

Opcode specifies the operation to be performed


- RISC fixed position and size
- CISC no fixed position and size

**RISC** instruction format:

6 bits
Opcode

32 bits

#### **CISC** instruction format:




#### RISC vs CISC - Pros & Cons

#### **CISC:**

- Emphasis on HW
- Multi-clock complex instructions
- Less "instructions/program" with "complex" instructions
- Easy for assembly-level programmers, good code density
- Easy for compiler writers
   support more complex higher-level
   languages

#### RISC:

- Emphasis on SW
- Single-clock simple instructions
- Less "cycles/instruction" with single-cycle instructions
- $\bullet$  Faster design and implementation RISC takes about 1/5 the design time
- The performance of the RISC processors highly depends mostly on the compiler or programmer



#### RISC vs CISC - Conclusions

- Nowadays, the two architectures almost seem to have adopted the strategies of the other
- CISC and RISC implementations are becoming more and more alike
  - Today's RISC chips
    - support as many instructions as yesterday's CISC chips
    - incorporate more complicated, CISC-like commands
    - make use of more complicated hardware, making use of extra function units for superscalar execution
  - Today's CISC chips
    - use many techniques formerly associated with RISC chips
    - are now able to execute more than one instructions within a single clock

#### Think-Pair-Share 2<sup>nd</sup> Exercise


**Question:** What is in your opinion the best Instruction Set Architecture (ISA) and why?

**Answer:** There is no good and bad ISA, but appropriate and not appropriate. The appropriate ISA depends on the target goals and on the target application

#### Moore's Law – The number of transistors on integrated circuit chips (1971-2016)


Our World in Data

Moore's law describes the empirical regularity that the number of transistors on integrated circuits doubles approximately every two years. This advancement is important as other aspects of technological progress – such as processing speed or the price of electronic products – are strongly linked to Moore's law.



#### Hardware Architecture Trends





Taken from <a href="https://www.researchgate.net/publication/336577121">https://www.researchgate.net/publication/336577121</a> BACKUS Comprehensive High-Performance Research Software Engineering Approach for Simulations in Supercomputing Systems

#### Conclusions

- Computer architectures are complex and diverse
- There is a large number of different computer architecture classifications
- Classification helps us to select the most appropriate architecture
- Computer architectures are evolving year by year
- The computer architecture requirements are continually increasing
- There is no good or bad computer architecture. It depends on the
  - √ target goals, e.g., performance, flexibility
  - √ target application

# Further Reading

Structured Computer Organization. Sixth Edition, Andrew S. Tanenbaum, Todd Austin, PEARSON, 2012,

 $\frac{https://universalflowuniversity.com/Books/Computer%20Programming/Computers%2C}{\%20Architecture\%20and\%20Design/Structured\%20Computer\%20Organization\%206t}{h\%20Edition.pdf}$ 

Computer Organization & Architecture. Designing for Performance. William Stallings, Seventh Edition, available at

http://home.ustc.edu.cn/~louwenqi/reference books tools/Computer%20Organization%20and%20Architecture%2010th%20-

<u>louwenqi/reference books tools/Computer%20Organization%20and%20Architecture%2010th%20-%20William%20Stallings.pdf</u>

Nicholas FitzRoy-Dale, The VLIW and EPIC processor architectures, available at <a href="https://www.cse.unsw.edu.au/~cs9244/06/seminars/02-nfd.pdf">https://www.cse.unsw.edu.au/~cs9244/06/seminars/02-nfd.pdf</a>

Thank you