

## A.P. SHAH INSTITUTE OF TECHNOLOGY

Department of Computer Science and Engineering **Data Science** 

Class: S.E.D.S. Semester:- III

**Subject: Computer Graphics** A.Y:- 2022-23

# Memory banking in 8086

In any processor, there is memory. This memory is stored in locations. Each location can hold one byte(8-bits) of data. Memory banking in 8086 is, having divided the memory into two banks (two parts).

Why can one location store only one byte?

Minimum byte operation needs 1 byte. So it is preferred to assign minimum memory to one location, so that memory is not wasted.

If each location can hold 2 bytes (16-bits) of memory,

- When processor performs 16-bit operations it is good
- But when the processor performs 8-bit operation, then the remaining 8 bits are wasted.

Even if it is a 64-bit intel processor, each location can hold 8 bits of memory only.

Whenever 16-bit data is stored in locations, it is stored in two consecutive memory locations, lower byte is stored in lower address and higher byte is stored in higher address. This concept of lower byte lower location, higher byte in higher location is known as little Endian rule.

If each location can store 8-bits how can the processor perform 16-bit operation?

By memory banking.

## **Memory Banking:**

Here we shall consider an 8086 processor which can hold 1MB of memory due to its 20 address lines ( $2^{20} = 1MB$ ) [Refer introduction tutorials]. So this 1MB memory is divided into two parts ( two banks ), where one bank consists of all even addresses and the other bank consists of odd addresses.






# A.P. SHAH INSTITUTE OF TECHNOLOGY

Department of Computer Science and Engineering **Data Science** 

Class: S.E.D.S. **Semester:- III** 

A.Y:- 2022-23 **Subject: Computer Graphics** 



Purpose of memory banking:

As the 16-bit data is stored in 2 locations, lower byte in lower address and upper byte in next consecutive address location.

location	data
00000H	45H
00001H	13H
00002H	
00003H	



# A.P. SHAH INSTITUTE OF TECHNOLOGY

Department of Computer Science and Engineering **Data Science** 

Class: S.E.D.S. Semester:- III **Subject: Computer Graphics** A.Y:- 2022-23

The data stored here is 1345H. This is representation of data in hexadecimal form. So whenever the processor needs to fetch this, it first gives the address to the address bus and fetches 45H and then it gives the next address, then it fetches 13H. So overall a 16-bit processor needs 2 cycles to perform a 16-bit operation, which is completely a wrong concept. This thing led to memory banking.

If the memory can be divided into two parts, with some algorithm, two 8-bit datas can be fetched in one cycle.

As Even bank starts from  $00000_H$  and goes up to FFFFE<sub>H</sub>, it stores the lower byte so also known as lower bank. Odd bank locations start from 00001<sub>H</sub> and go upto FFFFF<sub>H</sub>, this stores higher byte, thus also known as **Higher bank** in 8086.

How does banking work?

There are totally 20 address lines in 8086, that can access the locations. Each location is decided by these 20 address lines ( $A_0$ ,  $A_1$ ...... $A_{19}$ ).

				$\wedge$	
A19,	А3,	A2,	A1,	AO	location
0	0	0	0	0	0
0	0	0	0	1	1
0 0	0	0	1	0	2
0	0	0	1	1	3
0	0	1	0	0	4
0	0	1	0	1	5
1	1	1	1	0	FFFFE
1	1	1	1	1/	FFFFF





# A.P. SHAH INSTITUTE OF TECHNOLOGY

Department of Computer Science and Engineering **Data Science** 

Class: S.E.D.S. Semester:- III **Subject: Computer Graphics** A.Y:- 2022-23

If observed, for every consecutive location starting from even location, there is only change in address ( $A_0$  is only different).

### For Eg:

Locations  $0_H$  and  $1_H$  are consecutive and have the same address except  $A_0$ .

Locations 3<sub>H</sub> and 4<sub>H</sub> are consecutive but their addresses don't have that similarity.

## Aligned data:

Locations 0<sub>H</sub> and 1<sub>H</sub> is the example of aligned data. 8086 can fetch this type of data in one cycle.

## **Misaligned data:**

Locations 3<sub>H</sub> and 4<sub>H</sub> are the example of misaligned data, 8086 needs 2 cycles to fetch this type of data.

	hig	her bank	lower l	oank	
000	01H			- 000	00H
000	03H			- 000	02H
000	05H			000	04H
000	07H			000	06H
FFF	FF H			FFF	FE H

Now we would learn how we can access 16-bit aligned data in one cycle.

If A<sub>0</sub> address line is discarded, 8086 sends a 19-bit address, there are two locations, one location in higher bank and other location in lower with the same address, in this way 8086 can fetch 16 bit data in one cycle. But if A<sub>0</sub> is always discarded, 8086 can only perform 16-bit operations, and cannot perform 8-bit operations.

#### So we need that

- 8086 can be able to select lower bank only for 8-bit operations.
- 8086 can be able to select higher bank only for 8-bit operations.
- 8086 can be able to select both banks at single time for 16-bit operations.

Then BHE, comes into picture. It stands for bus high enable or bank high enable, and it is pronounced as BHE bar.




# A.P. SHAH INSTITUTE OF TECHNOLOGY

Department of Computer Science and Engineering
Data Science

Class :- S.E.D.S. Semester:- III

Subject : Computer Graphics A.Y:- 2022-23



BHE bar is connected to the active low of the higher bank and  $A_0$  is connected to the active low of lower bank.

Whenever  $A_0 = 0$ , lower bank is selected

And if  $A_0 = 1$ , lower bank is not selected

A<sub>0</sub> has nothing to do with higher bank

Whenever BHE = 0, higher bank is selected



# A.P. SHAH INSTITUTE OF TECHNOLOGY

Department of Computer Science and Engineering **Data Science** 

Class:- S.E.D.S. **Semester:- III** 

A.Y:- 2022-23 **Subject : Computer Graphics** 

And if BHE = 1, higher bank is not selected

BHE has nothing to do with lower bank

ВНЕ	$A_0$	Mode
0	0	Both the banks are selected and 8086 performs 16-bit operations.
0	1	Higher bank is selected and 8086 performs 8-bit operations with higher bank memory only.
1	0	Lower bank is selected and 8086 performs 8-bit operations with Lower bank memory only.
1	1	Both the banks are discarded and 8086 is in idle mode.

BHE bar and  $A_0$  are decided by the processor according to instructions given.

- If it is an 8-bit instruction given an odd address then BHE=0 and  $A_0 = 1$ .
- If it is a 16-bit instruction then BHE = 0,  $A_0 = 0$

If it is a pentium processor, which is a 64-bit processor. Then there will be 8 memory banks.