Subject: Noise Control Applications - Module 1 Assignement

Date: February 6, 2025 (Submitted)

Problem 1 - Cut-on Frequencies in Ducts and Pipes

The Matlab code for this problem is listed in Appendix 1.

Problem 1a

The lowest cut-on frequency for a rectangular duct with air flow is given by equation,

$$f_{\text{cut-on}} = 0.5 \cdot \frac{c}{L} \tag{1}$$

where c is the speed of sound in air, 343 $\frac{m}{s}$, and L is the largest side of the rectangular cross-section.

With cross-sectional dimensions of $L_x=12~\mathrm{cm}$ and $L_y=20~\mathrm{cm}$, the lowest cut-on frequency for this rectangular duct is,

$$f_{\text{cut-on}} = 0.5 \cdot \frac{343 \frac{m}{s}}{0.20 \text{ m}} = 857.5 \text{ Hz}$$

Problem 1b

The lowest cut-on frequency for a circular duct with air flow with the same cross-sectional area as the rectangular duct in part (a.) can be calculated using equation,

$$f_{\text{cut-on}} = 0.568 \cdot \frac{c}{d} \tag{2}$$

where c is the speed of sound in air, 343 $\frac{m}{s}$, and d is diameter of the circular duct.

The cross-sectional area of the rectangular duct is,

Area
$$_{\text{rectangular duct}} = 0.12 \text{ m} \cdot 0.20 \text{ m} = 0.024 \text{ m}$$

The corresponding diameter for this area is,

$$\mathrm{diameter} = \sqrt{\frac{0.24~\mathrm{m}^2}{\pi}} \cdot 2 = 0.17~\mathrm{m}$$

Using Eq. 2, the lowest cut-on frequency for this circular duct with air flow is,

$$f_{\text{cut-on}} = 0.568 \cdot \frac{1,500 \frac{\text{m}}{\text{s}}}{0.17 \text{ m}} = 1,114.5 \text{ Hz}$$

Problem 1c

The lowest cut-on frequency for this circular duct with water flow can be calculated using Eq. 2,

$$f_{\rm cut-on} = 0.568 \cdot \frac{1,500 \frac{m}{s}}{0.17 m} = 4,873.9 \; Hz$$

The lowest cut-on frequency for water is considerable larger than it is for air flow.

Problem 1d

The speed of sound in air is calculated by,

$$c = \sqrt{\gamma \cdot R \cdot T_K} \tag{3}$$

where $\gamma=1.4$ is the ratio of specific heats, $R=287~\frac{J}{kg\cdot K}$ is the gas constant, and T_K is the absolute temperature in Kelvin.

Figure 1 illustrates how the lowest cut-on frequency changes as the air heats from 0° to 500° Celsius.

The square-root relationship between temperature and the speed of sound in air is apparent and governs the behaviour of the cut-on frequency.

Lowest Cut-on Frequency for a Circular Pipe with Air Flow Versus Air Temperature




Figure 1: Lowest cut-on frequency for a circular 5 cm diameter duct versus air temperature.

Problem 1e

Question: Are cut-on frequencies higher for a circular or rectangular duct for a given cross-sectional area?

The lowest cut-on frequency is higher for a circular duct than for a rectangular duct for a given cross-sectional area.

For the dimensions given in class, the rectangular duct is not square. This produces a larger dimension and thus a smaller, lowest cut-on frequency. If the rectangular duct is square dimensions on the order of the circular duct diameter with the same cross-sectional area, the cut-on frequencies are approximately equal.

Question: What about in air versus water?

The lowest cut-on frequency is larger for water than for air. The cut-on frequency is proportional to the speed of sound and the speed of sound in water is greater than the speed of sound in air.

Question: What about cold versus hot air?

The lowest cut-on frequency is higher for warm air than it is for cold air.

Problem 2 - Muffler Design Comparison

The Matlab code for this problem is listed in Appendix 2.

For these muffler comparisons, it is assumed that there is no resistive terms and no flow. Since transmission losses are considered, the end corrections (i.e., load impedance at outlet of the system) have no physical meaning and are not accounted for in the computations.

Problems 2a, 2b, and 2c

Figure 2 shows the transmission loss profiles for a simple expansion chamber, a double-tuned expansion chamber, and a cascaded double-tuned expansion chamber muffler.

The peaks for the simple expansion chamber (red, dashed line) are approximately 22 dB and occur at frequencies with a wavelength that is a quarter of the length of the expansion chamber. Minimal loss occurs at half wavelength multiples.

The addition of the extension tube inside the muffler produces a quarter wavelength resonator. The side branch of Ji (2005; Slide 11, Lecture 3 notes) was used to calculate L_o . For the cascaded double-tuned expansion chamber, the extension tubes produce a secondary quarter wavelength resonator.

As noted in the office hours session, there is no damping which produces artificially high resonances.




Figure 2: Transmission loss profiles for a simple expansion chamber, a double-tuned expansion chamber, and a cascaded double-tuned expansion chamber mufflers.

Problem 2d

Figure 3 shows the transmission loss profiles for a cascaded double-tuned expansion chamber, and a modified cascaded double-tuned expansion chamber muffler.

Two modifications were made to the original system:

1. The left 3" extension tube in the left chamber was shortened to 2" inches, making the respective muffler section 1" longer.

2. The left 3" extension tube in the right chamber was lengthened to 4", making the respective muffler section 1" shorter.




Figure 3: Transmission loss profiles for a cascaded double-tuned expansion chamber muffler and a modified version of this muffler.

These modifications change the symmetry of the cascaded system, and allow the resonate frequencies to be independently changed.

Problem 3 - Bugle Recorder

Diameters of holes should be smaller than a wavelength.

 $R_{\rm A}$ is neglected (energy loss).

Problem 3a

Problem 3b

Problem 4 - Intake Duct

Problem 4a

Problem 4b

Problem 4c

Problem 4d

Problem 5 - Intake Duct Silencer

Problem 5a
Problem 5b
Problem 5c
Problem 5d
Problem 5e

```
%% Synopsis
3
4
    % Question 1 - Cut-on Frequencies in Ducts and Pipes
9
   %% Environment
10
    close all; clear; clc;
12 % restored efault path;
    \% \ addpath ( \ genpath ( \ '' \ ) \, , \ '-begin ' \ ) \, ; addpath ( genpath ( \ '../40 \ Assignments/00 \ Support ' \ ) , \ '-begin ' \ );
14
16
    \% \ set (\ 0\ ,\ 'DefaultFigurePosition',\ [\ 400\ 400\ 900\ 400\ ]\ );\ \%\ [\ left\ bottom\ width\ height\ ] \ set (\ 0\ ,\ 'DefaultFigurePaperPositionMode',\ 'manual'\ );
18
    set (0, 'DefaultFigureWindowStyle', 'normal');
    set( 0, 'DefaultLineLineWidth', 1.5 );
set( 0, 'DefaultTextInterpreter', 'Latex' );
   format ShortG;
24
    pause ( 1 );
26
    PRINT FIGURES = 0;
28
29
   %% Define Constants and Anonymous Functions
    c\_air = 343; % The speed of sound in air (meters per second).
    c water = 1500; % The speed of sound in water (meters per second).
    gamma \ = \ 1.4\,; \quad \% \ The \ ratio \ of \ specific \ heats \ [unitless].
    R = 287; % The gas constant [Joules per ( kilogram * Kelvin)].
38
40
    h_f_{cut}_{on}_{rectangular}_{duct} = @(c, L) 0.5 .* c./ L;
41
    \% c - The speed of sound.
    \% L - The largest cross-section dimension of the rectangular duct.
45
    h f cut on circular duct = @(c, d) 0.568 .* c ./ d;
46
47
48 \quad \% \quad c \quad - \quad The \quad speec \quad of \quad sound.
49
    \% L - The diameter of the circular duct.
    h speed of sound in air = @(gamma, R, temperature Kelvin) sqrt(gamma .* R .*
        temperature Kelvin );
56 %% Problem 1a
58
   \% The cross-sectional dimensions for the rectangular duct are: Lx = 12 cm and Ly = 20 cm.
59
60 % The largest dimension is Ly = 20 cm or 0.2 m.
61
    % The cut-on frequency is,
62
63
    h_f_cut_on_rectangular_duct( c_air, 0.2 ); % 857.5 Hz (shown in class 858 Hz)
         fprintf( 1, '\n Problem 1a: The lowest cut-on frequency for the rectangular pipe with air is
64
          \%3.1f Hz.\n', h_f_cut_on_rectangular_duct( c_air, 0.2 ));
68
   %% Problem 1b
70
    \% The cross-sectional dimensions for the rectangular duct are: Lx = 12 cm and Ly = 20 cm.
   \% \ \ The \ \ cross-sectional \ \ area \ \ of \ \ the \ \ rectangular \ \ duct \ \ is \ \ 12 \ \ cm \ \ * \ \ 20 \ \ cm \ ^2 \ \ or \ \ 0.024 \ \ m^2.
72
    rectangular duct cross sectional area = 0.12 * 0.20; % 0.024 m^2
```

```
74
75 % The diameter of the circulat pipe is,
   circular_duct_diameter = sqrt ( 0.024 / pi ) * 2; % 0.17481 meters
78
   % Check:
79
       \% pi * ( circular duct diameter / 2 ) ^2 CHECKED
80
81
82
   % The cut-on frequency for the circular duct is,
   83
84
       ) with air is \%3.1f\ Hz.\n', h_f_cut_on_circular_duct( c_air, circular_duct_diameter ) );
85
86
87
   %% Problem 1c
88
89
   \% The cut-on frequency for the circular duct with water is,
   h_f_cut_on_circular_duct( c_water, circular_duct_diameter ); % 4,873.9 Hz
       fprintf( 1, '\n Problem 1c: The lowest cut—on frequency for the circular pipe (of equal area
       ) with water is \%3.1f\ Hz.\n', h_f\_cut\_on\_circular\_duct(c\_water, circular\_duct\_diameter));
   \% The cut-on frequency should be higher because it is proportional to the
   % speed of sound in a given medium.
97
9.8
99
   %% Problem 1d
   fprintf( 1, '\n Problem 1d: See the figure.\n' );
    \texttt{temperature\_range\_celsius} \ = \ 0:0.1:500\,; \quad \% \ \textit{Celsius}
       temperature range kelvin = temperature range celsius + 273.15; % Kelvin
   FONT SIZE = 14;
    figure(); ...
       temperature_range_kelvin ), 0.05 ) ./ 1e3 ); grid on; legend( 'Duct Diameter = 5.0 cm', 'Location', 'East', 'FontSize', FONT_SIZE, 'Interpreter
          'Latex');
          set ( gca, 'FontSize', FONT SIZE );
       116
       ylabel( 'Lowest Cut-on Frequency [kHz]', 'FontSize', FONT_SIZE );
118
           caption = sprintf( 'Lowest Cut-on Frequency for a Circular Pipe with Air Flow Versus Air
       Temperature\n');
           title ( caption , 'FontSize', FONT SIZE );
       ylim([3 7]);
128
129
   %% Problem 1e
   fprintf( 1, '\n Problem 1e: See Section Problem 1e of the Matlab script for the answers.\n\n');
   % Question: Are cut-on frequencies higher for a circular or rectangular duct for a given cross-
       sectional area?
   \% The lowest cut-on frequency is higher for a circular duct than for a
   \% rectangular duct for a given cross-sectional area.
138
   % For the dimensions given in class, the rectangular duct is not square.
   % This produces a larger dimension and thus a smaller, lowest cut-on
   % frequency.
   \% If the rectangular duct is square dimensions on the order of the circular
   \% duct diameter with the same cross-sectional area, the the cut-on
   % frequencies are approximately equal.
```

```
146
148
    % Question: What about in air versus water?
149
    \% The lowest cut-on frequency is larger with water than air. This due to
    % the fact that the cut-on frequency is proportional to the speed of sound
    % and the speed of sound in water is greater than it is in air.
154
155 % Question: What about cold versus hot air?
156
    % For a circular pipe, the cut-on frequency is higher in warm air than cold
158
    \% air.
159
162 \quad \% \quad Clean-up
    if ( ~isempty( findobj( 'Type', 'figure')))
    monitors = get( 0, 'MonitorPositions');
164
165
              if ( size( monitors, 1 ) == 1 )
    autoArrangeFigures( 2, 2, 1 );
elseif ( 1 < size( monitors, 1 ) )
167
168
169
                  autoArrangeFigures(2,2,1);
170
    end
172
173
     if (PRINT FIGURES == 1)
174
         saveas (gcf, 'Cut-on Frequency Versus Temperature - Sunday, January 19, 2025.pdf');
176
    fprintf(1, '\n\n*** Processing Complete ***\n\n');
```

```
%% Synopsis
4
    % Question 2 - Muffler Design Comparison
9
   %% Environment
10
    close all; clear; clc;
   \% restored efault path;
    \label{eq:continuous_problem} \% \ \ addpath \left( \ \ genpath \left( \ \ ' \ ' \ \right), \ \ '-begin' \ \right);
    addpath ( genpath ( '../00 Support'), '-begin');
16
   % set(0, 'DefaultFigurePosition', [ 400 400 900 400 ]); % [ left bottom width height ] set(0, 'DefaultFigurePaperPositionMode', 'manual'); set(0, 'DefaultFigureWindowStyle', 'normal'); set(0, 'DefaultLineLineWidth', 1.5); set(0, 'DefaultTextInterpreter', 'Latex');
18
19
24
    format ShortG;
26
    pause ( 1 );
28
    PRINT FIGURES = 0;
29
   % Constants
    rho0 = 1.21; % Air density (kg per m^3).
    c = 343; % Speed of sound in air (meters per second).
    frequency set = 0:1:5e3; % Hertz
38
40
    %% Dimensions
41
42
43
    convert.inches to meters = 0.0254;
    convert.foot\_to\_meters = 0.3048;
45
46
    dimensions.inlet diameter meters = 2 * convert.inches to meters; % 0.0508 meters
    dimensions.inlet length meters = 6 * convert.foot to meters; % 1.82 meters
47
48
    {\tt dimensions.muffler\_diameter\_meters} = 10 \ * \ {\tt convert.inches\_to\_meters}; \quad \% \ \textit{0.254} \ \textit{meters}
    dimensions.muffler\_length\_meters = 18 * convert.inches\_to\_meters; ~\% ~0.4572 ~meters
    {\tt dimensions.outlet\_diameter\_meters} \ = \ 2 \ * \ {\tt convert.inches\_to\_meters}; \quad \% \ \textit{0.0508} \ \textit{meters}
    dimensions.outlet length meters = 1 * convert.foot to meters; % 0.3048 meters
54
    outlet\_flanged = false;
56
    dimensions.overhang = 3 *convert.inches_to_meters; % 0.0762 meters
58
    segment\_diameters = [ ...
59
         dimensions.outlet_diameter_meters, ...
61
          dimensions.muffler diameter meters, ...
62
          dimensions.inlet diameter meters, ...
         ].';
64
    h_area_from_diameter = @(d) pi .* d.^2 ./ 4;
67
    segment areas = h area from diameter (segment diameters);
68
69
    segment lengths = [ ...
70
         dimensions.outlet length meters, ...
          {\tt dimensions.muffler\_length\_meters}\;,\;\; \dots
         dimensions.inlet_length_meters, ...
         {\tt dimensions.overhang} \ , \ \ \dots
74
```

```
78
    %% Part a - Simple Expansion Chamber
79
    nFreq = length ( frequency set );

TL = zeros ( nFreq , 1 );
80
81
82
83
    for frequency_index = 1:1:nFreq
84
         f \ = \ frequency\_set \left( \ frequency\_index \ \right);
85
86
        T \text{ total} = [1 0; 0 1];
87
88
89
        T1 = duct\_segment\_transfer\_matrix (~f~,~rhoo~,~c~,~0.3048~,~0.0020268~)~;~~\%~Duct~-~Outlet~
        90
91
92
        97
                                                                                             + (rho0*c)*
99
             % The transmission loss calculation does not require a load impedance.
    end
    TL parta = TL; % The maximum peak value should be about 22 (21.952) dB.
104
    % Expected behaviour:
         1.) 0 dB at 0 Hz.
108
         2.) The transmission loss of a straight duct section is zero; energy out equals energy in.
    max( TL parta ); % 22 dB
114 7\% Part b - Double-tuned Expansion Chamber
    annulus_area_squared_meters = pi/4 * (0.254^2 - 0.0508^2);
116
    L\ o=0; % Assume that the Lo extension is neglible.
118
119
120
    \begin{array}{rll} nFreq &=& length \, ( & frequency \underline{\hspace{0.5cm}} set & ) \, ; \\ TL &=& zeros \, ( & nFreq \, , & 1 \, \end{array} ) \, ; \end{array}
    for frequency index = 1:1:nFreq
126
         f = frequency set(frequency index);
128
        T_{total} = [1 0; 0 1];
        T1 = \; duct\_segment\_transfer\_matrix\left( \;\; f \;, \;\; rho0 \;, \;\; c \;, \;\; \left(0.3048 \;+\; 0.0762\right) \;, \;\; 0.0020268 \;\; \right);
        134
        k = 2 * pi * f / c;
             {\rm Z\_A} \, = \, -1\,{\rm j} * {\rm rh} \, {\rm o} 0 * {\rm c} / \, {\rm annulus\_area\_squared\_meters} * \, {\rm cot} \, \left( \, k \; * \; \left( \; \; 0.0762 \; + \; L\_o \; \right) \; \right) \, ;
                 T2 = [ 1 0; 1/Z_A 1 ];
                     T4 = T2;
139
        T \text{ net} = T5 * T4 * T3 * T2 * T1 * T \text{ total};
        T11 = T \text{ net}(1, 1); \quad T12 = T \text{ net}(1, 2); \quad T21 = T \text{ net}(2, 1); \quad T22 = T \text{ net}(2, 2);
        144
             \% \ \ The \ transmission \ loss \ calculation \ does \ not \ require \ a \ load \ impedance.
    end
148
149
    TL partb = TL;
    % Expected behaviour:
```

76

```
%
                                   0 dB at 0 Hz.
                       1.)
           %
154
                       2.)
                                   0 dB at same locations as a simple expansion chamber.
                       3.) Peaks at 1,125 Hz and 3,376 Hz;
155 %
156
            \% Frequency at which the quarter-wavelength is 0.0762 meters.
           \% 343 / ( 4 * 0.0762 ); \hat{\%} 1,125 Hz.
158
            \% Also work at three-quarter-wavelength.
           % 3 * 1125; % 3,375 Hz
           %% Part c - Cascaded, Double-tuned Expansion Chamber
166
           annulus_area_squared_meters = pi/4 * (0.254^2 - 0.0508^2);
168
169
           Lo = 0; % Assume that the Lo extension is neglible.
172
           nFreq = length ( frequency \_set );
173
                       TL = zeros(nFreq, 1);
174
            for frequency_index = 1:1:nFreq
176
                       f \ = \ frequency\_set \left( \ frequency\_index \ \right);
                                 k = 2 * pi * \overline{f} / c;
178
179
                                           Z A = -1j*rho0*c/annulus area squared meters*cot(k * ( 0.0762 + L o ) );
181
                       T_{total} = [1 0; 0 1];
182
                      T1 = duct\_segment\_transfer\_matrix( f, rho0, c, (0.3048 + 0.0762), 0.0020268 ); % Duct - (0.3048 + 0.0762), 0.0020268 
                      184
185
186
                       T5 = \ duct\_segment\_transfer\_matrix (\ f\ ,\ rho0\ ,\ c\ ,\ 2*0.0762\ ,\ 0.050671\ )\ ; \quad \%\ \mathit{Duct}
187
                      T6 = T2;
                                                  \% Straight Side Branch
                       T7 = T3; \% Duct
                      T8 = T2; % Straight Side Branch
                      T9 = duct segment transfer matrix (f, rho0, c, (1.8288 + 0.0762), 0.0020268); % Duct -
                       Inlet
                      T \quad net \ = \ T9 \ * \ T8 \ * \ T7 \ * \ T6 \ * \ T5 \ * \ T4 \ * \ T3 \ * \ T2 \ * \ T1 \ * \ T \ \ total;
                      T11 = T_net(1, 1); T12 = T_net(1, 2); T21 = T_net(2, 1); T22 = T_net(2, 2);
                      198
           end
           TL partc = TL;
           %% Part d - Cascaded, Double-tuned Expansion Chamber
            nFreq = length ( frequency set );
                      TL = zeros(nFreq, 1);
208
            210
                       f = frequency\_set (frequency\_index);

k = 2*pi*f/c;
213
                                           Z A = -1j*rho0*c/annulus area squared meters*cot(k * ( 0.0762 + L o ));
214
215
                       T_{total} = [1 0; 0 1];
216
                      T2 = [1 0; 1/Z A 1]; \% Straight Side Branch
                      T3 = duct\_segment\_transfer\_matrix (\ f \,,\ rho0 \,,\ c \,,\ 0.0076 \,,\ 0.050671\ ) \,; \quad \% \ \mathit{Duct}
                                                  % Straight Side Branch
                       T5 = \ duct \_segment \_transfer \_matrix (\ f \,,\ rho0 \,,\ c \,,\ 2*0.0762 \,,\ 0.050671\ ) \,; \quad \% \ \mathit{Duct}
                      T6 = T2; % Straight Side Branch
                      T9 = duct\_segment\_transfer\_matrix( f, rho0, c, (1.8288 + 0.0762), 0.0020268 ); % Duct - (1.8288 + 0.0762), 0.0020268
```

```
Inlet
          T_{net} = T9 * T8 * T7 * T6 * T5 * T4 * T3 * T2 * T1 * <math>T_{total};
          T11 = T_{net}(1, 1); \quad T12 = T_{net}(1, 2); \quad T21 = T_{net}(2, 1); \quad T22 = T_{net}(2, 2);
          end
     TL partd = TL;
238
    %% Plot Transmission Loss Profiles
    Y LIMITS = \begin{bmatrix} -5 & 320 \end{bmatrix};
     h_figure_1 = figure(); ...
          plot (frequency_set, TL_parta, 'LineWidth', 1.0, 'LineStyle', ':', 'Color', 'r'); hold on; plot (frequency_set, TL_partb, 'LineWidth', 0.9, 'LineStyle', '--', 'Color', 'b'); plot (frequency_set, TL_partc, 'LineWidth', 0.9, 'LineStyle', '-', 'Color', 'k'); grid on;
246
          grid on;
               legend ( ...
                     'Simple Expansion Chamber', ...
249
                    'Double-tuned Expansion Chamber', ...
                    'Cascaded Double-tuned Expansion Chamber', ...
          'Location', 'SouthOutside');
xlabel('Frequency [Hz]'); ylabel('Transmission Loss [dB]');
                   Transmission Loss Profiles );
253
          title (
254
          Ax = gca;
256
               Ax. XAxis. TickLabelInterpreter = 'latex';
               Ax.YAxis.TickLabelInterpreter = \ \ {}^{\shortmid}latex\ \ ;
259
          axis ( \begin{bmatrix} -50 & 5e3+50 & Y & LIMITS \end{bmatrix} );
261
262
    Y LIMITS = \begin{bmatrix} -5 & 315 \end{bmatrix};
264
     h figure 2 = figure(); \dots
          plot (frequency_set, TL_partc, 'LineWidth', 1.0, 'LineStyle', '-', 'Color', 'k'); hold on; plot (frequency_set, TL_partd, 'LineWidth', 0.6, 'LineStyle', '--', 'Color', 'b'); grid on;
               legend ( ...
                     'Cascaded Double-tuned Expansion Chamber', ...
                    'Modified Cascaded Double-tuned Expansion Chamber', ...
                    'Location', 'SouthOutside');
          xlabel( 'Frequency [Hz]' ); ylabel( 'Transmission Loss [dB]' );
                   'Transmission Loss Profiles - Cascaded and Modified Double-tuned Cascaded Systems');
272
          title (
          %
          Ax \ = \ g\,c\,a\ ;
               Ax. XAxis. TickLabelInterpreter = 'latex';
276
               axis ( \begin{bmatrix} -50 & 5e3+50 & Y & LIMITS \end{bmatrix} );
280
281
    % Clean-up
283
     if ( ~isempty( findobj( 'Type', 'figure')))
    monitors = get( 0, 'MonitorPositions');
284
               if ( size( monitors, 1 ) == 1 )
    autoArrangeFigures( 2, 2, 1 );
287
288
               elseif (1 < size (monitors, 1))
                    autoArrangeFigures(2,2,1);
289
               end
     end
     if (PRINT FIGURES == 1)
              exportgraphics (h figure 1, 'Assignment 1 - Question 2 Figure All TL Profiles.pdf', '
          Append', true );
               exportgraphics (h figure 2, 'Assignment 1 - Question 2 Figure Comparison TL Plot For
          Cascaded Systems.pdf', 'Append', true');
     fprintf(1, '\n\n*** Processing Complete ***\n\n');
298
```

```
2
   %% Synopsis
4
   % Question 3 - Bugle Recorder
9
10 \(\overline{\pi_\infty}\) Note(s)
   \% For the lowest frequency, use 1 duct sgement with an open-ended
   % impedance (see the example of the horn in class).
14
16
   % See "2025-01-31 13 07 33-Zoom Meeting.png".
18
19
20 %% Environment
   close all; clear; clc;
   % restored efault path;
24
   \% addpath( genpath( ''), '-begin');
   addpath ( genpath ( '../00 Support'), '-begin');
26
28
   \% \ set (\ 0, \ 'DefaultFigurePosition', \ [ \ 400 \ 400 \ 900 \ 400 \ ] \ ); \ \% \ [ \ left \ bottom \ width \ height \ ]
   set (0, 'DefaultFigurePaperPositionMode', 'manual');
set (0, 'DefaultFigureWindowStyle', 'normal');
set (0, 'DefaultLineLineWidth', 1.5);
set (0, 'DefaultLineLineWidth', 1.5);
29
    set( 0, 'DefaultTextInterpreter', 'Latex' );
   format ShortG;
   pause( 1 );
   PRINT FIGURES = 0;
38
40
41
42 7% Constants and Anonymous Functions
43
   rho0 = 1.21; % Density of air (kg per cubic-meter).
45
   c = 343; % Speed of sound in air (meters per second).
46
48
   \label{eq:linear_mu} h\_R\_A = @(\ rho0\ ,\ c\ ,\ S\ ,\ k\ ,\ delta\_mu\ ,\ D\ ,\ w\ ,\ gamma\ ,\ h\ ,\ epsilon\ ,\ M\ )\ ...
        49
   % See Equation 8.34 on page 479 of Bies et al (2024).
54
   %% Define Shape
   L mouth piece = 0.09; % Meters
58
59
   pipe.inner diameter = 0.009; % Meters
   pipe.thickness = 0.004; % Meters
61
   % The recorder is unflanged.
62
63
64
   hole diameter = 0.006; % Meters
66
68 \frac{7}{8} Part a
70 % Determine the length of the recorder to produce 523 Hz.
72
   \% The total length of the recorder, including the 0.09 meter long mouthpiece, is L.
   a = 0.009 / 2; \% Meters
```

```
L \ o = 0.61*a; % Slide 18 of Lecture 2 slide set.
 76
    f = 523; \% Hz
 78
         k = 2*pi*f/c; % The wave number for the respective frequency.
 79
 80
    S = pi/4*(0.009)^2; % squared-meters
 81
 82
 83
    test lengths = 0:1e-3:1;
 84
         test\_lengths = test\_lengths + 0.09;
 8.5
 86
    nLengths = length ( test_lengths );
 87
         A = zeros(nLengths, 1);
 88
 89
     for iLength = 1:1:nLengths
 91
         L = test lengths(iLength);
         T_{total} = [1 0; 0 1];
95
         L e = L + L o;
             \% Z = 1\overline{j} * rhoo * c / S * tan( k* L_e );
              Z = open\_end\_impedance(f, rho0, c, 0, S(1), 0);
99
         T = [ \dots ]
         cos(k*L),
                                                  1j*rho0*c/S*sin(k*L); ...
         1j*S/(rho0*c)*sin(k*L),
                                          cos(k*L) ...
104
         \label{eq:total} \texttt{T\_total} \, = \, \texttt{T} \, * \, \texttt{T} \quad \texttt{total} \, ;
             T11 = T_{total}(1, 1); T12 = T_{total}(1, 2);
108
         A(iLength) = -10*log10(abs(T11 + T12 / Z)^2);
110
    end
     figure(); ...
         plot( test_lengths * 1e3, A ); grid on;
xlabel( 'Total Recorder Length [mm] ' ); ylabel( 'Amplitude [dB] ' );
114
         title ( 'Amplification Versus Recorder Length' );
116
118
    return
119
120 \frac{\%\% Part b}{}
    \% L_net = 0.325; \% Meters - First Peak
    L net = 0.653; % Meters - Second Peak
    a = 0.009 / 2; \% Meters
126
         L\ o=0.61*a; % Slide 18 of Lecture 2 slide set.
128
    f = 698; \% Hz
129
         k = 2*pi*f/c; % The wave number for the respective frequency.
    S = pi/4*(0.009)^2; \% squared-meters
134
    test lengths = 0:0.001:0.5;
         test\_lengths = L\_net - test\_lengths;
     nLengths = length(test_lengths);
         A = zeros(nLengths, 1);
139
     for iLength = 1:1:nLengths
         L = test lengths(iLength);
             L_duct_2 = L;
              L_duct_1 = L_net - L_duct_2;
         T_{total} = [1 0; 0 1];
148
         \% \ End \ section \ .
         T_1 = [ \dots ]
         \cos(k*\dot{L}_duct_1),
                                                          1j*rho0*c/S*sin(k*L_duct_1); ...
         1j*S/(rho0*c)*sin(k*L_duct_1),
                                                  cos(k*L_duct_1) ...
```

```
1;
         % Orifice side branch.
156
         epsilon = 0.006 / 0.009; % 0.67
158
              a = 0.006 / 2;
159
         L_o = a * (0.9326 - 0.6196*epsilon); % Lecture 3, Slide 11
             L e = 0.004 + 2*L o;
         Z_A = 1j * rho0 * (2 * pi * f) * L_e / ( pi*0.006^2/4 );
         k \,=\, 2*\,p\,i*\,f\,/\,c\,; \quad \text{\% The wave number for the respective frequency}\,.
         S hole = pi/4*(0.006)^2; \% squared-meters
         167
169
         D = pi * 0.006;
         w \; = \; 2 * p \, i * f \; ;
         gamma = 1.4;

{h}=0.003; % Larger of the edge radius or delta mu.
         Mach number = 0;
174
             \overline{R}_A = h_R_A (\text{rho0}, c, S_hole, k, delta_mu, D, w, gamma, h, epsilon, Mach_number);
              \% \ Z_A = Z_A + R_A
                  T_Branch = [1 0; 1/Z_A 1];
178
180
         % Section next to mouthpiece.
         T \ 2 = \ [ \ \dots
181
182
         cos(k*L duct 2),
                                                          1 j * rho0 * c/S * sin(k*L_duct_2); \dots
                                                \cos(k*L\_duct\_2) ...
183
         1 j*S/(rho0*c)*sin(k*L_duct_2),
         ];
185
         T \text{ total} = T 2 * T \text{ Branch} * T 1 * T \text{ total};
187
             T11 = T total(1, 1); T12 = T total(1, 2);
188
189
         A(\ iLength\ ) = -10*log10 (\ abs(\ T11\ +\ T12\ /\ Z\ )^2\ );
191
    end
    figure( ); ...
         plot ( test_lengths * 1e3, A ); grid on;
    set ( gca, 'XDir', 'reverse' );
196
         xlabel( 'Offset from End of 162.6 mm Length Recorder [mm]') title( 'Amplification Versus Offset from End of Recorder');
198
                  'Offset from End of 162.6 mm Length Recorder [mm]'); ylabel( 'Amplitude [dB]');
    %% Part b Verification
204
    a = 0.009 / 2; \% Meters
         L_o = 0.61*a; % Slide 18 of Lecture 2 slide set.
    f = 698; \% Hz
208
209
         k = 2*pi*f/c; % The wave number for the respective frequency.
    S = pi/4*(0.009)^2; \% squared-meters
214
    f = 0:1:5 e3;
    nFreq = length(f);
217
         A = zeros(nFreq, 1);
218
219
    L1 = 0.2
         L2 = 0.325 - L1;
    for iFreq = 1:1:nFreq
226
         k = 2 * pi * f(iFreq)/c;
228
         T \text{ total} = [1 0; 0 1];
         % End duct.
```

```
T 1 = [ ... ]
                                                     1 j * rho 0 * c / S * sin (k*L1); ...
          cos(k*L1),
          1j*S/(rho0*c)*sin(k*L1),
                                          cos(k*L1) ...
234
         % Orifice side branch.
          epsilon = 0.006 / 0.009; \% 0.67
238
239
              a = 0.006 / 2;
         L_o = a * (0.9326 - 0.6196*epsilon); % Lecture 3, Slide 11
              L e = 0.004 + 2*L o;
         Z A = 1j * rho0 * 2 * pi * f(iFreq) * L e / (pi*0.006^2/4);
244
              T_Branch = \begin{bmatrix} 1 & 0; & 1/Z_A & 1 \end{bmatrix};
247
         % R A is neglected (energy loss).
248
         \% Front duct.
         T 2 = [ ... ]
          cos(k*L2),
                                                     1 j * rho 0 * c / S * sin (k*L2); ...
          1 j*S/(rho0*c)*sin(k*L2),
                                             cos(k*L2) ...
         T_total = T_2 * T_Branch * T_1 * T_total;
258
         T11 = T total(1, 1); T12 = T total(1, 2);
259
260
              A( i\overline{F}req ) = -10*log10 ( abs ( T11 + T12 / Z )^2 );
261
     end
264
     figure( ); ...
         plot( f, A ); grid on;
xlabel( 'Frequency [Hz]' ); ylabel( 'Amplitude [dB]' );
title( 'Amplification Versus Frequency' );
266
267
268
269
272
    %% Clean-up
273
     if ( ~isempty( findobj( 'Type', 'figure')))
    monitors = get( 0, 'MonitorPositions');
274
              if (size(monitors, 1) == 1)
276
               278
279
                   autoArrangeFigures(2,2,1);
280
              end
281
     end
282
283
     fprintf(1, '\n\n*** Processing Complete ***\n\n');
284
285
286
287
288 \quad \frac{\%}{\%} \quad Reference(s)
```

```
%% Synopsis
    % Question 4 - Intake Duct
9
   %% To Do
10
   % Check loss profile.
   % Implement the loss Helmholtz resonator.
14
16
   %% Note(s)
18
19
   % Search for FIXMEs.
    % In class note, the areas for the impedance might have bee wrong; switch them?
24
    % Use negative Mach numbers in the equations. The analysis for this case
26
   % is the same as for the horn example. Inlet on the left, outlet on the
    % right.
28
29
   %% Environment
   close all; clear; clc;
34
    % restored efault path;
   \%~addpath (~genpath (~''~)~,~'-begin~'~)~; \\ addpath (~genpath (~'../40~Assignments/00~Support~'~)~,~'-begin~'~)~; \\
38
   \% \ set (\ 0, \ 'DefaultFigurePosition', [\ 400\ 400\ 900\ 400\ ]\ ); \ \% \ [\ left\ bottom\ width\ height\ ] \\ set (\ 0, \ 'DefaultFigurePaperPositionMode', \ 'manual'\ );
39
40
   set (0, 'DefaultFigureWindowStyle', 'normal');
set (0, 'DefaultLineLineWidth', 1.5);
set (0, 'DefaultTextInterpreter', 'Latex');
41
43
45
   format ShortG;
46
47
    pause ( 1 );
48
49
   PRINT FIGURES = 0;
   % Constants
54
   {
m rho0} = 1.21; % Density of air (kg per cubic-meter).
    c=3\,43; % Speed of sound in air (meters per second).
56
58
   h area = @(diameter) pi * diameter^2 / 4;
59
60
61
   %% Define Shape
62
64 % Source
   67
68
69 % Outlet
70 duct 2.diameter meters = 0.1016; % 4 inches
    duct_2.length_meters = 0.127; % 5 inches
    duct 2. area = h_area ( duct 2. diameter meters );
73
    \% Flanged.
74
```

```
76
         %
         flow_rate_cubic_meters_per_second = 1.04772 / 60; % or 37 cubic-feet per minute
 78
 79
 80
        % return
 81
 82
         %% Part a
 83
 84
         % Calculate the Mach number of the flow in both pip sections.
 85
 86
         duct_1.Mach = -1.0 * flow_rate_cubic_meters_per_second / (pi * duct_1.diameter_meters^2 / 4 ) / c
                  ; \% 0.100 unitless
         duct 2.Mach = -1.0 * flow rate cubic meters per second / (pi * duct 2.diameter meters^2 / 4) / c
 87
                   ; % 0.00628 unitless
 88
         \% return
 89
        %% Part b
 91
         % No flow.
 95
         outlet_flanged = true; % Flanged end.
 96
 98
        TEST FLAG = 1; \% 1: right-to-left.
 99
         frequency \_set = 0:0.1:2.5e3;
                   nFreq = length ( frequency s
TL = zeros ( nFreq , 1 );
                                                                             set );
104
          f = frequency\_set(frequency\_index);
                  T \text{ total} = [1 0; 0 1];
                  if ( TEST FLAG == 1 )
                           \% \ Right-to-left \ .
                           118
119
                            T_inlet = duct_segment_transfer_matrix( f, rho0, c, duct_1.length_meters, duct_1.area );
                           Z = open\_end\_impedance(f, rho0, c, duct\_2.length\_meters, duct\_2.area, outlet\_flanged);
                   else
                            \% Left-to-right.
                            Т
                                _outlet = duct_segment_transfer_matrix(f, rho0, c, duct_1.length_meters, duct_1.area);
                            T contraction = \begin{bmatrix} 1 & 0; 0 & duct_1 \cdot area/duct_2 \cdot area \end{bmatrix};
                            T_inlet = duct_segment_transfer_matrix( f, rho0, c, duct_2.length_meters, duct_2.area );
                           Z = open end impedance( f, rho0, c, duct 1.length meters, duct 1.area, outlet flanged );
                  end
                  T \hspace{0.1in} net \hspace{0.1in} = \hspace{0.1in} T \hspace{0.1in} inlet \hspace{0.1in} * \hspace{0.1in} T \hspace{0.1in} contraction \hspace{0.1in} * \hspace{0.1in} T \hspace{0.1in} outlet \hspace{0.1in} * \hspace{0.1in} T \hspace{0.1in} total;
138
139
                  T11 = T \text{ net} (1, 1); \quad T12 = T \text{ net} (1, 2); \quad T21 = T \text{ net} (2, 1); \quad T22 = T \text{ net} (2, 2);
                   if ( TEST FLAG == 1 )
                             \text{TL}( \ \overline{\text{frequency\_index}} \ ) \ = \ 10 \ * \ \log 10 \ ( \ \text{abs}( \ ( \ \text{T11} \ + \ \text{duct\_1.area}*\text{T12/(rho0*c)} \ + \ ( \ \text{rho0*c})*
                  T21/duct 2.area + T22 / / 2 )^2
                           TL( frequency\_index ) = 10 * log10( abs( (T11 + duct\_2.area*T12/(rho0*c) + (rho0*c)* + (
                  T21/duct 1.area + T22) / 2)^2;
                  end
148
         end \% End: for f = frequency set
149
```

```
TL part b = TL;
         % return
154
        %% Part c
156
         % Flow present (use Mach numbers).
         outlet flanged = true; % Flanged end.
158
159
161
          frequency\_set = 0:0.1:2.5e3;
                   nFreq = length ( frequency \_set );
                           TL = zeros(nFreq, 1);
164
          for frequency index = 1:1:nFreq
                   f = frequency set (frequency index);
168
                   T_{total} = [1 0; 0 1];
                    T\_outlet = duct\_segment\_transfer\_matrix\_flow( f, rho0, c, duct\_2.length\_meters, duct\_2.area, length\_meters, length\_meters, duct\_2.area, length\_meters, length\_meters, duct\_2.area, length\_2.area, length\_meters, duct\_2.area, l
                   duct 2.Mach);
174
                   T_expansion = duct_expansion_connection_transfer_matrix( rho0, c, duct_2.area, duct_1.area,
                   duct 1. Mach);
                   T_inlet = duct_segment_transfer_matrix_flow( f, rho0, c, duct_1.length_meters, duct_1.area,
                   duct 1. Mach);
178
179
                  T net = T inlet * T expansion * T outlet * T total;
180
181
                  Z = open end impedance (f, rhoo, c, duct 2.length meters, duct 2.area, outlet flanged);
182
183
                   T11 = T_{net}(1, 1); T12 = T_{net}(1, 2); T21 = T_{net}(2, 1); T22 = T_{net}(2, 2);
184
                            TL(\ \ frequency\_index\ ) = 10 \ * \ log10 (\ abs(\ (\ \overline{T}11\ +\ duct\_1.area*\overline{T}12/(rho0*c)\ +\ (rho0*c)*
185
                  T21/duct_2.area + T22) / 2)^2;
186
187
188
         end \% End: for f = frequency set
189
         TL\_part\_c = TL;
191
         % return
194
        %% Part d
         % Flow present (use Mach numbers).
197
         % Helmholtz resonator in place (between lefthand duct and expansion).
198
         outlet_flanged = true; % Flanged end.
202
         % Resonance
        w_o = 2*pi*136.6; % Estimated from plot.
        \%\ helmholtz\_\ diameter\_\ cavity =
         \% helmholtz_diameter_neck = 1e-3;
                        helmholtz L01 = 0.82 * (1 - 1.33*(helmholtz diameter neck/helmholtz diameter cavity));
208
         %
210
         %
                        epsilon = helmholtz diameter cavity / duct 1.length meters;
                       \% \ \ helmholtz \ \ L02 =
         %
212
213 % helmholtz volume = 1e-3;
214
         % % keyboard
216
         218
         % Q = 2;
219 %
220 \quad \% \ R\_A = rho0*c \ / \ Q \ * \ sqrt( \ L\_e \ / \ ( \ pi*helmholtz\_diameter\_neck^2/4 \ * \ helmholtz\_volume \ ) \ );
```

```
frequency set = 0:0.1:2.5e3;
         nFreq = length ( frequency_set );
              TL = zeros(nFreq, 1);
228
229
     for frequency index = 1:1:nFreq
         f = frequency_set( frequency_index );
         T \text{ total} = [1 0; 0 1];
         T outlet = duct segment transfer matrix flow(f, rho0, c, duct 2.length meters, duct 2.area,
         duct 2. Mach);
          T\_expansion = duct\_expansion\_connection\_transfer\_matrix ( rho0 , c , duct\_2.area , duct\_1.area , \\ 
         duct_1.Mach);
239
         \% Z A = 1j*rho0*2*pi*f(frequency index) * L e / ( pi*helmholtz neck diameter^2/4 ) - 1j*
         rho0*c^2/(helmholtz\_volume*2*pi*f(frequency\_index)) + R\_A;
              % T_Helmholtz = [1 0; 1/Z_A 1];
         T inlet = duct segment transfer matrix flow (f, rho0, c, duct 1.length meters, duct 1.area,
         duct 1.Mach);
         \% \ T \ net = \ T \ inlet \ * \ T \ Helmholtz \ * \ T \ expansion \ * \ T \ outlet \ * \ T \ total;
248
249
         T_net = T_inlet * T_expansion * T_outlet * T_total;
         Z = open end impedance(f, rho0, c, duct 2.length meters, duct 2.area, outlet flanged);
         T11 = T_{net}(1, 1); T12 = T_{net}(1, 2); T21 = T_{net}(2, 1); T22 = T_{net}(2, 2);
              TL(frequency\_index) = 10 * log10(abs((\overline{T}11) + duct\_1.area*\overline{T}12/(rho0*c) + (rho0*c)*
         T21/duct \ 2.area + T22 ) / 2 )^2 );
    end \% End: for f = frequency\_set
258
259
    TL part d = TL;
262
    % return
264
    %% Plot
265
    Y_LIMITS = [0 50];
268
    figure(); ...
         plot (frequency_set, TL_part_b); hold on; plot (frequency_set, TL_part_c, '-'); plot (frequency_set, TL_part_d, '-.'); grid on;
         legend ( ...
              'No Flow - Part b', ...
              ^{\scriptscriptstyle |}Flow - Part c^{\scriptscriptstyle |}, ...
274
              'Flow and Resonator - Part d', ...
275
              'Location', 'SouthOutside');
276
         xlabel( 'Frequency [Hz]' ); ylabel( 'Amplitude [dB]' );
title( 'Transmission Loss Profiles' );
278
279
         %
         Ax \ = \ g\,c\,a\ ;
              Ax. XAxis. TickLabelInterpreter = 'latex';
281
              Ax.YAxis.TickLabelInterpreter = 'latex';
282
283
         \% axis ( [ -50 5e3+50 Y_LIMITS ] );
284
         %
285
286
            ( PRINT FIGURES == 1 )
287
              exportgraphics (gcf, 'Figure TL All Profiles.pdf', 'Append', true );
288
         end
    return
    %% Part c
294
     return
```

24

```
297
       %% Part d
298
299 return
       \%\% Clean-up
302
        if ( ~isempty( findobj( 'Type', 'figure') ) )
   monitors = get( 0, 'MonitorPositions');
   if ( size( monitors, 1 ) == 1 )
      autoArrangeFigures( 2, 2, 1 );
   elseif ( 1 < size( monitors, 1 ) )
      autoArrangeFigures( 2, 2, 1 );</pre>
304
305
306
307
308
                         \mathbf{end}
309
310
        end
311
312
313 fprintf( 1, '\n\n\*** Processing Complete ***\n\n');
314
315
316
317 \frac{\%\%}{Reference(s)}
```

```
%% Synopsis
3
4
   % Question 4 - Intake Duct
9
   %% To Do
10
   % Check loss profile.
13
14
   %% Note(s)
16
   % Search for FIXMEs.
18
19
   % In class note, the areas for the impedance might have bee wrong; switch them?
   \% Use negative Mach numbers in the equations. The analysis for this case
24
    \% is the same as for the horn example. Inlet on the left, outlet on the
   \% right.
28 % The S in the diagram (pink area) for the Helmholtz resonator is the
29
   % cross-sectional area of the resonator neck connecting it to the tube.
   % For Lo2, use the value for a quarter-wavelength side tube.
   % The area expansion ratio is determined using the original duct diameters.
38
39 % Environment
40
   close all; clear; clc;
41
42
   % restored efault path;
43
   % addpath( genpath( ''), '-begin');
45
   addpath ( genpath ( '../40 Assignments/00 Support' ), '-begin');
46
   % set(0, 'DefaultFigurePosition', [ 400 400 900 400 ]); % [ left bottom width height ] set(0, 'DefaultFigurePaperPositionMode', 'manual'); set(0, 'DefaultFigureWindowStyle', 'normal'); set(0, 'DefaultLineUineWidth', 1.5);
47
48
    set( 0, 'DefaultTextInterpreter', 'Latex' );
   format ShortG;
54
   pause( 1 );
56
   PRINT FIGURES = 0;
58
59
61
   %% Define Constants and Anonymous Functions
62
   {
m rho0} = 1.21; % Density of air (kg per cubic-meter).
63
64
   c=3\,43; % Speed of sound in air (meters per second).
67
   h area = @(diameter) pi * diameter^2 / 4;
68
69
70
71
   %% Define Shape
73 % Source
   duct_1.diameter_meters = 0.0254; % 1 inch
74
   duct 1.length meters = 0.1524; % 6 inches
```

```
duct 1.area = h area( duct 1.diameter meters );
 76
 78 % Outlet
 79 \operatorname{duct}_2.\operatorname{diameter}_{\operatorname{meters}} = 0.1016; % 4 \operatorname{inches}
    \operatorname{duct} 2.\operatorname{length} \operatorname{meters} = 0.127; % 5 in ches
 80
    duct 2. area = h area ( duct 2. diameter meters );
 81
 82
    \% Flanged.
 8.3
 84
 8.5
 86
 87
    flow rate cubic meters per second = 1.04772 / 60; % or 37 cubic-feet per minute
88
 89 % return
 90
91 %% Part a
 92
    \% The -35 dB transmission loss dip | notch is at about 1,150 Hz.
    f = 1150:
96 % Total attenuation required is +35 dB to make it 0 dB.
97
    l = 0.0381; % meters (1.5 inches)
98
    h = 0.0127; % meters (0.5 inches)
    % The total attenuation of the lining from Figure 8.37 (Bies et. al., Fifth Edition),
     \% \ m = (h \ area(\ 0.1016\ ) - h \ area(\ 0.0254\ )) / h \ area(\ 0.0254\ )
    % ASSUMPTION: Cross-section area of lined duct is the same as the inlet.
106
    m = 1;
108
    k = 2 * pi * 1.15 e3;
109
length of expansion chamber = 0.127; % meters
112 \% kL = k*length of expansion chamber
113
    % ASSUMPTION:
114
116
    % Expansion ratio is m = 1;
    % Assume peak difference is 10 dB.
118
    % Total attunation of lining is 10 dB.
119
120 % The attenuation rate is about 10 dB / 0.127 meters or 78.7 dB per meter.
    % return
124 \( \bar{7}\bar{7}\) \( Part \ b \)
126 \quad l = 0.0381; \quad \% \ meters \ (1.5 \ inches)
128
    h = 0.011255; \% meters
          \label{eq:h_validate} \mbox{$h_validate} = 0.5* \mbox{$sqrt( (pi*(duct_2.diameter_meters - 2*l)^2 )/4 ); $\%$ $Same value. } 
133 \quad \frac{\%\% \ Part \ c}{}
135 % The liner thickness ratio is,
136 l / h; % 3.3852 unitless
    % The normalized frequency is,
138
    ( 2 * h ) / ( 343 / \hat{f} ); % 0.075471 unitless
141
143 \frac{7}{2} Part d
145 % Assume the attenuation rate from Part a is 18 dB per meter.
146
    % Use bottom, right subplot (16).
148
149 % The approximate resistivity parameter is 16.
    %% Part e
```

```
% Calculate the flow resistivity.
    R1 = 16 * rho0*c / l; \% 1.74e5 kg / m^3*s
158
159
    %% Placeholder
    % % Flow present (use Mach numbers).
    % Helmholtz resonator in place (between lefthand duct and expansion).
    \% outlet flanged = true; \% Flanged end.
168
    % % Resonance
170 % w \ o = 2*pi*136.6; % Estimated from plot.
172
173 \quad \% \ \% \ helmholtz\_diameter\_cavity \ =
    \% % helmholtz\_diameter\_neck = 1e-3;
174
              helmholtz\_L01 = 0.82 * (1 - 1.33*(helmholtz\_diameter\_neck/helmholtz\_diameter\_cavity));
    % %
176
    % %
    % %
              epsilon = helmholtz\_diameter\_cavity / duct\_1.length\_meters;
    % %
178
              \% \ \ helmholtz \ \ L02 =
179
    % %
180 \% \% helmholtz_volume = 1e-3;
181
     % %
    % % % keyboard
182
183
    % %
184
    \% % helmholtz_L_neck = 1e-3;
    \% \ \% \ Q = 2;
185
    % %
187
    \% \ \ R\_A = \ rho \ 0 * c \ / \ Q * \ sqrt( \ L\_e \ / \ ( \ pi * helmholtz\_diameter\_neck \ ^2/4 * \ helmholtz\_volume \ ) \ );
188
189
    %
191
    \% \ frequency\_set = 0:0.1:2.5e3;
           nFreq = length (frequency\_set);
    %
                TL = zeros(nFreq, 1);
194
196 % for frequency index = 1:1:nFreq
197
    %
198
            f = frequency\_set(frequency\_index);
    %
    %
           T_total = [1 0; 0 1];
202
    %
    %
            T outlet = duct segment transfer matrix flow (f, rho0, c, duct 2.length meters, duct 2.area
         , duct 2.Mach);
204
    %
    %
           T\_expansion = duct\_expansion\_connection\_transfer\_matrix(\ rho0\ ,\ c\ ,\ duct\_2\ .area\ ,\ duct\_1\ .area\ ,
          duct_1 . Mach);
    %
         \label{eq:sum_energy} \begin{array}{lll} \% \ Z\_A = 1 \ j * rho0 * 2 * pi * f(frequency\_index) & * L\_e \ / \ ( \ pi * helmholtz\_neck\_diameter ^ 2/4 \ ) & - \ 1 \ j * rho0 * c ^ 2/(helmholtz\_volume * 2 * pi * f(frequency\_index)) & + \ R\_A; \end{array}
    %
    %
               \% T Helmholtz = [1 0; 1/Z_A 1];
    %
    %
    %
            T\_inlet = duct\_segment\_transfer\_matrix\_flow(\ f,\ rho0,\ c,\ duct\_1.length\_meters,\ duct\_1.area,
          duct 1. Mach);
    %
214
    %
           \% \ T \ net = \ T \ inlet \ * \ T \ Helmholtz \ * \ T \ expansion \ * \ T \ outlet \ * \ T \ total;
    %
           T\_net = T\_inlet * T\_expansion * T\_outlet * T\_total;
216
217
    %
218
    0%
           Z = open\_end\_impedance (\ f,\ rho0\,,\ c\,,\ duct\_2.length\_meters\,,\ duct\_2.area\,,\ outlet\_flanged\ )\,;
219
220 %
           %
    %
         )*T21/duct 2.area + T22 ) / 2 )^2 );
224
    %
    \% end \% End: for f = frequency\_set
```

```
% TL part d = TL;
228
229 \quad \% \ return
    %% Plot
    % Y LIMITS = [ 0 50 ];
    % figure(); ...
           238
239
    %
           % legend(...
    %
                  'No Flow - Part b', ...
240
           %
                  'Flow - Part \ c', \dots
'Flow \ and \ Resonator - Part \ d', \dots
    %
    %
           %
    %
                  'Location', 'SouthOutside');
243
           %
    %
246 %
    %
           Ax = gca;
    %
               Ax. XAxis. TickLabelInterpreter = 'latex';
248
                Ax. YAxis. TickLabelInterpreter = 'latex';
249
   %
    %
           %
    %
           \% axis ( \begin{bmatrix} -50 & 5e3+50 & Y & LIMITS \end{bmatrix} );
    %
    %
%
            if (PRINT\_FIGURES == 1)
253
                export\overline{g}raphics(\ gcf,\ 'Figure\ TL\ All\ Profiles.pdf',\ 'Append',\ true\ );
254
    %
256
    % return
258
259
    %% Clean-up
    if ( ~isempty( findobj( 'Type', 'figure')))
    monitors = get( 0, 'MonitorPositions');
262
              if ( size( monitors, 1 ) == 1 )
   autoArrangeFigures( 2, 2, 1 );
264
              elseif ( 1 < size ( monitors, 1 ) )
265
                  autoArrangeFigures(2,2,1);
267
268
    end
270
    fprintf(\ 1,\ '\backslash n\backslash n ****\ Processing\ Complete\ ***\backslash n\backslash n'\ );
274
275 \%\% Reference(s)
```