Subject: Noise Control Applications - Module 1 Assignement

Date: February 9, 2025 (Submitted)

### Problem 1 - Cut-on Frequencies in Ducts and Pipes

The Matlab code for this problem is listed in Appendix 1.

### Problem 1a

The lowest cut-on frequency for a rectangular duct with air flow is given by equation,

$$f_{\text{cut-on}} = 0.5 \cdot \frac{c}{L} \tag{1}$$

where c is the speed of sound in air, 343  $\frac{m}{s}$ , and L is the largest side of the rectangular cross-section.

With cross-sectional dimensions of  $L_x = 12$  cm and  $L_y = 20$  cm, the lowest cut-on frequency for this rectangular duct is,

$$f_{\text{cut-on}} = 0.5 \cdot \frac{343 \frac{m}{s}}{0.20 \text{ m}} = 857.5 \text{ Hz}$$

### Problem 1b

The lowest cut-on frequency for a circular duct with air flow with the same cross-sectional area as the rectangular duct in part (a.) can be calculated using equation,

$$f_{\text{cut-on}} = 0.568 \cdot \frac{c}{d} \tag{2}$$

where c is the speed of sound in air, 343  $\frac{m}{s}$ , and d is diameter of the circular duct.

The cross-sectional area of the rectangular duct is,

Area 
$$_{\text{rectangular duct}} = 0.12 \text{ m} \cdot 0.20 \text{ m} = 0.024 \text{ m}$$

The corresponding diameter for this area is,

$$\mathrm{diameter} = \sqrt{\frac{0.24~\mathrm{m}^2}{\pi}} \cdot 2 = 0.17~\mathrm{m}$$

Using Eq. 2, the lowest cut-on frequency for this circular duct with air flow is,

$$f_{\text{cut-on}} = 0.568 \cdot \frac{1,500 \frac{\text{m}}{\text{s}}}{0.17 \text{ m}} = 1,114.5 \text{ Hz}$$

### Problem 1c

The lowest cut-on frequency for this circular duct with water flow can be calculated using Eq. 2,

$$f_{\text{cut-on}} = 0.568 \cdot \frac{1,500 \frac{\text{m}}{\text{s}}}{0.17 \text{ m}} = 4,873.9 \text{ Hz}$$

The lowest cut-on frequency for water is considerable larger than it is for air flow.

### Problem 1d

The speed of sound in air is calculated by,

$$c = \sqrt{\gamma \cdot R \cdot T_K} \tag{3}$$

where  $\gamma=1.4$  is the ratio of specific heats,  $R=287~\frac{J}{kg\cdot K}$  is the gas constant, and  $T_K$  is the absolute temperature in Kelvin.

Figure 1 illustrates how the lowest cut-on frequency changes as the air heats from 0° to 500° Celsius.

The square-root relationship between temperature and the speed of sound in air is apparent and governs the behaviour of the cut-on frequency.

Lowest Cut-on Frequency for a Circular Pipe with Air Flow Versus Air Temperature




Figure 1: Lowest cut-on frequency for a circular 5 cm diameter duct versus air temperature.

### Problem 1e

# Question: Are cut-on frequencies higher for a circular or rectangular duct for a given cross-sectional area?

The lowest cut-on frequency is higher for a circular duct than for a rectangular duct for a given cross-sectional area.

For the dimensions given in class, the rectangular duct is not square. This produces a larger dimension and thus a smaller, lowest cut-on frequency. If the rectangular duct is square dimensions on the order of the circular duct diameter with the same cross-sectional area, the cut-on frequencies are approximately equal.

#### Question: What about in air versus water?

The lowest cut-on frequency is larger for water than for air. The cut-on frequency is proportional to the speed of sound and the speed of sound in water is greater than the speed of sound in air.

### Question: What about cold versus hot air?

The lowest cut-on frequency is higher for warm air than it is for cold air.

# Problem 2 - Muffler Design Comparison

The Matlab code for this problem is listed in Appendix 2.

For these muffler comparisons, the following assumptions were made:

- There is no flow.
- There are no resistive terms.
- The load impedance was not included because the transmission loss does not require them.
- For Parts b, c, and d, the side branch length offset, L<sub>0</sub>, was set to zero.

### Problems 2a, 2b, and 2c

Figure 2 shows the transmission loss profiles for a simple expansion chamber, a double-tuned expansion chamber, and a cascaded double-tuned expansion chamber muffler.

The peaks for the simple expansion chamber (red, dashed line) are approximately 22 dB and occur at frequencies with a wavelength that is a quarter of the length of the expansion chamber. Minimal loss occurs at half wavelength multiples.

The addition of the extension tube inside the muffler produces a quarter wavelength resonator. The side branch of Ji (2005; Slide 11, Lecture 3 notes) was used to calculate  $L_o$ . For the cascaded double-tuned expansion chamber, the extension tubes produce a secondary quarter wavelength resonator.

As noted in the office hours session, there is no damping which produces artificially high resonances.




Figure 2: Transmission loss profiles for a simple expansion chamber, a double-tuned expansion chamber, and a cascaded double-tuned expansion chamber mufflers.

### Problem 2d

Figure 3 shows the transmission loss profiles for a cascaded double-tuned expansion chamber, and a modified cascaded double-tuned expansion chamber muffler.

Two modifications were made to the original system:

- 1. The left 3" extension tube in the left chamber was shortened to 2" inches, making the respective muffler section 1" longer.
- 2. The left 3" extension tube in the right chamber was lengthened to 4", making the respective muffler section 1" shorter.




Figure 3: Transmission loss profiles for a cascaded double-tuned expansion chamber muffler and a modified version of this muffler.

These modifications change the symmetry of the cascaded system, and allow the resonate frequencies to be independently changed.

# Problem 3 - Bugle Recorder

### Problem 3a

The Matlab code for this problem is listed in Appendix 3.

Table 1 lists the length of the pipe section and the mouthpiece.

Item	Length [mm]
Pipe	145
Mouthpiece	90

Table 1: Calculated length of the pipe and length of the mouthpiece.

### Problem 3b

Table 2 summarizes the placement of the holes for each note relative to the end of the pipe.

Note	Frequency [Hz]	Length from End of Pipe [mm]
C5	523	n/a
F5	698	87.75
A5	880	138.25
С6	1,046	0.168

Table 2: Hole placement distances.

Figure 4 shows the respective spectrum for each of the bugle recorder notes.




Figure 4: Spectrum for the C5, F5, A5, and C6 bugle recorder notes.

# Problem 4 - Intake Duct

The Matlab code for this problem is listed in Appendix 4.

# Problem 4a

Table 3 lists the Mach numbers for each pipe section.

Pipe	Mach Number [unitless]
Inlet	-0.10047
Outlet	-0.0062795

Table 3: Calculated Mach numbers.

Problem 4b

Problem 4c

Problem 4d

# Problem 5 - Intake Duct Silencer

Problem 5a
Problem 5b
Problem 5c
Problem 5d
Problem 5e

```
%% Synopsis
4
    % Question 1 - Cut-on Frequencies in Ducts and Pipes
9
10 \quad \overline{\%\% \quad Environment}
    close all; clear; clc;
13
   \% restored efault path;
    \% addpath( genpath( ''), '-begin');
16
    addpath (genpath ('../40 Assignments/00 Support'), '-begin');
   % set(0, 'DefaultFigurePosition', [ 400 400 900 400 ]); % [ left bottom width height ] set(0, 'DefaultFigurePaperPositionMode', 'manual'); set(0, 'DefaultFigureWindowStyle', 'normal'); set(0, 'DefaultLineLineWidth', 1.5); set(0, 'DefaultTextInterpreter', 'Latex');
18
19
24
    format ShortG;
26
    pause ( 1 );
28
    PRINT FIGURES = 0;
29
32 %% Define Constants and Anonymous Functions
34
    c air = 343; % The speed of sound in air (meters per second).
   c water = 1500; % The speed of sound in water (meters per second).
    gamma = 1.4; % The ratio of specific heats [unitless].
   R = 287; % The gas constant [Joules per (kilogram * Kelvin)].
38
40
    h_f_{cut}_{on}_{rectangular}_{duct} = @(c, L) 0.5 .* c./ L;
41
    \% c - The speed of sound.
    \% L - The largest cross-section dimension of the rectangular duct.
45
46
47
    h f cut on circular duct = @(c, d) 0.568 .* c ./ d;
48 %
49
    \% c - The speec of sound.
    \% \ L - The \ diameter \ of \ the \ circular \ duct.
    \verb|h_speed_of_sound_in_air| = @( gamma, R, temperature_Kelvin) \\ \qquad \qquad sqrt( gamma .* R .* R) \\
         temperature Kelvin );
   %% Problem 1a
58
59 % The cross-sectional dimensions for the rectangular duct are: Lx = 12 cm and Ly = 20 cm.
60
61
   \% The largest dimension is Ly = 20 cm or 0.2 m.
62
63
   % The cut-on frequency is,
    h_f_cut_on_rectangular_duct( c_air, 0.2 ); % 857.5 Hz (shown in class 858 Hz) fprintf( 1, '\n Problem 1a: The lowest cut—on frequency for the rectangular pipe with air is %3.1f Hz.\n', h_f_cut_on_rectangular_duct( c_air, 0.2 ) );
66
67
68
69 %% Problem 1b
70
    \% The cross-sectional dimensions for the rectangular duct are: Lx = 12 cm and Ly = 20 cm.
    \% The cross-sectional area of the rectangular duct is 12 cm * 20 cm = 240 cm^2 or 0.024 m^2.
```

```
74
        rectangular duct cross sectional area = 0.12 * 0.20; % 0.024 m^2
 76 % The diameter of the circulat pipe is,
        circular duct diameter = sqrt ( 0.024 / pi ) * 2; % 0.17481 meters
 78
 79
 80
               \% pi * ( circular duct diameter / 2 )^2 CHECKED
 81
 82
        % The cut-on frequency for the circular duct is,
 83
       84
 85
 86
 87
 88
      %% Problem 1c
 89
 91
        % The cut-on frequency for the circular duct with water is,
        h f cut on circular duct ( c water, circular duct diameter ); % 4,873.9 Hz
               fprintf( 1, '\n Problem 1c: The lowest cut—on frequency for the circular pipe (of equal area) with water is %3.1f Hz.\n', h_f_cut_on_circular_duct(c_water, circular_duct_diameter));
 93
        % The cut-on frequency should be higher because it is proportional to the
        % speed of sound in a given medium.
 97
 9.8
 99
      %% Problem 1d
        fprintf(1, '\n Problem 1d: See the figure.\n');
        temperature range celsius = 0:0.1:500; % Celsius
                temperature_range_kelvin = temperature_range_celsius + 273.15; % Kelvin
        FONT SIZE = 14;
108
        figure(); ...
                plot (\ temperature\_range\_celsius\,,\ h\_f\_cut\_on\_circular\_duct (\ h\_speed\_of\_sound\_in\_air (\ gamma,\ R, and an extraction of temperature\_range\_celsius), and the property of temperature\_range\_celsius and temperature\_range\_celsius and temperature\_range\_celsius and temperature\_range\_celsius and temperature\_range\_celsius and temperature\_range\_celsius and temperature\_celsius and temper
                 temperature_range_kelvin ), 0.05 ) ./ 1e3 ); grid on; legend( 'Duct Diameter = 5.0 cm', 'Location', 'East', 'FontSize', FONT_SIZE, 'Interpreter
                      legend (
                     'Latex');
                       set ( gca, 'FontSize', FONT SIZE );
               %
                xlabel( 'Temperature [Celsius]', 'FontSize', FONT_SIZE );
                       \% \ xl = get(\ gca,\ 'xlabel'); position', pxl); 
116
                                                                                pxl = get(xl, 'position'); pxl(2) = 1.1 * pxl(2);
118
                \label{lowest_cut-on_frequency} \ [kHz]^+, \ ^+FontSize^+, \ FONT\_SIZE \ ) \, ;
119
                      caption = sprintf( 'Lowest Cut-on Frequency for a Circular Pipe with Air Flow Versus Air
                Temperature\n');
                       title ( caption , 'FontSize', FONT SIZE );
124
               ylim([3 7]);
128
129
130 %% Problem 1e
        fprintf( 1, '\n Problem 1e: See Section Problem 1e of the Matlab script for the answers.\n\n');
134
        \% Question: Are cut-on frequencies higher for a circular or rectangular duct for a given cross-
                sectional area?
        \% The lowest cut-on frequency is higher for a circular duct than for a
138
        % rectangular duct for a given cross-sectional area.
        % For the dimensions given in class, the rectangular duct is not square.
141
        \% This produces a larger dimension and thus a smaller, lowest cut-on
        % frequency.
        % If the rectangular duct is square dimensions on the order of the circular
145
        \% duct diameter with the same cross-sectional area, the the cut-on
```

```
146 % frequencies are approximately equal.
148
149 % Question: What about in air versus water?
    % The lowest cut-on frequency is larger with water than air. This due to
     % the fact that the cut-on frequency is proportional to the speed of sound
    % and the speed of sound in water is greater than it is in air.
154
156 % Question: What about cold versus hot air?
158 % For a circular pipe, the cut-on frequency is higher in warm air than cold
159 % air.
162
163 \frac{\%\% Clean-up}{}
    if ( ~isempty( findobj( 'Type', 'figure')))
    monitors = get( 0, 'MonitorPositions');
165
166
              if (size(monitors, 1) == 1)
autoArrangeFigures(2, 2, 1);
elseif (1 < size(monitors, 1))
167
168
170
                   autoArrangeFigures(2,2,1);
              end
172
     end
173
     if ( PRINT_FIGURES == 1 )
174
         saveas (gcf, 'Cut-on Frequency Versus Temperature - Sunday, January 19, 2025.pdf');
176
178
    fprintf(1, \frac{|\cdot|}{n \cdot n} = Processing Complete *** \frac{|\cdot|}{n \cdot n});
```

```
%% Synopsis
4
    % Question 2 - Muffler Design Comparison
9
10 \quad \overline{\%\%} \quad Environment
    close all; clear; clc;
   \% restored efault path;
    \% \ \ addpath \left( \ \ genpath \left( \ \ ' \ ' \ \right), \ \ '-begin \ ' \ );
    addpath ( genpath ( '../00 Support'), '-begin');
16
   % set(0, 'DefaultFigurePosition', [ 400 400 900 400 ]); % [ left bottom width height ] set(0, 'DefaultFigurePaperPositionMode', 'manual'); set(0, 'DefaultFigureWindowStyle', 'normal'); set(0, 'DefaultLineLineWidth', 1.5); set(0, 'DefaultTextInterpreter', 'Latex');
18
19
24
    format ShortG;
26
    pause ( 1 );
28
    PRINT FIGURES = 0;
29
   % Constants
    rho0 = 1.21; % Air density (kg per m^3).
    c = 343; % Speed of sound in air (meters per second).
    frequency set = 0:1:5e3; % Hertz
38
40
    %% Dimensions
41
42
43
    convert.inches to meters = 0.0254;
    convert.foot\_to\_meters = 0.3048;
45
46
    dimensions.inlet diameter meters = 2 * convert.inches to meters; % 0.0508 meters
    dimensions.inlet length meters = 6 * convert.foot to meters; % 1.82 meters
47
48
    {\tt dimensions.muffler\_diameter\_meters} = 10 \ * \ {\tt convert.inches\_to\_meters}; \quad \% \ \textit{0.254} \ \textit{meters}
    dimensions.muffler\_length\_meters = 18 * convert.inches\_to\_meters; ~\% ~0.4572 ~meters
    {\tt dimensions.outlet\_diameter\_meters} \ = \ 2 \ * \ {\tt convert.inches\_to\_meters}; \quad \% \ \textit{0.0508} \ \textit{meters}
    dimensions.outlet length meters = 1 * convert.foot to meters; % 0.3048 meters
54
    outlet\_flanged = false;
56
    dimensions.overhang = 3 *convert.inches_to_meters; % 0.0762 meters
58
    segment\_diameters = [ ...
59
         dimensions.outlet_diameter_meters, ...
61
          dimensions.muffler diameter meters, ...
62
          dimensions.inlet diameter meters, ...
64
    h_area_from_diameter = @(d) pi .* d.^2 ./ 4;
67
    segment areas = h area from diameter (segment diameters);
68
69
    segment lengths = [ ...
70
         dimensions.outlet length meters, ...
          {\tt dimensions.muffler\_length\_meters}\;,\;\; \dots
         dimensions.inlet_length_meters, ...
         {\tt dimensions.overhang}\;,\;\; \dots
74
```

```
78
    %% Part a - Simple Expansion Chamber
79
    nFreq = length ( frequency set );

TL = zeros ( nFreq , 1 );
80
81
82
83
    for frequency_index = 1:1:nFreq
84
        f \ = \ frequency\_set \left( \ frequency\_index \ \right);
85
86
        T \text{ total} = [1 0; 0 1];
87
88
89
        T1 = duct\_segment\_transfer\_matrix (~f~,~rhoo~,~c~,~0.3048~,~0.0020268~)~;~~\%~Duct~-~Outlet~
        90
91
92
        97
                                                                                           + (rho0*c)*
99
             % The transmission loss calculation does not require a load impedance.
    end
    TL parta = TL; % The maximum peak value should be about 22 (21.952) dB.
104
    % Expected behaviour:
         1.) 0 dB at 0 Hz.
108
        2.) The transmission loss of a straight duct section is zero; energy out equals energy in.
    max( TL parta ); % 22 dB
114 7\% Part b - Double-tuned Expansion Chamber
    annulus_area_squared_meters = pi/4 * (0.254^2 - 0.0508^2);
116
    L\ o=0; % Assume that the Lo extension is neglible.
118
119
120
    \begin{array}{ll} nFreq = \mbox{ length ( frequency \_set );} \\ TL = \mbox{ zeros ( } nFreq \mbox{ , } 1 \mbox{ );} \end{array}
    for frequency index = 1:1:nFreq
126
        f = frequency set(frequency index);
128
        T_{total} = [1 0; 0 1];
        T1 = \; duct\_segment\_transfer\_matrix\left( \;\; f \;, \;\; rho0 \;, \;\; c \;, \;\; \left(0.3048 \;+\; 0.0762\right) \;, \;\; 0.0020268 \;\; \right);
        134
        k = 2 * pi * f / c;
            {\rm Z\_A} \, = \, -1\,{\rm j} * {\rm rh} \, {\rm o} 0 * {\rm c} / \, {\rm annulus\_area\_squared\_meters} * \, {\rm cot} \, \left( \, k \; * \; \left( \; \; 0.0762 \; + \; L\_o \; \right) \; \right) \, ;
                T2 = [ 1 0; 1/Z_A 1 ];
                     T4 = T2;
139
        T \text{ net} = T5 * T4 * T3 * T2 * T1 * T \text{ total};
        T11 = T \text{ net}(1, 1); \quad T12 = T \text{ net}(1, 2); \quad T21 = T \text{ net}(2, 1); \quad T22 = T \text{ net}(2, 2);
        144
            \% \ \ The \ transmission \ loss \ calculation \ does \ not \ require \ a \ load \ impedance.
    end
148
149
    TL partb = TL;
    % Expected behaviour:
```

76

```
%
                                   0 dB at 0 Hz.
                       1.)
           %
154
                       2.)
                                   0 dB at same locations as a simple expansion chamber.
                       3.) Peaks at 1,125 Hz and 3,376 Hz;
155 %
156
            \% Frequency at which the quarter-wavelength is 0.0762 meters.
           \% 343 / ( 4 * 0.0762 ); \hat{\%} 1,125 Hz.
158
            \% Also work at three-quarter-wavelength.
           % 3 * 1125; % 3,375 Hz
           %% Part c - Cascaded, Double-tuned Expansion Chamber
166
           annulus_area_squared_meters = pi/4 * (0.254^2 - 0.0508^2);
168
169
           Lo = 0; % Assume that the Lo extension is neglible.
172
           nFreq = length ( frequency \_set );
173
                       TL = zeros(nFreq, 1);
174
            for frequency_index = 1:1:nFreq
176
                       f = frequency\_set ( frequency\_index );
                                 k = 2 * pi * \overline{f} / c;
178
179
                                           Z A = -1j*rho0*c/annulus area squared meters*cot(k * ( 0.0762 + L o ) );
181
                       T_{total} = [1 0; 0 1];
182
                      T1 = duct\_segment\_transfer\_matrix( f, rho0, c, (0.3048 + 0.0762), 0.0020268 ); % Duct - (0.3048 + 0.0762), 0.0020268 
                      184
185
186
                       T5 = \ duct\_segment\_transfer\_matrix (\ f\ ,\ rho0\ ,\ c\ ,\ 2*0.0762\ ,\ 0.050671\ )\ ; \quad \%\ \mathit{Duct}
187
                      T6 = T2;
                                                  \% Straight Side Branch
                       T7 = T3; \% Duct
                      T8 = T2; % Straight Side Branch
                      T9 = duct segment transfer matrix (f, rho0, c, (1.8288 + 0.0762), 0.0020268); % Duct -
                       Inlet
                      T \quad net \ = \ T9 \ * \ T8 \ * \ T7 \ * \ T6 \ * \ T5 \ * \ T4 \ * \ T3 \ * \ T2 \ * \ T1 \ * \ T \ \ total;
                      T11 = T_net(1, 1); T12 = T_net(1, 2); T21 = T_net(2, 1); T22 = T_net(2, 2);
                      198
           end
           TL partc = TL;
           %% Part d - Cascaded, Double-tuned Expansion Chamber
            nFreq = length ( frequency set );
                      TL = zeros(nFreq, 1);
208
            for frequency_index = 1:1:nFreq
210
                       f = frequency\_set (frequency\_index);

k = 2*pi*f/c;
213
                                           Z A = -1j*rho0*c/annulus area squared meters*cot(k * ( 0.0762 + L o ));
214
215
                       T_{total} = [1 0; 0 1];
216
                      T2 = [1 0; 1/Z A 1]; \% Straight Side Branch
                      T3 = duct\_segment\_transfer\_matrix (\ f \,,\ rho0 \,,\ c \,,\ 0.0076 \,,\ 0.050671\ ) \,; \quad \% \ \mathit{Duct}
                                                  % Straight Side Branch
                       T5 = \ duct \_segment \_transfer \_matrix (\ f , \ rho0 \, , \ c \, , \ 2*0.0762 \, , \ 0.050671 \ ) \, ; \quad \% \ \mathit{Duct}
                      T6 = T2; % Straight Side Branch
                      T9 = duct\_segment\_transfer\_matrix( f, rho0, c, (1.8288 + 0.0762), 0.0020268 ); % Duct - (1.8288 + 0.0762), 0.0020268
```

```
Inlet
          T_{net} = T9 * T8 * T7 * T6 * T5 * T4 * T3 * T2 * T1 * <math>T_{total};
          T11 = T_{net}(1, 1); \quad T12 = T_{net}(1, 2); \quad T21 = T_{net}(2, 1); \quad T22 = T_{net}(2, 2);
          end
     TL partd = TL;
238
    %% Plot Transmission Loss Profiles
    Y LIMITS = \begin{bmatrix} -5 & 320 \end{bmatrix};
     h_figure_1 = figure(); ...
          plot (frequency_set, TL_parta, 'LineWidth', 1.0, 'LineStyle', ':', 'Color', 'r'); hold on; plot (frequency_set, TL_partb, 'LineWidth', 0.9, 'LineStyle', '--', 'Color', 'b'); plot (frequency_set, TL_partc, 'LineWidth', 0.9, 'LineStyle', '-', 'Color', 'k'); grid on;
246
              legend ( ...
                    'Simple Expansion Chamber', ...
                    'Double-tuned Expansion Chamber', ...
                    'Cascaded Double-tuned Expansion Chamber', ...
249
          \label{location} \begin{tabular}{ll} $$ 'Location', "SouthOutside" ); \\ xlabel( "Frequency [Hz]" ); ylabel( "Transmission Loss [dB]" ); \\ \end{tabular}
          title ( 'Transmission Loss Profiles');
253
          %
254
          Ax \ = \ g\,c\,a\ ;
              Ax. XAxis. TickLabelInterpreter = 'latex';
256
               Ax. YAxis. TickLabelInterpreter = 'latex';
          axis ( \begin{bmatrix} -50 & 5e3+50 & Y & LIMITS \end{bmatrix} );
259
261
     Y_LIMITS = [ -5 315 ];
262
     h_figure_2 = figure(); ...
          plot (frequency_set, TL_partc, 'LineWidth', 1.0, 'LineStyle', '-', 'Color', 'k'); hold on; plot (frequency_set, TL_partd, 'LineWidth', 0.6, 'LineStyle', '--', 'Color', 'b'); grid on;
264
               legend ( ...
                    'Cascaded Double-tuned Expansion Chamber', ...
                    'Modified Cascaded Double-tuned Expansion Chamber', ...
                    'Location', 'SouthOutside');
          272
          %
          Ax \ = \ g\,c\,a\ ;
              Ax.XAxis.TickLabelInterpreter = 'latex';
               Ax.YAxis.TickLabelInterpreter = 'latex';
          axis ( \begin{bmatrix} -50 & 5e3+50 & Y_LIMITS \end{bmatrix} );
279
280
281
     % Clean-up
     if ( ~isempty( findobj( 'Type', 'figure')))
    monitors = get( 0, 'MonitorPositions');
283
284
               if (size(monitors, 1) == 1)
               autoArrangeFigures(2, 2, 1);
elseif (1 < size(monitors, 1))</pre>
287
288
                    autoArrangeFigures(2,2,1);
               \mathbf{end}
289
     end
     if ( PRINT FIGURES == 1 )
               exportgraphics (h_figure_1, 'Assignment 1 - Question 2 Figure All TL Profiles.pdf', '
          Append', true );
               exportgraphics (h_figure_2, 'Assignment 1 - Question 2 Figure Comparison TL Plot For
          Cascaded Systems.pdf', 'Append', true );
     end
```

```
%% Synopsis
4
    % Question 3 - Bugle Recorder
9
10 \quad \overline{\%\%} \quad Environment
    close all; clear; clc;
13 \quad \% \quad restoredefaultpath;
14
   \% addpath( genpath( ''), '-begin');
   addpath ( genpath ( '../00 Support'), '-begin');
16
   % set( 0, 'DefaultFigurePosition', [ 400 400 900 400 ] ); % [ left bottom width height ]
set( 0, 'DefaultFigurePaperPositionMode', 'manual' );
set( 0, 'DefaultFigureWindowStyle', 'normal' );
set( 0, 'DefaultLineLineWidth', 0.8 );
set( 0, 'DefaultTextInterpreter', 'Latex' );
18
19
24
    format ShortG;
26
   pause ( 1 );
28
   PRINT FIGURES = 0;
29
32 %% Constants and Anonymous Functions
   rho0 = 1.21; % Density of air (kg per cubic-meter).
34
35 c = 343; % Speed of sound in air (meters per second).
   h RA term 2 = @( rho0 , c , S , k , delta mu , D , w , h ) ( rho0*c/S ) * 0.288*k*3.178e-5*log10((4*))
38
         \overline{S})/(\overline{pi*h^2});
39
    \label{eq:continuous_section} $h_RA_{term_3} = @( \ rhoo, \ c \ , \ S, \ k, \ delta_mu \, , \ D, \ w, \ h \ ) \\ \ \ ( \ rhoo*c/S \ ) \ * \ (0.5*S*k^2)/(2*pi); 
41
    \% See Equation 8.34 on page 479 of Bies et al (2024).
43
44
45 \frac{7}{2} \frac{7}{2} \frac{7}{2} \frac{7}{2} \frac{7}{2}
46
47
   % The estimated total length of the recorder is 0.325 meters.
48
49 % Estimation of hole location was done by trial-and-error.
    pipe net length = 0.325;
52
    pipe area = pi*0.009^2/4;
54
   flanged = false;
    frequency set = 1:1:2e3;
58
59
   nFreq = length ( frequency set );
60
         A = zeros(nFreq, 1);
61
62
    for frequency_index = 1:1:nFreq
         f = frequency\_set(frequency\_index);
         T \text{ total} = [1 0; 0 1];
68
         T segment = duct segment transfer matrix (f, rhoo, c, pipe net length, pipe area);
         T_total = T_segment * T_total;
         Z = open end impedance (f, rhoo, c, 0, pipe area, flanged);
```

```
74
        T11 = T total(1, 1); T12 = T_total(1, 2);
            A( frequency_index ) = -10 \cdot \log 10 ( abs( T11 + T12 / Z )^2 );
76
    end
78
79
    A \text{ parta} = A; \text{ clear } A;
80
81
    % figure(); ...
          82
83
              legend ( 'C5');
84
85
86
    % return
87
88
   %% Part b
89
90
    epsilon = 0.006 / 0.004; % Diameter of the hold divided by diameter of pipe section (1.5).
91
    switch (3)
93
        case 0 % Original Value
94
95
            L\_o \, = \, 0.00001; \quad \% \ \textit{Estimate}
96
                L_e = 0.004 + 2*L_o;
98
            fprintf( 1, '\nZero - Percentage change in pipe thickness: %3.1f%%.\n\n', ( L e - 0.004
        ) / 0.004 * 100 );
        case 1 % Ingard (2010)
            a = 0.006 / 2;
            L\ o = \ (\ 0.6*a\ +\ 0.85*a\ )\ /\ 2;
                L_e = 0.004 + 2*L_o;
            fprintf( 1, '\nIngard (2010) - Percentage change in pipe thickness: %3.1f%%\n\n', ( L e
         case 2 % Kurze and Riedel (2013)
            e = epsilon^2;
114
            a = 0.006 / 2;
            \label{eq:Lo} \text{L\_o} = \text{pi*a*( 1 - 1.47*e^0.5 + 0.47*e^1.5 );}
                L_e = 0.004 + 2*L_o;
118
            fprintf( 1, '\nKurze and Riedel (2013) - Percentage change in pipe thickness: %3.1f%%.\n
        n', ( L e - 0.004 ) / 0.004 * 100 );
        case 3 % Ji (2005)
            a = 0.006 / 2;
            L o = a*(0.9326 - 0.6196*epsilon);
                L_e = 0.004 + 2*L_o;
            fprintf(1, '\nJi(2005) - Percentage change in pipe thickness: <math>\%3.1f\%\%.\n\n', (Le-
        0.004 ) / 0.004 * 100 );
129
        otherwise
            error ( '*** Invalid SWITCH Index *** );
    end
134
    duct_lengths = 0.235/4 * ones(4,1); \% 523 Hz, all holes covered.
138
139
    frequency \_set = 0:1:2 e3;
    nFreq = length ( frequency_set );
        A = zeros(nFreq, 1);
    for frequency_index = 1:1:nFreq
        f = frequency\_set(frequency\_index);
147
```

```
148
                T \text{ total} = [1 0; 0 1];
                Z\_A = 1\, \text{j} \ * \ \text{rho0} \ * \ (2 \ * \ \text{pi} \ * \ \text{f}) \ * \ L\_e \ / \ (\ \text{pi*0.006^2/4} \ ) \, ;
                 term 1 = h RA term 1( rho0, c, pi*(0.006)^2/4, 2*pi*f/c, sqrt((2*3.178e-5)) / (2*pi*f*
                 rho0)), pi * 0.006, 2*pi*f);
                 term\_2 = h\_RA\_term\_2( \ rho0 \ , \ c \ , \ pi*(0.006)^2/4 \ , \ 2*pi*f/c \ , \ sqrt( \ (2 * 3.178e-5 \ ) \ / \ (2*pi*f * 2*pi*f/c \ , \ sqrt( \ (2 * 3.178e-5 \ ) \ / \ (2*pi*f/c \ , \ sqrt( \ (2 * 3.178e-5 \ ) \ / \ (2*pi*f/c \ ) \ / \ (2*pi*f/
                 rho0 ) ), pi * 0.006, 2*pi*f, 0.3 );
                 \begin{array}{l} \text{term} \quad 3 = \text{h\_RA\_term\_3} ( \text{ rhoo }, \text{ c}, \text{ pi*(0.006)^2/4}, \text{ } 2*\text{pi*f/c}, \text{ } \text{sqrt} ( \text{ (2 * 3.178e-5 ) } / \text{ ( } 2*\text{pi*f * rhoo }) ), \text{ pi * 0.006}, \text{ } 2*\text{pi*f}, \text{ } 0.3 ); \\ \end{array} 
                        R A = term 1 + term 2 + term 3;
                Z A = Z A + R A;
158
159
                         T_{\overline{H}}ole = [ 1 0; 1/Z_A 1 ];
                switch (0)
                         case 0 % All holes covered. 523 Hz
166
                                 T1 = duct_segment_transfer_matrix(f, rho0, c, 0.05875, pipe_area); % Duct - Outlet
167
                                 T2 = [1 \overline{0}; 0 1]; \% Hole
                                 T3 = duct\_segment\_transfer\_matrix ( f, rho0, c, 0.05875, pipe\_area ); ~\%~Duct
                                 T4 = [ 1 0; 0 1 ]; \% Hole
                                 T5 = \texttt{duct\_segment\_transfer\_matrix(f, rho0, c, 0.05875, pipe\_area);} \ \% \ \textit{Duct}
                                 T6 = [1 \ 0; \ 0 \ 1]; \% Hole
                                 T7 = duct segment transfer matrix (f, rho0, c, 0.05875, pipe area); % Duct
174
                                 % Check
                                 \% 4 * 0.05875 = 0.235;
                         case 1 % Hole 1 uncovered. 698 Hz
178
                                 T1 = \texttt{duct\_segment\_transfer\_matrix} \left( \begin{array}{ccc} \texttt{f} \,, & \texttt{rhoo} \,, & \texttt{c} \,, & \texttt{0.08775} \,, & \texttt{pipe\_area} \end{array} \right); \quad \% \ \textit{Duct} \, - \, \textit{Outlet}
                                 T2 = T Hole:
180
                                 T3 = duct segment transfer matrix (f, rho0, c, 0.02975, pipe area); % Duct
                                 T4 = [ 1 0; 0 1 ]; \% Ho le
181
182
                                 T5 = duct_segment_transfer_matrix( f, rho0, c, 0.05875, pipe_area ); % Duct
                                 T6 = \begin{bmatrix} 1 & \overline{0}; & 0 & 1 \end{bmatrix}; \% Hole
183
                                 T7 = duct_segment_transfer_matrix(f, rho0, c, 0.05875, pipe_area); % Duct
                                 % Check
187
                                 \% 0.08775 + 0.02975 + 2*0.05875 = 0.235;
188
189
                         case 2 % Hole 2 uncovered. 880 Hz
                                  offset = 0.00625; \% 874
                                 T1 = duct segment transfer matrix (f, rho0, c, 0.08775, pipe area); % Duct - Outlet
                                 T2 = T Hole;
                                 T3 = duct segment transfer matrix (f, rho0, c, 0.0505, pipe area); % Duct
                                 T4 = T Hole;
                                 T5 = duct_segment_transfer_matrix( f, rho0, c, 0.038, pipe_area ); % Duct
                                 T6 = [ 1 0; 0 1 ]; \% Hole
                                 T7 = duct\_segment\_transfer\_matrix ( \ f , \ rho0 \, , \ c \, , \ 0.05875 \, , \ pipe\_area \ ) \, ; \quad \% \ \textit{Duct}
                                 % Check
                                 \% \ 0.08775 + 0.0505 + 0.038 + 0.05875 = 0.235
                         \mathbf{case} \ \ \mathbf{3} \quad \  \  \, \textit{Mole 3 uncovered} \, . \qquad 1 \, , 04 \, 6 \, \, \textit{Hz}
                                 T1 = duct_segment_transfer_matrix(f, rho0, c, 0.08775, pipe_area); % Duct - Outlet
                                 T2 = T Hole;
                                 T3 = duct_segment_transfer_matrix( f, rho0, c, 0.0505, pipe_area ); % Duct
209
                                 T4 = T Hole:
                                 T5 = duct segment transfer matrix (f, rhoo, c, 0.02975, pipe area); % Duct
                                 T6 = T \text{ Hole};
                                 T7 = duct segment transfer matrix (f, rhoo, c, 0.067, pipe area); % Duct
                                 % Check
                                 \% \ 0.08775 + 0.0505 + 0.02975 + 0.067 = 0.235 \ m
217
                 end
218
                         T8 = \texttt{duct\_segment\_transfer\_matrix(f, rho0, c, 0.09, pipe\_area);} \ \% \ \textit{Duct-Inlet}
                         T total = T8 * T7 * T6 * T5 * T4 * T3 * T2 * T1 * T total;
```

```
Z = open end impedance( f, rho0, c, 0, pipe area, flanged);
               T11 = T \text{ total}(1, 1); T12 = T \text{ total}(1, 2);
226
                    A( frequency index ) = -10*\log 10 ( abs( T11 + T12 / Z )^2);
228
     end
229
     % figure(); ...
             plot(frequency_set, A); grid on;
xlabel( 'Frequency [Hz]' ); ylabel( 'Amplitude [dB]' );
234
     %% Plot Note Set
238
239
    load ( 'A_C5_Data.mat' );
                                      % Variable(s): A C5
                                     % Variable(s): A_F5
% Variable(s): A_A5
% Variable(s): A_C6
     load ( 'A_F5_Data.mat' );
load ( 'A_A5_Data.mat' );
     load ( 'A C6 Data.mat' );
244
     h_figure_1 = figure(); ...
          plot ( frequency set , A_C5 );
text ( 523, 25, 'C5' );
                                               hold on;
247
          plot ( frequency _ set , A_F5 );
text ( 698, -1, 'F5' );
248
          plot ( frequency _ set , A_A5 );
text( 880, -14, 'A5' );
plot ( frequency _ set , A_C6 );
text( 1042, -23, 'C6' );
                                                grid on;
255
                legend ( 'C5, 523 Hz', 'F5, 698 Hz', 'A5, 880 Hz', 'C6, 1046 Hz', 'Location', 'NorthWest'
           xlabel( 'Frequency [Hz] '); ylabel( 'Amplitude [dB] ');
           title ( 'Notes Spectrums for a Bugle Recorder');
258
260
    %% Clean-up
     if ( ~isempty( findobj( 'Type', 'figure')))
    monitors = get( 0, 'MonitorPositions');
265
                if (size(monitors, 1) == 1)
                    autoArrangeFigures(2,2,1);
267
                elseif (1 < size (monitors, 1))
268
                    autoArrangeFigures(2,2,1);
                end
270
     end
     if ( PRINT FIGURES == 1 )
               exportgraphics (h figure 1, 'Assignment 1 - Question 3 Bugle Recorder Note Spectrums.pdf'
             'Append', true );
274
     end
     fprintf(1, \nn n \times ** Processing Complete *** \nn n \n');
277
278
279
280
     \%\% Reference (s)
```

```
%% Synopsis
 4
         % Question 4 - Intake Duct
 9
10 \quad \overline{\%\%} \quad Environment
         close all; clear; clc;
13
       \% restored efault path;
         \% add path ( genpath ( '' ), '-begin' );
16
        addpath (genpath ('../40 Assignments/00 Support'), '-begin');
       % set(0, 'DefaultFigurePosition', [ 400 400 900 400 ]); % [ left bottom width height ] set(0, 'DefaultFigurePaperPositionMode', 'manual'); set(0, 'DefaultFigureWindowStyle', 'normal'); set(0, 'DefaultLineLineWidth', 1.5); set(0, 'DefaultTextInterpreter', 'Latex');
18
19
24
         format ShortG;
26
        pause ( 1 );
28
       PRINT FIGURES = 0;
29
32 % Constants
        rho0 = 1.21; % Density of air (kg per cubic-meter).
34
       c = 343; % Speed of sound in air (meters per second).
         h area = @(diameter) pi * diameter^2 / 4;
38
40
        %% Define Shape
41
42
43
         % Source
         \texttt{duct\_1.diameter\_meters} \ = \ \texttt{0.0254}; \quad \% \ \textit{meters}
45
                    duct_1.area = h_area( duct_1.diameter_meters ); % squared-meters
46
         duct 1 length meters = 0.1524; % meters
48
49
        % Outlet
         duct_2.diameter_meters = 0.1016; % 4 inches
        % Flanged.
54
56
        flow_rate_cubic_meters_per_second = 1.04772 / 60; % or 37 cubic-feet per minute
58
59
60 %% Part a
61
        % Calculate the Mach number of the flow in both pip sections.
62
64
         duct_1.Mach = -1.0 * flow_rate_cubic_meters_per_second / ( (pi * duct_1.diameter_meters^2 / 4 ) *
                       c); \% 0.100 unitless
         \label{eq:duct_2.Mach} duct\_2.Mach = -1.0 * flow_rate\_cubic\_meters\_per\_second / ( (pi * duct\_2.diameter\_meters^2 / 4 ) * ( (pi * duct\_2.diameter\_meters^2 / 4 ) * ( (pi * duct\_2.diameter_meters^2 / 4 
                       c); % 0.00628 unitless
         return
68
69 7% Part b
70
         % No flow.
         outlet flanged = true; % Flanged end.
```

```
76 TEST FLAG = 1; \% 1: right-to-left.
 78
     frequency\_set = 0:0.1:2.5e3;
           nFreq = length ( frequency s TL = zeros ( nFreq , 1 );
 79
                                            set ):
 80
 81
 82
     for frequency_index = 1:1:nFreq
 84
 85
           f = frequency set (frequency index);
 87
 88
          T_total = [1 0; 0 1];
 89
 90
 91
           if ( TEST FLAG == 1 )
                \% Right-to-left.
                \mathbf{T}
                   _outlet = duct_segment_transfer_matrix(f, rho0, c, duct_2.length_meters, duct_2.area);
                T\_contraction = \begin{bmatrix} 1 & 0; & 0 & duct & 2 \\ . & area & duct & 1 \\ . & area & ];
                T\_inlet = duct\_segment\_transfer\_matrix( f, rho0, c, duct\_1.length\_meters, duct\_1.area );
                Z = open\_end\_impedance( \ f \ , \ rho0 \ , \ c \ , \ duct\_2.length\_meters \ , \ duct\_2.area \ , \ outlet\_flanged \ ) \ ;
           else
                \% Left-to-right.
                T_outlet = duct_segment_transfer_matrix( f, rho0, c, duct_1.length_meters, duct_1.area );
                T contraction = \begin{bmatrix} 1 & 0; & 0 & duct & 1.area/duct & 2.area & \end{bmatrix};
                 T\_inlet = duct\_segment\_transfer\_matrix( f, \overline{r}ho0, c, duct\_2.length\_meters, duct\_2.area ); 
                Z = open \ end \ impedance(\ f \ , \ rho0 \ , \ c \ , \ duct \_1.length\_meters \ , \ duct \_1.area \ , \ outlet \_flanged \ );
109
           \mathbf{end}
          T net = T inlet * T contraction * T outlet * T total;
           T11 = T \text{ net}(1, 1); \quad T12 = T \text{ net}(1, 2); \quad T21 = T \text{ net}(2, 1); \quad T22 = T \text{ net}(2, 2);
118
119
           if (TEST_FLAG == 1)
                TL(frequency\_index) = 10 * log10(abs(T11 + duct\_1.area*T12/(rho0*c) + (rho0*c)*
           T21/duct_2.area + T22 ) / 2 )^2 );
                TL(\  \, frequency\_index\  \, )\  \, =\  \, 10\  \, *\  \, log10\,(\  \, abs(\  \, (\  \, T11\  \, +\  \, duct\_2.area*T12/(rho0*c)\  \, +\  \, (rho0*c)*c)*c
           T21/duct 1.area + T22 ) / 2 )^2
           end
126
     end \% End: for f = frequency set
128
     TL part b = TL;
129
     \% return
     %% Part c
134
     % Flow present (use Mach numbers).
     outlet flanged = true; % Flanged end.
138
139
     frequency set = 0:0.1:2.5e3;
           n \, F \, req \, = \, l \, e \, n \, g \, t \, h \, \left( \begin{array}{c} f \, re \, q \, u \, e \, n \, c \, y \, \underline{\hspace{1cm}} \, s \, et \end{array} \right) \, ;
141
                TL = zeros(nFreq, 1);
144
     for frequency index = 1:1:nFreq
           f = frequency_set( frequency_index );
149
          T_{total} = [1 0; 0 1];
```

74

```
 T\_outlet = duct\_segment\_transfer\_matrix\_flow( f, rho0, c, duct\_2.length\_meters, duct\_2.area, length\_meters, duct\_2.area, length\_2.area, length\_2.area, length\_2.area, l
                            duct 2. Mach);
                            T expansion = duct expansion connection transfer matrix ( rho0, c, duct 2.area, duct 1.area,
                            duct 1. Mach);
                            T_inlet = duct_segment_transfer_matrix_flow( f, rho0, c, duct_1.length_meters, duct_1.area,
                            duct 1. Mach);
                           T net = T inlet * T expansion * T outlet * T total;
                           Z = open end impedance (f, rhoo, c, duct 2.length meters, duct 2.area, outlet flanged);
161
                            T11 = T_net(1, 1); T12 = T_net(1, 2); T21 = T_net(2, 1); T22 = T_net(2, 2);
                                         TL(\ frequency\_index\ ) = 10\ *\ log10(\ abs(\ (\ \overline{T}11\ +\ duct\_1.area*\overline{T}12/(rho0*c)\ +\ (rho0*c)*
                           T21/duct_2.area + T22) / 2)^2
              end % End: for f = frequency set
167
             TL\_part\_c = TL;
168
              % return
             %% Part d
172
174
              % Flow present (use Mach numbers).
              \% \ \ Helmholtz \ \ resonator \ \ in \ \ place \ \ (between \ \ lefthand \ \ duct \ and \ \ expansion) \, .
176
               outlet_flanged = true; % Flanged end.
178
179
            % Resonance
             w o = 2 * pi * 136.6; % Estimated from plot.
181
182
183
184
             \%\ helmholtz\_\ diameter\_\ cavity =
185
              \% \ helmholtz\_diameter\_neck = 1e-3;
186
                                   helmholtz \ L01 = 0.82 * (1 - 1.33*(helmholtz \ diameter \ neck/helmholtz \ diameter \ cavity));
187
188
                                   epsilon = helmholtz diameter cavity / duct 1.length meters;
189
                                  \% \ \ helmholtz \ \ L02 =
              \% \ \ helmholtz\_volume = 1e-3;
              % % keyboard
194
              \% \ \ helmholtz\_L\_neck \ = \ 1e-3\,;
              \% \ Q = 2;
197
198
              \label{eq:reconstruction} \ensuremath{\%} \ensuremath{R\_A} = \ensuremath{\textit{rho0*c}} \ensuremath{/} \ensuremath{Q} \ * \ sqrt(\ L\_e\ /\ (\ pi*helmholtz\_diameter\_neck^2/4\ *\ helmholtz\_volume\ )\ );
               f\,re\,q\,u\,e\,n\,c\,y\,\_\,s\,et\ =\ 0:0.1:2.5\,e\,3\ ;
                            nFreq = length (frequency set);
                                         TL = zeros(nFreq, 1);
               for frequency index = 1:1:nFreq
                            f = frequency_set( frequency_index );
210
212
                            T_total = [1 0; 0 1];
                             T\_outlet = duct\_segment\_transfer\_matrix\_flow( f, rho0, c, duct\_2.length\_meters, duct\_2.area, length\_meters, duct\_2.area, length\_2.area, length\_2.area, length\_2.area, l
                            duct 2. Mach);
                             T\_expansion = duct\_expansion\_connection\_transfer\_matrix ( rho0 , c , duct\_2.area , duct\_1.area , \\ 
                            duct 1. Mach);
218
                           219
                                         % T_Helmholtz = [1 0; 1/Z_A 1];
```

```
T_inlet = duct_segment_transfer_matrix_flow( f, rho0, c, duct_1.length_meters, duct_1.area,
          duct 1. Mach);
          \% \ T \ net = \ T \ inlet \ * \ T \ Helmholtz \ * \ T \ expansion \ * \ T \ outlet \ * \ T \ total;
226
          T_net = T_inlet * T_expansion * T_outlet * T_total;
228
          Z = open end impedance (f, rhoo, c, duct 2.length meters, duct 2.area, outlet flanged);
          T11 \, = \, T\_net \, (\, 1 \, , \  \, 1\, ) \, ; \quad T12 \, = \, T\_net \, (\, 1 \, , \  \, 2\, ) \, ; \quad T21 \, = \, T\_net \, (\, 2 \, , \  \, 1\, ) \, ; \quad T22 \, = \, T\_net \, (\, 2 \, , \  \, 2\, ) \, ;
          \mathbf{end} \quad \% \ End: \quad for \ f = frequency\_set
238
     TL part d = TL;
240
     \% return
     %% Plot
243
     Y_LIMITS = [ 0 50 ];
246
     figure(); ...
          plot ( frequency_set , TL_part_b ); hold on; plot ( frequency_set , TL_part_c , '-' ); plot ( frequency_set , TL_part_d , '-.' ); gr
248
                                                               grid on;
           legend ( ...
251
                'No Flow - Part b', ...
                ^{+}Flow - Part c^{+}, ...
                'Flow and Resonator - Part d', ...
254
                'Location', 'SouthOutside');
           xlabel( 'Frequency [Hz]' ); ylabel( 'Amplitude [dB]' );
title( 'Transmission Loss Profiles' );
          Ax = gca;
259
                Ax. XAxis. TickLabelInterpreter = 'latex';
                Ax.YAxis.TickLabelInterpreter = 'latex';
262
           \% axis ( [ -50 5 e3 + 50 Y LIMITS ] );
           if (PRINT FIGURES == 1)
                export graphics ( gcf, 'Figure TL All Profiles.pdf', 'Append', true );
265
           end
268
     return
270
     %% Part c
     return
274
     %% Part d
275
276
     return
278
279
     %% Clean-up
     \begin{array}{ll} \textbf{if} & (~~\text{isempty}\,(~~\text{findobj}\,(~~\text{'Type'}\,,~\text{'figure'}\,)~)~)\\ & & \text{monitors} = \text{get}\,(~~0\,,~\text{'MonitorPositions'}~)~; \end{array}
281
282
283
                if (size(monitors, 1) == 1)
                     autoArrangeFigures(2,2,1);
284
                elseif (1 < size (monitors, 1))
285
286
                     autoArrangeFigures( 2, 2, 1 );
287
                end
288
     end
     fprintf(1, '\n\n*** Processing Complete ***\n\n');
     \%\% Reference (s)
```

```
%% Synopsis
3
4
   % Question 4 - Intake Duct
9
   %% To Do
10
   % Check loss profile.
13
14
   %% Note(s)
16
   % Search for FIXMEs.
18
19
   % In class note, the areas for the impedance might have bee wrong; switch them?
   \% Use negative Mach numbers in the equations. The analysis for this case
24
    % is the same as for the horn example. Inlet on the left, outlet on the
   \% right.
28 % The S in the diagram (pink area) for the Helmholtz resonator is the
29
   % cross-sectional area of the resonator neck connecting it to the tube.
   % For Lo2, use the value for a quarter-wavelength side tube.
35 % The area expansion ratio is determined using the original duct diameters.
38
39 % Environment
40
   close all; clear; clc;
41
42
   % restored efault path;
43
   % addpath( genpath( ''), '-begin');
45
   addpath ( genpath ( '../40 Assignments/00 Support' ), '-begin');
46
   % set(0, 'DefaultFigurePosition', [ 400 400 900 400 ]); % [ left bottom width height ] set(0, 'DefaultFigurePaperPositionMode', 'manual'); set(0, 'DefaultFigureWindowStyle', 'normal'); set(0, 'DefaultLineUineWidth', 1.5);
47
48
    set( 0, 'DefaultTextInterpreter', 'Latex' );
   format ShortG;
54
   pause( 1 );
56
   PRINT FIGURES = 0;
58
59
61
   %% Define Constants and Anonymous Functions
62
   {
m rho0} = 1.21; % Density of air (kg per cubic-meter).
63
64
   c=3\,43; % Speed of sound in air (meters per second).
67
   h area = @(diameter) pi * diameter^2 / 4;
68
69
70
71
   %% Define Shape
73 % Source
   duct_1.diameter_meters = 0.0254; % 1 inch
74
   duct 1.length meters = 0.1524; % 6 inches
```

```
duct 1.area = h area( duct 1.diameter meters );
 76
 78 % Outlet
 79 \operatorname{duct}_2.\operatorname{diameter}_{\operatorname{meters}} = 0.1016; % 4 \operatorname{inches}
    duct_2.length_meters = 0.127;  % 5 inches
 80
    duct 2. area = h area ( duct 2. diameter meters );
 81
 82
    \% Flanged.
 8.3
 84
 8.5
 86
 87
    flow rate cubic meters per second = 1.04772 / 60; % or 37 cubic-feet per minute
88
 89 % return
 90
91 %% Part a
 92
    \% The -35 dB transmission loss dip | notch is at about 1,150 Hz.
    f = 1150:
96 % Total attenuation required is +35 dB to make it 0 dB.
97
    l = 0.0381; % meters (1.5 inches)
98
    h = 0.0127; % meters (0.5 inches)
    % The total attenuation of the lining from Figure 8.37 (Bies et. al., Fifth Edition),
     \% \ m = (h \ area(\ 0.1016\ ) - h \ area(\ 0.0254\ )) / h \ area(\ 0.0254\ )
    % ASSUMPTION: Cross-section area of lined duct is the same as the inlet.
106
    m = 1;
108
    k = 2 * pi * 1.15 e3;
109
length of expansion chamber = 0.127; % meters
112 \% kL = k*length of expansion chamber
113
    % ASSUMPTION:
114
116
    % Expansion ratio is m = 1;
    % Assume peak difference is 10 dB.
118
    % Total attunation of lining is 10 dB.
119
120 % The attenuation rate is about 10 dB / 0.127 meters or 78.7 dB per meter.
    % return
124 \( \bar{7}\bar{7}\) \( Part \ b \)
126 \quad l = 0.0381; \quad \% \ meters \ (1.5 \ inches)
128
    h = 0.011255; \% meters
          \label{eq:h_validate} \mbox{$h_validate} = 0.5* \mbox{$sqrt( (pi*(duct_2.diameter_meters - 2*l)^2 )/4 ); $\%$ $Same value. } 
133 \frac{\%\% Part c}{}
135 % The liner thickness ratio is,
136 l / h; % 3.3852 unitless
    % The normalized frequency is,
138
    ( 2 * h ) / ( 343 / \hat{f} ); % 0.075471 unitless
141
143 \frac{7}{2} Part d
145 % Assume the attenuation rate from Part a is 18 dB per meter.
146
    % Use bottom, right subplot (16).
148
149 % The approximate resistivity parameter is 16.
    %% Part e
```

```
% Calculate the flow resistivity.
    R1 = 16 * rho0*c / l; \% 1.74e5 kg / m^3*s
158
159
    %% Placeholder
    % % Flow present (use Mach numbers).
    % Helmholtz resonator in place (between lefthand duct and expansion).
    \% outlet flanged = true; \% Flanged end.
168
    % % Resonance
170 % w \ o = 2*pi*136.6; % Estimated from plot.
172
173 \quad \% \ \% \ helmholtz\_diameter\_cavity \ =
    \% % helmholtz\_diameter\_neck = 1e-3;
174
              helmholtz\_L01 = 0.82 * (1 - 1.33*(helmholtz\_diameter\_neck/helmholtz\_diameter\_cavity));
    % %
176
    % %
    % %
              epsilon = helmholtz\_diameter\_cavity / duct\_1.length\_meters;
    % %
178
              \% \ \ helmholtz \ \ L02 =
179
    % %
180 \% \% helmholtz_volume = 1e-3;
181
     % %
    % % % keyboard
182
183
    % %
184
    \% % helmholtz_L_neck = 1e-3;
    \% \ \% \ Q = 2;
185
    % %
187
    \% \ \ R\_A = \ rho \ 0 * c \ / \ Q * \ sqrt( \ L\_e \ / \ ( \ pi * helmholtz\_diameter\_neck \ ^2/4 * \ helmholtz\_volume \ ) \ );
188
189
    %
191
    \% \ frequency\_set = 0:0.1:2.5e3;
           nFreq = length (frequency\_set);
    %
                TL = zeros(nFreq, 1);
194
196 % for frequency index = 1:1:nFreq
197
    %
198
            f = frequency\_set(frequency\_index);
    %
    %
           T_total = [1 0; 0 1];
202
    %
    %
            T outlet = duct segment transfer matrix flow (f, rho0, c, duct 2.length meters, duct 2.area
         , duct 2. Mach );
204
    %
    %
           T\_expansion = duct\_expansion\_connection\_transfer\_matrix(\ rho0\ ,\ c\ ,\ duct\_2\ .area\ ,\ duct\_1\ .area\ ,
          duct_1 . Mach);
    %
         \label{eq:sum_energy} \begin{array}{lll} \% \ Z\_A = 1 \ j * rho0 * 2 * pi * f(frequency\_index) & * L\_e \ / \ ( \ pi * helmholtz\_neck\_diameter ^ 2/4 \ ) & - \ 1 \ j * rho0 * c ^ 2/(helmholtz\_volume * 2 * pi * f(frequency\_index)) & + \ R\_A; \end{array}
    %
    %
                \% T Helmholtz = [1 0; 1/Z_A 1];
    %
    %
    %
            T\_inlet = duct\_segment\_transfer\_matrix\_flow(\ f,\ rho0,\ c,\ duct\_1.length\_meters,\ duct\_1.area,
          duct 1. Mach);
    %
214
    %
           \% \ T \ net = \ T \ inlet \ * \ T \ Helmholtz \ * \ T \ expansion \ * \ T \ outlet \ * \ T \ total;
    %
           T\_net = T\_inlet * T\_expansion * T\_outlet * T\_total;
216
217
    %
218
    0%
           Z = open\_end\_impedance (\ f,\ rho0\,,\ c\,,\ duct\_2.length\_meters\,,\ duct\_2.area\,,\ outlet\_flanged\ )\,;
219
220 %
           %
    %
         )*T21/duct 2.area + T22 ) / 2 )^2 );
224
    %
    \% end \% End: for f = frequency\_set
```

```
% TL part d = TL;
228
229 \quad \% \ return
    %% Plot
    % Y LIMITS = [ 0 50 ];
    % figure(); ...
           238
239
    %
           % legend(...
    %
                  'No Flow - Part b', ...
240
           %
                  'Flow - Part \ c', \dots
'Flow \ and \ Resonator - Part \ d', \dots
    %
    %
           %
    %
                  'Location', 'SouthOutside');
243
           %
    %
246 %
    %
           Ax = gca;
    %
               Ax. XAxis. TickLabelInterpreter = 'latex';
248
                Ax. YAxis. TickLabelInterpreter = 'latex';
249
   %
    %
           %
    %
           \% axis ( \begin{bmatrix} -50 & 5e3+50 & Y & LIMITS \end{bmatrix} );
    %
    %
%
            if (PRINT\_FIGURES == 1)
253
                export\overline{g}raphics(\ gcf,\ 'Figure\ TL\ All\ Profiles.pdf',\ 'Append',\ true\ );
254
    %
256
    % return
258
259
    %% Clean-up
    if ( ~isempty( findobj( 'Type', 'figure')))
    monitors = get( 0, 'MonitorPositions');
262
              if ( size( monitors, 1 ) == 1 )
   autoArrangeFigures( 2, 2, 1 );
264
              elseif ( 1 < size ( monitors, 1 ) )
265
                  autoArrangeFigures(2,2,1);
267
268
    end
270
    fprintf(\ 1,\ '\backslash n\backslash n ****\ Processing\ Complete\ ***\backslash n\backslash n'\ );
274
275 \%\% Reference(s)
```