ASM+C & C+ASM ABI std. compliancy Code optimization

Paolo Bernardi

Cross compiler

- A cross compiler is a compiler capable of creating executable code for a platform other than the one on which the compiler is running
- For example, a compiler that runs on a Windows 7 PC but generates a code that runs on ARM SoC is a cross compiler
- To cross compile is typical for embedded application written in C language
- When integrating ASM functions, a special care is needed
 - To correctly identify the argument
 - To use the proper resources to return a result
- The knowledge of the ABI standard is fundamental in this context.

Branch to main.c from startup.s

```
Reset_Handler PROC

EXPORT Reset_Handler [WEAK]

IMPORT __main

LDR RO, =__main


BX RO

ENDP
```

ABI_C+ASM project (I)

(in the software/example folder - startup_LPC17xx.s)

- In our setup we find the following source codes:
 - startup_LPC17xx.s
 - main.c
 - ASM funct.s



 The startup_LPC17xx.s file includes the banch to main in the reset handler

```
Reset_Handler PROC

EXPORT Reset_Handler [WEAK]

IMPORT main

LDR R0, = main

BX R0

ENDP
```

ABI_C+ASM project (II) (in the software/example folder - main.c)

- The main.c file is a C source code
 - It invokes a function called ASM_funct with 6 parameters
 - After executing the called function, it enters an endless loop.

```
extern int ASM_funct(int, int, int, int, int, int);
int main(void) {
   int i=0xFFFFFFFFF, j=2, k=3, l=4, m=5, n=6;
   volatile int r=0;
   r = ASM_funct(i, j, k, l, m, n);
   while(1);
}
```

ABI_C+ASM project (III) (in the software/example folder - ASM_funct.s)

Inline ASM

__ASM("SVC #0x10");

External ASM function invoked by a C function

r = ASM_funct(i, j, k, l, m, n);

Where are parameters stored?

```
How to return results?
```


```
AREA asm functions, CODE, READONLY
EXPORT ASM funct
  save current SP for a faster access
; to parameters in the stack
                                          Parameters are in
      r12, sp
                                            RO-R3 (a1-a4)
; save volatile registers
STMFD sp!, {r4-r8, r10-r11, lr}
; extract argument 4 and 5 into R4 and R5
      r4, [r12]
LDR
      r5, [r12,#4]
; setup a value for RO to return
                                         Stacked parameters
      r0, r5
MOV
; restore volatile registers
LDMFD sp!, {r4-r8, r10-r11, pc}
```

C and ASM helpful directives

- EXPORT: makes visible a function outside the file defining it
- IMPORT: makes visible a function from other files
- extern: permits to import a variable from another file (where it is defined)

COMPILER OPTIMIZATION

• As we are now working in C language, the compiled can be asked to optimize the produced machine code.



Compiler optimization and the <u>volatile</u> attribute

- Higher optimization levels can reveal problems in some programs that are not apparent at lower optimization levels
- This happens when, for example, missing the volatile qualifiers
- The declaration of a variable as <u>volatile</u> tells the compiler that the variable can be modified at any time externally to the implementation
 - by the operating system,
 - by another thread of execution such as an interrupt routine or signal handler,
 - by hardware.

Example

Table 12. C code for nonvolatile and volatile buffer loops

Nonvolatile version of buffer loop int buffer_full; int read_stream(void) { int count = 0; while (!buffer_full) { count++; } return count; } Volatile version of buffer loop volatile int buffer_full; int read_stream(void) { int count = 0; while (!buffer_full) { count++; } return count; }

Table 13. Disassembly for nonvolatile and volatile buffer loop

Nonvolatile version of buffer loop	Volatile version of buffer loop	
read_stream PROC	read_stream PROC	
LDR r1, L1.28 MOV r0, #0 LDR r1, [r1, #0]	LDR r1, L1.28 MOV r0, #0	
L1.12	LDR r2, [r1, #0]; ; buffer_fu] CMP r2, #0 ADDEQ r0, r0, #1 BEQ L1.8 BX r ENDP	
L1.28	L1.28 DCD .data AREA .data , DATA, ALIGN=2 buffer_full ctures - Polite@@ di Torin@x00000000	
compater / tremtee		

ABI standard for ARM

ABI for the ARM Architecture (Base Standard)



Application Binary Interface for the ARM® Architecture

The Base Standard

Document number: Date of Issue: ARM IHI 0036B, current through ABI release 2.09 10th October 2008, reissued 30th November 2012

Abstract

This document describes the structure of the Application Binary Interface (ABI) for the ARM architecture, and links to the documents that define the base standard for the ABI for the ARM Architecture. The base standard governs inter-operation between independently generated binary files and sets standards common to ARM-based execution environments.

Keywords

ABI for the ARM architecture, ABI base standard, embedded ABI

Register	Synonym	Special	Role in the procedure call standard	
r15		PC	The Program Counter.	
г14		LR	The Link Register.	
r13		SP	The Stack Pointer.	
r12		IP	The Intra-Procedure-call scratch register.	
r11	v 8		Variable-register 8.	
r10	v7		Variable-register 7.	n be freely used to hold local variables
г9		v6 SB TR	Platform register. The meaning of this register	ed by the platform standard.
r8	v 5		Variable-register 5.	
r7	v4		Variable register 4.	If there are more than 4
r6	v 3		Variable register 3.	formal arguments, they
r5	v2		Variable register 2.	have to be saved in the
r4	v1		Variable register 1.	stack
r3	a4		Argument / scratch register 4.	
r2	a3		Argument / scratch register 3.	
r1	a2		Argument / result / scratch register 2.	
r0	a1		Argument / result / scratch register 1.	

Passing arguments

- The first four registers r0-r3 (a1-a4) are used to pass argument values into a subroutine and to return a result value in r0-r1 from a function.
 - A subroutine must preserve the contents of the registers r4-r8, r10, r11 and SP
- The base standard provides for passing arguments in core registers (r0-r3) and on the stack.
 - For subroutines that take a small number of parameters, only registers are used, greatly reducing the overhead of a call.

STACK management

- The stack implementation is *full-descending*, with the current extent of the stack held in the register SP (r13).
- The stack will, in general, have both a base and a limit though in practice an application may not be able to determine the value of either.

```
Disassembly
       4: int main(void) {
       5:
□>0x00000180 B50E
                     PUSH
                                 {r1-r3, lr}
                  int i=0xFFFFFFF, j=2, k=3, l=4, m=5, n=6;
 0x00000182 F04F34FF
                                 r4,#0xFFFFFFFF
                       MOV
 0x00000186 2502
                       MOVS
                             r5,#0x02
                                                          Variable allocation in
                   MOVS r6,#0x03
 0x00000188 2603
 0x0000018A 2704
                   MOVS
                              r7,#0x04
                                                         register and initialization
 0x0000018C F04F0805 MOV
                             r8,#0x05
 0x00000190 F04F0906 MOV
                                 r9,#0x06
                  volatile int r=0:
       8 :
 0x00000194 2000
                       MOVS
                                r0,#0x00
                                                       Volatile variable allocation in
 0x00000196 9002
                       STR
                                r0,[sp,#0x08]
                                                                the stack
                  r = ASM funct(i, j, k, l, m, n);
      10:
                       MOV
 0x00000198 463B
                                 r3, r7
                                                 Parameters i, j, k, l
 0x0000019A 4632
                                 r2.r6
                       MOV
                                               setup in registers r0-r3
 0x0000019C 4629
                       MOV
                                 r1.r5
 0x0000019E 4620
                    MOV
                                 r0,r4
                                                            Parameters m, n setup
 0x000001A0 E9CD8900 STRD
                                 r8, r9, [sp, #0]
 0x000001A4 F000F83E BL.W
                                 ASM funct (0x00000224)
                                                                  in stack
 0x000001A8 9002
                       STR
                                 r0,[sp,#0x08]
                  while (1);
      11:
 0x000001AA BF00
                        NOP
                                                              Returned value is
 0x000001AC E7FE
                                 0x000001AC
                                                            written at his address
                            Computer Architectures - Politecnico di Torino
```

What happens if don't declare r as volatile?

- A warning is signaled about missing usesfuleness of variable r
- An optimization of the machine code is implemented by the compiler.

```
Rebuild target 'Target 1'
assembling startup_LPC17xx.s...
compiling main.c...
main.c(7): warning: #550-D: variable "r" was set but never used
    int r;
main.c: 1 warning, 0 errors
assembling ASM_funct.s...
linking...
Program Size: Code=360 RO-data=408 RW-data=0 ZI-data=608
".\ABI C+ASM.axf" - 0 Error(s), 1 Warning(s).
```

What happens if don't declare r as volatile?

```
Disassembly
       4: int main(void) {
       5:
□0x00000180 B51C
                       PUSH
                                 {r2-r4, lr}
                  int i=0xFFFFFFFF, j=2, k=3, l=4, m=5, n=6;
                  int r:
 0x00000182 F04F34FF
                                 r4,#0xFFFFFFFF
                       MOV
                                                      Variable r is not allocated and
 0x00000186 2502
                       MOVS
                                 r5,#0x02
                                 r6,#0x03
 0x00000188 2603
                       MOVS
                                                       the ASM function translated
 0x0000018A 2704
                                 r7,#0x04
                   MOVS
                                                          into a "void" function
 0x0000018C F04F0805 MOV
                                 r8,#0x05
 0x00000190 F04F0906 MOV
                                 r9,#0x06
                  r = ASM funct(i, j, k, l, m, n);
     10:
 0x00000194 463B
                       MOV
                                 r3, r7
                                 r2, r6
 0x00000196 4632
                       MOV
                                 r1, r5
 0x00000198 4629
                       MOV
 0x0000019A 4620
                       MOV
                                 r0,r4
 0x0000019C E9CD8900
                       STRD
                                 r8, r9, [sp, #0]
 0x000001A0 F000F83C
                       BL.W
                                 ASM funct (0x0000021C)
     11:
                  while (1);
 0x000001A4 BF00
                       NOP
 0x000001A6 E7FE
                                 0x000001A6
                       В
                             Computer Architectures - Politecnico di Torino
```

Some extra C types

```
// testValue
// 1 byte -> [0-255] or [0x00-0xFF]
             number8 = testValue; // 255
uint8 t
unsigned char numberChar = testValue; // 255
// 2 bytes -> [0-65535] or [0x0000-0xFFFF]
             number16 = testValue; // 65535
uint16 t
unsigned short
            numberShort = testValue; // 65535
// 4 bytes -> [0-4294967295] or [0x00000000-0xFFFFFFF]
uint32 t
             number32 = testValue; // 4294967295
unsigned int
             numberInt = testValue; // 4294967295
number64
uint64 t
                         = testValue; // 18446744073709551615
unsigned long long numberLongLong = testValue; // 18446744073709551615
```