

# R307S Fingerprint Module User Manual



Hangzhou Grow Technology Co., Ltd

Nov. 2023 Ver: 1.1.2



# **Preface & Declaration**

Thank you for you selection of R307S Fingerprint Identification Module (Module) of GROW.

The Manual is targeted for hardware & software developing engineer, covering hardware interface, system resource, instruction system, installment information, etc. To ensure the developing process goes smoothly, it is highly recommended the Manual is read through carefully.

We will try our best to assure you the correctness of the Manual. However, should you find any problem or error with it, feel free to contact us or the sales representative of us. We would be very grateful.

Holding the principle of constantly improving and perfecting products, so both the module and contents of the Manual might subject to changes. Sorry for separate notice. You may visit our website or call us for the latest information.

The Manual contains proprietary information of GROW, which shall not be used by or disclosed to third parties without the permission of GROW, nor for any reproduction and alteration of information without any associated warranties, conditions, limitations, or notices.

No responsibility or liability is assumed by GROW for the application or use, nor for any infringements of patents or other intellectual property rights of third parties that may result from its use.

All products are sold subject to GROW's terms and conditions of sale supplied at the time of order acknowledgment. Testing, tool and other quality control techniques are used to the extent GROW considers necessary to support the warranty of relevant performance of its products to the specifications, except as expressly agreed to in writing by government requirements, testing of all parameters of each product is not necessarily performed.

www.hzgrow.com



# **Revised Version**

Version Number	Date	Revise Content	Modifier
V1.1	2022.06	Create a new version	Grow Tech
V1.1.1	2023.09	<ol> <li>Modify template size to 768 bytes</li> <li>Security level: 3</li> </ol>	Grow Tech
V1.1.2	2023.11	Cancel 300 capacity type.	Grow Tech



# Catalog

I	Introduction 1	-
	Operation Principle1	-
II	Hardware Interface ————————————————————————————————————	
	Exterior Interface	-
	Dimension — - 2	
	Serial Communication - 3	-
	USB Communication3	-
	Serial communication protocol3	
	Reset time	-
III	System Resources 4	
	Notepad4	
	Buffer 4	-
	Image buffer 4	
	Character file buffer ———————————————————————————————————	
	Fingerprint Library 4	-
	System Configuration Parameter 4	
	Baud rate control (Parameter Number: 4)5	
	Security Level (Parameter Number: 5) 5	-
	Data package length (Parameter Number: 6) 5	
	System status register 5	-
	Module password 5	-
	Module address 5	-
	Random number generator 6	
	Features and templates ————————————————————————————————————	-
IV	Communication Protocol7	-
	Data package format7	-
	Check and acknowledgement of data package7	
V	Module Instruction System9	
	Instruction Table ————————————————————————————————————	-
	System-related instructions ————————————————————————————————————	-
	Verify passwoard VfyPwd10	-
	Set password SetPwd	-
	Set Module address SetAdder 10	-
	Set module system's basic parameter SetSysPara11	-
	Port Control Control - 11	-
	Read system Parameter ReadSysPara 12	-
	Read valid template number TempleteNum 12	-
	Fingerprint-processing instructions 13	-
	To collect finger image GenImg13	-
	To upload image UpImage 13	
	To download the image DownImage 14	
	To generate character file from image Genchar 14	
	To generate template RegModel 15	-



	To upload character or template UpChar	16 -
	To download character file or template DownChar	16 -
	To store template Store	17 -
	To read template from Flash library LoadChar	17 -
	To delete template DeletChar	18 -
	To empty finger library Empty	18 -
	To carry out precise matching of two finger templates Match	19 -
	To search finger library Search	19 -
	Other instructions	20 -
	To generate a random code GetRandomCode	20 -
	To write note pad WriteNotepad	20 -
	To read note pad ReadNotepad	21 -
	Read fingerprint template index table ReadIndexTable	21 -
	Get Image in register GetEnrollImage	22 -
	To read information page ReadINFpage	22 -
	High Speed Search High Speed Search	23 -
	Generate to Minutiae Fingerprint Image GenBinImage	23 -
	HandShake instruction HandShake	24 -
	Check Sensor CheckSensor	24 -
VI	Operation Process	26 -
	Pressing fingerprint twice to record a template and store in flash fingerprint database;	26 -
	Reading an image from sensor and searching the database field from 10—100	27 -
	Capturing a fingerprint image from sensor and generating the feature file, then uple	oad to the
	host;	28 -
VII	Reference Circuit	29 -



# I Introduction

Power	DC 4.2V-6V	Interface	UART(TTL logical	
			level)/ USB 2.0	
Working current	Typical: 50mA	Matching Mode	1:1 and 1:N	
Baud rate	(9600*N)bps,	Character file size	256 bytes	
	$N=1\sim12$ (default $N=6$ )			
Image acquiring time	<0.5s	Template size	768 bytes	
Storage capacity	1000	Security level	3 (1, 2, 3, 4,	
			5(highest))	
FAR	<0.001%	FRR	<0.1%	
Average searching time	< 1s (1:1000)	Window dimension	19mm*21mm	
Working environment	Temp: -10°C - +40°C	Storage environment	Temp: -40°C - +85°C	
	RH: 20%-85%		RH: <85%	
<b>Outline Dimention</b>	Split type	Module: 44.1*20*23.5 mm		

# **Operation Principle**


Fingerprint processing includes two parts: fingerprint enrollment and fingerprint matching (the matching can be 1:1 or 1:N).

When enrolling, user needs to enter the finger two times. The system will process the two time finger images, generate a template of the finger based on processing results and store the template. When matching, user enters the finger through optical sensor and system will generate a template of the finger and compare it with templates of the finger library. For 1:1 matching, system will compare the live finger with specific template designated in the Module; for 1:N matching, or searching, system will search the whole finger library for the matching finger. In both circumstances, system will return the matching result, success or failure.





# **II** Hardware Interface

# **Exterior Interface**



# **Dimension**







#### **Serial Communication**

When the FP module communicates with user device, definition is as follows:

Pin Nmuber	Name	Type	Function Description		
1	5V	in	Power input (DC4.2V - 6V)		
2	GND	-	Signal ground. Connected to power ground		
3	TXD	out	Data output. TTL logical level		
4	RXD	in	Data input. TTL logical level		
5	Touch	out	Finger detection signal (maximum output current: 50mA)		
6	3.3V	in	Finger detection power (DC3.3V - 5V, about 5uA)		

#### **Hardware connection**

Via serial interface, the Module may communicate with MCU of 3.3V or 5V power: TXD (pin 3 of P1) connects with RXD (receiving pin of MCU), RXD (pin 4 of P1) connects with TXD (transferring pin of MCU). Should the upper computer (PC) be in RS-232 mode, please add level converting circuit, like MAX232, between the Module and PC.


#### **USB Communication**

Pin Number	Name	Type	Function Description	
1	Vin	in	Power input	
2	D-	in	USB data input	
3	D+	out	USB data output	
4	GND	-	Signal ground	

#### Serial communication protocol

The mode is semiduplex asychronism serial communication. And the default baud rate is 57600bps. User may set the baud rate in  $9600 \sim 115200$ bps.

Transferring frame format is 10 bit: the low-level starting bit, 8-bit data with the LSB first, and an ending bit. There is no check bit.



#### **Reset time**

At power on, it takes about 200ms for initialization. During this period, the Module can't accept commands for upper computer.



# **III** System Resources

To address demands of different customer, Module system provides abundant resources at user's use.

# Notepad

512-byte memory is set aside in flash for User's notepad. The notepad is divided into 16 pages logically, 32 bytes per page. The host can access any page by instruction GR WriteNotepad or GR ReadNotepad.

**Note**: when written, the whole page is taken as a whole and its former contents will be replaced.

#### Buffer

There are an image buffer and two 512-byte-character-file buffer within the RAM space of the module. Users can read & write any of the buffers by instructions.

Note: Contents of the above buffers will be lost at power-off.

### Image buffer

ImageBuffer serves for image storage and the image format is 256\*288 pixels, form is BMP.

When transferring through UART, to quicken speed, only the upper 4 bits of the pixel is transferred (that is 16 gray degrees). And two adjacent pixels of the same row will form a byte before the transferring. When uploaded to PC, the 16-grey-degree image will be extended to 256-grey-degree format. That's 8-bit BMP format.

When transferring through USB, the image is 8-bit pixel, that's 256 gray degrees.

#### Character file buffer

Character file buffer, CharBuffer1, CharBuffer2, can be used to store both character file and template file.

# Fingerprint Library

System sets aside a certain space within Flash for fingerprint template storage, that's fingerprint library. Contents of the library remain at power off.

Capacity of the library changes with the capacity of Flash, system will recognize the latter automatically. Fingerprint template's storage in Flash is in sequential order. Assume the fingerprint capacity N, then the serial number of template in library is 0, 1, 2, 3 ... N. User can only access library by template number.

# System Configuration Parameter

To facilitate user's developing, Module opens part system parameters for use. And the basic instructions are SetSysPara & ReadSysPara. Both instructions take Parameter Number as



When upper computer sends command to modify parameter, Module first responses with original configurations, then performs the parameter modification and writes configuration record into Flash. At the next startup, system will run with the new configurations.

#### **Baud rate control (Parameter Number: 4)**

The Parameter controls the UART communication speed of the Module. Its value is an integer N, N=[1, 12]. Corresponding baud rate is 9600\*N bps.

#### Security Level (Parameter Number: 5)

The Parameter controls the matching threshold value of fingerprint searching and matching. Security level is divided into 5 grades, and corresponding value is 1, 2, 3, 4, 5. At level 1, FAR is the highest and FRR is the lowest; however at level 5, FAR is the lowest and FRR is the highest.

#### Data package length (Parameter Number: 6)

The parameter decides the max length of the transferring data package when communicating with upper computer. Its value is 0, 1, 2, 3, corresponding to 32 bytes, 64 bytes, 128 bytes, 256 bytes respectively.

# System status register

System status register indicates the current operation status of the Module. Its length is 1 word, and can be read via instruction *ReadSysPara*. Definition of the register is as follows:

Bit Num	15 4	3	2	1	0
Description	Reserved	ImgBufStat	PWD	Pass	Busy

Note:

Busy: 1 bit. 1: system is executing commands; 0: system is free;

Pass: 1 bit. 1: find the matching finger; 0: wrong finger; PWD: 1 bit. 1: Verified device's handshaking password. ImgBufStat: 1 bit. 1: image buffer contains valid image.

# Module password

At power-on reset, system first checks whether the handshaking password has been modified. If not, system deems upper computer has no requirement of verifying password and will enter into normal operation mode. That's, when Module password remains the default, verifying process can be jumped. The password length is 4 bytes, and its default factory value is 0FFH, 0FFH, 0FFH. Should the password have be modified, *refer to instruction SetPwd*, then Module (or device) handshaking password must be verified before the system enter into normal operation mode. Or else, system will refuse to execute and command.

The new modified password is stored in Flash and remains at power off.

#### Module address

Each module has an identifying address. When communicating with upper computer, each



instruction/data is transferred in data package form, which contains the address item. Module system only responds to data package whose address item value is the same with its identifying address.

The address length is 4 bytes, and its default factory value is 0xFFFFFFF. User may modify the address via instruction *SetAdder*. The new modified address remains at power off.

# Random number generator

Module integrates a hardware 32-bit random number generator (RNG) (without seed). Via instruction *GetRandomCode*, system will generate a random number and upload it.

# Features and templates

Fingerprint feature file occupies 256 bytes, including general information as well as minutiae information; Template file occupies 512 bytes, sum of two features files of the same fingerprint.

#### **Feature file structure:**

The minutiae number of a feature file is no more than 50. Of the total 256 bytes (size of feature file is 256 bytes), the first 56 bytes is the file header used for general information; The latter 200 bytes are to store minutiae information, 4 bytes for each minutiae.

#### File Header Format:

0~5 byte	6~39 byte	40~43 byte	44~55 byte
Symbol\Type\ Character quality Character Number\ Serial number	Background table: 34bytes	Two center coordinates	System reserved

#### Note:

- 1. **Flag:** 1 byte. Feature file flag. To distinguish the feature files generated by different sensors or algorithms. 0: the feature file is invalid or deleted. So no feature file can be stored to database when the flag is 0.
- 2. **Type:** 1 byte. Feature file type. 0: the file only contains file header;
  - 1: the file contains file header and reduced minutiae information.
  - 2: the file contains file header and complete minutiae information.
- 3. **Quality:** 1 byte. Quality of feature. Value range is  $0\sim100$  with the larger value indicating the higher feature quality.
- 4. Number: 1 byte. Minutiae number within the range of 5~50. Minimum of 5, maximum of 50.
- 5. **Serial number:** 2 bytes. Searching assistant.
- 6. Background table: 34 bytes. Zipped information of background table
- 7. **Singularity point coordinate:** 4 bytes. Includes (x, y) coordination information of the two centre points.
- **8. System reserved bytes:** 12 bytes.

#### **Feature Unit Structure (4 bytes):**

31	23	22	14	13	5	4	1	0
	X	у		Angl	e	Characte	r point	Attribute
						quality		



# **IV** Communication Protocol

The protocol defines the data exchanging format when R30X series communicates with upper computer. The protocol and instruction sets apples for both UART and USB communication mode. For PC, USB interface is strongly recommended to improve the exchanging speed, especially in fingerprint scanning device.

# Data package format

When communicating, the transferring and receiving of command/data/result are all wrapped in data package format.

#### Data package format

Header	Adder	Package	Package	Package content	Checksum
		identifier	length	(instruction/data/Parameter)	

#### **Definition of Data package**

Name	Symbol	Length		Description		
Header	Start	2 bytes	Fixed value of 0xEF01; High byte transferred first.			
Adder	ADDER	4 bytes	Default value is 0xFFFFFFFF, which can be modified by command. High byte transferred first and at wrong adder value, module will reject to transfer.			
			01H C	Command packet;		
Package identifier	PID	1 byte	Data packet; Data packet shall not appear alone is executing process, must follow command packet of acknowledge packet.			
identifier			07H A	Acknowledge packet;		
			08H I	End of Data packet.		
Package length	LENGTH	2 bytes	Refers to the length of package content (command packets and data packets) plus the length of Checksum( 2 bytes). Unit is byte. Max length is 256 bytes. And high byte is transferred first.			
Package contents	DATA	_	It can be commands, data, command's parameters, acknowledge result, etc. (fingerprint character value, template are all deemed as data);			
Checksum	SUM	2 bytes	The arithmetic sum of package identifier, package length and all package contents. Overflowing bits are omitted. high byte is transferred first.			

# Check and acknowledgement of data package

Note: Commands shall only be sent from upper computer to the Module, and the Module acknowledges the commands.



Upon receipt of commands, Module will report the commands execution status and results to upper computer through acknowledge packet. Acknowledge packet has parameters and may also have following data packet. Upper computer can't ascertain Module's package receiving status or command execution results unless through acknowledge packet sent from Module. Acknowledge packet includes 1 byte confirmation code and maybe also the returned parameter.

Confirmation code's definition is:

00h: commad execution complete;

01h: error when receiving data package;

02h: no finger on the sensor;

03h: fail to enroll the finger;

04h: fail to generate character file due to the over-disorderly fingerprint image;

05h: fail to generate character file due to the over-wet fingerprint image;

06h: ail to generate character file due to the over-disorderly fingerprint image;

07h: fail to generate character file due to lackness of character point or over-smallness of fingerprint image

08h: finger doesn't match;

09h: fail to find the matching finger;

0Ah: fail to combine the character files;

0Bh: addressing PageID is beyond the finger library;

0Ch: error when reading template from library or the template is invalid;

0Dh: error when uploading template;

0Eh: Module can't receive the following data packages.

0Fh: error when uploading image;

10h: fail to delete the template;

11h: fail to clear finger library;

13h: wrong password!

14h: system reset failed

15h: no valid original image in buffer to generate image;

16h: on-line upgrading failed;

18h: error when writing flash;

19h: No definition error;

1Ah: invalid register number;

1Bh: incorrect configuration of register;

1Ch: wrong notepad page number;

1Dh: fail to operate the communication port;

1Eh: Automatic enroll failed;

1Fh: Fingerprint database is full;

others: system reserved;



# V Module Instruction System

R30X series provide 30 instructions. Through combination of different instructions, application program may realize muti finger authentication functions. All commands/data are transferred in package format.

# **Instruction Table**

code	identifier	Description	Code	Identifier	Description
01H	GenImg	Collect finger image	12H	SetPwd	To set password
02H	GenChar	To generate character	13H	VfyPwd	To verify password
		file from image			
03H	Match	Carry out precise	14H	GetRandomCode	to get random code
		matching of two			
		templates;			
04H	Search	Search the finger	15H	SetAdder	To set device address
		library			
05H	RegModel	To combine character	16H	ReadInfPage	To read information
		files and generate			page
		template			
06H	Store	To store template;	17H	Control	Port control
07H	LoadChar	to read/load template	18H	WriteNotepad	to write note pad
08H	UpChar	to upload template	19H	ReadNotepad	To read note pad
09H	DownChr	to download template	1BH	HiSpeedSearch	Search the library fast
0AH	UpImage	To upload image	1CH	GenBinImage	Generate to Minutiae
					Fingerprint Image
0BH	DownImage	To download image	1DH	TempleteNum	To read finger template
					numbers
0CH	DeletChar	to delete templates	1FH	ReadIndexTable	Read-fingerprint
					template index table
0DH	Empty	to empty the library	29H	GetEnrollImage	Get Image in register
0EH	SetSysPara	To set system	35H	ShakeHand	ShakeHand
		Parameter			
0FH	ReadSysPar	To read system	36H	CheckSensor	CheckSensor
	a	Parameter			



# System-related instructions

# Verify passwoard VfyPwd

Description: Verify Module's handshaking password.

Input Parameter: PassWord (4 bytes)

Return Parameter: Confirmation code (1 byte)

Instruction code: 13H

Command (or instruction) package format:

2 bytes	4bytes	1 byte	2 bytes	1 byte	4 byte	2 bytes
Header	Module	Package		Instruction	Password	Checksum
	address	identifier		code		
0xEF01	xxxx	01H	07H	13H	PassWord	sum

#### Acknowledge package format:

2 bytes	4bytes	1 byte	2 bytes	1 byte	2 bytes
Header	Module address	Package	Package	Confirmation	Checksum
		identifier	Length	code	
0xEF01	XXXX	07H	03H	xxH	sum

Note: Confirmation code = 00H: Correct password;

Confirmation code = 01H: error when receiving package;

Confirmation code = 13H: Wrong password;

# Set password SetPwd

Description: Set Module's handshaking password.

Input Parameter: PassWord (4 bytes)

Return Parameter: Confirmation code (1 byte)

Instruction code: 12H

Command (or instruction) package format:

2 bytes	4bytes	1 byte	2 bytes	1 byte	4 byte	2 bytes
Header	Module	Package	Package	Instruction	Password	Checksum
	address	identifier	length	code		
0xEF01	XXXX	01H	07H	12H	PassWord	sum

#### Acknowledge package format:

2 bytes	4 byte	2 bytes	1 byte	2 bytes
Header	Module address	Package length	Confirmation	Checksum
			code	
0xEF01	XXXX	03H	xxH	Sum

Note: Confirmation code=00H: password setting complete;

Confirmation code=01H: error when receiving package;

#### Set Module address SetAdder

Description: Set Module address.

Input Parameter: None;



Return Parameter: Confirmation code (1 byte)

Instruction code: 15H

Command (or instruction) package format:

2 bytes	4bytes	1 byte	2 bytes	1 byte	4 bytes	2 bytes
Header	Original	Package	Package	Instruction	New Module	Checksum
	Module address	identifier	length	code	address	
0xEF01	XXXX	01H	07H	15H	XXXX	sum

Acknowledge package format:

2 bytes	4bytes	1 byte	2 bytes	1 byte	2 bytes
Header	New Module	Package	Package	Confirmation	Checksum
	address	identifier	length	code	
0xEF01	XXXX	07H	07H	xxH	Sum

Note: Confirmation code=00H: address setting complete;

Confirmation code=01H: error when receiving package;

### Set module system's basic parameter SetSysPara

Description: Operation parameter settings.

Input Parameter: Parameter number;

Return Parameter: Confirmation code (1 byte)

Instruction code: 0eH

Command (or instruction) package format:

2 bytes	4bytes	1 byte	2 bytes	1 byte	1byte	1byte	2 bytes
Header	Module	Package	Package	Instruction	Parameter	Contents	Checksum
	address	identifier	length	code	number		
0xEF01	Xxxx	01H	05H	0eH	4/5/6	XX	sum

Acknowledge package format:

2 bytes	4bytes	1 byte	2 bytes	1 byte	2 bytes
Header	Module	Package	Package	Confirmation	Checksum
	address	identifier	length	code	
0xEF01	Xxxx	07H	03H	xxH	Sum

Note: Confirmation code=00H: parameter setting complete;

Confirmation code=01H: error when receiving package;

Confirmation code=1aH: wrong register number;

#### **Port Control** Control

Description:

For UART protocol, it control the "on/off" of USB port;

For USB protocol, it control the "on/off" of UART port;

Input Parameter: control code

Control code "0" means turns off the port;

Control code "1" means turns on the port;

Return Parameter: confirmation code;

Instruction code: 17H

Command (or instruction) package format:



2 bytes	4bytes	1 byte	2 bytes	1 byte	1byte	2 bytes
Header	Chip	Package	Package	Instruction	Control	Checksum
	address	identifier	length	code	code	
0xEF01	XXXX	01H	04H	17H	0/1	sum

Acknowledge package format:

2 bytes	4bytes	1 byte	2 bytes	1 byte	2 bytes
Header	Chip	Package	Package	Confirmation	Checksum
	address	identifier	length	code	
0xEF01	xxxx	07H	03H	xxH	sum

Note: Confirmation code=00H: Port operation complete;

Confirmation code=01H: error when receiving package;

Confirmation code=1dH: fail to operate the communication port;

# Read system Parameter ReadSysPara

Description: Read Module's status register and system basic configuration parameters;

Input Parameter: none

Return Parameter: Confirmation code (1 byte) + basic parameter (16bytes)

Instruction code: 0fH

Command (or instruction) package format:

2 bytes	4bytes	1 byte	2 bytes	1 byte	2 bytes
Header	Module	Package	Package length	Instruction	Checksum
	address	identifier		code	
0xEF01	Xxxx	01H	03H	0fH	sum

#### Acknowledge package format:

2 bytes	4bytes	1 byte	2 bytes	1 byte	16 bytes	2 bytes
Header	Module	Package	Package	Confirmation	Basic parameter	Checksum
	address	identifier	length	code	list	
0xEF01	xxxx	07H	3+16	xxH	See following	sum
					table	

Note: Confirmation code=00H: read complete;

Confirmation code=01H: error when receiving package;

Name	Description	Offset (word)	Size (word)
Status register	Contents of system status register	0	1
System identifier code	Fixed value: 0x0009	1	1
Finger library size	Finger library size	2	1
Security level	Security level (1, 2, 3, 4, 5)	3	1
Device address	32-bit device address	4	2
Data packet size Size code (0, 1, 2, 3)		6	1
Baud settings	N (baud = 9600*N bps)	7	1

# Read valid template number TempleteNum

Description: read the current valid template number of the Module

Input Parameter: none



Return Parameter: Confirmation code (1 byte), template number:N

Instruction code: 1dH

Command (or instruction) package format:

2 bytes	4bytes	1 byte	2 bytes	1 byte	2 bytes
Header	Module address	Package	Package	Instruction	Checksum
		identifier	length	code	
0xEF01	XXXX	01H	0003H	1dH	0021H

#### Acknowledge package format:

2 bytes	4bytes	1 byte	2 bytes	1 byte	2 bytes	2 bytes
Header	Module	Package	Package	Confirmation	Template	Checksum
	address	identifier	length	code	number	
0xEF01	XXXX	07H	5	xxH	N	sum

Note: Confirmation code=00H: read complete;

Confirmation code=01H: error when receiving package;

# Fingerprint-processing instructions

#### To collect finger image GenImg

Description: detecting finger and store the detected finger image in ImageBuffer while returning successfully confirmation code; If there is no finger, returned confirmation code would be "can't detect finger".

Input Parameter: none

Return Parameter: Confirmation code (1 byte)

Instruction code: 01H

Command (or instruction) package format:

2 bytes	4bytes	1 byte	2 bytes	1 byte	2 bytes
Header	Module	Package	Package length	Instruction	Checksum
	address	identifier		code	
0xEF01	Xxxx	01H	03H	01H	05H

#### Acknowledge package format:

2 bytes	4bytes	1 byte	2 bytes	1 byte	2 bytes
Header	Module	Package	Package	Confirmation	Checksum
	address	identifier	length	code	
0xEF01	Xxxx	07H	03H	xxH	Sum

Note: Confirmation code=00H: finger collection success;

Confirmation code=01H: error when receiving package;

Confirmation code=02H: can't detect finger; Confirmation code=03H: fail to collect finger;

# To upload image UpImage

Description: to upload the image in Img\_Buffer to upper computer.

Input Parameter: none



Return Parameter: Confirmation code (1 byte)

Instruction code: 0aH

Command (or instruction) package format:

2 bytes	4bytes	1 byte	2 bytes	1 byte	2 bytes
Header	Module address	Package identifier	Package length	Instruction code	Checksum
0xEF01	Xxxx	01H	03H	0aH	000eH

#### Acknowledge package format:

2 bytes	4bytes	1 byte	2 bytes	1 byte	2 bytes
Header	Module	Package	Package	Confirmation	Checksum
	address	identifier	length	code	
0xEF01	Xxxx	07H	03H	xxH	sum

Note 1: Confirmation code=00H: ready to transfer the following data packet;

Confirmation code=01H: error when receiving package;

Confirmation code=0fH: fail to transfer the following data packet;

2: Module shall transfer the following data packet after responding to the upper computer.

### To download the image DownImage

Description: to download image from upper computer to Img Buffer.

Input Parameter: none

Return Parameter: Confirmation code (1 byte)

Instruction code: 0bH

Command (or instruction) package format:

2 bytes	4bytes	1 byte	2 bytes	1 byte	2 bytes
Header	Module address	Package	Package	Instruction	Checksum
		identifier	length	code	
0xEF01	Xxxx	01H	03H	0bН	000fH

#### Acknowledge package format:

2 bytes	4bytes	1 byte	2 bytes	1 byte	2 bytes
Header	Module	Package	Package	Confirmation	Checksum
	address	identifier	length	code	
0xEF01	Xxxx	07H	03H	xxH	sum

Note: 1: Confirmation code=00H: ready to transfer the following data packet;

Confirmation code=01H: error when receiving package;

Confirmation code=0eH: fail to transfer the following data packet;

2: Module shall transfer the following data packet after responding to the upper computer. Data package length must be 64, 128, or 256.

# To generate character file from image Genchar

Description: to generate character file from the original finger image in ImageBuffer and store the file in CharBuffer1 or CharBuffer2.

Input Parameter: BufferID (character file buffer number)

Return Parameter: Confirmation code (1 byte)



Instruction code: 02H

Command (or instruction) package format:

2 bytes	4bytes	1 byte	2 bytes	1 byte	1 byte	2 bytes
Header	Module	Package	Package	Instruction	Buffer	Checksum
	address	identifier	length	code	number	
0xEF01	xxxx	01H	04H	02H	BufferID	sum

Note: BufferID of CharBuffer1 and CharBuffer2 are 1h and 2h respectively. Other values (except 1h, 2h) would be processed as CharBuffer2.

Acknowledge package format:

2 bytes	4bytes	1 byte	2 bytes	1 byte	2 bytes
Header	Module	Package	Package length	Confirmation	Checksum
	address	identifier		code	
0xEF01	xxxx	07H	03H	XxH	sum

Note: Confirmation code=00H: generate character file complete;

Confirmation code=01H: error when receiving package;

Confirmation code=06H: fail to generate character file due to the over-disorderly

fingerprint image;

Confirmation code=07H: fail to generate character file due to lackness of character

point or over-smallness of fingerprint image;

Confirmation code=15H: fail to generate the image for the lackness of valid primary

image;

### To generate template RegModel

Description: To combine information of character files from CharBuffer1 and CharBuffer2 and generate a template which is stored back in both CharBuffer1 and CharBuffer2.

Input Parameter: none

Return Parameter: Confirmation code (1 byte)

Instruction code: 05H

Command (or instruction) package format:

		, i			
2 bytes	4bytes	1 byte	2 bytes	1 byte	2 bytes
Header	Module	Package	Package	Instruction	Checksum
	address	identifier	length	code	
0xEF01	xxxx	01H	03H	05H	09H

#### Acknowledge package format:

2 bytes	4bytes	1 byte	2 bytes	1 byte	2 bytes
Header	Module	Package	Package	Confirmation	Checksum
	address	identifier	length	code	
0xEF01	xxxx	07H	03H	xxH	sum

Note: Confirmation code=00H: operation success;

Confirmation code=01H: error when receiving package;

Confirmation code=0aH: fail to combine the character files. That's, the character files don't belong to one finger.



### To upload character or template UpChar

Description: to upload the character file or template of CharBuffer1/CharBuffer2 to upper

computer;

Input Parameter: BufferID (Buffer number)
Return Parameter: Confirmation code (1 byte)

Instruction code: 08H

Command (or instruction) package format:

2 bytes	4bytes	1 byte	2 bytes	1 byte	1 byte	2 bytes
Header	Module	Package	Package	Instruction	Buffer	Checksum
	address	identifier	length	code	number	
0xEF01	XXXX	01H	04H	08H	BufferID	sum

Note: BufferID of CharBuffer1 and CharBuffer2 are 1h and 2h respectively. Other values (except 1h, 2h) would be processed as CharBuffer2.

#### Acknowledge package format:

2 bytes	4bytes	1 byte	2 bytes	1 byte	2 bytes
Header	Module	Package	Package	Confirmation	Checksum
	address	identifier	length	code	
0xEF01	XXXX	07H	03H	xxH	sum

Note 1: Confirmation code=00H: ready to transfer the following data packet;

Confirmation code=01H: error when receiving package;

Confirmation code=0dH: error when uploading template;

2: Module shall transfer following data packet after responding to the upper computer.;

3: The instruction doesn't affect buffer contents.

# To download character file or template DownChar

Description: to download character file or template from upper computer to the specified buffer of

Module;

Input Parameter: BufferID (buffer number)
Return Parameter: Confirmation code (1 byte)

Instruction code: 09H

Command (or instruction) package format:

2 bytes	4bytes	1 byte	2 bytes	1 byte	1 byte	2 bytes
Header	Module	Package Package		Instruction	buffer	Checksum
	address	identifier	length	code	number	
0xEF01	XXXX	01H	04H	09H	BufferID	sum

Note: BufferID of CharBuffer1 and CharBuffer2 are 1h and 2h respectively. Other values (except 1h, 2h) would be processed as CharBuffer2.

2 bytes	4bytes	1 byte	2 bytes	1 byte	2 bytes				
Header	Module Package		Package	Confirmation	Checksum				
	address	identifier	length	code					
0xEF01	XXXX	07H	03H	xxH	sum				

Note 1: Confirmation code=00H: ready to transfer the following data packet;



Confirmation code=01H: error when receiving package;

Confirmation code=0eH: fail to receive the following data packages.

2: Module shall transfer the following data packet after responding to the upper computer.

#### To store template Store

Description: to store the template of specified buffer (Buffer1/Buffer2) at the designated location of

Flash library.

Input Parameter: BufferID(buffer number), PageID (Flash location of the template, two bytes with

high byte front and low byte behind)

Return Parameter: Confirmation code (1 byte)

Instruction code: 06H

Command (or instruction) package format:

2 bytes	4bytes	1 byte	2 bytes	1 byte	1 byte	2 bytes	2 bytes
Header	Module	Package	Package	Instruction	buffer	Location	Checksum
	address	identifier	length	code	number	number	
0xEF01	XXXX	01H	06H	06H	BufferID	PageID	sum

Note: BufferID of CharBuffer1 and CharBuffer2 are 1h and 2h respectively. Other values (except 1h, 2h) would be processed as CharBuffer2.

#### Acknowledge package format:

2 bytes	4bytes	1 byte	2 bytes	1 byte	2 bytes
Header	Module	Package	Package	Confirmation	Checksum
	address	identifier	length	code	
0xEF01	Xxxx	07H	03H	xxH	sum

Note: Confirmation code=00H: storage success;

Confirmation code=01H: error when receiving package;

Confirmation code=0bH: addressing PageID is beyond the finger library;

Confirmation code=18H: error when writing Flash.

# To read template from Flash library LoadChar

Description: to load template at the specified location (PageID) of Flash library to template buffer

CharBuffer1/CharBuffer2

Input Parameter: BufferID(buffer number), PageID (Flash location of the template, two bytes with

high byte front and low byte behind).

Return Parameter: Confirmation code (1 byte)

Instruction code: 07H

Command (or instruction) package format:

2 bytes	4bytes	1 byte	2 bytes	1 byte	1 byte	2 bytes	2 bytes
Header	Module	Package	Package	Instruction	buffer	Page	Checksum
	address	identifier	length	code	number	number	
0xEF01	xxxx	01H	06H	07H	BufferID	PageID	sum

Note: BufferID of CharBuffer1 and CharBuffer2 are 1h and 2h respectively. Other values (except 1h, 2h) would be processed as CharBuffer2.



2 bytes	4bytes	1 byte	2 bytes	1 byte	2 bytes
Header	Module address	Package	Package	Confirmation	Checksum
		identifier	length	code	
0xEF01	xxxx	07H	03H	XxH	sum

Note: Confirmation code=00H: load success;

Confirmation code=01H: error when receiving package;

Confirmation code=0cH: error when reading template from library or the readout template is

invalid;

Confirmation code=0BH: addressing PageID is beyond the finger library;

# To delete template DeletChar

Description: to delete a segment (N) of templates of Flash library started from the specified

location (or PageID);

Input Parameter: PageID (template number in Flash), N (number of templates to be deleted)

Return Parameter: Confirmation code (1 byte)

Instruction code: 0cH

Command (or instruction) package format:

2 bytes	4bytes	1 byte	2 bytes	1 byte	2 bytes	2bytes	2 bytes
Header	Module	Package	Package	Instruction	Page	number of	Checksum
	address	identifier	length	code	number	templates to	
						be deleted	
0xEF01	Xxxx	01H	07H	0сН	PageID	N	sum

#### Acknowledge package format:

2 bytes	4bytes	1 byte	2 bytes	1 byte	2 bytes
Header	Module	Package identifier	Package	Confirmation	Checksum
	address		length	code	
0xEF01	Xxxx	07H	03H	xxH	sum

Note: Confirmation code=00H: delete success;

Confirmation code=01H: error when receiving package; Confirmation code=10H: failed to delete templates;

# To empty finger library Empty

Description: to delete all the templates in the Flash library

Input Parameter: none

Return Parameter: Confirmation code (1 byte)

Instruction code: 0dH

Command (or instruction) package format:

2 bytes	4bytes	1 byte	2 bytes	1 byte	2 bytes
Header	Module	Package	Package	Instruction	Checksum
	address	identifier	length	code	
0xEF01	Xxxx	01H	03H	0dH	0011H

2 bytes	4bytes	1 byte	2 bytes	1 byte	2 bytes
Header	Module	Package	Package	Confirmation	Checksum



	address	identifier	length	code	
0xEF01	Xxxx	07H	03H	xxH	sum

Note: Confirmation code=00H: empty success;

Confirmation code=01H: error when receiving package; Confirmation code=11H: fail to clear finger library;

### To carry out precise matching of two finger templates Match

Description: to carry out precise matching of templates from CharBuffer1 and CharBuffer2,

providing matching results.

Input Parameter: none

Return Parameter: Confirmation code (1 byte), matching score.

Instruction code: 03H

Command (or instruction) package format:

		1 0			
2 bytes	4bytes	1 byte	2 bytes	1 byte	2 bytes
Header	Module	Package	Package length	Instruction code	Checksum
	address	identifier			
0xEF01	Xxxx	01H	03H	03H	07H

#### Acknowledge package format:

2 bytes	4bytes	1 byte	2 bytes	1 byte	2 bytes	2 bytes
Header	Module	Package	Package	Confirmation	Matching	Checksum
	address	identifier	length	code	score	
0xEF01	Xxxx	07H	05H	XxH	XxH	sum

Note 1: Confirmation code=00H: templates of the two buffers are matching!

Confirmation code=01H: error when receiving package;

Confirmation code=08H: templates of the two buffers aren't matching;

2: The instruction doesn't affect the contents of the buffers.

# To search finger library Search

Description: to search the whole finger library for the template that matches the one in CharBuffer1 or CharBuffer2. When found, PageID will be returned.

Input Parameter: BufferID, StartPage (searching start address), PageNum (searching numbers)

Return Parameter: Confirmation code (1 byte), PageID (matching templates location)

Instruction code: 04H

Command (or instruction) package format:

2 bytes	4bytes	1 byte	2 bytes	1 byte	1 byte	2 bytes	2 bytes	2 bytes
Header	Module	Package	Package	Instructio	buffer	Parameter	Parameter	Checks
	address	identifie	length	n code	number			um
		r	C					
0xEF01	xxxx	01H	08H	04H	BufferID	StartPage	PageNum	sum

Note: BufferID of CharBuffer1 and CharBuffer2 are 1h and 2h respectively. Other values (except 1h, 2h) would be processed as CharBuffer2.

		2 bytes	4bytes	1 byte	2 bytes	1 byte	2 bytes	2 bytes	2 bytes
--	--	---------	--------	--------	---------	--------	---------	---------	---------



Header	Module	Package	Package	Confirmation	页码	得分	Checksum
	address	identifier	length	code			
0xEF01	XXXX	07H	7	xxH	PageID	MatchScore	sum

Note 1: Confirmation code=00H: found the matching finer;

Confirmation code=01H: error when receiving package;

Confirmation code=09H: No matching in the library (both the PageID and

matching score are 0);

2: The instruction doesn't affect the contents of the buffers.

#### Other instructions

## To generate a random code GetRandomCode

Description: to command the Module to generate a random number and return it to upper computer;

Input Parameter: none

Return Parameter: Confirmation code (1 byte)

Instruction code: 14H

Command (or instruction) package format:

2 bytes	4bytes	1 byte	2 bytes	1 byte	2 bytes
Header	Module	Package	Package length	Instruction	Checksum
	address	identifier		code	
0xEF01	XXXX	01H	03H	14H	0018H

#### Acknowledge package format:

2 bytes	4bytes	1 byte	2 bytes	1 byte	4 bytes	2 bytes
Header	Module	Package	Package	Confirmation	Random	Checksum
	address	identifier	length	code	number	
0xEF01	xxxx	07H	07H	xxH	XXXX	sum

Note: Confirmation code=00H: generation success;

Confirmation code=01H: error when receiving package;

### To write note pad WriteNotepad

Description: for upper computer to write data to the specified Flash page . Also see ReadNotepad;

Input Parameter: NotePageNum, user content (or data content)

Return Parameter: Confirmation code (1 byte)

Instruction code: 18H

Command (or instruction) package format:

2 bytes	4bytes	1 byte	2 bytes	1 byte	1byte	32 bytes	2 bytes
Header	Module	Package	Package	Instruction	Page	Data	Checksum
	address	identifier	length	code	number	content	
0xEF01	XXXX	01H	36	18H	0~15	content	sum

	0 1 0				
2 bytes	4bytes	1 byte	2 bytes	1 byte	2 bytes



Header	Module address	Package	Package	Confirmation code	Checksum
		identifier	length		
0xEF01	XXXX	07H	03H	xxH	sum

Note: Confirmation code=00H: write success;

Confirmation code=01H: error when receiving package;

### To read note pad ReadNotepad

Description: to read the specified page's data content; Also see WriteNotepad.

Input Parameter: none

Return Parameter: Confirmation code (1 byte) + data content

Instruction code: 19H

Command (or instruction) package format:

2 bytes	4bytes	1 byte	2 bytes	1 byte	1byte	2 bytes
Header	Module	Package	Package	Instruction	Page	Checksum
	address	identifier	length	code	number	
0xEF01	XXXX	01H	04H	19H	0~15	xxH

#### Acknowledge package format:

2 bytes	4bytes	1 byte	2 bytes	1 byte	32bytes	2 bytes
Header	Module	Package	Package	Confirmation	User content	Checksum
	address	identifier	length	code		
0xEF01	XXXX	07H	3+32	xxH	User content	sum

Note: Confirmation code=00H: read success;

Confirmation code=01H: error when receiving package;

# Read fingerprint template index table ReadIndexTable

Description: Read the fingerprint template index table of the module, read the index table of the

fingerprint template up to 256 at a time (32 bytes)

Input Parameter: Index page

Return Parameter: Confirmation code+Fingerprint template index table

Instruction code: 1fH

Command (or instruction) package format:

2 bytes	4bytes	1 byte	2 bytes	1 byte	1 byte	2 bytes
Header	Module	Package	Package	Instruction	Index page	Checksum
	address	identifier	length	code		
0xEF01	xxxx	01H	04H	1fH	xxH	Sum

Index tables are read per page, 256 templates per page

Index page 0 means to read  $0 \sim 256$  fingerprint template index table

Index page 1 means to read 256 ~ 512 fingerprint template index table

Index page 2 means to read 512 ~ 768 fingerprint template index table

Index page 3 means to read  $768 \sim 1024$  fingerprint template index table

2 bytes	4bytes	1 byte	2 bytes	1 byte	32 bytes	2 bytes
Header	Module	Package	Package	Confirmation	Index page	Check-



	address	identifier	length	code		sum
0xEF01	xxxx	07H	23H	xxH	Index	sum

Note: Confirmation code=00H: OK, read complete;

Confirmation code=01H: error when receiving package;

Confirmation code=0bH: Indicates that the serial number of the address exceeds the

range of the fingerprint database.

# Get Image in register GetEnrollImage

Description: when in register fingerprint, detect finger, and the fingerprint image is recorded and

stored in the image buffer; Input Parameter: none

Return Parameter: Confirmation code

Instruction code: 29H

Command (or instruction) package format:

2 bytes	4bytes	1 byte	2 bytes	1 byte	2 bytes
Header	Module	Package	Package length	Instruction	Checksum
	address	identifier		code	
0xEF01	xxxx	01H	03H	29H	002DH

#### Acknowledge package format:

2 bytes	4bytes 1 byte 2 bytes		1 byte	2 bytes	
Header	Module	Package	Package	Confirmation	Checksum
	address	identifier	length	code	
0xEF01	XXXX	07H	03H	xxH	sum

Note: Confirmation code=00H: success;

Confirmation code=01H: error when receiving package;

Confirmation code=03H: fail when input image;

# To read information page ReadINFpage

Description: Reading the information page in FLASH (512bytes)

Input Parameter: none

Return Parameter: Confirmation code

Instruction code: 16H

Command (or instruction) package format:

2 bytes	4bytes	1 byte	2 bytes	1 byte	2 bytes
Header	Module	Package	Package length	Instruction	Checksum
	address	identifier		code	
0xEF01	XXXX	01H	03H	16H	001aH

2 bytes	4bytes	1 byte	2 bytes	1 byte	2 bytes
Header	Module	Package	Package	Confirmation	Checksum
	address	identifier	length	code	



	L				
0xEF01	xxxx	07H	03H	xxH	sum

Note: Confirmation code=00H: transmitting data packet later;

Confirmation code=01H: error when receiving package;

Confirmation code=0dH: instruction running failed;

Receiving subsequent packets after the reply:

2 bytes	4bytes	1 byte	2 bytes	1 byte	2 bytes
Header	Module	Package	Package	Data	Checksum
	address	identifier	length		
0xEF01	xxxx	xxH	xxH	xxH	sum

Note: Package identifier=02, Packets, and subsequent packets.

Package identifier=08, The last packet, the end packet.

# High Speed Search High Speed Search

Description: High-speed searching the whole or part of fingerprint database with the feature files in CharBuffer1 or CharBuffer2.If get, jump to the original page. The instruction will soon work out

the searching result if the fingerprint really be in the database and with good quality.

Input Parameter: BufferID, StartPage, PageNum Return Parameter: Confirmation code, Page number

Instruction code: 1bH

Command (or instruction) package format:

2 bytes	4bytes	1 byte	2 bytes	1 byte	1 byte	2 bytes	2 bytes	2 bytes
Header	Module	Package	Package	Instruction	Buffer	Parameter	Parameter	Checksum
	address	identifier	length	code	number			
0xEF01	xxxx	01H	08H	1bH	Buffer	Start	Page	sum
					ID	Page	Num	

Comment: The BufferID in CharBuffer1 and CharBuffer2 are 1h and 2h.

Acknowledge package format:

2 bytes	4bytes	1 byte	2 bytes	1 byte	2 bytes	2 bytes	2 bytes
Header	Module	Package	Package	Confirmat	Page	Score	Checksum
	address	identifier	length	ion code	Number		
0xEF01	XXXX	07H	7	xxH	PageID	MatchScore	sum

Note: Confirmation code=00H: searching success;

Confirmation code=01H: error when receiving package;

Confirmation code=09H: searching failed, here the page number and score are "0";

# Generate to Minutiae Fingerprint Image GenBinImage

Description: Processing the fingerprint image in image buffer and generate it to minutiae

fingerprint image

Input Parameter: BinImgTpye

0: Binary images

1: Minutiae images without minutiae flag



2 or others: Minutiae images with minutiae flag

Return Parameter: Confirmation code

Instruction code: 1cH

Command (or instruction) package format:

2 bytes	4bytes	1 byte	2 bytes	1 byte	1 byte	2 bytes
Header	Module	Package	Package	Confirmation	Target	Checksum
	address	identifier	length	code	type	
0xEF01	XXXX	01H	04H	1cH	0/1/2	sum

#### Acknowledge package format:

2 bytes	4bytes	1 byte	2 bytes	1 byte	2 bytes
Header	Module	Package	Package	Confirmation	Checksum
	address	identifier	length	code	
0xEF01	XXXX	07H	03H	xxH	sum

Note: Confirmation code=01H: error when receiving package;

Confirmation code=15H: invalid fingerprint images;

Confirmation code=07H: without enough feature information;

Confirmation code=06H: images with too low quality;

#### Handshake instruction HandShake

Description: Check whether the module works normally.

Input Parameter: none

Return Parameter: Confirmation code

Instruction code: 35H

Command (or instruction) package format:

2 bytes	4bytes	1 byte	2 bytes	1 byte	2 bytes
Header	Module	Package	Package	Confirmation	Checksum
	address	identifier	length	code	
0xEF01	XXXX	01H	03H	35H	0039Н

#### Acknowledge package format:

2 bytes	4bytes	1 byte	2 bytes	1 byte	2 bytes
Header	Module	Package	Package	Confirmation	Checksum
	address	identifier	length	code	
0xEF01	XXXX	07H	03H	xxH	sum

Note: Confirmation code=00H: OK;

Confirmation code=01H: error when receiving package;

#### Check Sensor CheckSensor

Description: Check whether the sensor works normally.

Input Parameter: none

Return Parameter: Confirmation code

Instruction code: 36H

Command (or instruction) package format:

2 bytes 4bytes	1 byte	2 bytes	1 byte	2 bytes
----------------	--------	---------	--------	---------



Header	Module	Package	Package	Confirmation	Checksum
	address	identifier	length	code	
0xEF01	XXXX	01H	03H	36H	003AH

#### Acknowledge package format:

2 bytes	4bytes	1 byte	2 bytes	1 byte	2 bytes
Header	Module	Package	Package	Confirmation	Checksum
	address	identifier	length	code	
0xEF01	XXXX	07H	03H	xxH	sum


Note: Confirmation code=00H: OK;

Confirmation code=01H: error when receiving package; Confirmation code=29H: error when check sensor;




# **VI** Operation Process

Pressing fingerprint twice to record a template and store in flash fingerprint database;






Reading an image from sensor and searching the database field from 10—100





Capturing a fingerprint image from sensor and generating the feature file, then upload to the host;





# **VII** Reference Circuit

