

NAME

iapws - Compute light and heavy water properties.

SYNOPSIS

iapws *SUBCOMMAND* [*OPTION...*]

DESCRIPTION

iapws is a command line interface for computing properties of light and heavy water according to IAPWS.

SUBCOMMANDS

Valid subcommands are:

- +kh** Compute the Henry's constant for gases in H₂O or D₂O. The default behavior is to compute the constant kH for O₂ at 25°C. See options.
- +kd** Compute the vapor-liquid distribution constant for gases in H₂O or D₂. The default behavior is to compute the constant kD for H₂ at 25°C. See options.
- +psat** Compute the saturation pressure. The default behavior is to compute psat at 25°C. See options.
- +Tsat** Compute the saturation temperature. The default behavior is to compute Tsat at 1 bar. See options.

Their syntax is:

- +kh** [*OPTION...*]
- +kd** [*OPTION...*]
- +psat** [*OPTION...*]
- +Tsat** [*OPTION...*]

OPTIONS

kh:

- temperature, -T TEMPERATURE...**
Temperature in °C. Default to 25°C.
- fugacity, -f FUGACITY...**
Liquid-phase fugacity in MPa. Default to 1 b
- gases, -g GAS...**
Gases for which to compute kH. Default to O₂
- D2O** Set heavywater as the solvent.
- listgases**
Display available gases for computing kH.

kd:

- temperature, -T TEMPERATURE...**
Temperature in °C. Default to 25°C.
- x2, -x x2...**
Molar fraction of gas in water. Default to 1
- gases, -g GAS...**
Gases for which to compute kD. Default to H₂
- D2O,** Set heavywater as the solvent.
- listgases**
Display available gases for computing kD.

psat:

--temperature, -T TEMPERATURE...
Temperature in °C. Default to 25°C.

Tsat:

--pressure, -p PRESSURE...
Pressure in bar. Default to 1 bar.

all:

--usage, -u
Show usage text and exit.

--help, -h
Show help text and exit.

--verbose, -V
Display additional information when available.

--version, -v
Show version information and exit.

NOTES

You may replace the default options from a file if your first options begin with @file. Initial options will then be read from the "response file" "file.rsp" in the current directory.

If "file" does not exist or cannot be read, then an error occurs and the program stops. Each line of the file is prefixed with "options" and interpreted as a separate argument. The file itself may not contain @file arguments. That is, it is not processed recursively.

For more information on response files see https://urbanjost.github.io/M_CLI2/set_args.3m_cli2.html

EXAMPLE

Minimal example

```
    iapws kh -T 25,100 -f 1,0.2 -g O2,H2  
    iapws kd -T 25,100 -x2 1d-9,1d-6 -g O2,H2
```

SEE ALSO

ciaaw(3), codata(3)