

Nios II Custom Instruction

User Guide



101 Innovation Drive San Jose, CA 95134 www.altera.com

UG-N2CSTNST-2.0



Contents



Chapter 1. Nios II Custom Instruction Overview	
Custom Instruction Overview	1–2
Implementing Custom Instruction Hardware	1–2
Implementing Custom Instruction Software	
Custom Instruction Types	
Combinational Custom Instructions	1–4
Multicycle Custom Instructions	
Extended Custom Instructions	
Internal Register File Custom Instructions	
External Interface Custom Instructions	
Chapter 2. Software Interface	
Custom Instruction Examples	2–1
Built-in Functions and User-defined Macros	
Custom Instruction Assembly Software Interface	2–3
Chapter 3. Implementing a Nios II Custom Instruction in SOPC Builder	
Design Example: Cyclic Redundancy Check	3–1
Implementing Custom Instruction Hardware in SOPC Builder	3–1
Setting up the Design Environment for the Design Example	3–2
Opening the Component Editor	
Adding the HDL Files	
Configuring the Custom Instruction Signal Type	
Setting Up the Custom Instruction Interfaces	
Setting the Details	
Saving and Adding the Custom Instruction	
Generating the System and Compiling in the Quartus II Software	
Accessing the Custom Instruction from Software	
Using the User-defined Custom Instruction Macro	
Chapter 4. Implementing a Nios II Custom Instruction in Qsys	
Design Example: Cyclic Redundancy Check	4_1
Implementing Custom Instruction Hardware in Qsys	
Setting up the Design Environment for the Design Example	
Opening the Component Editor	
Adding the HDL Files	
Configuring the Custom Instruction Signal Type	
Setting Up the Custom Instruction Interfaces	4_3
Setting the Details	
Saving and Adding the Custom Instruction	1_5
Generating the System and Compiling in the Quartus II Software	<u>4</u> –5
Accessing the Custom Instruction from Software	
Using the User-defined Custom Instruction Macro	
Oshig the Oser-defined Custom histraction Macro	4-0
Appendix A. Custom Instruction Templates	
VHDL Custom Instruction Template	
Verilog HDL Custom Instruction Template Example	A_3

iv Contents

Appendix B. Custom Instruction Built-in Functions	
Built-in Functions that Return a Void Value	B–1
Built-in Functions that Return a Value of Type Int	B–1
Built-in Functions that Return a Value of Type Float	
Built-in Functions that Return a Pointer Value	B-2
Appendix C. Floating Point Custom Instructions	
Appendix C. Floating Point Custom Instructions Additional Information	
Additional Information Document Revision History	Info-1
Additional Information	Info-1



1. Nios II Custom Instruction Overview

When you design a system that includes an Altera Nios II embedded processor, you can accelerate time-critical software algorithms by adding custom instructions to the Nios II processor instruction set. Custom instructions allow you to reduce a complex sequence of standard instructions to a single instruction implemented in hardware. You can use this feature for a variety of applications, for example, to optimize software inner loops for digital signal processing (DSP), packet header processing, and computation-intensive applications. In SOPC Builder, the Nios II parameter editor provides a GUI to add custom instructions to the Nios II processor. In Qsys, each custom instruction is a separate component in the Qsys system. You can add as many as 256 custom instructions to your system.

In SOPC Builder, the custom instruction logic connects directly to the Nios II arithmetic logic unit (ALU) as shown in Figure 1–1.




Figure 1-1. Custom Instruction Logic Connects to the Nios II ALU in SOPC Builder Systems

This chapter contains the following sections:

- "Custom Instruction Overview"
- "Custom Instruction Types" on page 1–3

For information about the custom instruction software interface, refer to Chapter 2, Software Interface. For step-by-step instructions for implementing a custom instruction, refer to Chapter 3, Implementing a Nios II Custom Instruction in SOPC Builder or Chapter 4, Implementing a Nios II Custom Instruction in Qsys.

Custom Instruction Overview

Nios II custom instructions are custom logic blocks adjacent to the ALU in the processor's datapath. Custom instructions give you the ability to tailor the Nios II processor core to meet the needs of a particular application. You can accelerate time critical software algorithms by converting them to custom hardware logic blocks. Because it is easy to alter the design of the FPGA-based Nios II processor, custom instructions provide an easy way to experiment with hardware-software tradeoffs at any point in the design process.

Implementing Custom Instruction Hardware

Figure 1–2 is a hardware block diagram of a Nios II custom instruction.

Conduit interface to external memory, FIFO, or other logic dataa[31..0] Combinational result[31..0] datab[31..0] clk clk en Multi-cycle done reset start n[7..0] Extended a[4..0] readra Internal b[4..0] Register File readrb c[4..0] writerc

Figure 1–2. Hardware Block Diagram of a Nios II Custom Instruction

A Nios II custom instruction logic receives input on its dataa port, or on its dataa and datab ports, and drives out the result on its result port. The custom instruction logic provides a result based on the inputs provided by the Nios II processor.

The Nios II processor supports different types of custom instructions. Figure 1–2 lists the additional ports that accommodate different custom instruction types. Only the ports used for the specific custom instruction implementation are required.

Figure 1–2 also shows a conduit interface to external logic. The interface to external logic allows you to include a custom interface to system resources outside of the Nios II processor datapath.

Implementing Custom Instruction Software

The Nios II custom instruction software interface is simple and abstracts the details of the custom instruction from the software developer. For each custom instruction, the Nios II Embedded Design Suite (EDS) generates a macro in the system header file, **system.h**. You can use the macro directly in your C or C++ application code, and you do not need to program assembly code to access custom instructions. Software can also invoke custom instructions in Nios II processor assembly language.

For more information about the custom instruction software interface, refer to Chapter 2, Software Interface.

Custom Instruction Types

Different types of custom instructions are available to meet the requirements of your application. The type you choose determines the hardware interface for your custom instruction.

Table 1–1 shows the available custom instruction types, applications, and associated hardware ports.

Table 1-1. Custom Instruction Types, Applications, and Hardware Ports (Part 1 of 2)

Туре	Application	Hardware Ports
		■ dataa[31:0]
Combinational	Single clock cycle custom logic blocks.	■ datab[31:0]
		■ result[31:0]
		■ dataa[31:0]
		■ datab[31:0]
		■ result[31:0]
Multicycle	Multi-clock cycle custom logic blocks of fixed or	■ clk
WithtiticyCle	variable durations.	clk_en (1)
		■ start
		■ reset
		■ done
		■ dataa[31:0]
		■ datab[31:0]
		■ result[31:0]
	Custom logic blocks that are capable of performing multiple operations	■ clk
Extended		clk_en (1)
		■ start
		■ reset
		■ done
		■ n[7:0]

Туре	Application	Hardware Ports
		■ dataa[31:0]
		■ datab[31:0]
		• result[31:0]
		■ clk
		■ clk_en
		■ start
	Custom logic blocks that access internal register files for input or output or both.	■ reset
Internal register file		■ done
		n[7:0]
		a [4:0]
		■ readra
		■ b[4:0]
		■ readrb
		■ c[4:0]
		■ writerc
External interface	Custom logic blocks that interface to logic outside of the Nios II processor's datapath	Standard custom instruction ports, plus user-defined interface to external logic.

Table 1-1. Custom Instruction Types, Applications, and Hardware Ports (Part 2 of 2)

Note to Table 1-1:

(1) The clk_en input signal must be connected to the clk_en signals of all the registers in the custom instruction, in case the Nios II processor needs to stall the custom instruction during execution.

The following sections discuss the basic functionality and hardware interface of each of the custom instruction types listed in Table 1–1.

Combinational Custom Instructions

A combinational custom instruction is a logic block that completes its logic function in a single clock cycle. Figure 1–3 shows a block diagram of a combinational custom instruction.

Figure 1–3. Combinational Custom Instruction Block Diagram



In Figure 1–3 the dataa and datab ports are inputs to the logic block, which drives the results on the result port. Because the logic function completes in a single clock cycle, a combinational custom instruction does not require control ports.

Table 1–2 describes the combination custom instruction ports.

Table 1-2. Combinational Custom Instruction Ports


Port Name	Direction	Required	Description
dataa[31:0]	Input	No	Input operand to custom instruction
datab[31:0]	Input	No	Input operand to custom instruction
result[31:0]	Output	Yes	Result of custom instruction

The only required port for combinational custom instructions is the result port. The dataa and datab ports are optional. Include them only if the custom instruction functionality requires input operands. If the custom instruction requires only a single input port, use dataa.

Figure 1–4 shows the combinational custom instruction hardware port timing diagram.

In Figure 1–4, the processor presents the input data on the dataa and datab ports on the rising edge of the processor clock. The processor reads the result port on the rising edge of the following processor clock cycle.

Figure 1-4. Combinational Custom Instruction Timing Diagram



The Nios II processor issues a combinational custom instruction speculatively; that is, it optimizes execution by issuing the instruction before knowing whether it is necessary, and ignores the result if it is not required. Therefore, a combinational custom instruction must not have side effects. In particular, a combinational custom instruction cannot have an external interface.


You can further optimize combinational custom instructions by implementing the extended custom instruction. Refer to "Extended Custom Instructions" on page 1–7.

Multicycle Custom Instructions

Multicycle or sequential, custom instructions consist of a logic block that requires two or more clock cycles to complete an operation. Additional control ports are required for multicycle custom instructions, as shown in Table 1–3.

Figure 1–5 shows the multicycle custom instruction block diagram.

Figure 1-5. Multicycle Custom Instruction Block Diagram



Multicycle custom instructions complete in either a fixed or variable number of clock cycles. For a custom instruction that completes in a fixed number of clock cycles, you specify the required number of clock cycles at system generation. For a custom instruction that requires a variable number of clock cycles, you instantiate the start and done ports. These ports participate in a handshaking scheme to determine when the custom instruction execution is complete.

Table 1–3 describes the multicycle custom instruction ports.


Table 1-3. Multicycle Custom Instruction Ports

Port Name	Direction Required Description		Description
clk	Input	Yes	System clock
clk_en	Input	Yes	Clock enable
reset	Input	Yes	Synchronous reset
start	Input	No	Commands custom instruction logic to start execution
done	Output	No	Custom instruction logic indicates to the processor that execution is complete
dataa[31:0]	Input	No	Input operand to custom instruction
datab[31:0]	Input	No	Input operand to custom instruction
result[31:0]	Output	No	Result of custom instruction

As indicated in Table 1–3, the clk, clk_en, and reset ports are required for multicycle custom instructions. However, the start, done, dataa, datab, and result ports are optional. Implement them only if the custom instruction functionality requires them.

Figure 1–6 shows the multicycle custom instruction hardware port timing diagram.





The processor asserts the active high start port on the first clock cycle of the custom instruction execution. At this time, the dataa and datab ports have valid values and remain valid throughout the duration of the custom instruction execution. The start signal is asserted for a single clock cycle.

For a fixed length multicycle custom instruction, after the instruction starts, the processor waits the specified number of clock cycles, and then reads the value on the result signal. For an n-cycle operation, the custom logic block must present valid data on the nth rising edge after the custom instruction begins execution.

For a variable length multicycle custom instruction, the processor waits until the active high done signal is asserted. The processor reads the result port on the same clock edge on which done is asserted. The custom logic block must present data on the result port on the same clock cycle on which it asserts the done signal.

The Nios II system clock feeds the custom logic block's clk port, and the Nios II system's master reset feeds the active high reset port. The reset port is asserted only when the whole Nios II system is reset.

The custom logic block must treat the active high clk_en port as a conventional clock qualifier signal, ignoring clk while clk_en is deasserted.


You can further optimize multicycle custom instructions by implementing the extended internal register file, or by creating external interface custom instructions. Refer to "Extended Custom Instructions", "Internal Register File Custom Instructions" on page 1–9, or "External Interface Custom Instructions" on page 1–10.

Extended Custom Instructions

Extended custom instruction allows a single custom logic block to implement several different operations. Extended custom instructions use an index to specify which operation the logic block performs. The index can be as many as eight bits wide, allowing a single custom logic block to implement as many as 256 different operations.

Figure 1–7 is a block diagram of an extended custom instruction with bit-swap, byte-swap, and half-word swap operations.

Figure 1–7. Extended Custom Instruction with Swap Operations



The custom instruction in Figure 1–7 performs swap operations on data received at the dataa port. It uses the two-bit-wide n port to select the output from a multiplexer, determining which result is presented to the result port.



This logic is just a simple example, using a multiplexer on the output. You can implement function selection based on an index in any way that is appropriate for your application.

Extended custom instructions can be combinational or multicycle custom instructions. To implement an extended custom instruction, simply add an n port to your custom instruction logic. The bit width of the n port is a function of the number of operations the custom logic block can perform.

Extended custom instructions occupy multiple custom instruction indices. For example, the custom instruction illustrated in Figure 1–7 occupies 4 indices, because n is two bits wide. Therefore, when this instruction is implemented in a Nios II system, 256 - 4 = 252 available indices remain.

For information about the custom instruction index, refer to "Custom Instruction Assembly Software Interface" on page 2–3.

All extended custom instruction port operations are identical to those for the combinational and multicycle custom instructions, with the exception of the n port, which is not present in combinational and multicycle custom instructions. The n port timing is the same as that of the dataa port. For example, for an extended variable multicycle custom instruction, the processor presents the index value to the n port on the same rising edge of the clock at which start is asserted, and the n port remains stable during execution of the custom instruction.

Internal Register File Custom Instructions

The Nios II processor allows custom instruction logic to access its own internal register file. This provides you the flexibility to specify if the custom instruction reads its operands from the Nios II processor's register file or from the custom instruction's own internal register file. In addition, a custom instruction can write its results to the local register file rather than to the Nios II processor's register file.

Custom instructions containing internal register files use readra, readrb, and writerc signals to determine if the custom instruction should use the internal register file or the dataa, datab, and result signals. Ports a, b, and c specify the internal registers from which to read or to which to write. For example, if readra is deasserted (specifying a read operation from the internal register), the a signal value provides an index to the internal register file. Ports a, b, and c are five bits each, allowing you to address as many as 32 registers.




Table 1–4 lists the internal register file custom instruction-specific optional ports. Use the optional ports only if the custom instruction functionality requires them.

Direction Required **Port Name** Description If readra is high, the Nios II processor supplies dataa; if readra is low, custom instruction logic reads the internal register file Input No readra indexed by a. If readrb is high, the Nios II processor supplies datab; Input No if readrb is low, custom instruction logic reads the internal register file readrb If writerc is high, the Nios II processor writes to the result port; No if writerc is low, custom instruction logic writes to the internal writerc Input register file indexed by c. a[4:0] Input No Custom instruction internal register file index Input No Custom instruction internal register file index b[4:0] Custom instruction internal register file index c[4:0] Input No

Table 1-4. Internal Register File Custom Instruction Ports

Figure 1–8 shows a simple multiply-accumulate custom logic block.




Figure 1–8. Multiply-accumulate Custom Logic Block

When writerc is deasserted, the Nios II processor ignores the value driven on the result port. The accumulated value is stored in an internal register. Alternatively, the processor can read the value on the result port by asserting writerc. At the same time, the internal register is cleared so that it is ready for a new round of multiply and accumulate operations.

The readra, readrb, writerc, a, b, and c ports behave similarly to dataa. When the custom instruction begins, the processor presents the new values of the readra, readrb, writerc, a, b, and c ports on the rising edge of the processor clock. All six of these ports remain stable during execution of the custom instructions.

To determine how to handle the register file, custom instruction logic reads the active high readra, readrb, and writerc ports. The logic uses the a, b, and c ports as register file indexes. When readra or readrb is asserted, the custom instruction logic ignores the corresponding a or b port, and receives data from the dataa or datab port. When writerc is asserted, the custom instruction logic ignores the c port and writes to the result port.

All other custom instruction port operations behave the same as for combinational and multicycle custom instructions.


External Interface Custom Instructions

Nios II custom instructions allow you to add an interface to communicate with logic outside of the processor's datapath. At system generation, conduits propagate out to the top level of the SOPC Builder or Qsys system, where external logic can access the signals.

By enabling custom instruction logic to access memory external to the processor, external interface custom instructions extend the capabilities of the custom instruction logic.

Figure 1–9 shows a multicycle custom instruction that has an external memory interface.

Figure 1–9. Custom Instructions Allow the Addition of an External Interface



Custom instruction logic can perform various tasks such as storing intermediate results or reading memory to control the custom instruction operation. The conduit interface also provides a dedicated path for data to flow into or out of the processor. For example, custom instruction logic with an external interface can feed data directly from the processor's register file to an external first-in first-out (FIFO) memory buffer.



The Nios II custom instruction software interface abstracts logic implementation details from the application code. During the build process the Nios II software build tools generate macros that allow easy access from application code to custom instructions.

This chapter contains the following sections:

- "Custom Instruction Examples" on page 2–1
- "Built-in Functions and User-defined Macros" on page 2–2
- "Custom Instruction Assembly Software Interface" on page 2–3

Custom Instruction Examples

Example 2–1 shows a portion of the **system.h** header file that defines a macro for a bit-swap custom instruction. This bit-swap example accepts one 32-bit input and performs only one function.

Example 2–1. Bit Swap Macro Definition

```
#define ALT_CI_BITSWAP_N 0x00
#define ALT_CI_BITSWAP(A) __builtin_custom_ini(ALT_CI_BITSWAP_N,(A))
```

In Example 2–1, ALT_CI_BITWSWAP_N is defined to be 0×0 , which is the custom instruction's index. The ALT_CI_BITSWAP(A) macro is mapped to a gcc built-in function that takes a single argument.

For more information about the gcc built-in functions, refer to Appendix B, Custom Instruction Built-in Functions.

Example 2–2 illustrates application code that uses the bit-swap custom instruction.

Example 2–2. Bit Swap Instruction Usage

```
#include "system.h"
int main (void)
{
  int a = 0x12345678;
  int a_swap = 0;

  a_swap = ALT_CI_BITSWAP(a);
  return 0;
}
```

The code in Example 2–2 includes the **system.h** file to enable the application software to use the custom instruction macro definition. The example code declares two integers, a and a_swap. Integer a is passed as input to the bit swap custom instruction and the results are loaded in a_swap.

Example 2–2 illustrates how most applications use custom instructions. The macros defined by the Nios II software build tools use C integer types only. Occasionally, applications require input types other than integers. In those cases, you can use a custom instruction macro to process non-integer return values.



You can define custom macros for Nios II custom instructions that allow other 32-bit input types to interface with custom instructions.

Built-in Functions and User-defined Macros

The Nios II processor uses gcc built-in functions to map to custom instructions. By default, the integer type custom instruction is defined in a **system.h** file. However, by using built-in functions, software can use non-integer types with custom instructions. Fifty-two built-in functions are available to accommodate the different combinations of supported types.

Built-in function names have the following format:

```
__builtin_custom_<return type>n<parameter types>
```

Table 2–1 lists the 32-bit types supported by custom instructions as parameters and return types, as well as the abbreviations used in the built-in function names.

Table 2–1. 32-bit Types Supported by Custom Instructions

32-bit Type	Built-in Function Abbreviation
int	i
float	f
void *	р

Example 2–3 shows the prototype definitions for two built-in functions.

Example 2-3. Two Example Built-in Function Prototypes

```
void __builtin_custom_nf (int n, float dataa);
float __builtin_custom_fnp (int n, void * dataa);
```

The built-in function __builtin_custom_nf takes a float as an input, and does not return a value. In contrast, the built-in function__builtin_custom_fnp takes a pointer as input, and returns a float.

To support non-integer input types, define macros with mnemonic names that map to the specific built-in function required for the application.



Refer to Appendix B, Custom Instruction Built-in Functions for detailed information and a list of built-in functions.

Example 2–4 shows user-defined custom instruction macros used in an application.

Example 2-4. Custom Instruction Macro Usage Example

```
1. /* define void udef_macro1(float data); */
2. #define UDEF_MACRO1_N 0x00
3. #define UDEF_MACRO1(A) __builtin_custom_nf(UDEF_MACRO1_N, (A));
4. /* define float udef_macro2(void *data); */
5. #define UDEF_MACRO2_N 0x01
6. #define UDEF_MACRO2(B) __builtin_custom_fnp(UDEF_MACRO2_N, (B));
8. int main (void)
9. {
10.
       float a = 1.789;
11.
       float b = 0.0;
12.
       float *pt_a = &a;
13.
14.
      UDEF_MACRO1(a);
       b = UDEF_MACRO2((void *)pt_a);
15.
16.
       return 0;
17. }
```

On lines 2 through 6, the user-defined macros are declared and mapped to the appropriate built-in functions. The macro UDEF_MACRO1 takes a float as an input parameter and does not return anything. The macro UDEF_MACRO2 takes a pointer as an input parameter and returns a float. Lines 14 and 15 show code that uses the two user-defined macros.

Custom Instruction Assembly Software Interface


The Nios II custom instructions are also accessible in assembly code. This section describes the assembly interface.

Custom instructions are R-type instructions, containing:

- A 6-bit opcode
- Three 5-bit register index fields
- Three 1-bit fields for the readra, readrb, and writerc signals
- An 8-bit N field, used for the custom instruction index (opcode extension), and optionally including a function select subfield

Figure 2–1 shows a diagram of the custom instruction word.

Figure 2-1. Custom Instruction Format



Bits 5–0 are the Nios II custom instruction opcode. The opcode for a custom instruction is 0x32.



A list of opcodes appears in the "Instruction Opcodes" section in the Instruction Set Reference chapter of the Nios II Processor Reference Handbook.

The N field, bits 13:6, is the custom instruction index. The custom instruction index distinguishes between different custom instructions, allowing the Nios II processor to support as many as 256 distinct custom instructions. Depending on the type of custom instruction, the N field has one of the following functions:

- A unique custom instruction index, for logic that implements a single custom function
- An extended custom instruction index, for logic that implements several custom functions

Example 2–5 shows the assembly language syntax for the custom instruction.

Example 2-5. Custom Instruction Assembly Syntax

custom N, xC, xA, xB

In the assembly code instruction in Example 2–5, N is the custom instruction index, xC is the destination for the result[31:0] port, xA is the dataa port, and xB is the datab port. To access the Nios II processor's register file, replace x with r. To access a custom register file, replace x with c. The use of r or c determines whether the custom instruction has the readra, readrb, and writerc bits held high or low. Refer to Figure 2–1 for the location of these three bits in the custom instruction low-level format.

Example 2–6, Example 2–7, and Example 2–8 demonstrate the syntax for custom instruction assembler calls.

Example 2–6. Assembly Language Call to Customer Instruction I

custom 0, r6, r7, r8

Example 2–6 shows a call to a custom instruction with index 0. The input to the instruction is the current contents of the Nios II processor registers r7 and r8, and the results are stored in the Nios II processor register r6.

Example 2–7. Assembly Language Call to Customer Instruction II

custom 3, c1, r2, c4

Example 2–7 shows a call to a custom instruction with index 3. The input to the instruction is the current contents of the Nios II processor register r2 and the custom register c4, and the results are stored in custom register c1.

Example 2–8. Assembly Language Call to Customer Instruction III

custom 4, r6, c9, r2

Example 2–8 shows a call to a custom instruction with index 4. The input to the instruction is the current contents of the custom register c9 and the Nios II processor register r2, and the results are stored in Nios II processor register r6.



For more information about the binary format of custom instructions, refer to the Instruction Set Reference chapter of the Nios II Processor Reference Handbook.



4. Implementing a Nios II Custom **Instruction in Qsys**

This chapter describes the process of implementing a Nios II custom instruction with the Qsys component editor. The component editor enables you to create new Qsys components, including Nios II custom instructions. This chapter also describes the process of accessing Nios II custom instructions from software.



For detailed information about the Qsys component editor, refer to Creating Qsys *Components* in volume 1 of the *Quartus II Handbook*.

Design Example: Cyclic Redundancy Check

The cyclic redundancy check (CRC) algorithm detects the corruption of data during transmission. It detects a higher percentage of errors than a simple checksum. The CRC calculation consists of an iterative algorithm involving XOR and shift operations. These operations are carried out concurrently in hardware and iteratively in software. Because the operations are carried out concurrently, the execution is much faster in hardware.

The CRC design files demonstrate the steps to implement an extended multicycle Nios II custom instruction. These design files are available for you to download from the Nios II Custom Instruction Design Example web page.

Implementing Custom Instruction Hardware in Qsys

This section describes the custom instruction tool-flow, and walks you through the process of implementing a Nios II custom instruction. Implementing a Nios II custom instruction hardware entails the following tasks:

- "Opening the Component Editor"
- "Adding the HDL Files"
- "Configuring the Custom Instruction Signal Type" on page 4–3
- "Setting Up the Custom Instruction Interfaces" on page 4–3
- "Setting the Details" on page 4–4
- "Saving and Adding the Custom Instruction" on page 4–5
- "Generating the System and Compiling in the Quartus II Software" on page 4–5

The following sections detail the steps required to set up the design example environment and to perform the list of tasks.

Setting up the Design Environment for the Design Example

Before you start the design example, you must set up the design environment to accommodate the processes described in the following sections. To set up the design example environment, follow these steps:

- 1. Open the **ug_custom_instruction_files.zip** file from the Nios II Custom Instruction Design Example web page and extract all the files to a new directory.
- Follow the instructions in the Quartus II Project Setup section in the
 readme_qsys.txt file in the extracted design files. The instructions direct you to
 determine a project_dir> working directory for the project and to open the design
 example project in the Quartus II software.

Opening the Component Editor

After you follow the steps in the Quartus II Project Setup section of the **readme_qsys.txt** file, you have an Quartus II project located in the *cproject_dir>* directory and open in the Quartus II software.

To open the component editor, follow these steps:

- 1. To open Qsys, on the Tools menu, click **Qsys**.
- 2. In Qsys, on the File menu, click **Open**.
- 3. Browse to the *<project_dir>* directory if necessary, select the **.qsys** file, and click **Open**.
- On the Qsys Component Library tab, click New. The component editor appears, displaying the Introduction tab.

Adding the HDL Files

To specify the synthesis HDL files for your custom instruction, follow these steps:

- 1. Click **Next** to display the **HDL Files** tab.
- 2. Click Add.
- 3. Browse to crc_hw, the location of the HDL files for this design example.
- 4. Select the CRC_Custom_Instruction.v and CRC_Component.v files and click Open.
 - The Quartus II Analysis and Synthesis program checks the design for errors when you add the files. Confirm that no error message appears.
- 5. Ensure the **Synth** setting is turned on for both files. This setting directs the component editor to generate models for synthesis..
- 6. Turn on the **Top** parameter for the **CRC_Custom_Instruction.v** file, to indicate it is the top-level HDL file for this custom instruction.
 - The Quartus II Analysis and Synthesis program checks the design for errors when you change the **Top** setting. Confirm that no error message appears.

- 7. Click **Top Level Module** and select the name of the top-level module of your custom instruction logic. The top-level module for this design example is **CRC_Custom_Instruction**.
- 8. To enable simulating the system in the ModelSim simulator, you can turn on Sim for both files. In cases other than the design example, you may need to add additional simulation files in the component editor HDL Files tab, turn on Sim and turn off Synth for these simulation-only files, and turn off Sim for the synthesis-only files.

Configuring the Custom Instruction Signal Type

To configure the custom instruction signal type, follow these steps:

- 1. Click **Next** to display the **Signals** tab.
- 2. For each port listed in the tab, follow these steps:
 - a. Select the port.
 - b. In the **Interface** column, select the name of the interface to which you want to assign the port.
 - For the design example, for the first port you configure, select **New Custom Instruction Slave**. For the remaining ports, select the name created for the first port, which is **nios_custom_instruction_slave**. These selections ensure that the ports appear together on a single interface, using the name assumed by the design example **crc_hw** files.
 - c. In the **Signal Type** column, select the appropriate signal type for the port. The available signal types are described in "Custom Instruction Types" on page 1–3. In the design example, the correct signal type for each signal has the same name as the signal.

Setting Up the Custom Instruction Interfaces

To set up the custom instruction interfaces, follow these steps:

- 1. Click **Next** to display the **Interfaces** tab.
- 2. If the **Remove Interfaces With No Signals** button is active, click it.
- 3. Ensure that a single interface remains, with **Name** set to the name in the Signals tab. For the design example, maintain the interface name nios_custom_instruction_slave.



If you rename an interface by changing the value in the **Name** field, the **Signals** tab **Interface** column value changes automatically. The value shown in the block diagram updates when you change tabs and return to the **Interfaces** tab.

- 4. Ensure the **Type** for this interface is **Custom Instruction Slave**.
- 5. For **Clock Cycles**, type 0 for a variable multicycle type custom instruction, and otherwise type the number of clock cycles your custom instruction logic requires. The design example builds a variable multicycle type custom instruction.



If the interface includes a done signal and a clk signal, the component editor automatically infers that the interface is a variable multicycle type custom instruction interface, and sets the value to 0.

6. For Clock Cycle Type, type Variable for a variable multicycle type custom instruction, Multicycle for a fixed multicycle type custom instruction, or Combinatorial for a combinational type custom instruction. Because the design example builds a variable multicycle type custom instruction, Clock Cycle Type is set to Variable.



If the interface does not include a clk signal, the component editor automatically infers that the interface is a combinational type interface. If the interface includes a clk signal, the component editor automatically infers that the interface is a multicycle interface. If the interface does not include a done signal, the component editor infers that the interface is a fixed multicycle type interface. If the interface includes a done signal, the component editor infers that the interface is a variable multicycle type interface.

7. For **Operands**, type the number of operands for your custom instruction. For the design example, type 1.

If your custom instruction logic requires additional interfaces, either to the Avalon-MM fabric or outside the Qsys system, you can specify the additional interfaces in the Interfaces tab. The design example does not require additional interfaces.



Most custom instructions use some combination of standard custom instruction ports, such as dataa, datab, and result, and do not require additional interfaces.

The following instructions provide the information you need if a custom instruction in your own design requires additional interfaces. If you are walking through the design example, proceed to "Setting the Details".

To specify additional interfaces on the **Interfaces** tab, follow these steps:

- 1. Click Add Interface. The new interface has Custom Instruction Slave interface type by default.
- 2. For **Type**, select the desired interface type.
- 3. Set the parameters for the newly created interface according to your system requirements.

Setting the Details

To specify the final details in the custom instruction parameter editor, follow these steps:

- 1. Click **Next** to display the **HDL Parameters** tab.
- 2. Click **Next** to display the **Library Info** tab.
- 3. For **Name** and for **Display Name**, type CRC.
- 4. For **Version**, type 1.0.

- 5. Leave the **Group** field blank.
- 6. Optionally, set the **Description**, **Created by**, and **Icon** fields as you prefer.
- 7. If the bottom pane of the dialog box displays something other than the message **Info:** No errors or warnings, review the other tabs to ensure you followed the instructions correctly.

Saving and Adding the Custom Instruction

To save the custom instruction and add it to your Nios II processor, follow these steps:


- 1. Click Finish. A dialog box prompts you to save your changes before exiting.
- 2. Click **Yes**, **Save**. The new custom instruction appears in the Qsys Component Library.
- 3. In the Qsys Component Library, under Library, select **CRC**, the new custom instruction you created in the design example.
- 4. Click **Add** to add the new instruction to the Qsys system.
- In the Connections panel, connect the new CRC_0 component's nios_custom_instruction_slave interface to the cpu component's custom_instruction_master interface.

Generating the System and Compiling in the Quartus II Software

After you add the custom instruction logic to the system, you can generate the Qsys system and compile it in the Quartus II software.

To generate the system and compile, follow these steps:

- 1. In Qsys, on the Generation tab, turn on Create HDL design files for synthesis.
- 2. Click **Generate**. System generation may take several seconds to complete.
- 3. After system generation completes, on the File menu, click Exit.
- 4. In the Quartus II software, on the Project menu, click **Add/Remove Files in Project**.
- 5. Ensure that the **.qip** file in the **synthesis** subdirectory is added to the project.
- 6. On the Processing menu, click **Start Compilation**.



Accessing the Custom Instruction from Software

Adding a custom instruction to a Nios II processor results in a significant change to the Qsys system. In this section, you create and build a new software project using the Nios II software build flow, and run the software that accesses the custom instruction. The software source files are included in the downloadable design files.

Table 4–1 lists the CRC application software source files and their corresponding descriptions.

Table 4-1. CRC Application Software Source Files

File Name	Description
crc_main.c	Main program that populates random test data, executes the CRC both in software and with the custom instruction, validates the output, and reports the processing time.
crc.c	Software CRC algorithm run by the Nios II processor.
crc.h	Header file for crc.c.
ci_crc.c	Program that accesses CRC custom instruction.
ci_crc.h	Header file for ci_crc.c.

To run the application software, you must create an Executable and Linking Format File (.elf) first. To create the .elf file, follow the instructions in the Nios II Software Build Flow section in the readme_qsys.txt file in the extracted design files.

The application program runs three implementations of the CRC algorithm on the same pseudo-random input data: an unoptimized software implementation, an optimized software implementation, and the custom instruction CRC. The program calculates the processing time and throughput for each of the versions, to demonstrate the improved efficiency of a custom instruction compared to a software implementation.

Example 4–1 shows the output from the application program run on a Nios II Embedded Evaluation Kit, Cyclone III Edition (NEEK) using the Quartus II software v10.1 Service Pack 1 and Nios II Embedded Design Suite (EDS) v10.1 Service Pack 1.

The output shows that the custom instruction CRC is more than 70 times faster than the unoptimized CRC calculated purely in software and is more than 45 times faster than the optimized version of the software CRC. The results you see using different target device and board may vary depending on the memory characteristics of the board and the clock speed of the device, but these ratios are representative.

Example 4–1. Output of the CRC Design Example Software Run on a NEEK Using the Quartus II Software v10.1 SP1

```
********************
Comparison between software and custom instruction CRC32
*****************************
System specification
System clock speed = 62.5 MHz
Number of buffer locations = 16
Size of each buffer = 65535 bytes
Initializing all of the buffers with pseudo-random data
Initialization completed
Running the software CRC
Completed
Running the optimized software CRC
Completed
Running the custom instruction CRC
Completed
Validating the CRC results from all implementations
All CRC implementations produced the same results
Processing time for each implementation
Software CRC = 9928.41 ms
Optimized software CRC = 6414.63 ms
Custom instruction CRC = 137.54 ms
Processing throughput for each implementation
Software CRC = 0.84 Mbps
Optimized software CRC = 1.31 Mbps
Custom instruction CRC = 60.99 Mbps
Speedup ratio
Custom instruction CRC vs software CRC = 72.2
Custom instruction CRC vs optimized software CRC = 46.6
Optimized software CRC vs software CRC = 1.5
```

Using the User-defined Custom Instruction Macro

The design example software uses a user-defined macro to access the CRC custom instruction. Example 4–2 shows the macro that is defined in the **ci_crc.c** file.

Example 4-2. CRC Custom Instruction Macro Usage

#define CRC_CI_MACRO(n, A) __builtin_custom_ini(ALT_CI_CRC_0_N + (n & 0x7), (A))

This macro takes a single int type input operand and returns an int type value. The CRC custom instruction has extended type; the n value in the macro $CRC_CI_MACRO()$ indicates the operation to be performed by the custom instruction. The custom instruction index is added to the value of n. The n value is masked because the n port of a custom instruction has only three bits.


To initialize the custom instruction, for example, you can add the initialization code in Example 4–3 to your application software.

Example 4-3. Using the User-defined Macro to Initialize the Custom Instruction Logic

/* Initialize the custom instruction CRC to the initial remainder value: */ CRC_CI_MACRO (0,0);

For details of each operation of the CRC custom instruction and the corresponding index value n, refer to the comments in the **ci_crc.c** file.

Example 4–2 and Example 4–3 demonstrate that you can define the macro in your application to accommodate your requirements. For example, you can determine the number and type of input operands, decide whether to assign a return value, and vary the custom instruction index. However, the macro definition and usage must be consistent with the port declarations of the custom instruction. For example, if you define the macro to return an int value, the custom instruction must have a result port.





A. Custom Instruction Templates

This appendix provides VHDL and Verilog HDL custom instruction wrapper file templates that you can reference when writing custom instructions in VHDL and Verilog HDL.

Full sets of template files are available in the <nios2eds installation directory>/examples/verilog/custom_instruction_templates and <nios2eds installation directory>/examples/vhdl/custom_instruction_templates directories.

VHDL Custom Instruction Template

Example A–1 shows a VHDL custom instruction template for an internal register type custom instruction.

Example A-1. VHDL Custom Instruction Template for Internal Register Logic Type Instruction

```
-- VHDL Custom Instruction Template File for Internal Register Logic
library ieee;
use ieee.std_logic_1164.all;
entity custominstruction is
port.(
   signal clk: in std_logic;
             -- CPU system clock (required for multicycle or extended multicycle)
   signal reset: in std_logic;
            -- CPU master asynchronous active high reset
               (required for multicycle or extended multicycle)
   signal clk_en: in std_logic;
            -- Clock-qualifier (required for multicycle or extended multicycle)
   signal start: in std_logic;
           -- Active high signal used to specify that inputs are valid
            -- (required for multicycle or extended multicycle)
   signal done: out std_logic;
           -- Active high signal used to notify the CPU that result is valid
           -- (required for variable multicycle or extended variable multicycle)
   signal n: in std_logic_vector(7 downto 0);
           -- N-field selector (required for extended);
           -- Modify width to match the number of unique operations in the instruction
   signal dataa: in std_logic_vector(31 downto 0); -- Operand A (always required)
   signal datab: in std_logic_vector(31 downto 0);-- Operand B (optional)
   signal a: in std_logic_vector(4 downto 0); -- Internal operand A index register
   signal b: in std_logic_vector(4 downto 0); -- Internal operand B index register
   signal c: in std_logic_vector(4 downto 0);-- Internal result index register
   signal readra: in std_logic;
           -- Read operand A from CPU (otherwise use internal operand A)
   signal readrb: in std_logic;
            - Read operand B from CPU (otherwise use internal operand B)
   signal writerc: in std_logic;
           -- Write result to CPU (otherwise write to internal result)
   signal result: out std_logic_vector(31 downto 0)-- result (always required)
);
end entity custominstruction;
architecture a_custominstruction of custominstruction is
   -- local custom instruction signals
begin
   -- custom instruction logic (note: external interfaces can be used as well)
   -- Use the n[7..0] port as a select signal on a multiplexer
      to select the value to feed result[31..0]
end architecture a_custominstruction;
```

Verilog HDL Custom Instruction Template Example

Example A–2 shows a Verilog HDL custom instruction template for an internal register type custom instruction.

Example A-2. Verilog HDL Custom Instruction Template for Internal Register Logic Type Instruction

```
// Verilog Custom Instruction Template File for Internal Register Logic
module custominstruction(
   clk, // CPU system clock (required for multicycle or extended multicycle)
   reset, // CPU master asynchronous active high reset
              (required for multicycle or extended multicycle)
   clk_en,// Clock-qualifier (required for multicycle or extended multicycle)
   start, // Active high signal used to specify that inputs are valid
             (required for multicycle or extended multicycle)
   done, // Active high signal used to notify the CPU that result is valid
             (required for variable multicycle or extended variable multicycle)
         // N-field selector (required for extended)
   dataa, // Operand A (always required)
   datab, // Operand B (optional)
         // Internal operand A index register
         // Internal operand B index register
         // Internal result index register
   readra,// Read operand A from CPU (otherwise use internal operand A)
   readrb, // Read operand B from CPU (otherwise use internal operand B)
   writerc,// Write result to CPU (otherwise write to internal result)
   result // Result (always required)
);
//INPUTS
inputclk;
inputreset;
inputclk_en;
inputstart;
input[7:0]n_i// modify width to match the number of unique operations in the instruction
input[4:0]a;
input[4:0]b;
input[4:0]c;
inputreadra;
inputreadrb;
inputwriterc;
input[31:0]dataa;
input[31:0]datab;
//OUTPUTS
outputdone;
output[31:0]result;
// custom instruction logic (note: external interfaces can be used as well)
// Use the n[7..0] port as a select signal on a multiplexer
       to select the value to feed result[31..0]
endmodule
```

B. Custom Instruction Built-in Functions

The Nios II gcc compiler, nios2-elf-gcc, is customized with built-in functions to support custom instructions. This section lists the built-in functions.

For more information about gcc built-in functions, refer to www.gnu.org.

Nios II custom instruction built-in functions have the following return types:

- void
- int
- float
- pointer

Built-in Functions that Return a Void Value

The following built-in functions return a void value:

```
void __builtin_custom_n (int n);
void __builtin_custom_ni (int n, int dataa);
void __builtin_custom_nf (int n, float dataa);
void __builtin_custom_np (int n, void *dataa);
void __builtin_custom_nii (int n, int dataa, int datab);
void __builtin_custom_nif (int n, int dataa, float datab);
void __builtin_custom_nip (int n, int dataa, void *datab);
void __builtin_custom_nfi (int n, float dataa, int datab);
void __builtin_custom_nff (int n, float dataa, float datab);
void __builtin_custom_nfp (int n, float dataa, void *datab);
void __builtin_custom_npf (int n, void *dataa, int datab);
void __builtin_custom_npf (int n, void *dataa, float datab);
void __builtin_custom_npf (int n, void *dataa, float datab);
void __builtin_custom_npf (int n, void *dataa, void *datab);
```

Built-in Functions that Return a Value of Type Int

The following built-in functions return a value of type int:

```
int __builtin_custom_in (int n);
int __builtin_custom_ini (int n, int dataa);
int __builtin_custom_inf (int n, float dataa);
int __builtin_custom_inp (int n, void *dataa);
```

```
int __builtin_custom_inii (int n, int dataa, int datab);
int __builtin_custom_inif (int n, int dataa, float datab);
int __builtin_custom_inip (int n, int dataa, void *datab);
int __builtin_custom_infi (int n, float dataa, int datab);
int __builtin_custom_inff (int n, float dataa, float datab);
int __builtin_custom_infp (int n, float dataa, void *datab);
int __builtin_custom_inpi (int n, void *dataa, int datab);
int __builtin_custom_inpf (int n, void *dataa, float datab);
int __builtin_custom_inpf (int n, void *dataa, void *datab);
```

Built-in Functions that Return a Value of Type Float

The following built-in functions return a value of type float:

```
float __builtin_custom_fn (int n);

float __builtin_custom_fni (int n, int dataa);

float __builtin_custom_fnf (int n, float dataa);

float __builtin_custom_fnp (int n, void *dataa);

float __builtin_custom_fnii (int n, int dataa, int datab);

float __builtin_custom_fnif (int n, int dataa, float datab);

float __builtin_custom_fnip (int n, int dataa, void *datab);

float __builtin_custom_fnif (int n, float dataa, int datab);

float __builtin_custom_fnff (int n, float dataa, float datab);

float __builtin_custom_fnfp (int n, float dataa, void *datab);

float __builtin_custom_fnpi (int n, void *dataa, int datab);

float __builtin_custom_fnpf (int n, void *dataa, float datab);

float __builtin_custom_fnpf (int n, void *dataa, void *datab);

float __builtin_custom_fnpp (int n, void *dataa, void *datab);
```

Built-in Functions that Return a Pointer Value

The following built-in functions return a pointer value:

```
void *_builtin_custom_pn (int n);
void *_builtin_custom_pni (int n, int dataa);
void *_builtin_custom_pnf (int n, float dataa);
void *_builtin_custom_pnp (int n, void *dataa);
void *_builtin_custom_pnii (int n, int dataa, int datab);
void *_builtin_custom_pnif (int n, int dataa, float datab);
void *_builtin_custom_pnip (int n, int dataa, void *datab);
```

```
void *__builtin_custom_pnfi (int n, float dataa, int datab);
void *__builtin_custom_pnff (int n, float dataa, float datab);
void *__builtin_custom_pnfp (int n, float dataa, void *datab);
void *__builtin_custom_pnpi (int n, void *dataa, int datab);
void *__builtin_custom_pnpf (int n, void *dataa, float datab);
void *__builtin_custom_pnpp (int n, void *dataa, void *datab);
```



C. Floating Point Custom Instructions

If you add a floating point custom instruction to your system, conflicts could arise in the software build process. This appendix describes how to handle these conflicts.

Both Qsys and SOPC Builder offer a predefined **Floating Point Hardware** component that you can add to your system. When you add this component to your system, a parameter editor displays, and you can turn on an option to include a floating point divider. The parameter editor notifies you that the component generates single-precision floating point hardware.

When you add the floating point custom instruction to your system and run the software build process, flags are added to your nios2-elf-gcc command line. These flags specify the opcode extensions of the custom instructions that are called by the software and select the appropriate library.

One of the following two flags appears:

- -mcustom-fpu-cfg=60-1
- -mcustom-fpu-cfg=60-2

The flag value 60-1 indicates your system does not include a custom instruction floating point divider, and the flag value 60-2 indicates your system includes a custom instruction floating point divider.

The -mcustom-fpu-cfg flags forces the use of single-precision constants. To allow double-precision constants, you must remove the -mcustom-fpu-cfg flag and replace it with different individual compiler flags, depending on the flag value.

To enable double-precision floating point constants, follow one of these steps:

Replace the command-line option string -mcustom-fpu-cfg=60-1 with the following command-line option string:

```
-mcustom-fmuls=252,-mcustom-fadds=253,-mcustom-fsubs=254
```

■ Replace the command-line option string -mcustom-fpu-cfg=60-2 with the following command-line option string:

-mcustom-fmuls=252,-mcustom-fadds=253,-mcustom-fsubs=254,-mcustom-fdivs=255



Change the flags only if required. Replacing the -mcustom-fpu-cfg flag disables floating point custom instruction support in your library calls, forcing the system to use the emulated or slower version of the instruction instead.



This chapter provides additional information about the document and Altera.

Document Revision History

The following table shows the revision history for this document.

Date	Version	Changes
		■ Updated for Quartus II software v10.1.
January 2011	2.0	Updated for new Qsys system integration tool flow.
		Updated with formatting changes.
		Add new tutorial design.
May 2008	1.5	Describe new custom instruction import flow.
		Minor corrections to terminology and usage.
May 2007	1.4	Add title and core version number to page footers.
		Describe new component editor import flow.
May 2007	1.3	Remove tutorial design.
		Minor corrections to terminology and usage.
December 2004	1.2	Updates for Nios II processor vresion 1.1.
September 2004	1.1	Updates for Nios II processor version 1.01.
May 2004	1.0	Initial release.

How to Contact Altera

To locate the most up-to-date information about Altera products, refer to the following table.

Contact (1)	Contact Method	Address
Technical support	Website	www.altera.com/support
Technical training	Website	www.altera.com/training
recinical training	Email	custrain@altera.com
Product literature	Website	www.altera.com/literature
Non-technical support (General)	Email	nacomp@altera.com
(Software Licensing)	Email	authorization@altera.com

Note to Table:

(1) You can also contact your local Altera sales office or sales representative.

Typographic Conventions

The following table shows the typographic conventions this document uses.

Visual Cue	Meaning
Bold Type with Initial Capital Letters	Indicate command names, dialog box titles, dialog box options, and other GUI labels. For example, Save As dialog box. For GUI elements, capitalization matches the GUI.
bold type	Indicates directory names, project names, disk drive names, file names, file name extensions, software utility names, and GUI labels. For example, quesigns directory, D: drive, and chiptrip.gdf file.
Italic Type with Initial Capital Letters	Indicate document titles. For example, Stratix IV Design Guidelines.
	Indicates variables. For example, $n + 1$.
italic type	Variable names are enclosed in angle brackets (< >). For example, <file name=""> and <project name="">.pof file.</project></file>
Initial Capital Letters	Indicate keyboard keys and menu names. For example, the Delete key and the Options menu.
"Subheading Title"	Quotation marks indicate references to sections within a document and titles of Quartus II Help topics. For example, "Typographic Conventions."
	Indicates signal, port, register, bit, block, and primitive names. For example, \mathtt{datal} , \mathtt{tdi} , and \mathtt{input} . The suffix \mathtt{n} denotes an active-low signal. For example, \mathtt{resetn} .
Courier type	Indicates command line commands and anything that must be typed exactly as it appears. For example, c:\qdesigns\tutorial\chiptrip.gdf.
	Also indicates sections of an actual file, such as a Report File, references to parts of files (for example, the AHDL keyword SUBDESIGN), and logic function names (for example, TRI).
4	An angled arrow instructs you to press the Enter key.
1., 2., 3., and a., b., c., and so on	Numbered steps indicate a list of items when the sequence of the items is important, such as the steps listed in a procedure.
	Bullets indicate a list of items when the sequence of the items is not important.
	The hand points to information that requires special attention.
	A question mark directs you to a software help system with related information.
	The feet direct you to another document or website with related information.
CAUTION	A caution calls attention to a condition or possible situation that can damage or destroy the product or your work.
WARNING	A warning calls attention to a condition or possible situation that can cause you injury.
⊠	The envelope links to the Email Subscription Management Center page of the Altera website, where you can sign up to receive update notifications for Altera documents.