

ENEE 3587
Microp Interfacing

Hardware Interrupt

- Asynchronous event initiated by a hardware signal
- Examples of events:
 - > IO device management
 - Performance of routine tasks
 - Response to emergency events
- The interrupt causes a function call to an interrupt service routine
 - Involves considerable "overhead"
- Polling methods can be used to detect flags set by these events
 - Requires constant monitoring of flags
 - Advantage: faster response to events than function calls
 - Disadvantages: power "hungry". Difficult to monitor multiple events concurrently


Hardware Interrupt Terminology

- Non-maskable interrupts: interrupts that don't require enabling
- Maskable interrupts: interrupts that must be enabled
- Mask bit: the enable bit
- Interrupt Service Routine:
 - > a function that is executed when an interrupts occurs
- Interrupt vector table: organized by number and corresponding address
 - Each interrupt has a unique number
 - Vector address is used to store address of ISR

Interrupt Steps (Overhead)

- 1. Finishes executing current instruction
- PUSHs the address of the next instruction (PC) on the stack.
- 3. Disable global interrupt bit
 - To prevent other bits from causing interrupts
- 4. Jumps to a fixed location in memory called the interrupt vector table.
 - > The interrupt vector table holds the address of the interrupt service routine (ISR).
- Jump to ISR
- 6. Return from interrupt: POPs (PC) address from stack
- 7. Set global interrupt bit
- ❖ Steps 2-5: 3 cycles min 5 cycles min
- Steps 6-7: 5 cycles min

Microcontroller Configuration Register (MCUCR)



- JTD: JTAG Disable
 - 0: JTAG interface is Enabled.
 - 1: JTAG interface is Disabled.
- PUD: Pullup Disable
 - 0: Enable pull-ups of all pins of all I/O PORTs.
 - > 1: Disable pull-ups of all pins of all I/O PORTs.
- **❖ IVSEL**: Interrupt vector select
 - 0: Interrupt vectors are placed at the start of the flash memory (i.e., 0x0002).
 - ➤ 1: Interrupt vectors are placed at the start of the boot section. The start of the boot section is set by programming the BOOTSZ fuses.
- ❖ IVCE: Interrupt vector change enable
 - 0: Disable interrupt vector change
 - > 1: Enable interrupt vector to be changed

BOOTRST	IVSEL	Reset address	Interrupt vectors start address
1	0	0×0000	0×0002
1	1	0×0000	Boot reset address + 0×0002
0	0	Boot reset address	0×0002
0	1	Boot reset address	Boot reset address + 0×0002

Enabling Interrupts

- Aka unmasking
- Each maskable interrupts requires two mask bits:
 - Global mask bit: an enable bit to enable all maskable interrupts
 - Local mask bit: an enable bit to enable specific maskable interrupts
- Global enable: bit I (bit 7) of the status register (SREG)
 - > From interrupt.h, use: sei() to set and cli() to clear
- Local enable: enable bit in the interrupt enable register
 - > E.g. TIMSK


ATmega Interrupt Table

Vector no.	Vector addr.	Source	Interrupt definition	Vector no.	Vector addr.	Source	Interrupt definition	
1	0x0000	RESET	Reset/Power-on,brown-out,watchdog, JTAG reset	29	0x0038	Analog	Comp Analog comparator	
2	0x0002	INT0	External interrupt request 0	30	0x003A	ADC	ADC conversion complete	
3	0x0004	INT1	External interrupt request 1	31	0x003C	EE Ready	EEPROM ready	
4	0x0006	INT2	External interrupt request 2	32	0x003E	Timer3 CAPT	Timer/Counter3 capture event	
5	8000x0	INT3	External interrupt request 3	33	0x0040	Timer3 COMPA	Timer/Counter3 compare match A	
6	0x000A	INT4	External interrupt request 4	34	0x0042	Timer3 COMPB	Timer/Counter3 compare match B	
7	0x000C	INT5	External interrupt request 5	35	0x0044	Timer3 COMPC	Timer/Counter3 compare match C	
8	0x000E	INT6	External interrupt request 6	36	0x0046	Timer3 OVF	Timer/Counter3 overflow	
9	0x0010	INT7	External interrupt request 7	37	0x0048	USART1 RX	USART1 Rx complete	
10	0x0012	PCINT0	Pin change interrupt request 0	38	0x004A	USART1 UDRE	USART1 data register empty	
11	0x0014	PCINT1	Pin change interrupt request 1	39	0x004C	USART1 TX	USART1 Tx complete	
12	0x0016	PCINT2	Pin change interrupt request 2	40	0x004E	TWI	2-wire serial interface	
13	0x0018	WDT	Watchdog time-out interrupt	41	0x0050	SPM	Ready Store program memory read	У
14	0x001A	Timer2 COMPA	Timer/Counter2 compare match A	42	0x0052	Timer4 CAPT	Timer/Counter4 capture event	
15	0x001C	Timer2 COMPB	Timer/Counter2 compare match B	43	0x0054	Timer4 COMPA	Timer/Counter4 compare match A	
16	0x001E	Timer2 OVF	Timer/Counter2 overflow	44	0x0056	Timer4 COMPB	Timer/Counter4 compare match B	
17	0x0020	Timer1 CAPT	Timer/Counter1 capture event	45	0x0058	Timer4 COMPC	Timer/Counter4 compare match C	
18	0x0022	Timer1 COMPA	Timer/Counter1 compare match A	46	0x005A	Timer4 OVF	Timer/Counter4 overflow	
19	0x0024	Timer1 COMPB	Timer/Counter1 compare match B	47	0x005C	Timer5 CAPT	Timer/Counter5 capture event	
20	0x0026	Timer1 COMPC	Timer/Counter1 compare match C	48	0x005E	Timer5 COMPA	Timer/Counter5 compare match A	
21	0x0028	Timer1 OVF	Timer/Counter1 overflow	49	0x0060	Timer5 COMPB	Timer/Counter5 compare match B	
22	0x002A	Timer0 COMPA	Timer/Counter0 compare match A	50	0x0062	Timer5 COMPC	Timer/Counter5 compare match C	
23	0x002C	Timer0 COMPB	Timer/Counter0 compare match B	51	0x0064	Timer5 OVF	Timer/Counter5 overflow	
24	0x002E	Timer0 OVF	Timer/Counter0 overflow	52	0x0066	USART2 RX	USART2 Rx complete	
25	0x0030	SPI, STC	SPI serial transfer complete	53	0x0068	USART2 UDRE	USART2 data register empty	
26	0x0032	USATR0	RX USARTO Rx complete	54	0x006A	USART2 TX	USART2 Tx complete	
27	0x0034	USATR0	UDRE USARTO data register empty	55	0x006C	USATR3 RX	USART3 Rx complete	
28	0x0036	USART0	TX USARTO Tx complete	56	0x006E	USATR3 UDRE	USART3 data register empty	_
Dr. Alsamman				57	0x0070	USART3 TX	USART3 Tx complete	7

RESET

- **Power-on reset:** reset when VCC is below the power-on reset threshold (VPOT)
- **External reset:** RESET pin signal is low longer than the min pulse width
- **Brown-out reset:** VCC is lower than the brown-out reset threshold (VBOT—)
 - > the brown-out detector must be enabled.
- * JTAG AVR reset. The MCU is reset as long as there is a logic 1 in the reset register
 - Joint Test Action Group
 - interface used for debugging and programming MCU
 - Requires special connector
- **Watchdog reset.** The MCU is reset when the watchdog timer overflows and the watchdog is enabled.
 - A counter used to ensure that program doesn't hang

MCU Status Reg (MCUSR)



- Flags reset by power-on or writing 0 into flag.
- JTRF: JTAG reset flag
 - > 0 = Reset is not caused by JTAG reset.
 - 1 = Reset is caused by a logic 1 in the JTAG reset register selected by the JTAG instruction AVR_RESET.
- WDRF: Watchdog reset flag
 - 0 = Reset is not caused by watchdog time out.
 - 1 = Reset is caused by watchdog time out (timer overflow).
- BORF: Brown-out reset flag
 - 0 = Reset is not caused by brown out.
 - 1 = Reset is caused by brown-out reset.
- EXTRF: External reset flag
 - 0 = Reset is not caused by RESET pin.
 - > 1 = Reset is caused by RESET pin.
- PORF: Power-on reset flag
 - > 0 = Reset is not caused by power-on reset.
 - 1 = Power-on reset occurred.

Interrupt Code Template

```
// define global variables
#include <avr/io.h>
#include <avr/interrupt.h>
int main (void)
                // enable local interrupt
   sei();
                // enable interrupts globally
ISR (ISR_name) // ISR name is from table on next slide
```

Interrupt.h: ISR Symbolic Name

Interrupt source	Vector no.	ISR name	Interrupt source	Vector no.	ISR name
INT0	2	(INTO_vect)	ADC	30	(ADC_vect)
INT1	3	(INT1_vect)	EE READY	31	(EE_READY_vect)
INT2	4	(INT2_vect)	TIMER3 CAPT	32	(TIMER3_CAPT_vect)
INT3	5	(INT3_vect)	TIMER3 COMPA	33	(TIMER3_COMPA_vect)
INT4	6	(INT4_vect)	TIMER3 COMPB	34	(TIMER3_COMPB_vect)
INT5	7	(INT5_vect)	TIMER3 COMPC	35	(TIMER3_COMPC_vect)
INT6	8	(INT6_vect)	TIMER3 OVF	36	(TIMER3_OVF_vect)
INT7	9	(INT7_vect)	USART1 RX	37	(USART1_RX_vect)
PCINTO	10	(PCINTO_vect)	USART1 UDRE	38	(USART1_UDRE_vect)
PCINT1	11	(PCINT1_vect)	USART1 TX	39	(USART1_TX_vect)
PCINT2	12	(PCINT2_vect)	TWI	40	(TWI_vect)
WDT	13	(WDT_vect)	SPM READY	41	(SPM_READY_vect)
TIMER2 COMPA	14	(TIMER2_COMPA_vect)	TIMER4 CAPT	42	(TIMER4_CAPT_vect)
TIMER2 COMPB	15	(TIMER2_COMPB_vect)	TIMER4 COMPA	43	(TIMER4_COMPA_vect)
TIMER2 OVF	16	(TIMER2_OVF_vect)	TIMER4 COMPB	44	(TIMER4_COMPB_vect)
TIMER1 CAPT	17	(TIMER1_CAPT_vect)	TIMER4 COMPC	45	(TIMER4_COMPC_vect)
TIMER1 COMPA	18	(TIMER1_COMPA_vect)	TIMER4 OVF	46	(TIMER4_OVF_vect)
TIMER1 COMPB	19	(TIMER1_COMPB_vect)	TIMER5 CAPT	47	(TIMER5_CAPT_vect)
TIMER1 COMPC	20	(TIMER1_COMPC_vect)	TIMER5 COMPA	48	(TIMER5_COMPA_vect)
TIMER1 OVF	21	(TIMER1_OVF_vect)	TIMER5 COMPB	49	(TIMER5_COMPB_vect)
TIMERO COMPA	22	(TIMERO_COMPA_vect)	TIMER5 COMPC	50	(TIMER5_COMPC_vect)
TIMERO COMPB	23	(TIMERO_COMPB_vect)	TIMER5 OVF	51	(TIMER5_OVF_vect)
TIMERO OVF	24	(TIMERO_OVF_vect)	USART2 RX	52	(USART2_RX_vect)
SPI STC	25	(SPI_STC_vect)	USART2 UDRE	53	(USART2_UDRE_vect)
USARTO RX	26	(USARTO_RX_vect)	USART2 TX	54	(USART2_TX_vect)
USARTO UDRE	27	(USARTO_UDRE_vect)	USART3 RX	55	(USART3_RX_vect)
USARTO TX	28	(USARTO_TX_vect)	USART3 UDRE	56	(USART3_UDRE_vect)
ANALOG COMP	29	(ANALOG_COMP_vect)	USART3 TX	57	(USART3_TX_vect)

Timer OC (non-PWM) Interrupt Example 1

❖ 5 kHz square wave, 50% duty cycle, IO frequency of 16 MHz.

```
#include <avr/io.h>
#include <avr/interrupt.h>
#define NN 200 // delay count to be used in OCOA compare operation
int main (void)
   DDRB |= 0x80; // configure OCOA pin for output
   TCCR0A = 0x40; // OC0A pin toggle on compare match
   TCCR0B = 0x02; // normal mode, clock source set to clkI/0÷8
   TIMSK0 = 0x02; // enable OCOA match interrupt
   TIFR0 = 0x02; // clear OCF0A flag
   OCROA = TCNTO + 10; // to avoid overflow
   sei();
             // enable interrupt globally
   while(1);
                          // wait for interrupt to occur
ISR(TIMER1 COMPA vect)
   OCROA += NN; // start the next OCOA compare with NN as delay count
```

Timer OC (non-PWM) Interrupt Example 2

- ❖ 50 Hz square wave, 75% duty cycle, assume I/O freq = 16 MHz.
- Use interrupts to signal OC match

13

```
void main (void)
   DDRB \mid = 0x20;
                            // configure OC1A pin for output
   TCCR1A = 0xC0; // OC1A pin pull high on compare match
   TCCR1B = 0x02; // normal mode, clock source set to clk_I/O/8
   TCCR1C = 0x80; // force OC1A pin to high
   TCCR1A = 0x40; // toggle
   OCR1A = TCNT1 + hiCnt; // start the first output compare operation
   HILO = 0;
   TIMSK1|= 0x02; // enable OC1A interrupt
   TIFR1 = 0x02;
                            // clear the OCF1A flag
   sei();
          // enable interrupt globally
   while(1);
                     // wait
```

Dr. Alsamman 14

15

Timer ICP Interrupt Example

- Measure the period of the signal connected to ICP1
- Solution: use polling method to detect edges, interrupts to detect overflow
 - Period = time_edge2 + OV*65536 time_edge1
 - Make time_edge1 = 0 by clearing TCTNT

```
#include <avr\io.h>
#include <avr\interrupt.h>
unsigned char tovCnt;
unsigned long period;

ISR (TIMER4_OVF_vect)
{ tovCnt++;
}
```

```
int main (void)
   tovCnt = 0;
                            // configure to normal mode
   TCCR4A = 0;
   DDRL = 0xFE;
                            // configure ICP4 pin for input (PL0)
   TIFR4 = 0x2F; // clear all flags related to Timer
   TCCR4B = 0x42;
                    // capture rising edge, presc = 8
   while(!(TIFR4 & 0x20));
                        // wait for the arrival of the 1st edge
   TCNT4 = 0;
                    // set TCNT=0 clear edge1 time
   TIFR4 = 0x21;
                         // clear ICF4 and TOV4 flags
                    // enable TOV interrupt
   TIMSK4 = 1;
   sei();
                         // enable interrupt globally
   while(!(TIFR4 & 0x20));
                        // wait for the arrival of the second rising edge
   TCCR4B = 0;
                    // stop Timer
   period = (unsigned long)tovCnt * 65536 + (unsigned long)ICR4;
   while(1);
```


Dr. Alsamman

17

External Interrupts


- Interrupt caused by an event received on INT7:0
 - ➤ INT0:4 connected to Port D pins 0:4
 - ➤ INT5:7 connected to Port E pins 5:7
 - Events: rising, falling, low level
- * Registers used to control EI:
 - > EICRA, EICRB: El control registers A, B
 - > EIMSK: EI mask register
 - > EIFR: EI flag register

EICRA, EICRB



- ❖ ISCn1: ISCn0: External interrupt 0-7 sense control (n = 0-7)
 - > 00 = The low level of INT**n** generates an interrupt request.
 - > 01 = Any edge of INTn generates an interrupt request.
 - ➤ 10 = The falling edge of INTn generates an interrupt request.
 - > 11 = The rising edge of INT**n** generates an interrupt request.

EIMSK, EIFR



- ❖ INTn: External interrupt request n enable (n = 0, ..., 7)
 - > 0 = External interrupt <u>n</u> is disabled.
 - 1 = External interrupt n is enabled.
- **❖ INTF**<u>n</u>: External interrupt flag (<u>n</u> = 0, ..., 7)
 - > 0 = External interrupt $\underline{\mathbf{n}}$ condition did not occur since last time this flag was cleared.
 - 1 = External interrupt n condition has occurred.


Example: External INT Interrupt

- Measure the frequency of a square signal connected to external INT pins.
- Solution
 - Connect signal to external INTO
 - ➤ INT0 for rising edges
 - Count rising edges
 - Configure INTO
 - DDRD = 0 (input, INT0 is PD0)
 - EICRA = 0b00000011 (INT0: detect rising edges)
 - EIMSK = 1 (INT0:1 enable)

```
#include <avr\io.h>
#include <avr\interrupt.h>
unsigned long long int freq=0; // 64 bit variable
int main (void)
   DDRD &= \sim(0x01); // PD0 Ext INT0 input
    EICRA = 0b00000011; // INTO rising edges(11)
              // INTO enable only
    EIMSK = 1;
    sei();
                     // global INT enable
    _delay_1ms(1000);
                    // wait 1 sec
    cli();
                      // disable INT globally
    while(1);
ISR (INTO_vect)
    freq++; }
```


Dr. Alsamman

External INT Example Simulation IDE



Simulation IDE: MCU Monitor


- Click on MCU Monitor
- Click on RAM tab
- Scroll to address 0x0200
- Data in little endian format
 - LSB first
 - > 0x00000000000EE03



Pin Change (PC)


- ❖ 24 PC pins that generate at interrupt when one or more pin(s) toggle
 - Toggle aka change from 1 to 0, or vice-versa
 - PC pin 0:7 are PB0:7
 - PC pin 8:15 are PE0, PJ0:6
 - PJ2:6 not connected on the board
 - PC pin 16:23 are PK0:7
 - PCINT0 interrupt: when any PC pins 7:0 toggle
 - PCINT1 interrupt: when any PC pins 15:8 toggle
 - PCINT2 interrupt: when any PC pins 23:16 toggle
- Registers to control PC:
 - PCMSK0,1,2:
 PC masks register 0,1,2
 - > PCICR: PC interrupt control reg
 - PCIFR: PC interrupt flags reg

PCICR




- PCIE2: PC interrupt enable 2
 - > 0 = PC interrupt 2 disabled
 - > 1 = PC interrupt 2 enabled (detects change on enabled PC pins 23:16)
- PCIE1: PC interrupt enable 1
 - > 0 = PC interrupt 1 disabled
 - > 1 = PC interrupt 1 enabled (detects change on enabled PC pins 15:8)
- ❖ PCIE0: PC interrupt enable 0
 - > 0 = PC interrupt 1 disabled
 - > 1 = PC interrupt 1 enabled (detects change on enabled PC pins 7:0)

PCIFR



- PCIF2: Pin change interrupt flag 2
 - > 0 = No change on PC pins 23:16.
 - 1 = At least one change on PC pins 23:16.
- PCIF1: Pin change interrupt flag 1
 - > 0 = No change on PC pins 15:8.
 - > 1 = At least one change on PC pins 15:8.
- ❖ PCIF0: Pin change interrupt flag 0
 - > 0 = No change on PC pins 23:16.
 - 1 = At least one change on PC pins 7:0.

PCMSK0,1,2



- ❖ PCINTn: Pin change enable mask (n = 23...0)
 - 0 = Disable interrupt on PC pin n
 - 1 = Enable interrupt on PC pin n (Must be set with PCICR)

28

PC Example

- Measure the frequency of a square signal using the PCINT.
- Solution:
 - Connect signal to PB0 (PC pin0)
 - > Setup: PORTB, PCMSK0, PCINT0, PCICR
 - Create a 1 sec delay in OC3.
 - Count the number of toggles
 - > Freq = number of toggles /2

```
#include <avr\io.h>
#include <util\delay.h>
#include <avr\interrupt.h>
long int edges=0, freq;
void main (void)
   DDRB &= !(0x01);
                              // configure PB0 (PC pin0) for input
   PCICR = 1; // PCINTO enable for PC pins 0:7
   PCMSK0 = 1;  // PC pin0 interrupt enable
   sei();
               // enable interrupt globally
   _delayby_1ms(1000); // wait for 1 second
   cli();
                  // disable interrupts
   freq = cnt/2;
   while(1);
ISR (PCINTO_vect)
   edges++;
```

Dr. Alsamman

Timer Example: Measure Frequency (non-ICP)

- Measure frequency of an unknown square signal connected to the T1 pin, assume 16 MHz IO clock. Don't use the ICP.
- Solution:
 - Set signal T1 as source for Timer 1
 - > Set Timer 3 to count delay for 1sec, using CPU cock source
 - Count T1 clock cycles in Timer 1 to get frequency

```
#include <avr\io.h>
#include <util\delay.h>
#include <avr\interrupt.h>
unsigned char tovCnt;
unsigned long freq;

ISR (TIMER1_OVF_vect)
{
   tovCnt++;
}
```

```
void main (void)
   tovCnt = 0;
   DDRD &= ~0x40; // configure T1 for input
   TCCR1A = 0; // configure Timer 1 to normal mode, no output
   TCCR1B = 0; // stop Timer 1
   TCNT1=0
   TIFR1 = 1; // clear TOV1 flag
   TIMSK1 = ; // enable TOV1 interrupt
   TCCR1B = 0x07; // enable Timer 1 to count using T1 input as clock source
              // enable interrupt globally
   sei();
   _delayby_1ms(1000); // wait for 1 second
   TCCR1B = 0; // stop Timer 1
   freq = (long)tovCnt * 65536 + (long)TCNT1;
   while(1);
```

Example: External INT Interrupt

- Measure the duty cycle of a square signal connected to external INT pins.
- Solution
 - Connect signal to external INT0 and INT1
 - ➤ INTO for rising edges (er), INT1 for falling edges (ef):
 - Detect 3 edges: 2 rising edges (period), 1 falling edge
 - Duty = (ON time)/period = (ef1 er0)/(er2 er0)
 - Configure INT0, INT1
 - DDRD = 3 (INT0:1: PD0:1)
 - EICRA = 0b00001011 (INT1: falling edges (10), INT0: detect rising edges (11))
 - EIMSK = 3 (INT0:1 enable)

```
#include <avr\io.h>
#include <avr\interrupt.h>
unsigned char tovCnt;
unsigned long int er0=0,er2=0,ef1=0;
int main (void)
    DDRD &= \sim (0x03); // PD0:1 Ext INT0:1 input
    EICRA = 0b00001011; // INTO rising edges(11), INT1 falling (10)
                 // INTO enable only
    EIMSK = 1;
    sei();
                            // global INT enable
    while(1);
ISR((INTO_vect)
     EIMSK = 2;
                            //enable INT1 only
```

Dr. Alsamman

36

PC Example 2

- Measure the frequency of a square signal using the PCINT. Use another signal to create a delay.
- Solution:
 - Connect input signal to PB0 (PC pin0)
 - Setup: PORTB, PCMSK0, PCINT0, PCICR
 - Connect a 0.5 Hz signal to PE0 to simulate a 2sec delay.
 - Period = 2s: rises in 1sec, falls in 1 sec
 - Count the number of toggles
 - Calculate frequency every edge
 - Freq = number of toggles

```
#include <avr\io.h>
#include <avr\interrupt.h>
long int edges=0,freq;
int main (void)
   DDRB &= 0xFE; // configure PB0 (PC pin0) for input
    PCICR = 3; // enable PCINTO for PC pins 0:7, PCINT1 for pins 8:15
    PCMSK0 = 1;  // PC pin0 interrupt enable
    PCMSK1 = 1; // PC pin8 interrupt
    sei();
   while(1);
ISR (PCINTO_vect)
   edges++;
ISR (PCINT1_vect)
   freq = edges;
   edges= 0;
```

Dr. Alsamman