Trust

What it is and how to get it

Dr. Perry Alexander

Information and Telecommunication Technology Center
Electrical Engineering and Computer Science
The University of Kansas
palexand@ku.edu



What is Trust?

"An entity can be trusted if it always behaves in the expected manner for the intended purpose" 1



¹ The Ten Page Introduction to Trusted Computing by Andrew Martin

Properties of Trust

- Unambiguous identification
- ▶ Unimpeded operation
- ► First-hand observation of good behavior *or* indirect experience of good behavior by a trusted third party



Required Capabilities for Establishing Trust

- ► Strong Identification An unambiguous, immutable identifier associated with the platform.
- Reporting Configuration An unambiguous identification mechanism for software and hardware running on the platform.
- ► Reporting Behavior A mechanism for observing and reporting execution behavior.



Tools for Trust

- #X Hash of X
 - ▶ #X is unique for each X
 - ▶ Guessing *X* from #*X* is impossible
- ▶ ${X}_Y$ Encrypt X with Y
 - ➤ X cannot be obtained from {X}_Y without Y
 - ► Guessing X from {X}_Y is impossible
 - Guessing Y is impossible
- ▶ $[X]_{Y^{-1}}$ Sign X with Y^{-1}
 - ▶ $[X]_{Y^{-1}}$ is unique for every X and Y^{-1} pair
 - ► Guessing [X]_{Y-1} from X is impossible
- ► M | #X Extend M with #X
 - ▶ Concatenate M with #X and hash the result
 - ▶ Ideal M | #X unique for M and X



Tools for Trust

- $(X, \{X^{-1}\}_{Y^{-1}})$ Wrap X with Y^{-1}
 - ► Can use *X* for encryption and signature checking
 - ► Cannot use X^{-1} for decryption or signing without Y^{-1}
- ▶ $(D, \{C\})$ Seal D to configuration C
 - ▶ D is not available if system is not in configuration C
 - Usually accompanied by encryption
- ▶ $({SK}_K, {D}_{SK})$ Envelope D with K
 - ► Encrypt large data *D* with session key *SK*
 - ► Encrypt SK with K
 - D behaves as if encrypted with K
- ► $[[(A, B)]]_{Y^{-1}}$ Certify binding of A and B with Y^{-1}
 - ▶ Y signs (A, B) with private key Y^{-1}
 - Certificate is checked using Y
 - ▶ Valid signature provides evidence *A* and *B* are bound together



Wrapping and Chaining Keys

Wrapping A Key

$$wrap(X, Y) = (X, \{X^{-1}\}_{Y^{-1}})$$

- $ightharpoonup X^{-1}$ is encrypted with Y^{-1} while X is clear
- $\{D\}_X$ and checking $[D]_{X^{-1}}$ may be done without Y
- ▶ Decrypting $\{D\}_X$ and generating $[D]_{X^{-1}}$ require Y

Chaining Keys

$$(X_0, \{X_0^{-1}\}_{X_1^{-1}}), (X_1, \{X_1^{-1}\}_{X_2^{-1}}) \dots (X_{n-1}, \{X_{n-1}^{-1}\}_{X_n^{-1}})$$

- ► Each key depends on the previous key
- ► If the root key is trustworthy the chain is trustworthy



Sealing Data

Sealing to State

 $(D, \{C\})$ — Seal D to configuration C

- ► *D* is protected by a key or other mechanism
- ► C describes an acceptable system state
- ► D cannot be accessed if system is not in state C
- Used to protect data even when system is mis-configured



Enveloping Data

Enveloping

$$envelope(K, D) = (\{SK\}_K, \{D\}_{SK})$$

- ► *SK* is a symmetric session key for bulk encryption
- ► *D* is encrypted with *SK*
- ► *SK* is encrypted with *K*
- ▶ D is protected as if encrypted with K



Certificates

Certificates and Certification

$$[[(A,B)]]_{Y^{-1}} = [(A,B)]_{Y^{-1}}$$

- ► (A, B) associates A with B
- Y certifies the association by signing with Y⁻¹
- ► Certificate is checked using Y
- ▶ If we trust *Y*, then we trust the binding of *A* to *B*



We would like to start A and B while gathering evidence for determining trust


Start with a root measurer and store that are trusted a priori

Trusted Store

Trusted Measurer




- Start with a root measurer and store that are trusted a priori
- Measure the new software to be launched






- Start with a root measurer and store that are trusted a priori
- Measure the new software to be launched
- Store the measurement of the new software






- Start with a root measurer and store that are trusted a priori
- Measure the new software to be launched
- Store the measurement of the new software
- Launch the new software






- Start with a root measurer and store that are trusted a priori
- Measure the new software to be launched
- Store the measurement of the new software
- Launch the new software
- Repeat for each system software component





We would like to start A and B while gathering evidence for determining trust

- Start with a root measurer and store that are trusted a priori
- Measure the new software to be launched
- Store the measurement of the new software
- Launch the new software
- Repeat for each system software component



Trusted

Measurer



Appraisal — What Do We Know?

Measurement \neq trust — Measurements must be appraised

- ► Determine if 0 | #A | #B is correct
 - ► Calculate a *golden hash* from A and B
 - ► Compare golden hash with 0 | #A | #B from trusted store
 - ► Correct 0 | #A | #B implies trusted boot
- ► Correct 0 | #A | #B implies A and B must be correct
 - ► Correct 0 | #A | #B implies #A and #B are the correct hashes
 - ► Correct #A and #B implies A and B are the correct binaries
 - A includes hash and launch functions
- ► Correct 0 | #A | #B implies measurement occurred in the right order
 - $\blacktriangleright \#(XY) \neq \#(YX)$
 - Trusted store started with 0



Appraisal — But Why Trust B?

A chain exists from the Trusted Measurer and Trusted Store to B

- ► Trusted Measurer and Trusted Store are trusted a priori
- ▶ A is trusted to be A because its measurement is:
 - ▶ Correct
 - Taken by a trusted party (Trusted Measurer)
 - Stored by a trusted party (Trusted Store)
- ▶ B is trusted to be B because its measurement is:
 - ▶ Correct
 - Taken by a trusted party (A)
 - Stored by a trusted party (Trusted Store)
 - If A's ability to measure B were compromised, #A would be wrong
- ▶ and so on and so on...



Trust is a Preorder

 $T^{x}[y]$ is an homogeneous relation over actors that is true when x trusts y. $T^{x}[y]$ is by definition a preorer:

- ▶ Reflexive $\forall x \cdot T^{x}[x]$
- ► Transitive $\forall x, y, z \cdot T^{x}[y] \land T^{y}[z] \Rightarrow T^{x}[z]$

Measured Boot gathers evidence to check trust relationships.



Trust is a Preorder

A *chain of trust* from X_0 to X_n :

$$\mathcal{T}^{X_0}[X_1] \wedge \mathcal{T}^{X_1}[X_2] \wedge \ldots \wedge \mathcal{T}^{X_{n-1}}[X_n]$$

- ▶ If X_0 is trusted, then X_n is trusted
- ► X₀ is called a root-of-trust
- ► Establishing trust chains defines a framework for measurement
- Measurement provides evidence that trust chains are not violated
- ► Appraisal checks evidence to assess trust chains



Trusted Platform Module

The *Trusted Platform Module (TPM)* is a cryptographic coprocessor for trust.

- ► Endorsement Key (EK) factory generated asymmetric key that uniquely identifies the TPM
- ► Attestation Instance Key (AIK) TPM_CreateIdentity generated asymmetric key alias for the EK
- Storage Root Key (SRK) TPM_TakeOwnership generated asymmetric key that encrypts data associated with the TPM
- Platform Configuration Registers (PCRs) protected registers for storing and extending hashes
- ► NVRAM Non-volatile storage associated with the TPM



Endorsement Key

- Asymmetric key generated at TPM fabrication
- $ightharpoonup EK^{-1}$ is protected by the TPM
- ► EK by convention is managed by a Certificate Authority
 - ▶ Binds *EK* with a platform
 - Classic trusted third party
- Only used for encryption
- Attestation Instance Keys (AIK) are aliases for the EK
 - Used for signing
 - Authorized by the EK



Storage Root Key

- ► Asymmetric key generated by TPM_TakeOwnership
- ► *SRK*⁻¹ is protected by the TPM
- ► SRK is available for encryption
- ► Used as the root for chaining keys by wrapping
 - A wrapped key is an asymmetric key pair with it's private key sealed
 - Safe to share the entire key
 - Only usable in the presence of the wrapping key with expected PCRs



Platform Configuration Registers

Operations on PCRs

- Extension Hash a new value juxtaposed with the existing PCR value
- ► Reset Set to 0
- Set Set to a known value

Operations using PCRs

- Sealing data PCR state dependent encryption
- Wrapping keys PCR state dependent encryption of a private key
- Quote Reporting PCR values to a third party

Properties

- Locality Access control like OS security rings
- Resettable PCR can be reset to known value after SENTER
- Many others that we don't need yet



Resetting PCRs

Non-Resettable

- History since reboot
- ► Reset only on reboot
- Good for recording trajectory

Resettable

- No history
- Reset before use
- Good for one-off user data
- Reset requires appropriate permissions based on locality
- ► A PCR is resettable if defined in platform spec



Locality

Locality = Access Control for PCRs

- ► Each PCR is assigned a locality
- Only processes with locality greater than or equal a PCR's locality may modify it
- ► Increases monotonically starting at SENTER invocation

Locality and What Runs There

Locality	Purpose
4	Trusted Hardware/SINIT Policy
3	Other MLE Components
2	Operating System
1	Applications Static
0	RTM/Legacy



Locality Rules of Thumb

- ► Only SENTER runs in locality 4
- ► Only SINIT runs in locality 3
- ▶ OS and core system run in locality 2
- Applications run in locality 1
- ► Locality 0 is rarely used



Roots of Trust

A *root of trust* provides a basis for transitively building trust. Roots of trust are trusted implicitly.

There are three important Roots of Trust:

- ► Root of Trust for Measurement (RTM)
- ► Root of Trust for Reporting (RTR)
- Root of Trust for Storage (RTS)



Root of Trust for Measurement

A *Root of Trust for Measurement* is trusted to take the base system measurement.

- ► A hash function called on an initial code base from a protected execution environment
- Starts the measurement process during boot
- ► In the Intel TXT process the RTM is SENTER implemented on the processor



Root of Trust for Reporting

A *Root of Trust for Reporting* is trusted to guarantee the integrity of the base system report or quote

- ► A protected key used for authenticating reports
- In the Intel TXT processes this is the TPM's Endorsement Key (EK)
- Created and bound to its platform by the TPM foundry
- ► EK⁻¹ is stored in the TPM and cannot be accessed by any entity other than the TPM
- ► EK is available for encrypting data for the TPM
- $ightharpoonup EK^{-1}$ is used for decrypting data inside the TPM
- ► Linking *EK* to its platform is done by a trusted Certificate Authority (CA)



Root of Trust for Storage


A Root of Trust for Storage is trusted to protect stored data

- ► A key stored in a protected location
- ► In the Intel TXT boot process this is the TPM's Storage Root Key (SRK)
- Created by TPM_TakeOwnership
- ► SRK⁻¹ is stored in the TPM and cannot be accessed by any entity other than the TPM
- SRK is available for encrypting data for the TPM
- SRK is used for protecting other keys



Roots of trust are used to build a trusted system from boot.

► Power-on reset









Roots of trust are used to build a trusted system from boot.

- ► Power-on reset
- ▶ Resettable PCRs set to -1









Roots of trust are used to build a trusted system from boot.

- ▶ Power-on reset
- ▶ Resettable PCRs set to -1
- SENTER called, resets resettable PCRs to 0








Roots of trust are used to build a trusted system from boot.

- ► Power-on reset
- Resettable PCRs set to -1
- SENTER called, resets resettable PCRs to 0
- ► SENTER measures SINIT policy into PCR 18





What We Know From Good PCR 18

A good value in PCR 18 tells us:

- ► SENTER was called Resetting PCR 18 starts measurements at 0 rather than -1
- ► SINIT was measured by SENTER Only SENTER can extend PCR 18
- SINIT uses the correct policy PCR 18 is extended with SINIT measurement policy
- ▶ SENTER ran before SINIT was measured $A \mid B \neq B \mid A$


Measurement \neq Trust

Measurements must be appraised to determine trust.



Two Steps from Roots of Trust


- SINIT measures the Measured Launch Environment (MLE) using measured SINIT policy
- ► SINIT returns control to SENTER





Two Steps from Roots of Trust

- SINIT measures the Measured Launch Environment (MLE) using measured SINIT policy
- ► SINIT returns control to SENTER
- ► SENTER invokes the MLE





What We Know From Good PCRs

- ► SENTER was called Resetting PCR 18 starts measurement sequence at 0 rather than -1
- ► SINIT policy was measured by SENTER Only SENTER can extend PCR 18
- ► SINIT uses the correct policy PCR 18 is extended with SINIT measurement policy
- ▶ SENTER ran before SINIT $0 \mid \#SINIT \neq -1 \mid \#SINIT$
- ► MLE is good Measured by good SINIT into PCR

Boot is generic until the MLE starts

MLE is the beginnings of the operating system.



► SENTER starts the MLE


- SENTER starts the initial image
- Initial image starts the system

initial image

Operating System

kernel file system drivers run-time trust applications


TPM





► SENTER starts the MLE

- SENTER starts the initial image
- Initial image starts the system
- Initial image initialized the kernel
 - Measures the kernel into the TPM
 - Starts the kernel





► SENTER starts the MLE


- SENTER starts the initial image
- Initial image starts the system

Initial image initialized the kernel

- Measures the kernel into the TPM
- Starts the kernel

Kernel boots the system

- Measures remaining images into the TPM
- Starts remaining images
- Measures application into the TPM
- Starts the application



► SENTER starts the MLE


- SENTER starts the initial image
- Initial image starts the system

Initial image initialized the kernel

- Measures the kernel into the TPM
- Starts the kernel

Kernel boots the system

- Measures remaining images into the TPM
- Starts remaining images
- Measures application into the TPM
- Starts the application



RMATION ECOMMUNICATION NOLOGY CENTER

What we know from good PCRs

Built from Good Parts

We can construct a proof that the platform is constructed correctly from PCR contents

- ► SINIT measured the right initial image PCR 18 measurement and we trust SENTER
- ► The right initial image started PCR 17 measurement and we trust SENTER, SINIT and SINIT Policy is measured
- ► The right kernel started PCR 19 measurement and we trust SENTER, SINIT, and initial image is measured
- ► The right system components started PCRs and the kernel is measured
- The right application started TPM PCRs and the kernel is measured

Chaining Trust (Reprise)

▶ Trust is transitive

- $ightharpoonup T^{x}[y] \wedge T^{y}[z] \Rightarrow T^{x}[z]$
- Construct evidence trust chains
- Remember "directly observed or indirectly observed by a trusted third party"
- Roots of Trust define the "root" for trust
 - Use Roots of Trust to establish base for chain
 - ► SENTER/SINIT is the Trusted Measurer
 - SRK and TPM is the Trusted Storage Root (Unused so far)
 - ► EK and TPM is the Trusted Reporter (Coming next)
- ► Extend chains of trust by measuring before executing



Getting a Quote

A *quote* is a signed data package generated by a TPM used to establish trust

- ▶ $q = [\langle n, pcr \rangle]_{AIK^{-1}}$
 - ▶ n A nonce or other data
 - pcr A PCR composite generated from TPM PCRs
 - ► AIK⁻¹ An alias for EK⁻¹ used for signing instead of EK⁻¹
- ► Generated by the TPM with command TPM_Quote



Attestation Identity Key

An AIK is A wrapped TPM key bound to an EK^{-1} usable only in the TPM that generated it in the right state

- ► $\{(AIK^{-1}, \{pcr\})\}_{EK^{-1}}$ the AIK^{-1} encrypted with EK^{-1} and sealed to pcr values.
- $\{(AIK^{-1}, \{pcr\})\}_{EK^{-1}}$ decrypts and installs only when
 - pcr matches the TPM's PCRs at decryption time
 - \triangleright EK⁻¹ is the TPM's endorsement key
- Protected by a combination of encryption and state
- Generated by a TPM



Appraising a Quote

Given *q* of the form:


$$q = [\langle n, pcr \rangle]_{AlK^{-1}}$$

- 1. Signature check using AIK verifies authenticity
 - Signature was generated by a TPM with AIK installed
 - ► Appraiser must know *AIK*
- 2. pcr check verifies built from good parts in the right order
 - ► Compare PCR composite to known good PCR composite
 - Composite generated from desired golden PCR values
- 3. Nonce check guarantees freshness
 - Nonce is random and known to the appraiser
 - Sent to the target during appraisal



Assume a trusted Certificate Authority (CA) that maintains links from ID to *EK* with well-known public key *CA*

► *ID_n* requests *AIK* certification from CA








Assume a trusted Certificate Authority (CA) that maintains links from ID to *EK* with well-known public key *CA*

- ► ID_n requests AIK certification from CA
- ► CA signs AIK with CA⁻¹




Attestation

Appraiser



Assume a trusted Certificate Authority (CA) that maintains links from ID to *EK* with well-known public key *CA*

- ► *ID_n* requests *AIK* certification from CA
- ► CA signs AIK with CA⁻¹
- ► CA encrypts [AIK]_{CA-1} with ID_n's EK_n




Appraiser



Assume a trusted Certificate Authority (CA) that maintains links from ID to *EK* with well-known public key *CA*

- ► ID_n requests AIK certification from CA
- ► CA signs AIK with CA⁻¹
- ► CA encrypts [AIK]_{CA-1} with ID_n's EK_n
- ► CA sends {[AIK]_{CA-1}}_{EK_n} to ID_n




Appraiser



Assume a trusted Certificate Authority (CA) that maintains links from ID to *EK* with well-known public key *CA*

- ► *ID_n* requests *AIK* certification from CA
- ► CA signs AIK with CA⁻¹
- ► CA encrypts [AIK]_{CA-1} with ID_n's EK_n
- ► CA sends $\{[AIK]_{CA^{-1}}\}_{EK_n}$ to ID_n
- ► ID_n decrypts encrypted AIK with EK_n⁻¹








Assume a trusted Certificate Authority (CA) that maintains links from ID to *EK* with well-known public key *CA*

- ► *ID_n* requests *AIK* certification from CA
- ► CA signs *AIK* with *CA*⁻¹
- ► CA encrypts [AIK]_{CA-1} with ID_n's EK_n
- ► CA sends $\{[AIK]_{CA^{-1}}\}_{EK_n}$ to ID_n
- ► ID_n decrypts encrypted AIK with EK_n⁻¹
- ► ID_n sends $[AIK]_{CA^{-1}}$ to appraiser







Why Believe AIK Belongs to ID_n ?

Cryptographic evidence ensures AIK is an alias for the right EK

- ► Only the CA can generate [AIK]_{CA-1}
- ► CA is trusted to know $ID_n \to EK_n$
- ► CA is trusted to generate $\{[AIK]_{CA^{-1}}\}_{EK_n}$
- ▶ Only ID_n can decrypt {[AIK]_{CA-1}}_{EK_n}
- ► Appraiser can check [AIK]_{CA-1} to ensure use of trusted CA
- ► If Appraiser can use AIK then it was decrypted by ID_n

AIK is now a certified alias for EK used for signing



Using Protocol Notation

Protocol notation specifies communication:

Sender
ightarrow Receiver : Messsage

Key Certification Protocol

$$ID_n \rightarrow CA : AIK$$
 $CA \rightarrow ID_n : \{[AIK]_{CA^{-1}}\}_{EK_n}$
 $ID_n \rightarrow App : [AIK]_{CA^{-1}}, [\langle n, pcr \rangle]_{AIK^{-1}}$

$$(1)$$



Remote Data Acquisition

Boot and appraise remote system for covert data acquisition

- Target reset triggers target boot initialization
- Target initial boot goes through BIOS and device startup
- Target secondary boot establishes comm link and "phones home"
- Appraiser evaluates target
- Appraiser responds to target with OS image
- ▶ Target boots OS image
- Target begins operation
- Appraiser evaluates target
- ► Target begins data acquisition and transmission



Assumptions

General assumptions:

- Nonces, keys and hashes cannot be guessed
- Perfect cryptography
- All messages are carried by the adversary

System specific assumptions:

- Secure communication subsystem is trustworthy
- Target knows what to communicate with
- ▶ TPM present on the target
- AIK is established and certified prior to system launch



Designing A Trusted System

What assets should be protected and how?

- What assets must be handled confidentially?
- What assets must be handled with integrity?
- What assets and behaviors must be appraised?
- What behaviors must be prevented?

Some initial observations:

- Initial boot software integrity, must be appraised
- Communication addresses confidentiality
- Hardware and tamper protections integrity, must be appraised
- Operating system integrity, must be appraised
- Data transmission key confidentiality



Trust is:

- ► Strong identification
- Direct observation of good behavior
- ► Indirect observation of good behavior by a trusted third party

Late Launch is:

- Initial measurement taken and stored by roots of trust for measurement and storage
- Reporting performed by root of trust for reporting
- Trust chains transitively from roots of trust outward
- System is constructed of good parts



Roots of Trust

- Root of trust for measurement
 - SENTER for launch
 - Initial measurement taken by SINIT
 - ► Hardware-based TPM initialization
- ► Root of trust for storage
 - ▶ TPM storage root key (SRK)
 - Locality enforcement
 - TPM separation
- Root of trust for reporting
 - ► TPM endorsement key (EK)
 - TPM separation



Initial Design Decisions

Design Decisions

- ▶ What are measurement responsibilities?
- ▶ What is in the MLE?
- ▶ Where are measurements stored?
- ► How is locality assigned?



Measurement Responsibilities

- SENTER measures SINIT policy
- ► SINIT measures the Measured Launch Environment (MLE)
- ▶ Initial boot measures hardware and Secondary boot software
- Secondary boot measures OS
- ▶ OS measures components as they start

Measurement Relation

$$\mathtt{SENTER} o \mathtt{SINIT} o \mathtt{MLE} o \mathtt{OS} o \mathtt{app}$$

- ▶ No measurement loops
- ► Everything is measured



Traditional Measurement Storage

PCR	Contents
0–15	Static RTM
16	Debug
17	Locality 4 measurements by SENTER
18	Locality 3 measurements by SINIT
19	Locality 2 measurements by MLE and OS
20	Locality 1 measurements by applications
21–22	T/OS controlled
23	Application specific measurements

Need a PCR?

- ► Available non-resettable PCRs are 8-15
- ► Available resettable PCRs are 16,23



What is in the MLE?

- ► Anything measured by SINIT is in the MLE by definition
- ► MLE could be the initial boot image or the entire boot image
- ► How much granularity desired in measurements?

What is in the MLE?

- ► Initial boot image
- ► Nothing more



Where Are Measurements Stored?

- ▶ Initial measurement storage location is standard
- ► Typically 1 hash per measurement, but could be a sequence

PCRs 17 and 18

- ► SINIT Policy measured by SENTER into PCR 17
- ► MLE Measured by SINIT into PCR 18
- ► PCRs 17 & 18 are non-resettable



Where Are Measurements Stored?

- ► Later measurements must be designed
- ► One big hash, many hashes, one PCR, many PCRs

PCRs 19 and 20

- ▶ OS measured into PCR 19
- ► Application(s) measured into PCR 20



What are the Measurements?

- Measure the OS
 - OS measured as one hash
 - OS measured as a hash sequence by the OS startup
- Applications measured as one hash each
- Ordering application measurement?
 - Enforce application hash order by sequencing startup
 - ▶ Use multiple PCRs
 - Produce multiple good hashes in appraiser
- ▶ Measurement *must* be performed as components are started



Measurement Options and Appraisal

Measurement granularity

- One hash says good or bad for all system binaries and is simple to take
- Many hashes extending a PCR says good or bad for all system binaries including order

▶ One or Many PCRs

- One PCR says good or bad for all system binaries with order
- Many PCRs says good or bad for individual system binaries without order

▶ Resettable or Non-Resettable

- Resettable ignores history prior to reset
- Non-resettable captures history from system startup



Where are Measurements Stored? (Redux)

- ▶ Poky Linux is measured as one hash into PCR 19
 - Need to know good or bad on startup
 - Using Poky Linux unmodified
- ► Application is measured as one hash into PCR 20
 - Need to know good or bad on startup
 - Only one application

PCRs 19 and 20

- ► OS measured into PCR 19 by secondary boot prior to start
- ► Application(s) measured into PCR 20 by OS prior to start



How is Locality Assigned?

- No reason to deviate from standard locality mapping
- ► No reason to reset PCRs

Locality Assignment

- ► PCR 17 Locality 4, non-resettable
- ► PCR 18 Locality 3, non-resettable
- ▶ PCR 19 Locality 2, non-resettable
- ► PCR 20 Locality 1, non-resettable



What The Appraiser Knows

- On initial measurement after startup
 - ▶ 0x00..0 | #SINITPolicy SENTER and SINIT ran
 - ▶ 0x00..0 | #MLE SINIT measured the MLE
 - MLE was correct on startup
- ► On measurement after application startup
 - 0x00..0 | #0S OS was correct on startup and was started by MLE
 - ► 0x00..0 | #app Application was correct on startup and was started by OS

Trusted ≠ Secure

- The Appraiser knows what it is talking to
- ► Nothing is protected

