


Mimio MyBot Base Kit Building Instructions








Base Kit Build Instructions

Use these step-by-step instructions to assemble the MyBot Base Kit robot from the components shown above (and detailed on the following pages). These instructions will allow you to add the optional *Planetary Exploration Add-on Pack* to your Base Kit robot in the future.

Copyright 2018-2020, Boxlight Robotics, All Rights Reserved No part of this document may be copied, published in print or shared online or otherwise publicly released without the express written consent of Boxlight Robotics.

Note: Specifications listed are subject to change without notice.

Illustrated List of Components Needed



11-4116

M4 x 16mm Screw

45-1300

6V Battery Pack

08-0007

Axle Hub

Illustrated List of Components Needed













X1 15-0016 Box for Spare Fasteners






































8 x2 x2




























































15 – Wiring

