

UDP/TCP RTU 8051 + W5500

Summary:

The goal of this project is the design of a simple UDP/TCP responder. An STC89/STC12 on a demo board will handle SPI transmissions between itself and a WIZNET LAN development board; it will also be connected via serial terminal to a laptop that will be used to configure parameters such as port and IP.

Required Components:

- WIZnet board (W5500)
- STC89/STC12 Demo Board or 8051 based chipset
- Wires/Transmission support equipment
- 2 LED diodes

Procedure:

Research and locate data sheets for all of the components above.

- 1. In your linux distro, install SDCC, and use python pip3 to install stcgal
 - Here are 2 different examples of ways to write data to the MCU:
 - O Using a make file: make && stcgal -p /dev/ttyUSB0 -P stc89 -a main.ihx
 - O Using sdcc: sdcc stcboot.c i2c.rel lcd_1602.rel pcf.rel && stcgal -P stc89 stcboot.ihx
 - Read STCgal Documentation

CP: bit-banging - Bit Banging Project 5 - Wiznet UPD and TCP Responder - Ver. 1 (02/05/2024)

To get the chip into 6T Mode. Change stcgal options to include cpu_6t_e	nabled=true
O Make sure to set the chip into 6T mode (6 Clock)	
Part 1 done on 5/4 ● When using sdcc use –model-smallmodel-small implemented 2. Set-up an SPI Protocol and Serial Communication	
Set up Serial Communication Serial Communication Done	
O Read data from Serial interface	
O Display data to Serial interface	
 Set up basic SPI communication functionality in C SPI Communication we	orks
O Set up WIZnet communication using previously developed SPI	
■ Read/Write to WIZnet	
■ Set SOCKETS for WIZnet (UDP/TCP) Wo	rks
 Set WIZnet registers for IP Add, MAC, Port, Subnet, and C Verify Ethernet Connectivity via Ping or similar 	Jateway
 3. Set up WIZnet and Demo Board to receive UDP packets UDP Packets via ether Using the Ethernet functionality O Setup STC89 functionality to be able to read/write UDP packets 	net done
■ Be able to read from RX buffer	
■ Be able to write to TX buffer Verified through rx_tx_test	
 Verify functionality using PacketSender or similar Create Python Script to send/receive UDP packets Need to be tweaked O Protocol for Packets 	
Sending messages should follow the format of ":<#messages	ge>''
 Where # is a RTU address 0-9 Where message is any characters a-z 	This is done
 Receiving messages should follow the format of ":[#MESS Where # is the address of the RTU replying 	
 Where MESSAGE is an echo of message but all up Configure STC89 to receive/return packets 	percase
 Confirm if RTU has the specified address 	
 Confirm that message is in correct format 	
 Return message in proper format with address of RTU 	
4. Configure Serial Communication to change WIZnet Network configuration	
• '?' will bring up Config Menu Fixed	
O Set/Change RTU Address (0-9): USING RTU=	
O Set/Change IP Address: USING IP=	
O Set/Change Subnet Mask: USING SUB=	
O Set/Change Gateway: USING GATE=	

O Set/Change MAC Address: USING MAC=
• To change any of the above use the following format as an examples:
O RTU=# (0-9) O IP=###.###.### -> IP=192.168.16.111
SUB= and GATE= follow the same formatMODE= UDP or MODE=TCP
O MAC=0f0f0f0f0f0f
5. Replicate UDP functionality in TCP
Add TCP functionality to STC89 O Keep all some formatting and functionality as LIDP made.
 Keep all same formatting and functionality as UDP mode Add TCP functionality to Python Script
O Let user change connection mode
O Keep all same formatting and functionality as UDP mode
6. Combine UDP and TCP
 Create an implementation where UDP and TCP can be polled simultaneously form the python script. Polling together at the same time from script is not done yet
python script. Polling together at the same time from script is not done yet
7.LEDS/Python Curses
 Add 3 LEDs to the STC89 Demo Board Done
O TX LED, shows response activity
O RX LED, shows receive activity
 Add Curses to your python script For this the layout should show the following: Everything below this, is not done
There is something wrong with pycurses script
■ The received packet
■ Errors
 Last message received
■ Current mode
■ Prompt same as before
Also the PING command should now poll until the user terminates the command Make this run as fast as possible.
O Make this run as fast as possibleO These polls will follow similar format as used before
■ The message should be random number of characters (a-z) between 8-16
O Use a logic analyser and an output pin to measure the response time of the
WIZnet
 Set pin high when you get message and low after you sent the response

- Document the response time
 - This should not be more than \sim 250 ms
- Add a Report function that will poll 100 times and generate a text file:
 - O Max Non-Error Response Time
 - O Min Non-Error Response Time
 - O Number of errors
 - Log reason of error (i.e) timeout or incorrect response

8. Interrupt Driven Polling

- Polling the STC 8051 should be done via W5500 interrupts. Wake up the board via interrupt before starting to listen for packets, to reduce the load on the chip.
- Read the Wiznet W5500 Datasheet to learn more about interrupts driven polling.


9. SPI Assembly Rewrite

- After completing and testing all points above, rewrite the SPI code into assembly for further optimization
 - O After this test all components for correct functionality
 - O Make this run as fast as possible with little to no delays
 - O Use a logic analyser and an output pin to measure the response time of the WIZnet
 - Set pin high when you get message and low after you sent the response
 - Document the response time
 - This should not be more than ~150 ms
- Compare results of C version of SPI to ASM version of SPI


10. Documentation

- Document the speed comparisons of C version of SPI and ASM version of SPI and fingerprint the performance with logic analyzer and other tools.
- Include Graphs of Data Transfer Speed, and Network latency between both versions of SPI.

Example Graph:



Example of Serial Menu Lay



Example of Python Curses Menu:

