

Application-Driven Power Management for Deeply Embedded Systems

Arliones Stevert Hoeller Jr Lucas Francisco Wanner Antônio Augusto Fröhlich*

http://www.lisha.ufsc.br/

August 2006



Deeply Embedded Systems (DES)

Application-specific, tiny devices with resource limitations

8-bit, 3-4 Mhz microcontrollers

Small data and program memories

Several peripherals

Battery = System Lifetime





Power management Infra-structure

- Hardware support for power management
 - Operating modes (CPU, UART, ADC, etc)
 - Frequency and voltage scaling
 - Event counters
- Power management standards: APM and ACPI
 - At the Hardware/Software interface
 - Too complex for DES
- Deeply embedded systems solutions
 - Context-specific
 - Partial hardware coverage
 - Compromise application portability



Power-awareness in DES

- DES "Operating Systems"
 - Simplistic HALs
 - No or few high-level abstractions
 - Power management targeted at the CPU
 - Power state transitions implemented by APP
- DES Energy-Awareness
 - Contestable energy efficiency
 - Peripherals often consume more than peripherals
 - Compromised portability
 - Hardware details exposed to applications



Proposal

- Application-Driven Power Management
 - Uniform PM API (software and hardware)
 - Including high-level abstractions
 - Hierarchical state transitions propagation
 - Formalized trough Petri Nets
 - Static-metaprogrammed implementation
 - No unnecessary overhead
 - Example

```
file.power(OFF);
communicator.power(OFF);
display.power(ON);
```



Power management API

Interface is simple and uniform

```
power(Mode s)
Mode power()
```

- Configurable operating modes
 - Components export all operating modes
 - Application programmer binds real operating modes to "label" modes

```
[FULL | LIGHT | STANDBY | OFF]
```




Power State Transition Propagation

- Components are hierarchically organized
- Application programmer sees high-level abstractions (e.g., Thread, File, Alarm, Temperature_Sensor)
- Operating mode transition messages are propagated throughout components following a static dependency nets



Accessing the API






Operating Mode Transition Nets

- Formalized through Petri Nets
- Define conditions to transitions
- Organized to represent the proposed power state transition mechanism
- Generalized transition structure
 - OFF, STANDBY, LIGHT, FULL
 - Finite reachability graph => state analysis




Generalized Transition Net




* the full version covers all operating modes







Shared Dependencies



- Solution
 - Reference counter for each operating mode
 - Component stays in the highest operating mode which has "users"

$$P_{j} = \sum_{i=1}^{0} opmode_{i}$$

- j is the wanted mode
- opmode is the set of counters
- If Pj = 0 then j is entered




Implementation

- Application-Oriented System Design
 - Domain Engineering methodology
 - Components + Aspects + Frameworks

- Power Management API
 - Power management is a non-functional feature of computing systems [Lohmann, 2005]
 - This interface was modeled as an Aspect Program implemented using C++ metaprogramming techniques



Power Manager Aspect






Source Code Example

```
#include <system.h>
#include <sensor.h>
#include <uart.h>
#include <alarm.h>
using namespace System;
System sys;
Temperature_Sensor sensor;
UART uart;
void alarm_handler() { uart.put(sensor.sample()); }
int main() {
    Handler_Function handler(& alarm_handler);
    Alarm alarm(1000000, & handler);
    while(1) {
        sys.power(STANDBY);
```



Power Consumption in Example

- Hardware
 - STK-500, ATMega16, 10 KΩ Thermistor



- Software
 - EPOS (System, Alarm, UART, Temp_Sensor)

Consumption: 3.96 J

38.1 % less energy

Consumption: 2.45 J

hlich (http://www.lisha.ufsc.br)



Conclusion

- Application-Driven power management on deeply embedded systems
 - Without excessive overhead
 - Platform-independent (application portability)
- Uniform API
 - Configurable operating modes
 - On high-level abstractions
 - Easier application programming
- Supports a dynamic manager ...



Complex example

```
MP3 Player player;
Display display;
//...
void main() {
  //...
  char * file name = select file();
  display.power(LIGHT);
  play_file(file_name);
  //...
//...
void play_file(char * file_name) {
  File file(file_name);
  player.load(file);
  file.power(OFF);
  player.play();
```