


## A way to calibrate a magnetometer

Dec 6, 2015

My first contact with a digital magnetometer dates back to the summer of 2009. At that time, as many *arduinoers*, I was more concerned about coding the I2C/SPI driver other than understanding the device itself. A few months later I got an iPhone 4 and realized that the compass application, which used the internal phone magnetometer, required calibration every time it had to be used. And so, I became interested on why was this step required and how can it be done. In this post I will try to explain, together with a practical example, a way to do it. It is in essence the method described here, but with some more details and references.



A digital triple-axis magnetometer sold nowadays. Source: Sparkfun (CC-BY-NC-SA)


# **Preliminary concepts**

Before we start it is important to have a few concepts clear. It seems logical that we need to have a basic understanding of the Earth magnetic field, as it is what we want to measure. Furthermore, basic knowledge of quadrics (e.g. spheres or ellipsoids) will turn out to be important. It may seem awkward to talk about quadrics here, but it will quickly make sense.

### The Earth magnetic field

At any location on Earth, the magnetic field can be locally represented as a constant three dimensional vector ( $\mathbf{h}_0$ ). This vector can be characterized by three properties. Firstly, the intensity or magnitude ( $\mathcal{F}$ ), normally measured in nanoteslas (nT) with an approximate range of 25000 nT to 65000 nT. Secondly, the inclination ( $\mathcal{I}$ ), with negative values (up to -90°)

if pointing up and positive (up to 90°) if pointing down. Thirdly, the declination ( $\mathcal{D}$ ) which measures the deviation of the field relative to the geographical north and is positive eastward.




Magnetic field frame of reference. Source: Wikimedia Commons

Using the frame of reference in the figure shown above, the Earth magnetic field vector  $\mathbf{h}_0$  can be written as:

$$\mathbf{h}_{0} = \mathcal{F} \begin{bmatrix} \cos(\mathcal{I})\cos(\mathcal{D}) \\ \cos(\mathcal{I})\sin(\mathcal{D}) \\ \sin(\mathcal{I}) \end{bmatrix}. \tag{1}$$

Given a geographical point the <u>WMM model</u> can be used to obtain the expected values for  $\mathcal F$ ,  $\mathcal I$  and  $\mathcal D$ . The magnetic declination is specially useful in order to calculate the geographical north in a compass.



WMM 2015.0 intensity, inclination and declination maps. Source: NOAA/NGDC & CIRES

### **Quadrics**

Quadrics are all surfaces that can be expressed as a second degree polynomial in x, y and z. They include popular surfaces such as spheres, ellipsoids, paraboloids, etc. The general implicit equation of a quadric surface S is given by:

$$S: ax^{2} + by^{2} + cz^{2} + 2fyz + 2gxz + 2hxy + px + qy + rz + d = 0.$$
 (2)

Eq. (2) can be written in a semi-matricial form, which will be particularly useful for our problem:

$$S: \mathbf{x}^T \mathbf{M} \mathbf{x} + \mathbf{x}^T \mathbf{n} + d = 0 \tag{3}$$

where  $\mathbf{x}$  is:

$$\mathbf{x} = \begin{bmatrix} x & y & z \end{bmatrix}^T$$

and  $\mathbf{M}$ ,  $\mathbf{n}$  are, respectively:

$$\mathbf{M} = egin{bmatrix} a & h & g \ h & b & f \ g & f & c \end{bmatrix}, \;\; \mathbf{n} = egin{bmatrix} p \ q \ r \end{bmatrix}.$$

A sphere of radius 1 centered at origin would be defined by:

$$\mathbf{M} = \begin{bmatrix} 1 & 0 & 0 \\ 0 & 1 & 0 \\ 0 & 0 & 1 \end{bmatrix}, \ \ \mathbf{n} = \begin{bmatrix} 0 \\ 0 \\ 0 \end{bmatrix} \ \mathrm{and} \ d = -1.$$

Eq. (2) can also be written purely in matrix form as:

$$S: \mathbf{x}^T \mathbf{Q} \mathbf{x} = 0$$

where  $\mathbf{x}$  and  $\mathbf{Q}$  are, respectively:

The type of quadric is determined by some properties of the matrices  ${f M}$  and  ${f Q}$  as detailed here.

# Measuring with a magnetometer


Initially, let's assume that we are in a magnetic disturbance free environment and that we have an ideal 3-axis magnetometer. Under these conditions, a magnetometer reading  ${\bf h}$  taken with an arbitrary orientation will be given by:

$$\mathbf{h} = \mathbf{R}_x(\phi)\mathbf{R}_y(\theta)\mathbf{R}_z(\varphi)\mathbf{h}_0,\tag{4}$$

where  $\mathbf{h}_0$  is the local Earth magnetic field given in (1) and  $\mathbf{R}_x(\phi)$ ,  $\mathbf{R}_y(\theta)$ ,  $\mathbf{R}_z(\varphi)$  are rotation matrices around the frame of reference x, y, z axis, respectively. Complementary sources of information would be needed to determine the orientation. It is easy to see that samples locus is a sphere of radius  $\mathcal{F}$ :

$$\mathbf{h}^T \mathbf{h} = \ldots = \mathcal{F}^2. \tag{5}$$

This way way of looking at the magnetometer samples gives us a geometric perspective of the problem. A calculated example is shown in the interactive plot found below.



Expected samples of a 3-axis magnetometer around Irvine, CA by the date of writing

### **Distortion sources**

In real life nothing is ideal neither the environment is disturbance free. As detailed in this <u>publication</u>, there are two main categories of measurement distortion sources: instrumentation errors and magnetic interferences. In the next sections they will be briefly described, concluding with the measurement model.

#### **Instrumentation errors**

Instrumentation errors are unique and constant for each device. They can be modeled as a result of three components. Firstly, a scale factor, which can be modeled as a diagonal matrix:


$$\mathbf{S} = \begin{bmatrix} s_x & 0 & 0 \\ 0 & s_y & 0 \\ 0 & 0 & s_z \end{bmatrix}$$
 (6)

Secondly, the non-orthogonality of the sensor axis, which can be modeled as:

$$\mathbf{N} = [ \mathbf{n}_x \quad \mathbf{n}_y \quad \mathbf{n}_z ] \tag{7}$$

where each column represents a vector of size 3 corresponding to each sensor axis with respect to the sensor frame. Finally, a sensor offset which can be simply modeled as:

$$\mathbf{b}_{so} = \left[ b_{so_x} \ b_{so_y} \ b_{so_z} \right]^T. \tag{8}$$



Schematic representation of each instrumentation error (-)

### **Magnetic interferences**

The magnetic interferences are caused by ferromagnetic elements present in the surroundings of the sensor. It is composed by permanent (hard iron) and induced magnetism (soft iron). Note that we ignore any non-constant magnetic interference.


Hard iron results from permanent magnets and magnetic hysteresis (remanence of magnetized iron). It is equivalent to a bias, which can be modeled as:

$$\mathbf{b}_{hi} = \left[ b_{hi_x} \ b_{hi_y} \ b_{hi_z} \right]^T. \tag{9}$$

Soft iron is due by the interaction of an external magnetic field with ferromagnetic materials, causing a change in the intensity and direction of the sensed field. It can be modeled as:

$$\mathbf{A}_{si} = \begin{bmatrix} a_{11} & a_{12} & a_{13} \\ a_{12} & a_{22} & a_{23} \\ a_{31} & a_{32} & a_{33} \end{bmatrix}$$
 (10)

You may find useful to read this <u>application note</u>, where it is discussed which elements on a PCB can cause magnetic interference.



Schematic representation of each magnetic interference (-)

#### Measurement model

After detailing each distortion source, we can easily write down the measurement model. All the distortion sources described in  $\underline{(6)}-\underline{(10)}$  can be combined to express the measured magnetic field  $\mathbf{h}_m$  as:

$$\mathbf{h}_m = \mathbf{SN}(\mathbf{A}_{si}\mathbf{h} + \mathbf{b}_{hi}) + \mathbf{b}_{so} \tag{11}$$

where  $\mathbf{h}$  is the true magnetic field given by (4). It is worth to note at this point that our measurement model does not include any stochastic noise. This is in some way unrealistic, however, it simplifies the solution approach at the cost of a slightly biased solution (assuming a small amplitude noise). You may use the method described in this paper to extend our solution by including noise.

Grouping terms (11) can be re-written as:

$$\mathbf{h}_m = \mathbf{A}\mathbf{h} + \mathbf{b} \tag{12}$$

where:

$$\mathbf{A} = \mathbf{SNA}_{si} \ \mathbf{b} = \mathbf{SNb}_{hi} + \mathbf{b}_{so}.$$

 ${f A}$  is a matrix combining scale factors, misalignments and soft-iron effects, while  ${f b}$  is the combined bias vector. It can be proved that the linear transformation of  ${f h}$  in  $\underline{(12)}$  makes the measurements  ${f h}_m$  to lie on an ellipsoid. Therefore, we will see in the next section that the calibration process reduces to an ellipsoid fitting problem.

## **Calibration**

It becomes clear from (12) that we need to find an estimate of  $\bf A$  and  $\bf b$ , which we will note as  $\bf \hat{A}$  and  $\bf \hat{b}$ . Then, any new measurement  $\bf h_n$  can be simply calibrated as:

$$\mathbf{\hat{h}}_n = \mathbf{\hat{A}}^{-1}(\mathbf{h}_n - \mathbf{\hat{b}}).$$

We first start expressing  ${f h}$ , using (12), as:

$$\mathbf{h} = \mathbf{A}^{-1}(\mathbf{h}_m - \mathbf{b})$$

which combined with (5) leads to:

$$\mathbf{h}_{m}^{T} \mathbf{A}^{-T} \mathbf{A}^{-1} \mathbf{h}_{m} - 2\mathbf{h}_{m}^{T} \mathbf{A}^{-T} \mathbf{A}^{-1} \mathbf{b} +$$

$$\mathbf{b}^{T} \mathbf{A}^{-T} \mathbf{A}^{-1} \mathbf{b} - \mathcal{F}^{2} = 0.$$
(13)

Eq. (13) can be re-written in the familiar quadric form:

$$\mathbf{h}_m^T \mathbf{M} \mathbf{h}_m + \mathbf{h}_m^T \mathbf{n} + d = 0 \tag{14}$$

where:

$$\mathbf{M} = \mathbf{A}^{-T} \mathbf{A}^{-1} \tag{15a}$$

$$\mathbf{n} = -2\mathbf{A}^{-T}\mathbf{A}^{-1}\mathbf{b} \tag{15b}$$

$$d = \mathbf{b}^T \mathbf{A}^{-T} \mathbf{A}^{-1} \mathbf{b} - \mathcal{F}^2. \tag{15c}$$

As we noted in the previous section our quadric surface will be an ellipsoid. Thus, we need to use an ellipsoid fitting algorithm which provides us with estimates of the quadric surface parameters,  $\hat{\mathbf{M}}$ ,  $\hat{\mathbf{n}}$  and  $\hat{d}$ . Multiple algorithms have been developed to fit a set of points to an ellipsoid surface. We will use the LS fitting method described in this <u>paper</u> by Q. Li et al. This method is easy to implement and there is also a MATLAB version readily <u>available</u>. Even though presented as an iterative method, a single step fit is enough if the points describe well the ellipsoid (which will be our case). Furthermore, it is shown that it performs reasonably well for low noise levels.

Using (14) and (15a)-(15c) with the estimated values  $\hat{\mathbf{M}}$ ,  $\hat{\mathbf{n}}$  and  $\hat{d}$  we can find  $\hat{\mathbf{A}}$  (or  $\hat{\mathbf{A}}^{-1}$ ) and  $\hat{\mathbf{b}}$ . As detailed in this paper, you will need to find the proper scale of the solution, which is found to be:

$$\hat{\mathbf{b}} = -\hat{\mathbf{M}}^{-1}\hat{\mathbf{n}} \tag{16}$$

$$\hat{\mathbf{A}}^{-1} = \frac{\mathcal{F}}{\sqrt{\hat{\mathbf{n}}^T \hat{\mathbf{M}}^{-1} \hat{\mathbf{n}} - \hat{d}}} \hat{\mathbf{M}}^{\frac{1}{2}}.$$
(17)

As you can observe from (17), knowledge of  $\mathcal F$  is required in order to calculate  $\mathbf{\hat A}^{-1}$ . This will make the calibrated sphere to have radius  $\mathcal F$ . However, in many applications such as in attitude estimation, the magnitude is irrelevant. If that is your case, you can make it one or any other convenient value.

In order to conclude this section, the proposed code to perform the calibration is shown below. It uses <u>Numpy</u> and <u>SciPy</u> for numeric calculations as well as the sensor class detailed in the next section.

```
import sys
import numpy as np
from scipy import linalg

class Magnetometer(object):
    ''' Magnetometer class with calibration capabilities.

    Parameters
    ------
    sensor : str
```


```
Sensor to use.
    bus : int
        Bus where the sensor is attached.
    F : float (optional)
        Expected earth magnetic field intensity, default=1.
# available sensors
_sensors = { 'ak8975c': SensorAK8975C}
def __init__(self, sensor, bus, F=1.):
    # sensor
    if sensor not in self._sensors:
       raise NotImplementedError('Sensor %s not available' % sensor)
    self.sensor = self._sensors[sensor](bus)
    # initialize values
    self.F = F
    self.b = np.zeros([3, 1])
    self.A_1 = np.eye(3)
def read(self):
    ''' Get a sample.
        Returns
        ____
        s: list
            The sample in uT, [x,y,z] (corrected if performed calibration).
    111
    s = np.array(self.sensor.read()).reshape(3, 1)
    s = np.dot(self.A_1, s - self.b)
    return [s[0,0], s[1,0], s[2,0]]
def calibrate(self):
    ''' Performs calibration. '''
    print('Collecting samples (Ctrl-C to stop and perform calibration)')
    try:
       s = []
       n = 0
        while True:
            s.append(self.sensor.read())
            sys.stdout.write('\rTotal: %d' % n)
            sys.stdout.flush()
    except KeyboardInterrupt:
        pass
    # ellipsoid fit
    s = np.array(s).T
    M, n, d = self.__ellipsoid_fit(s)
    # calibration parameters
    # note: some implementations of sqrtm return complex type, taking real
    M_1 = linalg.inv(M)
    self.b = -np.dot(M_1, n)
    self.A_1 = np.real(self.F / np.sqrt(np.dot(n.T, np.dot(M_1, n)) - d) *
                       linalg.sqrtm(M))
```

```
def ellipsoid fit(self, s):
    ''' Estimate ellipsoid parameters from a set of points.
       Parameters
        ____
        s: array_like
          The samples (M,N) where M=3 (x,y,z) and N=number of samples.
       Returns
       M, n, d : array_like, array_like, float
          The ellipsoid parameters M, n, d.
       References
        .. [1] Qingde Li; Griffiths, J.G., "Least squares ellipsoid specific
          fitting," in Geometric Modeling and Processing, 2004.
          Proceedings, vol., no., pp.335-340, 2004
    , , ,
    # D (samples)
   D = np.array([s[0]**2., s[1]**2., s[2]**2.,
                  2.*s[1]*s[2], 2.*s[0]*s[2], 2.*s[0]*s[1],
                 2.*s[0], 2.*s[1], 2.*s[2], np.ones_like(s[0])])
   # S, S_11, S_12, S_21, S_22 (eq. 11)
   S = np.dot(D, D.T)
   S 11 = S[:6,:6]
   S 12 = S[:6,6:]
   S 21 = S[6:,:6]
   S_22 = S[6:,6:]
   # C (Eq. 8, k=4)
   C = np.array([[-1, 1, 1, 0, 0, 0],
                  [1, -1, 1, 0, 0, 0],
                  [1, 1, -1, 0, 0, 0],
                  [0, 0, 0, -4, 0, 0],
                  [0, 0, 0, 0, -4, 0],
                  [0, 0, 0, 0, 0, -4]])
   # v_1 (eq. 15, solution)
   E = np.dot(linalg.inv(C),
               S_11 - np.dot(S_12, np.dot(linalg.inv(S_22), S_21)))
   E_w, E_v = np.linalg.eig(E)
   v_1 = E_v[:, np.argmax(E_w)]
   if v_1[0] < 0: v_1 = -v_1</pre>
   # v_2 (eq. 13, solution)
   v_2 = np.dot(np.dot(-np.linalg.inv(S_22), S_21), v_1)
   # quadric-form parameters
   M = np.array([[v_1[0], v_1[3], v_1[4]],
                  [v_1[3], v_1[1], v_1[5]],
                  [v_1[4], v_1[5], v_1[2]]])
   n = np.array([[v_2[0]]],
                  [v_2[1]],
                  [v_2[2]]])
   d = v_2[3]
```

## **Example**

To conclude this post we will use samples from a real magnetometer, which will allow us to see if the proposed solution behaves as expected. It is important to note that we will not evaluate the accuracy of our solution, neither other things such as how the number of samples or their spatial distribution affects the calibration. These are topics that would require further study, out of the scope of this post.

The chosen magnetometer is the one found inside the <u>Invensense MPU-9150</u>: AK8975C. It is a module that also contains an accelerometer and a gyroscope, not required for our purposes. A Raspberry Pi 2 will be used as a host platform, as shown below. This will allow us to quickly code a proof of concept by just using a few lines of Python. Note that you will need to activate the I2C driver and install python-smbus on the Raspberry Pi (details here).



The setup used for this example

The proposed code for the AK8975C drive is:

```
import smbus
# MPU9150 used registers
MPU9150 ADDR
                                   = 0x68
MPU9150 PWR MGMT 1
                                   = 0x6B
MPU9150_INT_PIN_CFG
                                   = 0x37
MPU9150_INT_PIN_CFG_I2C_BYPASS_EN = 0x02
# AK8975C used registers
AK8975C ADDR
                                   = 0x0C
AK8975C ST1
                                   = 0x02
AK8975C_ST1_DRDY
                                   = 0x01
```


```
AK8975C HXL
                                    = 0x03
AK8975C CNTL
                                    = 0x0A
AK8975C CNTL SINGLE
                                    = 0x01
# convert to s16 from two's complement
to_s16 = lambda n: n - 0x10000 if n > 0x7FFF else n
class SensorAK8975C(object):
    ''' AK8975C Simple Driver.
        Parameters
        _____
        bus : int
           I2C bus number (e.g. 1).
    # sensor sensitivity (uT/LSB)
    sensitivity = 0.3
    def __init__(self, bus):
        self.bus = smbus.SMBus(bus)
        # wake up and set bypass for AK8975C
        self.bus.write_byte_data(MPU9150_ADDR, MPU9150_PWR_MGMT_1, 0)
        self.bus.write_byte_data(MPU9150_ADDR, MPU9150_INT_PIN_CFG,
                                  MPU9150_INT_PIN_CFG_I2C_BYPASS_EN)
    def __del__(self):
        self.bus.close()
    def read(self):
        ''' Get a sample.
            Returns
            _____
            s: list
                The sample in uT, [x, y, z].
        # request single shot
        self.bus.write_byte_data(AK8975C_ADDR, AK8975C_CNTL,
                                                AK8975C_CNTL_SINGLE)
        # wait for data ready
        r = self.bus.read_byte_data(AK8975C_ADDR, AK8975C_ST1)
        while not (r & AK8975C_ST1_DRDY):
            r = self.bus.read_byte_data(AK8975C_ADDR, AK8975C_ST1)
        # read x, y, z
        data = self.bus.read_i2c_block_data(AK8975C_ADDR, AK8975C_HXL, 6)
        return [self._sensitivity * to_s16(data[0] | (data[1] << 8)),</pre>
                self._sensitivity * to_s16(data[2] | (data[3] << 8)),</pre>
                self._sensitivity * to_s16(data[4] | (data[5] << 8))]</pre>
```

Merging the sensor driver shown above with the code in the previous section will allow us to both sample and calibrate. We can also append the code shown below, which will allow us to

store non-calibrated and calibrated samples to then visualize the results with any plotting library:

```
from time import sleep
def collect(fn, fs=10):
    ''' Collect magnetometer samples
        Parameters
        fn:str
           Output file.
        fs : int (optional)
           Approximate sampling frequency (Hz), default 10 Hz.
    print('Collecting [%s]. Ctrl-C to finish' % fn)
    with open(fn, 'w') as f:
       f.write('x,y,z \mid n')
       try:
            while True:
                s = m.read()
                f.write('\%.1f,\%.1f,\%.1f\\n' \% (s[0], s[1], s[2]))
                sleep(1./fs)
        except KeyboardInterrupt: pass
m = Magnetometer('ak8975c', 1, 46.85)
collect('ncal.csv')
m.calibrate()
collect('cal.csv')
```

Real results are displayed in the following interactive plot:





Ghostery blocked comments powered by Disqus.



© 2019 Teslabs Engineering. All rights reserved.