GROUND Lite Communications Protocol Specification

Version 1.0.0

B.B.F.M. Verspaandonk, M.Y.A. Wierckx

January 25, 2025

Contents

1 Overview

The GROUND (GAIA Radio OUtput Network Delivery) Lite protocol is a power and data efficiency optimized version of the original GROUND protocol. All data is serialized in little-endian format, meaning the least significant byte is sent first. For example, the number `0x1234` would be transmitted as `0x34 0x12`.

2 Packet Structure

A packet comprises the following fields:

#	Field Name	Size
1	`magic_number`	4 bytes
2	`content_type`	1 bytes
3	`content_size`	1 bytes
4	`content`	`content_size` bytes

Field Descriptions

`magic_number`: A constant value `0x67616961` (ASCII for `gaia`) that marks the start of a packet.

`content_type`: Specifies the type and structure of the data. Its interpreted as follows:

Value	Data Type	Type	Description
`0x01`	`float`	`GPS_POS[3]`	GPS coordinates
`0x02`	`float`	`G_FORCES[3]`	G-force measurement
`0x03`	`float`	`ROTATION[3]`	Angle measurement

0x04	uint32_t	TIME	Time
0x05	uint32_t	GPS_FIX_AGE	Time in ms since last gps fix
0x06	float	GPS_HDOP	Horizontal Dilution of Precision
0x07	uint8_t	GPS_NUM_OF_SATS	Number of satellites in view
0x08	float	GPS_FAIL_PERCENTAGE	Percentage of GPS cheksums failed
0x09	uint16_t	CO2_CONCENTRATION	*UNUSED* CO_2 concentration in ppb
0x0A	float	TEMPERATURE	Temperature in °C
0x0B	float	PRESSURE	Pressure in Pa
0x0C	uint16_t	DUST_CONCENTRATION	Dust concentration in $\mu g/m^3$
0x0D	float	UV_RADIATON	UV radiation in mW/cm^2
0x0E	uint16_t	PACKET_NUM	Packet number

`content_size`: The number of bytes in the `content` field.

`content`: The actual data payload. Its interpretation depends on `content_type`.

3 Handling `magic_number` in Content

If the `magic_number` sequence `0x67616961` appears in the `content`, it must be escaped by appending a `0x00` byte immediately after. For example:

`67 61 69 61` → `67 61 69 61 00`

The escape byte contributes to `content_size` but should be removed during packet parsing.

4 Encoding order

The fields in a packet are encoded in the following order:

1. Check if the `magic_number` sequence appears in the `content` field. If so, escape it.
2. Calculate the content size.
3. Add the `magic_number` sequence, `content_type`, `content_size` and `content` fields.
4. Transmit the packet.

5 Examples

Single Value

Packet encoding a single unsigned 16-bit integer with value `4660`:

```
67 61 69 61 0B 04 00 50 7D 44
```

Breakdown:

```
67 61 69 61 // Magic number
0B          // Content type: Pressure
04          // Content size: 4 bytes
00 50 7D 44 // Content: 1013.25 Pa
```

Array

Packet encoding GPS coordinates (latitude, longitude) as two 64-bit doubles:

```
67 61 69 61 03 0C 00 00 B4 42 9A 99 16 43 C3 F5 48 40
```

Breakdown:

```
67 61 69 61             // Magic number
03                      // Content type: Angle measurement (float ROTATION[3])
0C                      // Content size: 12 bytes
00 00 B4 42             // Angle 1: 90.0
9A 99 16 43             // Angle 2: 150.6
C3 F5 48 40             // Angle 3: 3.14
```

Escaped Magic Number

GPS coordinates with a `magic_number` sequence in the content:

```
67 61 69 61 01 0E 67 61 69 61 00 00 00 20 40 67 61 69 61 00
```

Breakdown:

```
67 61 69 61             // Magic Number
01                      // Content type: GPS coordinates (float GPS_POS[3])
0E                      // Content size: 14 bytes
67 61 69 61 00          // Latitude with escaped magic number: 269069370000000000000 (this isn't a
00 00 20 40             // Longitude: 2.5
67 61 69 61 00          // Altitude with escaped magic number: 269069370000000000000 (about 28441
```