RTX Operating System Report

Tyler Babaran

 $20457511 \\ \texttt{tbabaran@uwaterloo.ca}$

Kelly McBride

insert student number here
EMAIL@waterloo.ca

Peter Socha

 $20484453 \\ \texttt{psocha@uwaterloo.ca}$

April 6, 2015

Contents

L	Intr	Introduction				
2	Des	ign De	escription			
	2.1	Global	Variables and Structures			
	2.2	Memo	ry Management			
		2.2.1	Memory Structure			
		2.2.2	Requesting Memory Blocks			
		2.2.3	Releasing Memory Blocks			
	2.3	Proces	sor Management			
		2.3.1	Process Control Structures			
		2.3.2	Process Queues			
		2.3.3	Process Scheduling			
	2.4	Proces	s Priority Management			
		2.4.1	Get Process Priority			
		2.4.2	Set Process Priority			
	2.5	Interp	rocess Communication			
		2.5.1	Message Structure			
		2.5.2	Sending Messages			
		2.5.3	Receiving Messages			
		2.5.4	Delayed Send			
	2.6	Interru	ipts and I-Processes			
		2.6.1	UART I-Process			
		2.6.2	Timer I-Process			
	2.7	Systen	n Processes			
		2.7.1	Null Process			
		2.7.2	KCD Process			
		2.7.3	CRT Process			
	2.8	User F	Processes			
		2.8.1	Wall Clock Process			
		2.8.2	Set Priority Process			
		2.8.3	Stress Test Processes			
	2.9		ization			
			gg			
		· 				
3	•	•	sign Changes			
	3.1	Struct	ure of Process Queue			

4	Lessons Learned						
	4.1 Source Control and Code Management	19					
	4.2 Team Dynamics and Scheduling	19					
5	Timing and Analysis	20					

List of Algorithms

1	The memory request function
2	The memory release function
3	The process priority changing function
4	The send message function
5	The receive message function
6	The delayed send function
7	The uart iprocess
8	The Timer iprocess
9	The null system process
10	The KCD System Process
11	The CRT Process
12	The Set Priority Process

List of Figures

Introduction

Kelly

Design Description

2.1 Global Variables and Structures

Kelly

2.2 Memory Management

2.2.1 Memory Structure

Tyler

The heapthat the processes request memory blocks from is maintained as a linked list. The length of the heap is exactly enough space for thirty memory blocks of size 0x80 (128 bytes).

Free space nodes keep track of the length of free space following this address and a pointer to the next chunk of unclaimed blocks. These headers are written directly into the blocks as they are returned to the heap. They are free to be overwritten, the only safe header is the starting address of the heap. The heap is shifted by four bytes to protect the last block from ever being overwritten.

The request and release methods maintain the optimal structure of the list, deleting and overwriting excess or useless nodes.

2.2.2 Requesting Memory Blocks

Tyler

int k_request_memory_block(void);

First, the procedure checks if all memory blocks in the system heap have been reserved already. If so, this process becomes blocked and will be unblocked once another process releases one of the memory blocks.

Once a memory block is free the procedure iterates through the free space nodes like a linked list, searching for the first chunk of free space that is large enough to satisfy the request. Then the procedure passes a pointer to the first address of the block to the process and updates the heap to

account for this space being reserved.

Algorithm 1 The memory request function

```
1: procedure REQUEST_MEMORY_BLOCK
2: while heap is full do
3: block the current process
4: end while
5: update the free space list
6: return the address of the top of the block
7: end procedure
```

2.2.3 Releasing Memory Blocks

Tyler

```
int k_release_memory_block(void* memory_block);
```

Releasing memory blocks requires a pointer to a memory block. The procedure focuses on optimally returning the block to the heap list. Then it unblocks the next process waiting for a memory block, if any.

Algorithm 2 The memory release function

```
1: procedure RELEASE_MEMORY_BLOCK(*memory_block)
      if this block is the top block of the heap then
2:
          modify heap header node (never gets overwritten)
3:
       end if
4:
      if there is free space immediately beneath this block then
5:
6:
          combine them by increasing this block's length
      else this block becomes a new block node, is added to the list
 7:
      end if
8:
      if there is free space immediately beneath this block then
9:
          combine them by increasing this block's length
10:
      end if
11:
      if a process is blocked on memory then
12:
13:
          unblock that process, release the processor
       end if
14:
15: end procedure
```

2.3 Processor Management

2.3.1 Process Control Structures

Kelly

2.3.2 Process Queues

Tyler

The process queues are implemented to use one queue for all priorities, instead of a separate queue for each priority. Each PCB contains a PCB pointer, allowing the PCBs themselves to be the queue nodes.

By using generic methods that use pointers of pointers as parameters, the same four methods are used for all process queues:

```
void enqueue(pcb** targetQueue, pcb* element);
pcb* dequeue(pcb** targetQueue);
void remove_queue_node(pcb** targetQueue, pcb* element);
U32 is_empty(pcb* targetQueue)
```

The enqueue method compares the priorities of each process in the queue and inserts the element beneath all processes of equal value, ensuring FIFO ordering.

dequeue simply pops the highest priority element off the front of the queue.

The remove_queue_node procedure is used when processes change priority and need to be removed and reinserted back into the queue. This searches the queue for a particular PCB, based on process ID.

is_empty is purely a helper function for the other three.

2.3.3 Process Scheduling

Kelly

2.4 Process Priority Management

2.4.1 Get Process Priority

Peter

```
int k_get_process_priority(int process_id);
```

The k_get_process_priority primitive is used to get the priority of a process. It takes a process ID as an input parameter. It outputs one of two things:

- The process's m_priority member if the process id is valid
- RTX_ERR (equal to -1) if the process id is invalid

k_get_process_priority never modifies any process and never modifies any process queues.

2.4.2 Set Process Priority

Tyler

```
int k_set_process_priority(int process_id, int priority);
```

Process priority changing is all done through this method. After checking that the process is allowed to have it's priority change and the priority it is being set to is legal, the priority value is set and the process is removed and re-enqueued to the queue matching the process's current state. The processor is then released to allow for higher priority processes to take over.

Algorithm 3 The process priority changing function

- 1: **procedure** SET_PROCESS_PRIORITY(processID, targetPriority)
- 2: **if** processID or targetPriority are not legal **then**
- 3: return RTX_ERR
- 4: end if
- 5: set processID's priority to targetPriority
- 6: determine state
- 7: remove queue node
- 8: enqueue processID's PCB
- 9: end procedure

2.5 Interprocess Communication

2.5.1 Message Structure

Kelly

2.5.2 Sending Messages

Tyler

```
int k_send_message(int process_id, void* message_envelope);
```

Message passing is implemented using a stucture very similar to the process queues. Processes can call this method after creating a typical message_envelope containing a message type and a char array of the message's contents. The function call also requires a destination process that will receive this message. k_send_message is the kernel primitive used to facilitate message sending.

The procedure begins by using message_new to create a message, our kernel level wrapper for the message_envelope containing additional necessary information such as the sender process's ID and the pointer necessary for message queue construction. The message is then enqueued on the message queue of the destination process. If the destination process is blocked on receive, we unblock and switch, releasing the processor to determine which process should be running next.

2.5.3 Receiving Messages

Tyler

```
int k_receive_message(int* sender_id);
```

Each process maintains it's own message queue in the PCB. k_receive_message is the kernel primitive used to facilitate message receiving. When a process tries to receive a message, first the

Algorithm 4 The send message function

```
1: procedure SEND_MESSAGE(destinationID, message envelope)
     m = create message object from message envelope
2:
     enqueue m on the destination process's message queue
3:
4:
     if destination process is waiting for a message then
         move destination process to Ready state
5:
         pre-empt the processor, switching to the waiting process
6:
7:
     end if
     return RTX_OK
8:
9: end procedure
```

procedure checks if the message queue is empty. If so, this process becomes blocked on receive and will become unblocked by the send_message procedure.

Once a message is in the queue, the procedure dequeues the first message and returns the message envelope data containing the message type and contents. The sender_id pointer parameter is set as the sender_id from the message wrapper for the process to cross reference and confirm this is the message it was waiting for.

Algorithm 5 The receive message function

```
1: procedure RECEIVE_MESSAGE(*sender_id)
2: while message queue is empty do
3: block this process
4: end while
5: m = dequeue the top message
6: set sender_id as m's sender_id
7: return m's message_envelope
8: end procedure
```

2.5.4 Delayed Send

Peter

```
int k_delayed_send(int process_id, void *message_envelope, int delay);
```

The purpose of delayed sending is so that messages are not received immediately. A message will not end up in the message queue of the receiving process until after a delay period has passed. k_delayed_send is the kernel primitive used to facilitate such message-passing.

The procedure begins by verifying its parameters, returning RTX_ERR if any of the values are unacceptable. It then creates a message structure using message_new with a delay equal to the delay argument given. In regular message-sending, the delay variable is set to zero. The message is finally enqueued on the message queue of the timer i-process. Regardless of the message's intended destination, it is given first to the timer i-process and all later handling is done by the timer i-process.

Algorithm 6 The delayed send function

```
1: procedure DELAYED_SEND(processID, message, delay)
2:
      if delay is negative then
         return RTX_ERR
3:
      end if
4:
      if No process has id processID then
5:
         return RTX_ERR
6:
      end if
7:
      m = create message object with expiry time of now + delay
8:
      enqueue m on the timer iprocess's message queue
9:
      return RTX_OK
10:
11: end procedure
```

2.6 Interrupts and I-Processes

2.6.1 UART I-Process

Peter

The UART i-process has two functions:

- Read characters entered through the keyboard
- Output characters to the screen

The uart iprocess sometimes sends messages to the KCD and CRT processes. If this happens, a g_-uart_flag variable is set to 1. When the iprocess completes, the asssembly routine that handles the interrupt checks the value of g_uart_flag. If the flag is true, it will call k_release_processor() to give KCD and CRT a chance to immediately run.

The i-process's functionality requires it to request memory in order to make messages. In order to prevent the i-process from ever getting blocked, it never allocates memory if there is no free space available.

When the _DEBUG_HOTKEYS flag is enabled, a set of characters has special status. When one of the characters below is typed, a message is printed to the screen using uart1. The messages consist of lists of processes, with the process id and priority stated line by line. These characters can be pressed at any time are not counted towards strings used for command-passing.

- ! prints the processes on the ready queue
- @ prints the processes on the blocked-on-memory queue
- # prints the processes on the blocked-on-receive queue

Algorithm 7 The uart iprocess

```
1: procedure UART_I_PROCESS
2:
      g_uart_flag = 0
3:
      if receive data available then
4:
          read g_char_in from register
5:
          if _DEBUG_HOTKEYS is enabled then
             PROCESS_HOT_KEY(g_char_in)
6:
          end if
7:
8:
          if heap space is available then
             m = K_REQUEST_MEMORY_BLOCK
9:
             Set the mtype of m to CRT_DISP
10:
             Set the mtext of m to g_char_in
11:
             Send m as a message to the CRT process
12:
             g_uart_flag = 1
13:
          end if
14:
          if g_char_in is a carriage return then
15:
16:
             if heap space is available then
                m = K_REQUEST_MEMORY_BLOCK
17:
18:
                Set the mtype of m to DEFAULT
19:
                Set the mtext of m to g_input_buffer
                Send m as a message to the KCD process
20:
                 g_uart_flag = 1
21:
             end if
22:
             reset the g_input_buffer
23:
24:
          else
             append g_char_in to g_input_buffer
25:
26:
          end if
27:
      else if output data available then
          Receive the message m
28:
29:
          Output the mtext of m until the null terminator is reached
          K_RELEASE_MEMORY_BLOCK(m)
30:
31:
      end if
32: end procedure
```

• \$ prints the process that is currently running

2.6.2 Timer I-Process

Peter

The timer i-process is called by the timer interrupt handler, which runs 1000 times each second. The purpose of the iprocess is to send delayed messages and to update the global timer count g_- timer_count.

The timer i-process treats its message queue differently than the other processes in the RTX. Instead of popping messages off of its queue one at a time, it scans the entire queue each time it runs. The expiry time of each message is compared with the current time and the message is sent to the destination process if the expiry time has passed. A special non-preemptive message-sending procedure is used so that the i-process is not pre-empted before it has finished scanning the queue. This non-preemptive sender places the receiving process on the ready queue but does not run it. Instead, a flag variable g_timer_flag is set that will cause k_release_processor() to run when the i-process is finished (this call is not made in the process, but in the assembly wrapper that handles the interrupt).

The timer i-process does not use receive_message() to read its queue and therefore never gets blocked.

Algorithm 8 The Timer iprocess

```
1: procedure TIMER_I_PROCESS
2:
       disable interrupts
      increment g_timer_count
3:
4:
      g_{timer_flag} = 0
      for message m in the timer iprocess's message queue do
5:
6:
          if m's expiry_time is less than the present time then
7:
             g_{timer_flag} = 1
              remove m from the timer iprocess's message queue
8:
              send the message to its desintation process without preempting
9:
          end if
10:
       end for
11:
12:
       enable interrupts
13: end procedure
```

2.7 System Processes

2.7.1 Null Process

Peter

The null process has the lowest priority of any process in the operating system. It runs only when there are no ready processes to be run. When it runs, all it does is invoke k_release_processor() so that the kernel can check if there is a ready process to be run.

Algorithm 9 The null system process

```
1: procedure NULL_PROCESS
2: while true do
3: K_RELEASE_PROCESSOR()
4: end while
5: end procedure
```

2.7.2 KCD Process

Peter

The Keyboard Command Decoder process exists so that users can send console commands to the system at runtime. A command can be registered by sending the KCD process a KCD_REG type message. The KCD maintains a list of registered commands inside an array. When a DEFAULT command is sent to the KCD, the KCD will try to recognize the command. If the command is found, the KCD will send a message to the process that registered the command; the message will have the KCD_DISPATCH type. In both cases, the contents of the command are stored inside the message's mtext. The KCD process is an intermediary between the UART i-process (which registers the keystrokes) and the eventual receiving message (which executes the command).

Algorithm 10 The KCD System Process

```
1: procedure KCD_PROCESS
      while true do
2:
         message = RECEIVE\_MESSAGE()
3:
         if message is of type DEFAULT then
4:
             Read the mtext up to first whitespace or newline
5:
             Try finding the mtext in the command array
6:
             if command is found then
7:
                Send KCD_DISPATCH message to the process that registered the command. Send
8:
   the entire mtext as contents.
             end if
9:
          else if message is of type KCD_REG then
10:
             Read the mtext and sending process
11:
             Add the command to the command array
12:
         end if
13:
          RELEASE_MEMORY_BLOCK(message)
14:
      end while
15:
16: end procedure
```

The KCD process assumes that command strings contain no whitespace. It assumes that any information between the first space and the end of the line is supplementary.

2.7.3 CRT Process

Peter

The CRT process is used to print text to the system console. The process waits for messages of type CRT_DISP. If it receives such a message, it will send it to the UART i-process and modify the IER register so that the UART treats the message as an output message. The UART is interrupted and therefore the UART i-process will start to run immediately.

Algorithm 11 The CRT Process 1: procedure CRT_PROCESS 2: while true do $message = RECEIVE_MESSAGE()$ 3: if message is of type CRT_DISPLAY then 4: Send message to UART iprocess 5: Set interrupt bits 6: 7: else RELEASE_MEMORY_BLOCK(message) 8: end if 9: 10: end while 11: end procedure

2.8 User Processes

2.8.1 Wall Clock Process

Peter

The wall clock process is used to display the time in 24-hour format. If the clock is on, it will print the time on the screen each second by sending messages to the CRT process. The process maintains second-by-second timing by sending itself delayed messages with a delay of 1000 milliseconds.

The wall clock process registers three commands with the KCD when it initializes. By typing commands into the console, the user can control the wall clock's behaviour. When the process launches, the wall clock starts as inactive.

- %WR Sets the clock time to 00:00:00 and sets the clock to active.
- %WT Sets the clock to inactive. Cancels any scheduled future clock ticks.
- %WS hh:mm:ss Sets the clock to active with the given time in 24-hour format.

The wall clock process relies on memory blocks to send display messages to the CRT process and to send itself delayed messages to re-awaken itself. If system memory has been depleted, it will be unable to properly funcion.

2.8.2 Set Priority Process

Peter

```
%C process_id new_priority
```

The set_process_priority() primitive described earlier can be used to programmatically change the priority of any process that is not a system process. It is, however, a programmatic call that must be set in user code in advance. The Set Priority process allows users to change the priority of a process at runtime using the %C command.

The priority change takes effect immediately. If the user enters invalid parameters, "Error" will be printed to the screen and the command will be ignored.

Algorithm 12 The Set Priority Process

```
1: procedure SET_PRIORITY_PROC
      register with KCD as %C command
2:
      while true do
3:
         message = RECEIVE\_MESSAGE()
4:
         parse message mtext to get a process_id and new_priority
5:
         if Setting process_id to new_priority is a valid operation then
6:
7:
             SET_PROCESS_PRIORITY(process_id)new_priority
         else
8:
             make and send an "Error" message to CRT
9:
         end if
10:
          RELEASE_MEMORY_BLOCK(message)
11:
12:
      end while
13: end procedure
```

2.8.3 Stress Test Processes

Peter

The stress test processes are a collection of three user processes called A, B, and C. The three of them are used to test how the system copes with the depletion of heap blocks in memory.

Process A waits until it receives a %Z command, after which it will repeatedly request memory, make messages, and send those messages to Process B.

Process B receives messages from A and sends them to Process C.

Process C receives messages from Process B. Every 20th message, it prints "Process C" to the screen by modifying B's message and passing it to the CRT. Every 20th message, it will then request a memory block and send itself a delayed WAKEUP10 message to be received in 10 seconds. During those 10 seconds, it goes into a hibernation state, receiving messages from B and putting them on its local queue, but otherwise not doing anything.

In general, Process A requests memory blocks and Process C ends up releasing them. If Process C's priority is too low, memory blocks may end up never being released and we may end up in deadlock.

2.9 Initialization

Kelly

2.10 Testing

Tyler

Major Design Changes

Add more sections as appropriate

3.1 Structure of Process Queue

Tyler

Lessons Learned

Everyone contribute something

4.1 Source Control and Code Management

We used GitHub as a repository for our code, which proved to be very helpful. However, we never developed any systematic protocols for using GitHub and we did not take advantage of many of its features.

Nearly all development was done on the master branch and was pushed directly to the master branch. We rarely coded on the same module at the same time so conflicts were surprisingly rare. However, we did not have a systematic code review process. While this saved us time in the short run, it meant that team members did not have much of a chance to learn about the code that the other team members were writing. The team became overly specialized; many of the modules in the OS were well-understood by only one team member. A more systematic review process may have helped keep all members on the team well-grounded on all aspects of the OS.

4.2 Team Dynamics and Scheduling

There were no major conflicts between any of the team members, which proved beneficial for all of us.

We did not have a systematic process for allocation and scheduling of tasks. Usually a release cycle would begin as a free-for-all with members choosing parts they wanted to work on. Later on in the cycle, an allocation system would be determined, but it was informal, frequently did not go according to plan, and rarely carried any concrete deadlines for individual group members.

With P1 and P2 in particular, we encountered time trouble and needed to use a late day for each. We could have avoided this problem by allocating responsibilities more precisely and maintaining deadlines for the main milestones.

Timing and Analysis

Peter

In order to do timing, a second timer (called "timer 1") was programmed. Whereas timer0 interrupted once every millisecond, timer1 never interrupts and never does anything other than maintain a count. Like timer0, timer1 operated at a speed of 100MHz.

The timer test code was added to the user test processes, with the tests conducted in proc5() after all the regular tests had been completed. The three primitives that had their time measured were k_request_memory_block(), k_send_message(), and k_receive_message(). The test was designed so that there would be no blocking or pre-emption during any of these calls. Each of these functions was called ten times inside a loop and the elapsed time was measured using the timer's TC register. By writing certain values to the timer's TCR register, we were able to programmatically start, stop, and reset the timer during and between tests.

The raw data proved to be very consistent and exhibited zero variance in 24 total runs. Since the timer ticked at 100MHz, it meant that each clock tick represented 10ns in time. Since each time value was obtained on a sample of 10 calls made consecutively, we divide by 10 to get the time elapsed per individual call. Here is the data, represented as ns per call.

	k_request_memory_block	k_send_message	k_receive_message
Time (ns)	420	1028	866

Figure 5.1: Timing Test Results

Judging by the high consistency of the results, the hardware always executed the code in the same predictable manner without any optimizations or stalls.

The primitives for message-handling are more expensive than the primitive for memory. This difference is likely due to the fact that the message primitives work with the message object type, which is larger and more complex than the heap_blk object type used to manage heap blocks.