cepton_sdk Documentation

Cepton Technologies

CONTENTS

1	Overview	1
2	Samples	3
3	Errors	17
4	Setup	21
5	Sensors	25
6	Points	29
7	Serial	31
8	Networking	33
9	Capture Replay	35
10	C++	37
11	Utilities	39
Index		45

OVERVIEW

The Cepton SDK provides the following features

• Parsing: parse sensor packets

• Calibration: apply sensor calibration

• Networking: listen for sensor packets

• Capture Replay: read sensor packets from a PCAP file

• Frame Accumulation: accumulate and output sensor points by frame

Currently, the Cepton LiDAR packet formats are under active development, and are not publicly available. The SDK is required for **Parsing** and **Calibration**. All other SDK features are optional, and can be done manually by the user.

1.1 Getting Started

To start, take a look at *Samples*. The sample code covers most common use cases.

For prototyping, it is recommended to use the high level C++ API (*C*++, *Utilities*).

1.2 Timestamps

All int64 timestamps are microseconds since the Unix epoch (UTC). All float timestamps are time differences measured in seconds. Point timestamps are based on one of the following sources (the first valid source is used):

- 1. GPS (NMEA + PPS)
- 2. PTP
- 3. Host PC

All float and int 64 time differences are seconds (measurement period, replay time, frame length, etc.).

1.3 Multiple Returns

To enable multiple returns, pass the CEPTON_SDK_CONTROL_ENABLE_MULTIPLE_RETURNS flag during initialization.

The returns are as follows:

1. Strongest signal.

2. Furthest signal, if it is not the strongest. Otherwise, the second strongest signal.

1.4 Concurrency

- If networking is enabled, the sdk creates 2 threads for networking. All callbacks occur in these networking threads.
- · If networking is disabled, the sdk does not create any threads. All callbacks occur in the main thread.
- All sdk getter functions are thread safe, and can be called from callbacks. Other sdk functions are not guarunteed to be thread safe, and can cause deadlock if called from callbacks.

1.5 Minimal SDK

If desired, the following SDK features can be disabled in the SDK and performed manually by the user:

• Networking: Network.

• Capture Replay: Replay.

• Frame Accumulation: Frame.

1.6 Sensor Fusion

Cepton sensors do not have a concept of a frame boundaries. This is especially useful with multiple sensors, since there is no need to worry about frame synchronization between sensors. We recommend choosing a desired frame length, and collecting data for all sensors simultaneously (*Process Single*, *Process Multi*). Longer frame lengths will allow for higher point density per frame, but higher latency. A frame length of ~0.1s (10Hz) is recommended for most applications.

CHAPTER

TWO

SAMPLES

2.1 Basic

Listing 1: samples/basic.cpp

```
* Sample code for general sdk usage.
2
   #include <vector>
   #include <cepton_sdk_api.hpp>
   #include "common.hpp"
   class FramesListener {
10
11
     void on_image_frame(cepton_sdk::SensorHandle handle, std::size_t n_points,
12
                          const cepton_sdk::SensorImagePoint *c_image_points) {
13
       // Get sensor info
14
       cepton_sdk::SensorInformation sensor_info;
15
       CEPTON_CHECK_ERROR(cepton_sdk::get_sensor_information(handle, sensor_info));
16
17
       // Print info
18
       if (i_frame < 5) {
19
          std::printf("Received %i points from sensor %i\n", (int)n_points,
20
                       (int) sensor_info.serial_number);
21
22
       ++i_frame;
23
24
25
26
    private:
    std::size_t i_frame = 0;
2.7
28
   };
29
   int main(int argc, char **argv) {
30
     check_help(argc, argv, "cepton_sdk_sample_basic [capture_path]");
31
     std::string capture_path;
32
     if (argc >= 2) capture_path = argv[1];
33
34
     std::printf("Press Ctrl+C to stop\n");
35
36
     // Initialize
     auto options = cepton_sdk::create_options();
```

```
options.frame.mode = CEPTON_SDK_FRAME_TIMED;
39
     options.frame.length = 0.1f;
40
     CEPTON_CHECK_ERROR(cepton_sdk::api::initialize(options, capture_path));
41
42
     // Get sensor
     std::printf("Waiting for sensor to connect...\n");
     while (cepton_sdk::get_n_sensors() == 0)
45
       CEPTON_CHECK_ERROR(cepton_sdk::api::wait(0.1f));
46
     cepton_sdk::SensorInformation sensor_info;
47
     CEPTON_CHECK_ERROR (
48
         cepton_sdk::get_sensor_information_by_index(0, sensor_info));
49
     std::printf("Sensor: %i\n", (int)sensor_info.serial_number);
     // Listen for frames
52
     std::printf("Listening for frames...\n");
53
     cepton_sdk::api::SensorImageFrameCallback callback;
54
     CEPTON_CHECK_ERROR(callback.initialize());
55
     FramesListener frames_listener;
     CEPTON_CHECK_ERROR (
57
         callback.listen(&frames_listener, &FramesListener::on_image_frame));
58
59
     // Run
60
     CEPTON_CHECK_ERROR(cepton_sdk::api::wait());
61
62
     // Deinitialize
     cepton_sdk::deinitialize().ignore();
65
```

2.2 C Basic

Listing 2: samples/c_basic.c

```
* Sample code for general C sdk usage.
   #include <stdio.h>
   #include <time.h>
   #include <cepton_sdk.h>
   void check_sdk_error() {
10
     const char *error_msg;
     const auto error_code = cepton_sdk_get_error(&error_msg);
11
     printf("%s: %s\n", cepton_get_error_code_name(error_code), error_msg);
12
     exit(1);
13
   }
14
   int frames_got = 0;
16
   time_t first_frame_time = 0;
17
   time_t current_frame_time = 0;
18
19
   void image_frame_callback(CeptonSensorHandle handle, size_t n_points,
20
                              const struct CeptonSensorImagePoint *c_points,
21
                              void *user_data) {
```

```
time_t t = time(NULL);
23
24
     if (frames_got == 0) first_frame_time = t;
25
     frames_got++;
26
     if (frames_got < 50)</pre>
27
       printf("Frame: %4d Time: %1ld\n", frames_got, (long long)t);
28
29
       printf("Frame: %4d Time: %1ld Frame rate: %.1fHz\n", frames_qot,
30
               (long long)t, frames_got * 1.0 / (t - first_frame_time));
31
32
33
   int main() {
35
     // Initialize
     struct CeptonSDKOptions options = cepton_sdk_create_options();
36
     options.frame.mode = CEPTON_SDK_FRAME_TIMED;
37
     options.frame.length = 0.1f;
38
     cepton_sdk_initialize(CEPTON_SDK_VERSION, &options, NULL, NULL);
39
     check_sdk_error();
41
     // Listen for frames
42
     cepton_sdk_listen_image_frames(image_frame_callback, NULL);
43
     check_sdk_error();
44
45
     // Run
46
47
     while (frames_got < 100)</pre>
       ; // Just spin loop for lack of cross platform sleep in C
49
     // Deinitialize
50
     cepton_sdk_deinitialize();
51
     check_sdk_error();
52
53
```

2.3 Callback

Listing 3: samples/callback.cpp

```
1
   * Sample code for callback usage.
2
3
   #include <cepton_sdk_api.hpp>
   // Sample global callback.
   void on_image_frame(cepton_sdk::SensorHandle handle, std::size_t n_points,
                        const cepton_sdk::SensorImagePoint *c_image_points) {}
   // Sample member callback.
10
   class FramesListener {
11
   public:
12
     void on_image_frame(cepton_sdk::SensorHandle handle, std::size_t n_points,
13
                          const cepton_sdk::SensorImagePoint *c_image_points) {}
14
   } ;
15
16
   int main(int argc, char **argv) {
17
   // Initialize
```

(continues on next page)

2.3. Callback 5

```
CEPTON_CHECK_ERROR(cepton_sdk::api::initialize());
19
     cepton_sdk::api::SensorImageFrameCallback callback;
20
     CEPTON_CHECK_ERROR(callback.initialize());
21
22
     // Listen lambda
23
     CEPTON_CHECK_ERROR(callback.listen(
24
         [](cepton_sdk::SensorHandle handle, std::size_t n_points,
25
            const cepton_sdk::SensorImagePoint *c_image_points) {}));
26
27
     // Listen global function
28
     CEPTON_CHECK_ERROR(callback.listen(on_image_frame));
29
31
     // Listen member function
     FramesListener frames_listener;
32
     CEPTON CHECK ERROR (
33
         callback.listen(&frames_listener, &FramesListener::on_image_frame));
34
35
     // Deinitialize
     cepton_sdk::deinitialize().ignore();
37
38
```

2.4 Error

Listing 4: samples/error.cpp

```
* Sample code for error callback usage.
   #include <cepton_sdk_api.hpp>
   int main(int argc, char** argv) {
     // Initialize
     cepton_sdk::api::SensorErrorCallback error_callback;
     CEPTON_CHECK_ERROR(error_callback.listen(
         [&] (cepton_sdk::SensorHandle handle,
10
             const cepton_sdk::SensorError& error) { throw error; }));
11
     CEPTON_CHECK_ERROR(cepton_sdk::initialize(
12
         CEPTON_SDK_VERSION, cepton_sdk::create_options(),
13
         error_callback.global_on_callback, &error_callback));
     // Deinitialize
16
     cepton_sdk::deinitialize().ignore();
17
18
```

2.5 Sensor

Listing 5: samples/sensor.cpp

```
/**
2 * Sample code for sensor information.
3 */
```

```
#include <string>
   #include <cepton_sdk_api.hpp>
6
   #include "common.hpp"
   int main(int argc, char **argv) {
10
     check_help(argc, argv, "cepton_sdk_sample_sensor [capture_path]",
11
                 "Print information for all sensors.");
12
     std::string capture_path;
13
     if (argc >= 2) capture_path = argv[1];
14
     // Initialize
     auto options = cepton_sdk::create_options();
17
     CEPTON_CHECK_ERROR(cepton_sdk::api::initialize(options, capture_path, true));
18
19
     // Get all sensors
20
     const int n_sensors = (int)cepton_sdk::get_n_sensors();
21
     for (int i = 0; i < n_sensors; ++i) {</pre>
22
       cepton_sdk::SensorInformation sensor_info;
23
       CEPTON_CHECK_ERROR (
24
           cepton_sdk::get_sensor_information_by_index(i, sensor_info));
25
       std::printf("%i: %s\n", (int)sensor_info.serial_number,
26
                    sensor_info.model_name);
27
     // Deinitialize
30
     cepton_sdk::deinitialize().ignore();
31
32
```

2.6 Advanced

2.6.1 Frame

Listing 6: samples/advanced/frame.cpp

```
* Sample code for custom frame accumulation.
2
   #include <cepton_sdk_api.hpp>
   int main(int argc, char **argv) {
     std::string capture_path;
     if (argc >= 2) capture_path = argv[1];
10
     // Initialize
11
     auto options = cepton_sdk::create_options();
12
     CEPTON_CHECK_ERROR(cepton_sdk::api::initialize(options, capture_path));
13
     cepton_sdk::api::SensorImageFrameCallback callback;
     CEPTON_CHECK_ERROR(callback.initialize());
15
16
     // Get sensor
```

(continues on next page)

2.6. Advanced 7

```
while (cepton_sdk::get_n_sensors() == 0)
18
       CEPTON_CHECK_ERROR(cepton_sdk::api::wait(0.1f));
19
     cepton_sdk::SensorInformation sensor_info;
20
     CEPTON_CHECK_ERROR (
21
         cepton_sdk::get_sensor_information_by_index(0, sensor_info));
22
23
     // Create accumulator
24
     auto frame_options = cepton_sdk::create_frame_options();
25
     frame_options.mode = CEPTON_SDK_FRAME_TIMED;
26
     frame_options.length = 0.1f;
27
     cepton_sdk::util::FrameAccumulator accumulator(sensor_info);
28
     CEPTON_CHECK_ERROR(accumulator.set_options(frame_options));
     CEPTON_CHECK_ERROR(callback.listen(
         [&] (cepton_sdk::SensorHandle handle, std::size t n_points,
31
             const cepton_sdk::SensorImagePoint *const c_image_points) {
32
           if (handle != sensor_info.handle) return;
33
           accumulator.add_points((int)n_points, c_image_points);
34
         }));
35
36
     // Listen
37
     CEPTON_CHECK_ERROR(accumulator.callback.listen(
38
         [&] (int n_points,
39
              const cepton_sdk::SensorImagePoint *const c_image_points) {
40
           std::printf("Received %i points\n", n_points);
41
         }));
42
     CEPTON_CHECK_ERROR(cepton_sdk::api::wait(5.0f));
44
45
     // Deinitialize
46
     cepton_sdk::deinitialize().ignore();
47
48
```

2.6.2 Network

Listing 7: samples/advanced/network.cpp

```
2
    * Sample code for custom networking.
    */
3
   #include <asio.hpp>
4
   #include <cepton_sdk_api.hpp>
6
   using asio::ip::udp;
8
   class SocketListener {
10
   public:
11
     SocketListener() : m_socket(m_io_service, udp::v4()) {
12
13
       m_socket.set_option(asio::socket_base::reuse_address(true));
       m_socket.bind(udp::endpoint(udp::v4(), 8808));
15
16
     void run() {
17
18
       listen();
       m_io_service.run_for(std::chrono::seconds(5));
```

```
}
20
21
     void listen() {
22
       m_socket.async_receive_from(
23
            asio::buffer(m_buffer), m_end_point,
            [this] (const asio::error_code& error, std::size_t buffer_size) {
25
              if (buffer_size == 0) return;
26
              if (error == asio::error::operation_aborted) return;
27
              const CeptonSensorHandle handle =
28
                  m_end_point.address().to_v4().to_ulong();
29
              // For more accurate timestamps, a separate network receive thread
30
              // should be
              // used.
              const int64 t timestamp = cepton_sdk::util::get_timestamp_usec();
33
              CEPTON_CHECK_ERROR(cepton_sdk::mock_network_receive(
34
                  handle, timestamp, m_buffer.data(), buffer_size));
35
              listen();
36
            });
37
38
39
    private:
40
     asio::io_context m_io_service;
41
     udp::socket m_socket;
42
43
     udp::endpoint m_end_point;
     std::array<uint8_t, 4096> m_buffer;
   };
46
   int main() {
47
     // Initialize
48
     auto options = cepton_sdk::create_options();
49
     options.control_flags |= CEPTON_SDK_CONTROL_DISABLE_NETWORK;
51
     options.frame.mode = CEPTON_SDK_FRAME_COVER;
     CEPTON_CHECK_ERROR(cepton_sdk::api::initialize(options));
52
53
     // Listen for points
54
     cepton_sdk::api::SensorImageFrameCallback callback;
55
     CEPTON_CHECK_ERROR(callback.initialize());
56
     CEPTON_CHECK_ERROR (
         callback.listen([](cepton_sdk::SensorHandle handle, std::size_t n_points,
                              const cepton_sdk::SensorImagePoint* c_image_points) {
59
            std::printf("Received %i points from sensor %lli\n", (int)n_points,
60
                         (long long) handle);
61
         }));
62.
63
     SocketListener listener;
     listener.run();
65
66
     // Deinitialize
67
     cepton_sdk::deinitialize().ignore();
68
```

2.6.3 Organize Points

2.6. Advanced 9

Listing 8: samples/advanced/organize_points.cpp

```
/************************
2
    ** Copyright (C) 2019 Cepton Technologies. All Rights Reserved.
    ** Contact: https://www.cepton.com
    ** Sample code which opens a cepton sensor pcap file, organizes **
6
    ** the points and continuously saves the most recent organized **
    ** points to a frame to a cvs file "organized_cloud.cvs
    *************************
   #include <cepton_sdk_util.hpp>
11
   #include <cepton_sdk/capture.hpp>
12
   #include <cepton_sdk_api.hpp>
13
14
   using namespace cepton_sdk::util;
15
   int main(int argc, char** argv) {
17
     if (argc < 2) return -1;
18
     const std::string capture_path = argv[1];
19
20
     // Initialize sdk
21
     auto options = cepton_sdk::create_options();
22
     options.control_flags |= CEPTON_SDK_CONTROL_DISABLE_NETWORK;
23
     options.frame.mode = CEPTON_SDK_FRAME_COVER;
24
     CEPTON_CHECK_ERROR(cepton_sdk::api::initialize(options));
25
26
     cepton_sdk::SensorInformation sensor_info;
27
28
     OrganizedCloud organized_cloud;
29
     std::ofstream os;
30
31
     cepton_sdk::Capture m_capture;
32
     CEPTON_CHECK_ERROR(m_capture.open_for_read(capture_path));
33
34
     CEPTON_CHECK_ERROR (
35
         cepton_sdk_set_control_flags(CEPTON_SDK_CONTROL_DISABLE_NETWORK,
                                      CEPTON_SDK_CONTROL_DISABLE_NETWORK));
37
     CEPTON_CHECK_ERROR(cepton_sdk_clear());
38
39
     // Listen for points
40
     cepton_sdk::api::SensorImageFrameCallback callback;
41
     CEPTON_CHECK_ERROR(callback.initialize());
42
     callback.listen([@](cepton_sdk::SensorHandle handle, std::size_t n_points,
43
                        const cepton_sdk::SensorImagePoint* c_image_points) {
44
45
       cepton_sdk::get_sensor_information(handle, sensor_info);
46
47
       std::printf("Received %i points from sensor %lli\n", static_cast<int>(n_points),
48
                   static_cast<long long>(handle));
49
50
       Organizer organizer (sensor_info);
51
52
       organizer.organize_points(n_points,
53
                                 sensor_info.return_count,
54
                                 c_image_points,
```

```
organized_cloud);
56
57
       os.open("organize_cloud.csv");
58
       for (const auto@ point : organized_cloud.points)
59
60
         if (point.valid)
61
62
            float x = 0;
63
            float y = 0;
64
           float z = 0;
65
            cepton_sdk::util::convert_image_point_to_point(
                point.image_x, point.image_z, point.distance, x,
69
           os << x << "," << y << "," << z << "\n";
70
71
       }
72
       os.close();
73
74
     });
75
     while (true) {
76
       cepton_sdk::Capture::PacketHeader header;
77
       const uint8_t* data;
78
       CEPTON_CHECK_ERROR(m_capture.next_packet(header, data));
79
81
       const cepton_sdk::SensorHandle handle =
           static_cast<cepton_sdk::SensorHandle>(header.ip_v4) |
82
            CEPTON_SENSOR_HANDLE_FLAG_MOCK;
83
       CEPTON_CHECK_ERROR(cepton_sdk_mock_network_receive(
84
            handle, header.timestamp, data, static_cast<size_t>(header.data_size)));
85
86
```

2.6.4 Process Multi

Listing 9: samples/advanced/process multi.cpp

```
* Sample code for processing multiple sensor data.
2
3
   #include <string>
4
   #include <vector>
   #include <cepton_sdk_api.hpp>
7
   struct Frame {
9
     int64_t timestamp;
10
     std::map<cepton_sdk::SensorHandle, std::vector<cepton_sdk::SensorImagePoint>>
11
12
         image_points_dict;
   };
14
   class FrameAccumulator {
15
   public:
16
     void on_image_frame(
17
         cepton_sdk::SensorHandle handle, std::size_t n_points,
```

(continues on next page)

2.6. Advanced 11

```
const cepton_sdk::SensorImagePoint* const c_image_points) {
19
       cepton_sdk::util::LockGuard lock(m_mutex);
20
21
        auto& image_points = m_image_points_dict[handle];
22
        image_points.reserve(image_points.size() + n_points);
23
        image_points.insert(image_points.end(), c_image_points,
24
                             c_image_points + n_points);
25
26
       check_and_publish();
27
     }
28
29
    private:
31
     void check_and_publish() {
       const auto timestamp = cepton_sdk::api::get_time();
32
33
       if (timestamp < m_timestamp) return;</pre>
34
       if ((timestamp - m_timestamp) < int64_t(m_frame_length * 1e6f)) return;</pre>
35
       m_timestamp = timestamp;
37
       auto frame = std::make_shared<Frame>();
38
       frame->timestamp = timestamp;
39
       frame->image_points_dict = m_image_points_dict;
40
       m_image_points_dict.clear();
41
42
       queue.push (frame);
43
45
     cepton_sdk::util::SingleConsumerQueue<Frame> queue;
46
47
    private:
48
49
     std::timed_mutex m_mutex;
     float m_frame_length = 0.1f;
     int64_t m_timestamp = 0;
51
     std::map<cepton_sdk::SensorHandle, std::vector<cepton_sdk::SensorImagePoint>>
52
         m_image_points_dict;
53
54
   };
55
   int main(int argc, char** argv) {
57
     std::string capture_path;
     if (argc >= 2) capture_path = argv[1];
58
59
     // Initialize
60
     auto options = cepton_sdk::create_options();
61
     CEPTON_CHECK_ERROR(cepton_sdk::api::initialize(options, capture_path));
62
63
     cepton_sdk::api::SensorImageFrameCallback callback;
     CEPTON_CHECK_ERROR(callback.initialize());
64
     if (cepton_sdk::capture_replay::is_open())
65
       CEPTON_CHECK_ERROR(cepton_sdk::capture_replay::resume());
66
67
     // Listen
68
     FrameAccumulator accumulator;
     CEPTON_CHECK_ERROR (
         callback.listen(&accumulator, &FrameAccumulator::on_image_frame));
71
     while (true) {
72
       const auto frame = accumulator.queue.pop(0.01f);
73
       if (!frame) continue;
74
        // Do processing
```

2.6.5 Process Single

Listing 10: samples/advanced/process_single.cpp

```
2
    * Sample code for processing single sensor data.
3
   #include <memory>
   #include <vector>
   #include <cepton_sdk_api.hpp>
   struct Frame {
9
     int64 t timestamp;
10
     cepton_sdk::SensorHandle handle;
11
     std::vector<cepton_sdk::SensorImagePoint> image_points;
12
   };
13
15
   int main(int argc, char **argv) {
     std::string capture_path;
16
     if (argc >= 2) capture_path = argv[1];
17
18
     // Initialize
19
     auto options = cepton_sdk::create_options();
     options.frame.mode = CEPTON_SDK_FRAME_TIMED;
21
     options.frame.length = 0.1f;
22
     CEPTON_CHECK_ERROR(cepton_sdk::api::initialize(options, capture_path));
23
     cepton_sdk::api::SensorImageFrameCallback callback;
24
     CEPTON_CHECK_ERROR(callback.initialize());
25
     if (cepton_sdk::capture_replay::is_open())
27
       CEPTON_CHECK_ERROR(cepton_sdk::capture_replay::resume());
28
     // Listen
29
     cepton_sdk::util::SingleConsumerQueue<Frame> queue;
30
     CEPTON_CHECK_ERROR (
31
         callback.listen([&](cepton_sdk::SensorHandle handle, std::size_t n_points,
32
33
                               const cepton_sdk::SensorImagePoint *c_image_points) {
           auto frame = std::make_shared<Frame>();
34
            frame->timestamp = cepton_sdk::api::get_time();
35
           frame->handle = handle;
36
           frame->image_points.reserve(n_points);
37
           frame->image_points.insert(frame->image_points.end(), c_image_points,
38
                                        c_image_points + n_points);
           queue.push (frame);
41
         }));
     while (true) {
42
       const auto frame = queue.pop(0.01f);
43
       if (!frame) continue;
44
        // Do processing
```

(continues on next page)

2.6. Advanced 13

```
46    }
47
48    // Deinitialize
49    cepton_sdk::deinitialize().ignore();
50  }
```

2.6.6 Replay

Listing 11: samples/advanced/replay.cpp

```
2
    * Sample code for custom packet replaying.
   #include <cepton_sdk/capture.hpp>
   #include <cepton_sdk_api.hpp>
   class CaptureReplay {
    public:
     CaptureReplay(const std::string& path) {
       CEPTON_CHECK_ERROR(m_capture.open_for_read(path));
10
11
       CEPTON_CHECK_ERROR (
12
           cepton_sdk_set_control_flags(CEPTON_SDK_CONTROL_DISABLE_NETWORK,
                                           CEPTON_SDK_CONTROL_DISABLE_NETWORK));
15
       CEPTON_CHECK_ERROR(cepton_sdk_clear());
     }
16
17
     ~CaptureReplay() {
18
19
       m_capture.close();
20
       if (cepton_sdk_is_initialized()) {
          CEPTON_CHECK_ERROR(cepton_sdk_clear());
21
22
     }
23
24
25
     void run() {
       while (true) {
         cepton_sdk::Capture::PacketHeader header;
         const uint8_t* data;
28
         CEPTON_CHECK_ERROR(m_capture.next_packet(header, data));
29
30
         const cepton_sdk::SensorHandle handle =
31
              (cepton_sdk::SensorHandle)header.ip_v4 |
32
33
              CEPTON_SENSOR_HANDLE_FLAG_MOCK;
          CEPTON_CHECK_ERROR(cepton_sdk_mock_network_receive(
34
              handle, header.timestamp, data, header.data_size));
35
36
37
38
   private:
     cepton_sdk::Capture m_capture;
41
42
   int main(int argc, char** argv) {
43
     if (argc < 2) return -1;
44
     const std::string capture_path = argv[1];
```

```
46
     // Initialize
47
     auto options = cepton_sdk::create_options();
48
     options.control_flags |= CEPTON_SDK_CONTROL_DISABLE_NETWORK;
49
     options.frame.mode = CEPTON_SDK_FRAME_COVER;
     CEPTON_CHECK_ERROR(cepton_sdk::api::initialize(options));
51
52
     // Listen for points
53
     cepton_sdk::api::SensorImageFrameCallback callback;
54
     CEPTON_CHECK_ERROR(callback.initialize());
55
     CEPTON_CHECK_ERROR (
56
         callback.listen([](cepton_sdk::SensorHandle handle, std::size_t n_points,
                              const cepton_sdk::SensorImagePoint* c_image_points) {
           std::printf("Received %i points from sensor %lli\n", (int)n_points,
59
                         (long long) handle);
60
         }));
61
62
     // Run
63
     CaptureReplay replay(capture_path);
     replay.run();
65
66
     // Deinitialize
67
     cepton_sdk::deinitialize().ignore();
68
```

2.6.7 Stray

Listing 12: samples/advanced/stray.cpp

```
2
    * Sample code for stray filter usage.
3
   #include <vector>
4
   #include <cepton_sdk_api.hpp>
   int main(int argc, char **argv) {
     // Initialize
     CEPTON_CHECK_ERROR(cepton_sdk::api::initialize());
10
11
     cepton_sdk::api::SensorImageFrameCallback callback;
12
     CEPTON_CHECK_ERROR(callback.initialize());
13
     cepton_sdk::util::StrayFilter filter;
     CEPTON_CHECK_ERROR (
15
         callback.listen([&](cepton_sdk::SensorHandle handle, std::size_t n_points,
16
                              const cepton sdk::SensorImagePoint *c image points) {
17
           // Get sensor
18
           cepton_sdk::SensorInformation sensor_info;
19
20
           CEPTON_CHECK_ERROR (
               cepton_sdk::get_sensor_information(handle, sensor_info));
21
22
           // Copy points to buffer
23
           std::vector<cepton_sdk::SensorImagePoint> image_points;
24
           image_points.insert(image_points.begin(), c_image_points,
25
                                c_image_points + n_points);
```

(continues on next page)

2.6. Advanced 15

```
27
            // Filter stray
28
            filter.init(sensor_info);
29
            filter.run((int)n_points, image_points.data());
31
32
      // Run
33
     CEPTON_CHECK_ERROR(cepton_sdk::api::wait(5.0f));
34
35
     // Deinitialize
     cepton_sdk::deinitialize().ignore();
37
```

CHAPTER

THREE

ERRORS

3.1 Types

class SensorError: public runtime_error

Error returned by most functions.

Implicitly convertible from/to SensorErrorCode. Getter functions do not return an error, because they cannot fail. Will call CEPTON_RUNTIME_ASSERT if nonzero error is not used (call ignore to manually use error).

Public Functions

```
SensorError (SensorErrorCode code_, const std::string &msg_)
SensorError (SensorErrorCode code_)
SensorError()
~SensorError()
SensorError (const SensorError &other)
SensorError &operator= (const SensorError &other)
bool used() const
    Internal use only.
const SensorError &ignore() const
    Mark error as used.
const std::string &msg() const
    Returns error message;.
SensorErrorCode code() const
    Returns error code.
operator SensorErrorCode() const
    Implicitly convert to SensorErrorCode.
operator bool() const
    Returns false if code is CEPTON_SUCCESS, true otherwise.
const std::string name() const
bool is_error() const
```

```
bool is_fault() const
_CeptonSensorErrorCode
     Values:
     1
     2
     4
     5
     6
          Networking error.
     7
     8
          Invalid value or uninitialized struct.
     9
     10
     11
     12
     13
     14
     15
     1000
          Internal parameter out of range.
     1001
          Reading exceed spec.
     1002
          Reading exceeds spec.
     1003
     1004
     1005
     1006
     1007
     1008
```

${\tt typedef} \ \, int 32_t \, {\tt CeptonSensorErrorCode}$

3.2 Methods

```
const char* cepton_get_error_code_name (CeptonSensorErrorCode error_code)
Returns string name of error code.

Returns empty string if error code is invalid.
```

18 Chapter 3. Errors

int cepton_is_error_code (CeptonSensorErrorCode error_code)

Returns true if error name is of the form CEPTON_ERROR_*, false otherwise.

 $int \verb|cepton_is_fault_code|| (\textit{CeptonSensorErrorCode}|| error_code)|$

Returns true if error name is of the form $\texttt{CEPTON_FAULT_*}$, false otherwise.

CeptonSensorErrorCode cepton_sdk_get_error (const char ** error_msg)

Returns and clears last sdk error.

error_msg is owned by the SDK, and is valid until the next call in the current thread.

3.2. Methods

20 Chapter 3. Errors

CHAPTER

FOUR

SETUP

4.1 Types

_CeptonSDKControl

SDK control flags.

Values:

1

Disable networking operations.

Useful for running multiple instances of sdk in different processes. Must pass packets manually to cepton_sdk::mock_network_receive.

2

Disable marking image clipped points as invalid.

Does not affect number of points returned.

3

Disable marking distance clipped points as invalid.

Does not affect number of points returned.

4

Enable multiple returns.

When set, <code>cepton_sdk::SensorInformation::return_count</code> will indicate the number of returns per laser. Can only be set at sdk initialization.

5

Enable marking stray points as invalid (measurement noise).

Uses cepton_sdk::util::StrayFilter to mark points invalid.

Does not affect number of points returned.

6

Always use packet timestamps (disable GPS/PTP timestamps).

7

Enable marking crosstalk points as invalid.

typedef uint32_t CeptonSDKControl

_CeptonSDKFrameMode

Controls frequency of points being reported.

Values:

```
0
          Report points by packet.
     1
          Report points at fixed time intervals.
          Interval controlled by CeptonSDKFrameOptions::length.
     2
          Report points when the field of view is covered once.
            • For HR80 series, detects half scan cycle (left-to-right or right-to-left).
     3
          Report points when the scan pattern goes through a full cycle.
          Typically 2x longer frame than COVER mode.
            • For HR80 series, detects full scan cycle (left-to-right-to-left).
            • For VISTA series, internally uses TIMED mode.
     3
typedef uint32_t CeptonSDKFrameMode
struct CeptonSDKFrameOptions
     Public Members
     size_t signature
          Internal use only.
     Cepton SDK Frame Mode \ \mathbf{mode}
          Default: CEPTON_SDK_FRAME_STREAMING.
     float length
          Frame length [seconds].
          Default: 0.05. Only used if mode=CEPTON_SDK_FRAME_TIMED.
struct CeptonSDKFrameOptions cepton_sdk_create_frame_options()
     Create default frame options.
struct CeptonSDKOptions
     SDK initialization options.
     Public Members
     size_t signature
          Internal use only.
     CeptonSDKControl control_flags
          Default: 0.
     struct CeptonSDKFrameOptions frame
     uint16_t port
          Default: 8808.
struct CeptonSDKOptions cepton_sdk_create_options()
     Create default options.
```

22 Chapter 4. Setup

4.2 Methods

float cepton_sdk_get_frame_length()

```
CeptonSensorErrorCode cepton_sdk_initialize (int ver, const struct CeptonSDKOptions *const op-
                                                        FpCeptonSensorErrorCallback cb,
                                                 tions,
                                                 *const user_data)
     Initializes settings and networking.
     Must be called before any other sdk function listed below.
CeptonSensorErrorCode cepton_sdk_deinitialize()
     Resets everything and deallocates memory.
CeptonSensorErrorCode cepton_sdk_clear()
     Clears sensors.
     Use when loading/unloading capture file.
CeptonSensorErrorCode cepton_sdk_set_control_flags (CeptonSDKControl mask, CeptonSD-
                                                          KControl flags)
CeptonSDKControl cepton_sdk_get_control_flags()
int cepton_sdk_has_control_flag (CeptonSDKControl flag)
uint16_t cepton_sdk_get_port()
CeptonSensorErrorCode cepton_sdk_set_port (uint16_t port)
     Sets network listen port.
     Default: 8808.
CeptonSensorErrorCode cepton_sdk_set_frame_options (const struct CeptonSDKFrameOptions
                                                          *const options)
CeptonSDKFrameMode cepton_sdk_get_frame_mode()
```

4.2. Methods 23

24 Chapter 4. Setup

CHAPTER

FIVE

SENSORS

5.1 Types

```
\textbf{typedef} \ \ Cepton Sensor Handle} \ cepton\_\texttt{sdk::Sensor Handle}
_CeptonSensorModel
     Values:
     1
     2
     3
     4
     5
     6
     7
     8
     10
     11
     12
     13
     14
     15
     16
     17
     18
     18
typedef uint16_t CeptonSensorModel
```

struct CeptonSensorInformation

Public Members

```
CeptonSensorHandle handle
uint64_t serial_number
char CeptonSensorInformation::model_name[28]
Cepton Sensor Model \ {\tt model}
uint16_t reserved
char CeptonSensorInformation::firmware_version[28]
uint8_t major
uint8_t minor
uint8_t CeptonSensorInformation::unused[2]
struct CeptonSensorInformation::@16 formal_firmware_version
float last_reported_temperature
    [celsius]
float last_reported_humidity
float last_reported_age
    [hours]
float measurement_period
    Time between measurements [seconds].
int64_t ptp_ts
    [microseconds]
uint8_t gps_ts_year
    0-99(2017 -> 17)
uint8_t gps_ts_month
    1-12
uint8_t gps_ts_day
    1-31
uint8_t gps_ts_hour
    0 - 23
uint8_t gps_ts_min
    0-59
uint8_t gps_ts_sec
    0-59
uint8_t return_count
uint8_t segment_count
    Number of image segments.
uint32_t flags
    Bit flags.
uint32 tis mocked
    Created by capture replay.
```

26 Chapter 5. Sensors

```
uint32_t is_pps_connected
GPS PPS is available.

uint32_t is_nmea_connected
GPS NMEA is available.

uint32_t is_ptp_connected
PTP is available.

uint32_t is_calibrated

uint32_t is_over_heated
Hit temperature limit (only available in Vista Gen2 for now)

uint32_t is_sync_firing_enabled

union CeptonSensorInformation::@17 CeptonSensorInformation::@18
```

5.2 Methods

```
size_t cepton_sdk_get_n_sensors()
```

Get number of sensors attached. Use to check for new sensors. Sensors are not deleted until deinitialization.

```
CeptonSensorErrorCode cepton_sdk_get_sensor_handle_by_serial_number (uint64_t serial_number, CeptonSensorHandle *const handle)
```

Returns error if sensor not found.

Valid indices are in range [0, n_sensors). Returns error if index invalid.

CeptonSensorErrorCode cepton_sdk_get_sensor_information (CeptonSensorHandle handle, struct CeptonSensorInformation *const info)

Returns error if sensor not found.

5.2. Methods 27

28 Chapter 5. Sensors

CHAPTER

SIX

POINTS

6.1 Types

struct CeptonSensorImagePoint

```
Point in image coordinates (focal length = 1).
To convert to 3d point, refer to cepton_sdk_util.hpp.
Public Members
int64_t timestamp
     Unix time [microseconds].
float image_x
    x image coordinate.
float distance
    Distance [meters].
float image_z
     z image coordinate.
float intensity
     Diffuse reflectance.
CeptonSensorReturnType return_type
uint8_t flags
     Bit flags.
uint8 t valid
     If false, then the distance and intensity are invalid.
uint8_t saturated
    If true, then the intensity is invalid. Also, the distance is valid, but inaccurate.
union CeptonSensorImagePoint::@21 CeptonSensorImagePoint::@22
uint8_t CeptonSensorImagePoint::reserved[2]
```

6.2 Methods

Callback for receiving image points.

Set the frame length to control the callback rate.

```
CeptonSensorErrorCode cepton_sdk_listen_image_frames (FpCeptonSensorImageDataCallback cb, void *const user_data)
```

Sets image frames callback.

Returns points at frequency specified by <code>cepton_sdk::FrameOptions::mode</code>. Each frame contains all possible points (use <code>cepton_sdk::SensorImagePoint::valid</code> to filter points). Points are ordered by measurement, segment, and return:

```
measurement_count = n_points / (segment_count * return_count)
idx = ((i_measurement) * segment_count + i_segment) * return_count + i_return
```

Returns error if callback already registered.

CeptonSensorErrorCode cepton_sdk_unlisten_image_frames()

30 Chapter 6. Points

CHAPTER

SEVEN

SERIAL

Serial callback. Primarily used for receiving data from GPS/INS attached to sensor.

7.1 Types

```
typedef void (* FpCeptonSerialReceiveCallback) (CeptonSensorHandle handle, const char *str, void *user_data)

Callback for receiving serial data (e.g. NMEA).
```

7.2 Methods

CeptonSensorErrorCode cepton_sdk_listen_serial_lines(FpCeptonSerialReceiveCallback cb, void *const user_data)

Sets serial line callback.

Useful for listening to NMEA data from GPS attached to sensor.

Each callback contains 1 line of serial data (including newline characters).

Returns error if callback already registered.

CeptonSensorErrorCode cepton_sdk_unlisten_serial_lines()

32 Chapter 7. Serial

CHAPTER

EIGHT

NETWORKING

Network callback for debugging.

8.1 Types

```
typedef void (* FpCeptonNetworkReceiveCallback) (CeptonSensorHandle handle, int64_t timestamp, const uint8_t *buffer, size_t buffer_size, void *user_data)

Callback for receiving network packets.
```

Parameters

• handle: Unique sensor identifier (e.g. IP address). Returns error if callback already set.

8.2 Methods

 $\label{listen_network_packet} CeptonSensorErrorCode\ {\tt cepton_sdk_listen_network_packet}\ (FpCeptonNetworkReceiveCallback\ cb,\ void\ *const\ user_data)$ Sets network packets callback.

Only 1 callback can be registered.

CeptonSensorErrorCode cepton_sdk_unlisten_network_packet()

CAPTURE REPLAY

PCAP capture file replay. Source code can be found in the *source* folder. Functions are not thread safe, and should only be called from the main thread.

```
int cepton_sdk_capture_replay_is_open()
CeptonSensorErrorCode cepton_sdk_capture_replay_open (const char *const path)
     Opens capture file.
     Must be called before any other replay functions listed below.
CeptonSensorErrorCode cepton_sdk_capture_replay_close()
const char* cepton_sdk_capture_replay_get_filename()
int64_t cepton_sdk_capture_replay_get_start_time()
     Returns capture start timestamp (unix time [microseconds]).
float cepton_sdk_capture_replay_get_position()
     Returns capture file position [seconds].
float cepton_sdk_capture_replay_get_length()
     Returns capture file length [seconds].
int cepton_sdk_capture_replay_is_end()
     Returns true if at end of capture file.
     This is only relevant when using resume_blocking methods.
CeptonSensorErrorCode cepton_sdk_capture_replay_seek (float position)
     Seek to capture file position [seconds].
     Position must be in range [0.0, capture length). Returns error if position is invalid.
CeptonSensorErrorCode cepton_sdk_capture_replay_set_enable_loop (int enable_loop)
     If enabled, replay will automatically rewind at end.
int cepton_sdk_capture_replay_get_enable_loop()
CeptonSensorErrorCode cepton_sdk_capture_replay_set_speed (float speed)
     Replay speed multiplier for asynchronous replay.
float cepton_sdk_capture_replay_get_speed()
CeptonSensorErrorCode cepton_sdk_capture_replay_resume_blocking_once()
     Replay next packet in current thread without sleeping.
     Pauses replay thread if it is running.
CeptonSensorErrorCode cepton_sdk_capture_replay_resume_blocking (float duration)
```

Replay multiple packets synchronously.

No sleep between packets. Resume duration must be non-negative. Pauses replay thread if it is running.

int cepton_sdk_capture_replay_is_running()

Returns true if replay thread is running.

CeptonSensorErrorCode cepton_sdk_capture_replay_resume()

Packets are replayed in realtime. Replay thread sleeps in between packets.

CeptonSensorErrorCode cepton_sdk_capture_replay_pause()

Pauses asynchronous replay thread.

CHAPTER

TEN

C++

```
High level C++ API for prototyping (cepton_sdk_api.hpp). Methods are agnostic to live/replay mode.

bool cepton_sdk::api::is_live()
    Returns true if capture replay is not open.

bool cepton_sdk::api::is_end()

int64_t cepton_sdk::api::get_time()
    Returns capture replay time or live time.

SensorError cepton_sdk::api::wait(float t_length = -1.0f)
    Sleeps or resumes capture replay for duration.

If t_length < 0, then waits forever.
```

10.1 Errors

```
SensorError cepton_sdk::api::check_error(const SensorError &error, const std::string &msg = "")

DEPRECATED: use CEPTON_CHECK_ERROR.

SensorError cepton_sdk::api::log_error(const SensorError &error, const std::string &msg = "")

DEPRECATED: use CEPTON_LOG_ERROR.

void cepton_sdk::api::default_on_error(SensorHandle h, SensorErrorCode error_code, const char *const error_msg, const void *const error_data, std::size_t error_data_size, void *const in-stance)

Basic SDK error callback.

Calls cepton_sdk::api::check_error_code.
```

10.2 Setup

class SensorErrorCallback : public cepton_sdk::util::CallbackSensorHandle, const SensorError&>
Callback for sensor errors.

Public Static Functions

```
static void global_on_callback (SensorHandle handle, SensorErrorCode error_code, const char *error_msg, const void *const error_data, size_t error_data_size, void *const instance)
```

class SensorImageFrameCallback : public cepton_sdk::util::CallbackSensorHandle, std::size_t, const SensorImagePort
Callback for image frames.

Must call initialize before use.

Public Functions

```
~SensorImageFrameCallback()

SensorError initialize()

SensorError deinitialize()

bool is_initialized() const
```

Must call initialize before use.

Public Functions

```
~NetworkPacketCallback()

SensorError initialize()

SensorError deinitialize()
```

10.3 Sensors

```
bool cepton_sdk::api::has_sensor_by_serial_number (uint64_t serial_number)

SensorError cepton_sdk::api::get_sensor_information_by_serial_number (uint64_t serial_number, SensorInformation & SensorInformatio
```

38 Chapter 10. C++

CHAPTER

ELEVEN

UTILITIES

Utility functions and classes for prototyping (cepton_sdk_util.hpp).

11.1 Common

```
int64_t cepton_sdk::util::get_timestamp_usec()
```

Returns current unix timestamp [microseconds].

This is the timestamp format used by all sdk functions.

11.2 Points

Convert image point to 3d point.

struct SensorPoint

3d point class.

Can't subclass from SensorImagePoint, needs to be POD.

Public Members

int64_t timestamp

Unix time [microseconds].

float image_x

x image coordinate.

float distance

Distance [meters].

float image_z

z image coordinate.

float intensity

Diffuse reflectance.

CeptonSensorReturnType return_type

uint8_t flags

```
uint8 t valid
     uint8_t saturated
     union cepton_sdk::util::SensorPoint::[anonymous] [anonymous]
     uint8_t reserved[5]
     float x
         x cartesian coordinate
     float y
         y cartesian coordinate
     float z
         z cartesian coordinate
void cepton_sdk::util::convert_sensor_image_point_to_point (const
                                                                                   SensorImage-
                                                                         Point
                                                                                  &image_point,
                                                                         SensorPoint &point)
     Convenience
                      method
                                           convert
                                                        cepton_sdk::SensorImagePoint
                                                                                                  to
     cepton_sdk::SensorPoint.
11.3 Callbacks
template<typename ... TArgs>
class Callback
     Expands SDK callback functionality.
     Allows for multiple callbacks to be registered. Allows for registering lambdas and member functions. See
     samples/basic.cpp.
```

Public Functions

11.4 Frames

class FrameDetector

Detects frames in streaming sensor data.

Public Functions

```
FrameDetector (const SensorInformation & sensor_info)

const FrameOptions & get_options () const

SensorError set_options (const FrameOptions & options)

void reset ()

Completely resets detector.

Only use if also clearing points accumulator.

bool add_point (const SensorImagePoint & point)

Returns true if frame found.

Automatically resets after frame is found.
```

Public Members

```
bool frame_found
int frame_idx
float frame_x
Number of points in current frame.
```

class FrameAccumulator

Accumulates image points, and emits frames to callback.

```
See samples/frame.cpp.
```

Public Functions

```
FrameAccumulator (const SensorInformation & sensor_info)

FrameOptions get_options() const

SensorError set_options (const FrameOptions & options)

void clear()

void add_points (int n_points, const SensorImagePoint *const image_points)
```

Public Members

Callback<int, const SensorImagePoint *> callback

11.4. Frames 41

11.5 Organizer

struct OrganizedCloud

The OrganizedCloud struct An organized version of the cepton point cloud.

Public Functions

```
int getIndex (int row, int col, int n_return)
```

getIndex Returns the index of the point corresponding to the inputed row, col and return number.

Return

Parameters

- [in] row: Row index
- [in] col: Colindex
- [in] n_return: Return index

Public Members

int64_t timestamp_start

timestamp_start The time of the oldest point in the cloud

int64_t timestamp_end

timestamp_end The time of the newest point in the cloud

int **height**

height Height of the cloud. Represents how many rows there are in the cloud

int width

width Width of the cloud. Represents how many columns there are in the cloud

int n returns

n_returns Number of return represented by the cloud.

std::vector<*CellInfo*> info_cells

info_cells Vector of cell info which provide information about the matching points

std::vector<CeptonSensorImagePoint>points

points Vector of organized points. Stored in Return, Row, Col order. So to get a point at row 10, col 15, return 1 would be points[(row * width

• col) n_returns + return

struct CellInfo

The CellInfo struct.

Public Members

bool occupied_cell = false

occupied_cell Is the cell at this index occupied with a point. If false can't assume this represents free space.

int original index = -1

original_index Index of the point that was used to generate the organized point. Can be used to match back with orginial data if required. Should only be use if occupied_cell is true.

class Organizer

The *Organizer* class Performs organization on cepton unorganized points. Creates an angular grid, places each point within that grid and outputs a point for each location in the grid in a row/col format. Thread safe. Defaults to a 0.4deg spaced grid.

Public Types

enum OrganizerMode

Values:

RECENT

Output the most recent point from the frame that fell within the grid

CENTER

Output the center of the grid. Uses median point distance.

Public Functions

```
Organizer (cepton_sdk::SensorInformation sensor_info)
Organizer.
```

Parameters

• sensor_info: Sensor info for organizer. Used to set min/max angles

```
void organize_points (const int num_points_in, const int n_returns, const CeptonSensorIm-agePoint *const unorganized_points, cepton_sdk::util::OrganizedCloud &organized_points)
organize points
```

Parameters

- [in] num_points_in: Number of unorganized points
- [in] n_returns: Number of returns
- [in] unorganized_points: Unorganized points to proces
- [out] organized_points: Points in organized form

void mode (OrganizerMode mode) mode

Parameters

mode: Change the mode of the organizer. [RECENT] Points are the most recent which fill within
the grid. [CENTER] Points outputted are at the center of the grid. More even spacing but less
accurate.

```
void binSize (float bin_size)
```

binSize Change the bin size of the organizer

11.5. Organizer 43

Parameters

• bin_size: The horizontal and vertical bin size to set. In radians

```
void settings (OrganizerSettings organizer_settings) settings
```

Parameters

• organizer_settings: Change organizer settings

```
Organizer::OrganizerSettings settings()
    settings
```

Return The settings the organizer is using

struct OrganizerSettings

Public Members

```
float horizontal_range_radians = to_radians(70.f)
float vertical_range_radians = to_radians(30.f)
float horizontal_bin_size_radians = to_radians(0.4f)
float vertical_bin_size_radians = to_radians(0.4f)

OrganizerMode mode = OrganizerMode::RECENT
```

INDEX

```
\mathsf{C}
                                                                                                                                                                                                                        (C++ function), 38
                                                                                                                                                                                         cepton_sdk::api::wait (C++ function), 37
 cepton_get_error_code_name (Cfunction), 18
                                                                                                                                                                                         cepton_sdk::FpSensorErrorCallback (C++
 cepton_is_error_code (Cfunction), 18
                                                                                                                                                                                                                        type), 22
 cepton_is_fault_code (C function), 19
                                                                                                                                                                                         cepton_sdk::SensorError(C++ class), 17
 cepton_sdk::api::check_error (C++ func-
                                                                                                                                                                                         cepton_sdk::SensorError::~SensorError
                                                                                                                                                                                                                        (C++ function), 17
\verb|cepton_sdk::api::default_on_error| (C++
                                                                                                                                                                                         cepton_sdk::SensorError::code (C++ func-
                              function), 37
 cepton_sdk::api::get_sensor_information_by_seritar_ntmber
                                                                                                                                                                                         cepton_sdk::SensorError::ignore
                                                                                                                                                                                                                                                                                                                                                        (C++
                               (C++ function), 38
                                                                                                                                                                                                                      function), 17
 cepton_sdk::api::get_sensor_serial_numbers
                                                                                                                                                                                         cepton_sdk::SensorError::is_error (C++
                               (C++ function), 38
                                                                                                                                                                                                                       function), 17
cepton_sdk::api::get_time(C++ function), 37
\verb|cepton_sdk::api::has_sensor_by_serial_number | on_sdk::SensorError::is_fault | (C++) | on_sdk::SensorError::is_fault | (C+
                                                                                                                                                                                                                       function), 17
                               (C++function), 38
                                                                                                                                                                                         cepton_sdk::SensorError::msg (C++ func-
 cepton_sdk::api::initialize(C++ function),
                                                                                                                                                                                                                        tion), 17
                                                                                                                                                                                         cepton_sdk::SensorError::name (C++ func-
cepton_sdk::api::is_end(C++ function), 37
                                                                                                                                                                                                                        tion), 17
 cepton_sdk::api::is_live (C++ function), 37
                                                                                                                                                                                         cepton_sdk::SensorError::operator bool
 cepton_sdk::api::log_error (C++ function),
                                                                                                                                                                                                                        (C++function), 17
                                                                                                                                                                                         cepton_sdk::SensorError::operator
cepton_sdk::api::NetworkPacketCallback
                                                                                                                                                                                                                        SensorErrorCode (C++ function), 17
                               (C++ class), 38
function), 17
                               (C++ function), 38
cepton_sdk::api::NetworkPacketCallback::dePhonisdk:eSensorError::SensorError
                                                                                                                                                                                                                        (C++ function), 17
                               (C++function), 38
\texttt{cepton\_sdk::api::NetworkPacketCallback::} \underline{\texttt{ShPtPalsdk}} :: SensorError:: used (\textit{C++ func-time}) + functional content of the content o
                                                                                                                                                                                                                        tion), 17
                               (C++ function), 38
                                                                                                                                                                                         cepton_sdk::SensorHandle (C++ type), 25
 cepton_sdk::api::SensorErrorCallback
                                                                                                                                                                                         cepton_sdk::util::Callback (C++ class), 40
                               (C++ class), 37
function), 40
                               (C++ function), 38
\verb|cepton_sdk::api::SensorImageFrameCallback@epton_sdk::util::Callback::global_on_callback@epton_sdk::util::Callback::global_on_callback@epton_sdk::util::Callback::global_on_callback@epton_sdk::util::Callback::global_on_callback@epton_sdk::util::Callback::global_on_callback@epton_sdk::util::Callback::global_on_callback@epton_sdk::util::Callback::global_on_callback@epton_sdk::util::Callback::global_on_callback@epton_sdk::util::Callback::global_on_callback@epton_sdk::util::Callback::global_on_callback@epton_sdk::util::Callback::global_on_callback@epton_sdk::util::Callback::global_on_callback@epton_sdk::util::Callback::global_on_callback@epton_sdk::util::Callback::global_on_callback.gepton_sdk::util::Callback::global_on_callback.gepton_sdk::util::Callback::global_on_callback.gepton_sdk::util::Callback::global_on_callback.gepton_sdk::util::Callback::global_on_callback.gepton_sdk::util::Callback::global_on_callback.gepton_sdk::util::Callback::global_on_callback.gepton_sdk::util::Callback::global_on_callback.gepton_sdk::util::Callback::global_on_callback.gepton_sdk::util::Callback::global_on_callback.gepton_sdk::util::Callback::global_on_callback.gepton_sdk::util::Callback::global_on_callback.gepton_sdk::util::Callback::global_on_callback.gepton_sdk::util::Callback::global_on_callback.gepton_sdk::util::Callback::global_on_callback.gepton_sdk::util::Callback::global_on_callback.gepton_sdk::util::Callback::global_on_callback.gepton_sdk::util::Callback::global_on_callback.gepton_sdk::util::Callback::global_on_callback.gepton_sdk::util::Callback::global_on_callback.gepton_sdk::util::callback::global_on_callback.gepton_sdk::util::callback::util::callback.gepton_sdk::util::callback::util::callback.gepton_sdk::util::callback::util::callback.gepton_sdk::util::callback::util::callback.gepton_sdk::util::callback.gepton_sdk::util::callback.gepton_sdk::util::callback.gepton_sdk::util::callback.gepton_sdk::util::callback.gepton_sdk::util::callback.gepton_sdk::util::util:::callback.gepton_sdk::util:::callback.gepton_sdk::util::::
                                                                                                                                                                                                                        (C++function), 40
                               (C++ class), 38
\verb|cepton_sdk::api::SensorImageFrameCallbackeptSenSelimageFrameCallbackeptSenSelimageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackeptSensorImageFrameCallbackept
                                                                                                                                                                                                                       function), 40
                               (C++function), 38
cepton_sdk::api::SensorImageFrameCallbackePteTnSdkaiYtel::Callback::operator()
                                                                                                                                                                                                                        (C++ function), 40
                               (C++ function), 38
cepton_sdk::api::SensorImageFrameCallbackeptnntsdkizutil::convert_image_point_to_point
                                                                                                                                                                                                                        (C++ function), 39
                               (C++ function), 38
cepton_sdk::api::SensorImageFrameCallbackeptSnindtialtied:convert_sensor_image_point_to_po
```

```
(C++ member), 42
       (C++ function), 40
cepton_sdk::util::FrameAccumulator(C++ cepton_sdk::util::OrganizedCloud::timestamp_start
                                                 (C++ member), 42
cepton_sdk::util::FrameAccumulator::add_pephos_sdk::util::OrganizedCloud::width
       (C++function), 41
                                                 (C++ member), 42
cepton_sdk::util::FrameAccumulator::callbepkon_sdk::util::Organizer(C++ class), 43
       (C++ member), 41
                                          cepton_sdk::util::Organizer::binSize
                                                 (C++function), 43
cepton_sdk::util::FrameAccumulator::clear
       (C++function), 41
                                          cepton_sdk::util::Organizer::CENTER
cepton_sdk::util::FrameAccumulator::FrameAccumu(Cattoenumerator), 43
       (C++function), 41
                                          cepton_sdk::util::Organizer::mode (C++
cepton_sdk::util::FrameAccumulator::get_option function), 43
       (C++function), 41
                                          cepton_sdk::util::Organizer::organize_points
cepton_sdk::util::FrameAccumulator::set_options(C++ function), 43
       (C++ function), 41
                                          cepton_sdk::util::Organizer::Organizer
cepton_sdk::util::FrameDetector
                                    (C++
                                                 (C++function), 43
                                          cepton_sdk::util::Organizer::OrganizerMode
       class), 41
cepton_sdk::util::FrameDetector::add_point
                                                 (C++enum), 43
       (C++function), 41
                                          cepton_sdk::util::Organizer::OrganizerSettings
cepton_sdk::util::FrameDetector::frame_found
                                                 (C++ class), 44
      (C++ member), 41
                                          cepton_sdk::util::Organizer::OrganizerSettings::ho:
cepton_sdk::util::FrameDetector::frame_idx
                                                 (C++ member), 44
       (C++ member), 41
                                          cepton_sdk::util::Organizer::OrganizerSettings::ho:
cepton_sdk::util::FrameDetector::frame_x
                                                 (C++ member), 44
                                          cepton_sdk::util::Organizer::OrganizerSettings::mod
       (C++ member), 41
cepton_sdk::util::FrameDetector::FrameDetector (C++ member), 44
       (C++ function), 41
                                          cepton_sdk::util::Organizer::OrganizerSettings::ve
                                                 (C++ member), 44
cepton_sdk::util::FrameDetector::get_options
       (C++ function), 41
                                          cepton_sdk::util::Organizer::OrganizerSettings::ve
cepton_sdk::util::FrameDetector::reset
                                                 (C++ member), 44
       (C++ function), 41
                                          cepton_sdk::util::Organizer::RECENT
cepton_sdk::util::FrameDetector::set_options
                                                 (C++ enumerator), 43
       (C++ function), 41
                                          cepton_sdk::util::Organizer::settings
cepton_sdk::util::get_timestamp_usec
                                                 (C++function), 44
       (C++ function), 39
                                          cepton_sdk::util::SensorPoint (C++ class),
cepton_sdk::util::OrganizedCloud (C++
                                          cepton_sdk::util::SensorPoint::distance
cepton_sdk::util::OrganizedCloud::CellInfo
                                                 (C++ member), 39
       (C++ class), 42
                                          cepton_sdk::util::SensorPoint::flags
(C++ member), 42
                                          cepton_sdk::util::SensorPoint::image_x
cepton_sdk::util::OrganizedCloud::CellInfo::ori(Cimanenhenex39
                                          cepton_sdk::util::SensorPoint::image_z
       (C++ member), 42
cepton_sdk::util::OrganizedCloud::getIndex
                                                 (C++ member), 39
                                          cepton_sdk::util::SensorPoint::intensity
       (C++function), 42
cepton_sdk::util::OrganizedCloud::height
                                                 (C++ member), 39
                                          cepton_sdk::util::SensorPoint::reserved
       (C++ member), 42
cepton_sdk::util::OrganizedCloud::info_cells
                                                 (C++ member), 40
       (C++ member), 42
                                          cepton_sdk::util::SensorPoint::return_type
cepton_sdk::util::OrganizedCloud::n_returns
                                                 (C++ member), 39
       (C++ member), 42
                                          cepton_sdk::util::SensorPoint::saturated
cepton_sdk::util::OrganizedCloud::points
                                                 (C++ member), 40
       (C++ member), 42
                                          cepton_sdk::util::SensorPoint::timestamp
cepton_sdk::util::OrganizedCloud::timestamp_end(C++ member), 39
```

46 Index

```
cepton_sdk_get_frame_length(C function), 23
cepton_sdk::util::SensorPoint::valid
       (C++ member), 39
                                             cepton_sdk_get_frame_mode (Cfunction), 23
cepton_sdk::util::SensorPoint::x
                                      (C++
                                            cepton_sdk_get_n_sensors (C function), 27
                                             cepton_sdk_get_port (C function), 23
       member), 40
cepton_sdk::util::SensorPoint::y
                                      (C++ cepton_sdk_get_sensor_handle_by_serial_number
                                                    (C function), 27
       member), 40
cepton sdk::util::SensorPoint::z
                                      (C++ cepton sdk get sensor information
                                                                                      (C
                                                    function), 27
       member), 40
cepton_sdk::util::SensorPoint::[anonymoustpton_sdk_get_sensor_information_by_index
                                                    (C function), 27
       (C++ member), 40
cepton_sdk_capture_replay_close (C func- cepton_sdk_has_control_flag(C function), 23
                                             cepton_sdk_initialize (C function), 23
       tion), 35
cepton_sdk_capture_replay_get_enable_loopepton_sdk_listen_image_frames (C func-
                                                    tion), 30
       (C function), 35
cepton_sdk_capture_replay_get_filename cepton_sdk_listen_network_packet (C func-
       (C function), 35
                                                    tion), 33
cepton_sdk_capture_replay_get_length (C cepton_sdk_listen_serial_lines (C func-
       function), 35
                                                    tion), 31
cepton_sdk_capture_replay_get_position
                                            cepton_sdk_set_control_flags (C function),
       (C function), 35
                                                    23
cepton_sdk_capture_replay_get_speed (C cepton_sdk_set_frame_options (C function),
       function), 35
                                                    23
cepton_sdk_capture_replay_get_start_timecepton_sdk_set_port (C function), 23
                                             cepton_sdk_unlisten_image_frames (C func-
       (C function), 35
cepton_sdk_capture_replay_is_end (C func-
                                                    tion), 30
       tion), 35
                                             cepton_sdk_unlisten_network_packet
cepton_sdk_capture_replay_is_open
                                         (C
                                                    function), 33
                                             cepton_sdk_unlisten_serial_lines (C func-
       function), 35
cepton_sdk_capture_replay_is_running (C
                                                    tion), 31
       function), 36
cepton_sdk_capture_replay_open (C func-
       tion), 35
cepton_sdk_capture_replay_pause (C func-
       tion), 36
cepton_sdk_capture_replay_resume (C func-
       tion), 36
cepton_sdk_capture_replay_resume_blocking
       (C function), 35
cepton_sdk_capture_replay_resume_blocking_once
       (C function), 35
cepton_sdk_capture_replay_seek (C func-
       tion), 35
cepton_sdk_capture_replay_set_enable_loop
       (C function), 35
cepton_sdk_capture_replay_set_speed (C
       function), 35
cepton_sdk_clear(Cfunction), 23
cepton_sdk_create_frame_options (C func-
       tion), 22
cepton_sdk_create_options(C function), 22
cepton_sdk_deinitialize(Cfunction), 23
cepton_sdk_get_control_flags (C function),
cepton_sdk_get_error (C function), 19
```

Index 47