Basic CPU architecture, Busses and Registers

January 4, 2019

1 Microprocessor Simulation

- $\bullet\,$ SMS32 is an 8-bit CPU Similar to the x86 family
- Only has 256 bytes of memory
- Some of the features of sms32
 - 8-bit CPU
 - Up to 256 I/O ports (only a few are realistically ever used)

2 The CPU

- The brains of the computer
- All calculations and decisions take place here
- Has small pieces of storage called *registers*
- \bullet Has $Arithmetic\ and\ Logic\ Unit\ (ALU)$ where calculations are performed
- \bullet The ALU reads information from the registers, calculates and puts the results back into registers
- MOV commands are used to move data between registers in the CPU and memory outside the CPU

3 General Purpose Registers

- SMS32 has four general purpose registers
 - AL
 - BL
 - CL
 - DL
- The names come from the real x86 CPU
- Each of these registers is 8-bits(one byte) wide
- Each register can hold:
 - Unsigned numbers from 0 to 255
 - Signed numbers from -128 to +127
 - These registers are temporary storage locations

4 Special Registers

- the Program Counter (PC)
 - Also called the *Instruction Pointer (IP)*
 - Instructions (code) are stored in memory
 - This register tells the CPU where in memory the next instruction is to be taken from
 - When the CPU gets an instruction, the PC is changed to point to the next instruction
 - Some instructions such as CALL and INT can change the PC more drasctically
- The Status Register (SR)
 - This should be viewed as 8 individual bits, or switches
 - Each of these bits has a special meaning (though some are unused)
 - The Z bit (Zero Flag) is set to 1 if the answer for a calculation is zero
 - The S bit (Sign Flag) is set to 1 if the answer for a calculation is negative
 - The O bit (Overflow Flag) is set to 1 if the answer for a signed calculation was too big

• The Stack Pointer (SP)

- The stack is an area of memory which uses a Last-In-First-Out)(LIFO)
 rule
- The SP points to the next free location in memory
- The simulator's stack starts at memory location BF
- The stack grows towards memory location 0
- Adding data to the stack is called a \boldsymbol{Push}
- Removing data from the stack is called a **Pop**
- Each time a push or pop happens, the SP is updated

5 Random Access Memory

- This simulator has only 256 locations in RAM
- Each location can only store one byte
- The locations are numbered from 00 to FF in Hex
- In the assembler, square brackets ([]) around a number have a special meaning
 - 45 means the number 45
 - [45] means the number stored at memroy location 45

6 Busses

- These are a set of wires used to cary out information around in the computer
- $\bullet\,$ You can see them on the printed circuit board (PCB) as parallel tracks of copper
- For example, between the CPU and memory, there is a set of wires called the Data Bus
- There are three busses we consider:
 - Data Bus
 - Address Bus
 - Control Bus

7 The Data Bus

- Used to transfer data between the CPU and memory
- Usually related to the size of registers
- A CPU with 8-bit registers will have 8 lines on the data bus
- There are exceptions to this rule
 - The 32-bit Pentium had a 64-bit data bus
- The width of the data bus (number of lines) conrols how much data can be transferred at once between CPU and memory

8 The Address Bus

- When the CPU wants to send information to memory, it needs to specify:
 - What information to store
 - Where the information should be stored
- When the CPU wants to read from memory, it has to specify:
 - Where to read from
- The address bus is how the CPU conveys these memory locations
- The address bus differs from the data bus because:
 - Data can be sent in both directions on the data bus (bi-directional)
 - The width of the address bus determines the maximum number of locations the CPU can send out
 - One address line can specify 2^1 addresses
 - * 0 or 1
 - Two address lines can specify 2^2 addresses
 - * 00, 01, 10, or 11
 - Three address lines can specify 2^3 addresses
 - * 000, 001, 010, 011, 100, 101, 110, 111

9 The Control Bus

- Has a wire to determine whether to access RAM or IO ports
- Also has a wire to determine whether data is being read or written
- The CPU is reading data when it flows to the CPU
- The CPU is writing data when it flows away from the CPU to RAM or the IO ports
- Has a system clock wire
- Carries regular pulses to allow synchronization of various components
- Clock speeds around 2-4 billion cycles per second are typical

10 Hardware Interrupts

- Hardware Interrupts require at least one wire
- These wires are considered part of the control bus
- These enable the CPU to respond to external events
 - For Example, printers running out of paper
- When the interrupt happens
 - The CPU pauses it's current task
 - It runs some machine code in response to the interrupt
 - It then (Usually) continues with the original task