- 1. Consider metal-oxide-semiconductor (MOS) capacitors on p-type substrates that are ideal, meaning the workfunction of the metal and semiconductor are equal. Assume no charge inside the oxide or at the interfaces. Then the gate voltage  $V_G$  may be written as the sum of the voltage drops in the semiconductor and the oxide:  $V_G = \psi_s + V_{ox}$ .
  - (a) Assume the MOS is in depletion. How does the voltage drop in the semiconductor vary (qualitatively) as a function of the oxide thickness  $t_{ox}$  for a given  $V_G$ ? Share your reasoning.
  - **(b)** Suppose the semiconductor substrate is silicon, with doping of  $N_a = 10^{16} \, cm^{-3}$ ; and the oxide is SiO<sub>2</sub>, with  $\varepsilon_r \left( SiO_2 \right) = 4$ , and thickness t = 10 nm. Calculate the threshold voltage  $V_T$ . How do you expect  $V_T$  to vary with temperature? Share your reasoning.